



GRAPHIC OPERATION TERMINAL

GOT2000 Series

Connection Manual (Non-Mitsubishi Electric Products 1)

For GT Works3 Version1



- | | |
|---|--|
| ■ IAI ROBOT CONTROLLER | ■ SHINKO TECHNOS INDICATING CONTROLLER |
| ■ AZBIL (former YAMATAKE) CONTROL EQUIPMENT | ■ CHINO CONTROLLER |
| ■ OMRON PLC | ■ TOSHIBA MACHINE PLC |
| ■ OMRON TEMPERATURE CONTROLLER | ■ TOSHIBA PLC |
| ■ KEYENCE PLC | ■ PANASONIC SERVO AMPLIFIER |
| ■ KOYO EI PLC | ■ PANASONIC INDUSTRIAL DEVICES |
| ■ JTEKT PLC | SUNX PLC |
| ■ SHARP PLC | |

SAFETY PRECAUTIONS

(Always read these precautions before using this equipment.)

Before using this product, please read this manual and the relevant manuals introduced in this manual carefully and pay full attention to safety to handle the product correctly.

The precautions given in this manual are concerned with this product.

In this manual, the safety precautions are ranked as "WARNING" and "CAUTION".




WARNING

Indicates that incorrect handling may cause hazardous conditions, resulting in death or severe injury.



CAUTION

Indicates that incorrect handling may cause hazardous conditions, resulting in minor or moderate injury or property damage.

Note that failure to observe  CAUTION may lead to a serious accident depending on the circumstances.

Make sure to observe both warnings and cautions to ensure personal safety.

Please save this manual to make it accessible when required and always forward it to the end user.

[DESIGN PRECAUTIONS]



WARNING

- Some failures of the GOT, communication unit or cable may keep the outputs on or off.
Some failures of a touch panel may cause malfunction of the input objects such as a touch switch.
An external monitoring circuit should be provided to check for output signals which may lead to a serious accident. Not doing so can cause an accident due to false output or malfunction.
- Do not use the GOT as the warning device that may cause a serious accident.
An independent and redundant hardware or mechanical interlock is required to configure the device that displays and outputs serious warning.
Failure to observe this instruction may result in an accident due to incorrect output or malfunction.
- When the GOT backlight has a failure, the GOT status will be as follows. Failure to observe this instruction may result in an accident due to incorrect output or malfunction.

[GT27, GT25, GT23]

The POWER LED blinks (orange/blue), the display section dims, and inputs by a touch switch are disabled.

[GT2105-Q]

The POWER LED blinks (orange/blue), and the display section dims. However, inputs by a touch switch are still available.

[GT2107-W, GT2104-R, GT2104-P, GT2103-P, GS21]

The display section dims. However, inputs by a touch switch are still available.

Even if the display section dims, inputs by a touch switch may still be available. This may cause an unintended operation of the touch switch.

For example, if an operator assumes that the display section has dimmed because of the screen save function and touches the display section to cancel the screen save, a touch switch may be activated.

The GOT backlight failure can be checked with a system signal of the GOT. (This system signal is not available on GT2107-W, GT2104-R, GT2104-P, GT2103-P, and GS21.)

[DESIGN PRECAUTIONS]

WARNING

- The display section of the GOT is an analog-resistive type touch panel.
When multiple points of the display section are touched simultaneously, an accident may occur due to incorrect output or malfunction.
[GT27]
Do not touch three points or more simultaneously on the display section. Doing so may cause an accident due to an incorrect output or malfunction.
[GT25, GT23, GT21, GS21]
Do not touch two points or more simultaneously on the display section. Doing so may cause a touch switch near the touched points to operate unexpectedly, or may cause an accident due to an incorrect output or malfunction.
 - When programs or parameters of the controller (such as a PLC) that is monitored by the GOT are changed, be sure to reset the GOT, or turn on the unit again after shutting off the power as soon as possible.
Not doing so can cause an accident due to false output or malfunction.
 - If a communication fault (including cable disconnection) occurs during monitoring on the GOT, communication between the GOT and PLC CPU is suspended and the GOT becomes inoperative.
For bus connection (GT27, GT25 Only): The CPU becomes faulty and the GOT becomes inoperative.
For other than bus connection: The GOT becomes inoperative.
A system where the GOT is used should be configured to perform any significant operation to the system by using the switches of a device other than the GOT on the assumption that a GOT communication fault will occur.
Not doing so can cause an accident due to false output or malfunction.
 - To protect the system incorporating the GOT against unauthorized access from networked devices, take preventive actions.
To protect the system against unauthorized access from Internet-connected devices, take preventive actions such as installing a firewall.
-

[DESIGN PRECAUTIONS]

CAUTION

- Do not bundle the control and communication cables with main-circuit, power or other wiring.
Run the above cables separately from such wiring and keep them a minimum of 100mm apart.
Not doing so noise can cause a malfunction.
 - Do not press the GOT display section with a pointed material as a pen or driver.
Doing so can result in a damage or failure of the display section.
 - When the GOT connects to an Ethernet network, the IP address setting is restricted according to the system configuration.
[GT27, GT25, GT23]
When a GOT2000 series model and a GOT1000 series model are on an Ethernet network, do not set the IP address 192.168.0.18 for the GOTs and the controllers on this network.
Doing so can cause IP address duplication at the GOT startup, adversely affecting the communication of the device with the IP address 192.168.0.18.
The operation at the IP address duplication depends on the devices and the system.
[GT21, GS21]
When multiple GOTs connect to the Ethernet network:
Do not set the IP address (192.168.3.18) for the GOTs and the controllers in the network.
When one GOT connects to the Ethernet network:
Do not set the IP address (192.168.3.18) for the controllers other than the GOT in the network.
Doing so can cause IP address duplication at the GOT startup, adversely affecting the communication of the device with the IP address 192.168.3.18.
The operation at the IP address duplication depends on the devices and the system.
 - Turn on the controllers and the network devices to be ready for communication before they communicate with the GOT.
Failure to do so can cause a communication error on the GOT.
 - When the GOT is subject to shock or vibration, or some colors appear on the screen of the GOT, the screen of the GOT might flicker.
-

[MOUNTING PRECAUTIONS]

WARNING

- Be sure to shut off all phases of the external power supply used by the system before mounting or removing the GOT main unit to/from the panel.
Not doing so can cause the unit to fail or malfunction.
 - Be sure to shut off all phases of the external power supply used by the system before mounting or removing the option unit onto/from the GOT. (GT27, GT25 Only)
-

[MOUNTING PRECAUTIONS]

CAUTION

- Use the GOT in the environment that satisfies the general specifications described in this manual.
Not doing so can cause an electric shock, fire, malfunction or product damage or deterioration.
 - When mounting the GOT to the control panel, tighten the mounting screws in the specified torque range with a Phillips-head screwdriver No. 2.
[GT27, GT2512, GT2510, GT2508, GT23, GT2107-W, GS21]
Specified torque range (0.36 N•m to 0.48 N•m)
[GT2505-V, GT2105-Q]
Specified torque range (0.30 N•m to 0.50 N•m)
[GT2104-R, GT2104-P, GT2103-P]
Specified torque range (0.20 N•m to 0.25 N•m)
Undertightening can cause the GOT to drop, short circuit or malfunction.
Overtightening can cause a drop, short circuit or malfunction due to the damage of the screws or the GOT.
 - When mounting a unit on the GOT, tighten the mounting screws in the following specified torque range.
[GT27, GT25 (except GT25-W)]
When loading the communication unit or option unit other than wireless LAN unit to the GOT, fit it to the connection interface of the GOT and tighten the mounting screws in the specified torque range (0.36 N•m to 0.48 N•m) with a Phillips-head screwdriver No. 2.
When loading the wireless LAN unit to the GOT, fit it to the side interface of GOT and tighten the mounting screws in the specified torque range (0.10 N•m to 0.14 N•m) with a Phillips-head screwdriver No. 1.
When the GOT is installed vertically, its side interface is positioned on the bottom.
To prevent the falling of the wireless LAN communication unit from the side interface, install or remove the unit while holding it with hands.
[GT25-W]
When mounting the wireless LAN communication unit on the GOT, fit it to the wireless LAN communication unit interface and tighten the mounting screws in the specified torque range (0.10 N•m to 0.14 N•m) with a Phillips-head screwdriver No.1.
[GT2103-P]
When mounting the SD card unit on the GOT, fit it to the side of the GOT and tighten the tapping screws in the specified torque range (0.3 N•m to 0.6 N•m) with a Phillips-head screwdriver No. 2.
Under tightening can cause the GOT to drop, short circuit or malfunction.
Overtightening can cause a drop, failure or malfunction due to the damage of the screws or unit.
 - When closing the USB environmental protection cover, note the following points to ensure the IP rating.
[GT27, GT25 (except GT25-W and GT2505-V)]
Push the [PUSH] mark on the latch firmly to fix the cover to the GOT.
[GT2510-WX, GT2507-W, GT2505-V, GT2107-W]
Push the [PULL] mark firmly, and slide the latch part to the right side in order to fix the latch part to the GOT.
[GT2105-Q]
Tighten the lower fixing screws of the cover in the specified torque range (0.36 N•m to 0.48 N•m) to fix the cover to the GOT.
-

[MOUNTING PRECAUTIONS]

CAUTION

- Remove the protective film of the GOT.
When the user continues using the GOT with the protective film, the film may not be removed.
In addition, for the models equipped with the human sensor function, using the GOT with the protective film may cause the human sensor not to function properly.
 - For GT2512F-S, GT2510F-V, and GT2508F-V, attach an environmental protection sheet dedicated to the open frame model (sold separately) to the display section.
Or, attach a user-prepared environmental protection sheet.
Not doing so may damage or soil the GOT or cause foreign matter to enter the GOT, resulting in a failure or malfunction.
 - When installing the supplied fittings on GT2512F-S, GT2510F-V, or GT2508F-V, tighten screws in the specified torque range (0.8 N•m to 1.0 N•m).
Meld studs on the control panel to fasten the fittings.
The studs must have strength adequate to withstand a tightening torque of 0.9 N•m or more.
Make sure that no foreign matter such as welding waste is at and around the bases of the studs.
Tighten nuts on the studs in the specified torque range (0.8 N•m to 0.9 N•m) with a wrench for M4 nuts.
Undertightening a screw or nut may cause the GOT to drop, short-circuit, or malfunction.
Overtightening a screw or nut may damage it or the GOT, causing the GOT to drop, short-circuit, or malfunction.
 - Do not operate or store the GOT in the environment exposed to direct sunlight, rain, high temperature, dust, humidity, or vibrations.
 - Although GT2507T-W is ruggedized for environments such as UV rays, temperatures and vibrations, its operation is not guaranteed in all conditions and environments.
Make sure to use or store the GOT in an appropriate environment.
 - When using the GOT in the environment of oil or chemicals, use the protective cover for oil.
Failure to do so may cause failure or malfunction due to the oil or chemical entering into the GOT.
 - Do not operate the GOT with its display section frozen.
The water droplets on the display section may freeze at a low temperature.
Touch switches and other input objects may malfunction if the display section is frozen.
-


[WIRING PRECAUTIONS]

WARNING

- Be sure to shut off all phases of the external power supply used by the system before wiring.
Failure to do so may result in an electric shock, product damage or malfunctions.
-

[WIRING PRECAUTIONS]

CAUTION

- When grounding the FG terminal and LG terminal of the GOT power supply section, note the following points.
Not doing so may cause an electric shock or malfunction.
[GT27, GT25, GT23, GT2107-W, GT2105-Q, GS21]
Make sure to ground the FG terminal and LG terminal of the GOT power supply section solely for the GOT (ground resistance: 100 Ω or less, cross-sectional area of the ground cable: 2.0 mm² or more). (GT2107-W, GT2105-Q, and GS21 do not have the LG terminal.)
[GT2104-R, GT2104-P, GT2103-P]
Make sure to ground the FG terminal of the GOT power supply section with a ground resistance of 100 Ω or less. (For GT2104-PMBLS and GT2103-PMBLS, grounding is unnecessary.)
 - When tightening the terminal screws, use the following screwdrivers.
[GT27, GT25, GT23, GT2107-W, GT2105-Q, GS21]
Use a Phillips-head screwdriver No. 2.
[GT2104-R, GT2104-P, GT2103-P]
For the usable screwdrivers, refer to the following.
 GOT2000 Series User's Manual (Hardware)
 - Tighten the terminal screws of the GOT power supply section in the following specified torque range.
[GT27, GT25, GT23]
Specified torque range (0.5 N•m to 0.8 N•m)
 - For a terminal processing of a wire to the GOT power supply section, use the following terminal.
[GT27, GT25, GT23, GT2107-W, GT2105-Q, GS21]
Use applicable solderless terminals for terminal processing of a wire and tighten them with the specified torque.
Not doing so can cause a fire, failure or malfunction.
[GT2104-R, GT2104-P, GT2103-P]
Connect a stranded wire or a solid wire directly, or use a rod terminal with an insulation sleeve.
 - Correctly wire the GOT power supply section after confirming the rated voltage and terminal arrangement of the product.
Not doing so can cause a fire or failure.
 - Tighten the terminal screws of the GOT power supply section in the following specified torque range.
[GT27, GT25, GT23, GT2107-W, GT2105-Q]
Specified torque range (0.5 N•m to 0.8 N•m)
[GT2104-R, GT2104-P, GT2103-P]
Specified torque range (0.22 N•m to 0.25 N•m)
[GS21]
Specified torque range (0.5 N•m to 0.6 N•m)
 - Exercise care to avoid foreign matter such as chips and wire offcuts entering the GOT.
Not doing so can cause a fire, failure or malfunction.
 - The module has an ingress prevention label on its top to prevent foreign matter, such as wire offcuts, from entering the module during wiring.
Do not peel this label during wiring. Before starting system operation, be sure to peel this label because of heat dissipation. (GT27, GT25 Only)
-

[WIRING PRECAUTIONS]

CAUTION

- Plug the communication cable into the GOT interface or the connector of the connected unit, and tighten the mounting screws and the terminal screws in the specified torque range.
Undertightening can cause a short circuit or malfunction.
Overtightening can cause a short circuit or malfunction due to the damage of the screws or unit.
 - Plug the QnA/ACPU/Motion controller (A series) bus connection cable by inserting it into the connector of the connected unit until it "clicks".
After plugging, check that it has been inserted snugly.
Not doing so can cause a malfunction due to a contact fault. (GT27, GT25 Only)
-

[TEST OPERATION PRECAUTIONS]

WARNING

- Before testing the operation of a user-created monitor screen (such as turning on or off a bit device, changing the current value of a word device, changing the set value or current value of a timer or counter, and changing the current value of a buffer memory), thoroughly read the manual to fully understand the operating procedures.
During the test operation, never change the data of the devices which are used to perform significant operation for the system.
Doing so may cause an accident due to an incorrect output or malfunction.
-

[STARTUP/MAINTENANCE PRECAUTIONS]

WARNING

- When power is on, do not touch the terminals.
Doing so can cause an electric shock or malfunction.
 - Correctly connect the battery connector.
Do not charge, disassemble, heat, short-circuit, solder, or throw the battery into the fire.
Doing so will cause the battery to produce heat, explode, or ignite, resulting in injury and fire.
 - Before starting cleaning or terminal screw retightening, always switch off the power externally in all phases.
Not switching the power off in all phases can cause a unit failure or malfunction.
Undertightening can cause a short circuit or malfunction.
Overtightening can cause a short circuit or malfunction due to the damage of the screws or unit.
-

[STARTUP/MAINTENANCE PRECAUTIONS]

CAUTION

- Do not disassemble or modify the unit.
Doing so can cause a failure, malfunction, injury or fire.
 - Do not touch the conductive and electronic parts of the unit directly.
Doing so can cause a unit malfunction or failure.
 - The cables connected to the unit must be run in ducts or clamped.
Not doing so can cause the unit or cable to be damaged due to the dangling, motion or accidental pulling of the cables or can cause a malfunction due to a cable connection fault.
 - When unplugging the cable connected to the unit, do not hold and pull from the cable portion.
Doing so can cause the unit or cable to be damaged or can cause a malfunction due to a cable connection fault.
 - Do not drop the module or subject it to strong shock. A module damage may result.
 - Do not drop or give an impact to the battery mounted to the unit.
Doing so may damage the battery, causing the battery fluid to leak inside the battery.
If the battery is dropped or given an impact, dispose of it without using.
 - Before touching the unit, always touch grounded metals, etc. to discharge static electricity from human body, etc.
Not doing so can cause the unit to fail or malfunction.
 - Use the battery manufactured by Mitsubishi Electric Corporation.
Use of other batteries may cause a risk of fire or explosion.
 - Dispose of used battery promptly.
Keep away from children. Do not disassemble and do not dispose of in fire.
 - Be sure to shut off all phases of the external power supply before replacing the battery or using the dip switch of the terminating resistor.
Not doing so can cause the unit to fail or malfunction by static electricity.
 - Before cleaning the GOT, be sure to turn off the power.
Before cleaning, check the following items.
 - Ensure that there are no problems with the installation condition of the GOT to the control panel.
 - Ensure that there are no damages on the environmental protection sheet (not replaceable).If the environmental protection sheet peels or the cleaning solution enters between the sheet and the display section during cleaning, stop the cleaning immediately.
In such a case, do not use the GOT.
-

[TOUCH PANEL PRECAUTIONS]

CAUTION

- For the analog-resistive film type touch panels, normally the adjustment is not required.
However, the difference between a touched position and the object position may occur as the period of use elapses.
When any difference between a touched position and the object position occurs, execute the touch panel calibration.
 - When any difference between a touched position and the object position occurs, other object may be activated.
This may cause an unexpected operation due to incorrect output or malfunction.
-

[PRECAUTIONS FOR USING A DATA STORAGE]

WARNING

- Do not remove the SD card from drive A while the SD card is being accessed by the GOT, or the GOT may stop processing for about 20 seconds.
During this stop, you cannot operate the GOT, and the functions running in the background, including the screen refresh, alarm, logging, and script, also stop.
This stop may affect the system operation, causing an accident.
Before removing the SD card, check the following items.
[GT27, GT25, GT23 (Except for GT2505-V)]
Before removing the SD card, check that the SD card access LED is off.
[GT2505-V]
Make sure to turn off the SD card access switch before removing the SD card. Not doing so may damage the SD card and files.
[GT21, GS21]
Disable the SD card access in the GOT utility, and then check that the SD card access LED is off before removing the SD card.
 - Do not remove the data storage from the file server (drive N) that is being accessed by the GOT, or the system operation may be affected.
Before removing the data storage, check the relevant system signal to make sure that the data storage is not being accessed.
-

[PRECAUTIONS FOR USING A DATA STORAGE]

CAUTION

- Do not remove the data storage from the GOT while the data storage is being accessed by the GOT, or the data storage and files may be damaged.
Before removing the data storage, check the SD card access LED, relevant system signal, or others to make sure that the data storage is not being accessed.
 - Turning off the GOT while it accesses the SD card results in damage to the SD card and files.
 - When using the GOT with an SD card inserted, check the following items.
[GT27, GT25, GT23 (Except for GT2505-V)]
When inserting a SD card into the GOT, make sure to close the SD card cover.
Not doing so causes the data not to be read or written.
[GT2505-V]
Before inserting an SD card into the GOT, turn on the SD Card Access Switch.
Not doing so causes the data not to be read or written.
[GT21, GS21]
When inserting an SD card into the SD card unit, make sure to enable the SD card access in the GOT utility in advance.
Not doing so causes the data not to be read or written.
-

[PRECAUTIONS FOR USING A DATA STORAGE]

CAUTION

- When removing the SD card from the GOT, make sure to support the SD card by hand as it may pop out.
Not doing so may cause the SD card to drop from the GOT, resulting in a failure or break.
 - When inserting a USB device into a USB interface of the GOT, make sure to insert the device into the interface firmly.
Not doing so may cause the USB device to drop from the GOT, resulting in a failure or break. (GT27, GT25, and GT2107-W)
 - Before removing the data storage from the GOT, follow the procedure for removal on the utility screen of the GOT. After the successful completion dialog is displayed, remove the data storage by hand carefully.
Not doing so may cause the data storage to drop from the GOT, resulting in a failure or break.
-

[PRECAUTIONS FOR USE]

CAUTION

- Do not touch the edges of the touch panel (display section) repeatedly.
Doing so may result in a failure.
 - Do not turn off the GOT while data is being written to the storage memory (ROM) or SD card.
Doing so may corrupt the data, rendering the GOT inoperative.
 - The GOT rugged model uses the environmental protection sheet (not replaceable) with UV protection function on the front surface.
Therefore, it is possible to suppress deterioration of the touch panel or the liquid crystal display panel that may be caused by ultraviolet rays.
Note that if the rugged model is exposed to ultraviolet rays for an extended period of time, the front surface may turn yellow.
If the rugged model is likely to be exposed to ultraviolet rays for an extended period of time, it is recommended to use a UV protective sheet (option).
-

[PRECAUTIONS FOR REMOTE CONTROL]

WARNING

- Remote control is available through a network by using GOT functions, including the SoftGOT-GOT link function, the remote personal computer operation function, the VNC server function, and the GOT Mobile function.
If you remotely operate control equipment using such functions, the field operator may not notice the remote operation, leading to an accident.
In addition, a communication delay or interruption may occur depending on the network environment, and remote control of control equipment cannot be performed normally in some cases.
Before using the above functions to perform remote control, fully grasp the circumstances of the field site and ensure safety.
 - When operating the server (GOT) of the GOT Mobile function to disconnect a client, notify the operator of the client about the disconnection beforehand.
Not doing so may cause an accident.
-

[PRECAUTIONS FOR EXCLUSIVE AUTHORIZATION CONTROL]

WARNING

- Before using the GOT network interaction function to prevent simultaneous operations from multiple pieces of equipment, make sure you understand the function.
You can enable or disable the exclusive authorization control of the GOT network interaction function for each screen. (For all screens, the exclusive authorization control is disabled by default.)
Properly determine the screens for which the exclusive authorization control is required, and set the control by screen.
A screen for which the exclusive authorization control is disabled is operable simultaneously from multiple pieces of equipment. Make sure to determine the operation period for each operator, fully grasp the circumstances of the field site, and ensure safety to perform operations.
-

[DISPOSAL PRECAUTIONS]

CAUTION

- When disposing of this product, treat it as industrial waste.
When disposing of batteries, separate them from other wastes according to the local regulations. (Refer to the GOT2000 Series User's Manual (Hardware) for details of the battery directive in the EU member states.)
-

[TRANSPORTATION PRECAUTIONS]

CAUTION

- When transporting lithium batteries, make sure to treat them based on the transport regulations. (Refer to the GOT2000 Series User's Manual (Hardware) for details of the regulated models.)
 - Make sure to transport the GOT main unit and/or relevant unit(s) in the manner they will not be exposed to the impact exceeding the impact resistance described in the general specifications of this manual, as they are precision devices.
Failure to do so may cause the unit to fail.
Check if the unit operates correctly after transportation.
 - When fumigants that contain halogen materials such as fluorine, chlorine, bromine, and iodine are used for disinfecting and protecting wooden packaging from insects, they cause malfunction when entering our products.
Please take necessary precautions to ensure that remaining materials from fumigant do not enter our products, or treat packaging with methods other than fumigation (heat method).
Additionally, disinfect and protect wood from insects before packing products.
-

INTRODUCTION

Thank you for choosing Mitsubishi Electric Graphic Operation Terminal (GOT).

Before using the product, read this manual carefully and make sure you understand the functions and performance of the GOT for correct use.

CONTENTS

SAFETY PRECAUTIONS	1
INTRODUCTION	12
Manuals for GT Works3	22
Abbreviations, Generic Terms, and Model Icons	24

PART 1 PREPARATORY PROCEDURES FOR MONITORING

CHAPTER 1 PREPARATORY PROCEDURES FOR MONITORING	32
1.1 Setting the Communication Interface	33
Setting connected equipment (Channel setting)	33
GOT Ethernet Setting	43
I/F communication setting	47
Precautions	49
1.2 Writing the Project Data onto the GOT	50
Writing the project data and OS onto the GOT	50
Checking the project data and OS writing on GOT	51
1.3 Option Devices for the Respective Connection	52
Communication module	52
Option unit	54
Conversion cables	54
Serial Multi-Drop Connection Unit	54
Field Network Adapter Unit	54
RS-232/485 signal conversion adapter	54
Precautions for installing units on another unit	55
1.4 Connection Cables for the Respective Connection	58
GOT connector specifications	58
Coaxial cableconnector connection method	60
Terminating resistors of GOT	62
Setting the RS-232/485 signal conversion adaptor	67
1.5 Verifying GOT Recognizes Connected Equipment	68
1.6 Checking for Normal Monitoring	70
Check on the GOT	70
Confirming the communication state on the GOT side (For Ethernet connection)	73
Confirming the communication state to each station (Station monitoring function)	75

PART 2 CONNECTIONS TO NON-MITSUBISHI ELECTRIC PRODUCTS

CHAPTER 2 CONNECTION TO IAI ROBOT CONTROLLER	80
2.1 Connectable Model List	80
2.2 System Configuration	82
System Configuration for connecting to X-SEL, SSEL, ASEL, PSEL	82
System Configuration for connecting to PCON, ACON, SCON, ERC2	84

2.3	Connection Diagram	97
	RS-232 cable	97
	RS-422/485 cable	100
2.4	GOT Side Settings	106
	Setting communication interface (Communication settings)	106
	Communication detail settings	107
2.5	Robot Controller Side Setting	108
	Connecting to X-SEL	108
	Connecting to SSEL, ASEL, PSEL	110
	Connecting to PCON, ACON, SCON	111
	Connecting to ERC2	111
	Station No.settings	112
2.6	Device Range that Can Be Set	113
	IAI robot controller (IAI X-SELController)	113
	IAI robot controller (IAI PCON, ACON, SCON, ERC2 controller)	124
2.7	Precautions	131

CHAPTER 3 CONNECTION TO AZBIL CONTROL EQUIPMENT 133

3.1	Connectable Model List	133
3.2	System Configuration	135
	Connecting to DMC10	135
	Connecting to DMC50	137
	Connecting to SDC15, SDC25/26 or SDC35/36	139
	Connecting to SDC20/21	141
	Connecting to SDC30/31	144
	Connecting to SDC40A/40B/40G	146
	Connecting to SDC45/46	149
	Connecting to CMS, MQV, MPC, MVF, RX	151
	Connecting to CMF015, CMF050	153
	Connecting to CML, PBC201-VN2	156
	Connecting to AUR350C, AUR450C	158
	Connecting to CMC10B	160
	Connecting to AHC2001	162
	Connecting to NX series	165
3.3	Connection Diagram	166
	RS-232 cable	166
	RS-485 cable	168
3.4	GOT Side Settings	190
	Setting communication interface (Communication settings)	190
	Communication detail settings	191
3.5	Control Equipment Side Setting	193
	Connecting to DMC10	193
	Connecting to SDC40A/40B/40G	194
	Connecting to SDC15, SDC25/26 or SDC35/36	194
	Connecting to SDC20/21, SDC30/31	195
	Connecting to CMC10L	195
	Connecting to DMC50	197
	Connecting to SDC45/46	197
	Connecting to CMS, CMF015	198
	Connecting to CML, CMF050	198

Connecting to MQV	198
Connecting to MPC	199
Connecting to PBC201-VN2	199
Connecting to MVF	199
Connecting to AUR350C, AUR450C	201
Connecting to RX	202
Connecting to CMC10B	202
Connecting to AHC2001 CPU	203
Connecting to AHC2001 SCU	203
Station number setting	204
3.6 Device Range that Can Be Set	205
AZBIL SDC/DMC Series	206
AZBIL DMC50/AHC2001	206
3.7 Precautions	208
 CHAPTER 4 CONNECTION TO OMRON PLC	 209
4.1 Connectable Model List	209
4.2 Serial Connection	211
System Configuration for connecting to CPM1, CPM1A, CPM2A, CPM2C or CQM1	211
System Configuration for connecting to CQM1H	214
System Configuration for connecting to CJ1H, CJ1G, CJ1M, CJ2H, or CJ2M	217
System Configuration for connecting to CP1H, CP1L, or CP1E	222
System Configuration for connecting to C200HS, C200H, C200HX, C200HG, or C200HE	225
System Configuration for connecting to CS1H, CS1G, or CS1D	228
System Configuration for connecting to C1000H or C2000H	231
System Configuration for connecting to CV500, CV1000, CV2000, or CVM1	232
Connection Diagram	233
GOT Side Settings	238
PLC Side Setting	240
Connecting to CPM2A, CQM1, CQM1H, C200Hα or RS-232C adapter	241
Connecting to CJ1, CJ2, CS1, CP1H, CP1L, or CP1E	242
Connecting to CV500/CV1000/CV2000 or CVM1	245
Connecting to connection cable	246
Connecting to rack type host link unit	247
Connecting to serial communication unit	251
Connecting to communication board, serial communication board (CQM1-SCB41)	251
Connecting to serial communication board (CS1W-SCB21(-V1), CS1W-SCB41(-V1))	253
Connecting to RS-422A/485 Option board	254
Connecting to RS-422A converter	254
4.3 Ethernet Connection	255
System Configuration for connecting to SYSMAC CJ1/CJ2/CS1 series	255
System Configuration for connecting to NJ/NX series	257
GOT side settings	259
PLC side setting	264
Precautions	267
4.4 Device Range that Can Be Set	268
OMRON PLC (SYSMAC CJ1/CJ2/CS1 series)	269
OMRON PLC (NJ/NX series)	269

CHAPTER 5	CONNECTION TO OMRON TEMPERATURE CONTROLLER	271
5.1	Connectable Model List	271
5.2	System Configuration	272
	Connecting to the THERMAC NEO series	272
	Connecting to the INPANEL NEO	279
	Connecting to the E5□C series, E5□D series	281
	Connecting to the THERMAC R series	283
5.3	Connection Diagram	285
	RS-232 cable	285
	RS-422 cable	287
	RS-485 cable	289
5.4	GOT Side Settings	295
	Setting communication interface (Communication settings)	295
	Communication detail settings	296
5.5	Temperature Controller Side Setting	298
	Connecting E5AN, E5EN, E5CN, E5GN	298
	Connecting E5AN-H, E5CN-H, E5EN-H, E5AN-HT, E5CN-HT, E5EN-HT	298
	Connecting E5ZN	299
	Connecting E5CC(-T,-B), E5DC, E5GC, E5EC(-T,-B), E5AC(-T)	299
	Connecting E5CD(-B), E5ED(-B)	299
	Connecting E5AR(-T), E5ER(-T)	300
	Connection to interface converter (K3SC-10)	300
	Station No. settings	302
5.6	Device Range that Can Be Set	303
	OMRON temperature controller (OMRON THERMAC/INPANEL NEO)	305
	OMRON temperature controller (OMRON digital temperature controller)	306
5.7	Precautions	307
CHAPTER 6	CONNECTION TO KEYENCE PLC	309
6.1	Connectable Model List	309
6.2	Serial Connection	311
	Connecting to KV-7500, KV-7300	311
	Connecting to KV-5500, KV-5000	314
	Connecting to KV-3000	316
	Connecting to KV-1000	319
	Connecting to KV-700	322
	Connecting to KV-N14□□, KV-N24□□, KV-N40□□, KV-N60□□, KV-NC32T	325
	Connection Diagram	328
	GOT Side Settings	335
	PLC Side Setting	337
6.3	Ethernet Connection	341
	Connecting to KV-700, KV-1000, KV-3000, KV-5000, KV-5500, KV-7300, KV-7500, KV-N24□□, KV-N40□□, KV-N60□□, KV-NC32T	341
	GOT side settings	343
	PLC side setting	347
6.4	Device Range that Can Be Set	348
	KV-700, 1000, 3000, 5000, 7000, and KV Nano	349

CHAPTER 7 CONNECTION TO KOYO EI PLC 351

7.1	Connectable Model List	351
7.2	System Configuration	352
	Connecting to SU-5E or SU-6B	352
	Connecting to SU-5M or SU-6M	355
	Connecting to DirectLOGIC 05 series	358
	Connecting to DirectLOGIC 06 series	361
	Connecting to D2-240, D2-250-1 or D2-260	364
	Connecting to PZ	366
7.3	Connection Diagram	368
	RS-232 cable	368
	RS-422 cable	369
7.4	GOT Side Settings	374
	Setting communication interface (Communication settings)	374
	Communication detail settings	375
7.5	PLC Side Setting	376
	Connecting to SU-5E/6B	377
	Connecting to SU-5M/6M	378
	Connecting to DirectLOGIC 05 series or DirectLOGIC 06 series	378
	Connecting to DirectLOGIC 205 series	379
	Connecting to PZ Series	379
	Connecting to U-01DM	380
	Connecting to D0-DCM	382
	Connecting to D2-DCM	382
	Station No. settings	383
7.6	Device Range that Can Be Set	384
	KOYO EI PLC (KOYO KOSTAC/DL)	385
7.7	Precautions	386

CHAPTER 8 CONNECTION TO JTEKT PLC 387

8.1	Connectable Model List	387
8.2	System Configuration	388
	Connecting to PC3JG, PC3JG-P, PC3JD or PC3JD-C	388
	Connecting to PC3J or PC3JL	390
	Connecting to PC2J, PC2JS or PC2JR	392
	Connecting to PC2JC, PC2J16P or PC2J16PR	394
8.3	Connection Diagram	396
	RS-232 cable	396
	RS-422 cable	397
8.4	GOT Side Settings	400
	Setting communication interface (Communication settings)	400
	Communication detail settings	401
8.5	PLC Side Setting	402
	Connecting to PC3JG, PC3JD, PC3JD-C, PC3JG-P, PC3J, PC3JL, PC2J, PC2JS or PC2JR	402
	Connecting to PC2JC	403
	Connecting to PC2J16P or PC2J16PR	404
	RS-232/RS-422 interface converter setting	405
	Link unit setting	406
	Station number setting	407

8.6	Device Range that Can Be Set	408
	JTEKT PLC (JTEKT TOYOPUC-PLC)	409
8.7	Precautions	410

CHAPTER 9 CONNECTION TO SHARP PLC 411

9.1	Connectable Model List	411
9.2	System Configuration	412
	Connecting to JW-21CU or JW-22CU	412
	Connecting to JW-31CUH, JW-32CUH or JW-33CUH	413
	Connecting to JW-50CUH, JW-70CUH, JW-100CUH or JW-100CU	414
	Connecting to Z-512J	415
9.3	Connection Diagram	416
	RS-232 cable	416
	RS-422 cable	417
9.4	GOT Side Settings	419
	Setting communication interface (Communication settings)	419
	Communication detail settings	420
9.5	PLC Side Setting	421
	Connecting to JW-22CU, JW-70CUH, JW-100CUH or JW-100CU	422
	Connecting to JW-32CUH, JW-33CUH or Z-512J	423
	Connecting to the link unit (JW-21CM)	424
	Connecting to the link unit (JW-10CM or ZW-10CM)	426
9.6	Device Range that Can Be Set	428
	SHARP PLC (SHARP JW)	430
9.7	Precautions	431

CHAPTER 10 CONNECTION TO SHINKO TECHNOS INDICATING CONTROLLER 433

10.1	Connectable Model List	433
10.2	System Configuration	435
	Connecting to ACS-13A, JC, JCM-33A, JIR-301-M, PCD-300 Series, PC-900 Series (PC-955-[]/M,C5, PC-935-[]/M,C5)	435
	Connecting to FCD-100, FCR-100, FCR-23A, FIR Series, PC-900 Series (PC-955[]/M,C, PC-935-[]/M,C)	437
	When connecting to DCL-33A Series	438
10.3	Connection Diagram	440
	RS-232 cable	440
	RS-485 cable	441
10.4	GOT Side Settings	448
	Setting communication interface (Communication settings)	448
	Communication detail settings	449
10.5	Indicating Controller Side Setting	450
	Connecting to ACS-13A, DCL- 33A, JC, JCM-33A, JIR-301- M, PCD-300 Series, PC-900 Series (PC-955-[]/M,C5, PC- 935-[]/M,C5)	450
	Connecting to FCD-100, FCR- 100, FCR-23A, FIR Series, PC-900 Series (PC-955-[]/ M,C, PC-935-[]/M,C)	450
	Connecting to communication converter (IF-400)	451
	Station No. settings	452
10.6	Device Range that Can Be Set	453
	SHINKO indicating controller (Shinko Technos Controller)	455
10.7	Precautions	456

CHAPTER 11 CONNECTION TO CHINO CONTROLLER	457
11.1 Connectable Model List	457
11.2 System Configuration	458
Connecting to LT230, LT300, LT400, LT830, DZ1000, DZ2000, DB1000, DB2000 series	458
Connecting to KP1000, KP2000, AL3000, AH3000 series	461
Connecting to SE3000, JU, KE3000, LE5000 series	464
Connecting to GT120 Series	467
11.3 Connection Diagram	469
RS-232 cable	469
RS-422 cable	470
RS-485 cable	474
11.4 GOT Side Settings	483
Setting communication interface (Communication settings)	483
Communication detail settings	484
11.5 Controller Side Setting	485
Connecting to LT230, LT300 Series	485
Connecting to LT400, LT830 Series	486
Connecting to DZ1000, DZ2000 Series	486
Connecting to DB1000, DB2000 Series	487
Connecting to GT120 Series	487
Connecting to KP1000, KP2000	488
Connecting to AL3000, AH3000	488
Connecting to SE3000	489
Connecting to JU	490
Connecting to KE3000	491
Connecting to LE5000	492
Connecting to converter SC8-10	493
Station number setting	494
11.6 Device Range that Can Be Set	496
CHINO controller (CHINO Controllers)	497
11.7 Precautions	498
CHAPTER 12 CONNECTION TO TOSHIBA PLC	499
12.1 Connectable Model List	499
12.2 Serial Connection	500
System configuration for connecting to PROSEC T series	500
System configuration for connecting to PROSEC V series	502
Connection Diagram	503
GOT Side Settings	506
PLC Side Setting	508
12.3 Ethernet Connection	510
System configuration for connecting to Unified Controller nv Series	510
GOT side settings	511
PLC side setting	514
Precautions	515
12.4 Device Range that Can Be Set	516
CHAPTER 13 CONNECTION TO TOSHIBA MACHINE PLC	521
13.1 Connectable Model List	521
13.2 System Configuration	522

	Connecting to TC3, TC5, TC6, TC8	522
	Connecting to TS2000, TS2100	523
13.3	Connection Diagram	524
	RS-232 cable	524
	RS-485 cable	526
13.4	GOT Side Settings	530
	Setting communication interface (Communication settings)	530
	Communication detail settings	531
13.5	PLC Side Setting	532
	Connecting to TC3, TC8 series	532
	Connecting to TC5 series	532
	Connecting to TC6 series	532
	Connecting to TS2000, TS2100	532
13.6	Device Range that Can Be Set	533
	TOSHIBA MACHINE PLC (TOSHIBA MACHINE TCmini)	534

CHAPTER 14 CONNECTION TO PANASONIC SERVO AMPLIFIER 535

14.1	Connectable Model List	535
14.2	System Configuration	536
	Connecting to MINAS A4, MINAS A4F, MINAS A4L series	536
	Connecting to MINAS A5 series	537
14.3	Connection Diagram	538
	RS-232 cable	538
	RS-485 cable	539
	RS-232/RS-485 cable	543
14.4	GOT Side Settings	544
	Setting communication interface (Communication settings)	544
	Communication detail settings	545
14.5	Servo Amplifier Side Setting	546
	Connecting to MINAS A4/A4F/A4L	546
	Connecting to MINAS A5	546
	Station number setting	547
14.6	Device Range that Can Be Set	548
	PANASONIC servo amplifier (PANASONIC MINAS-A4 Series)	549
	PANASONIC servo amplifier (PANASONIC MINAS-A5 Series)	550
14.7	Precautions	551

CHAPTER 15 CONNECTION TO PANASONIC INDUSTRIAL DEVICES SUNX PLC 553

15.1	Connectable Model List	553
15.2	System Configuration	554
	Connecting to FP0-C16CT, FP0-C32CT, or FP0R	554
	Connecting to FP1-C24C or FP1-C40C	555
	Connecting to FP2 or FP2SH	556
	Connecting to FP3 or FP5	559
	Connecting to FP10(S)	561
	Connecting to FP10SH	564
	Connecting to FP-M(C20TC) or FP-M(C32TC)	566
	Connecting to FPΣ	568
	Connecting to FP-X	570
	Connecting to FP7	573

15.3	Connection Diagram	578
	RS-232 cable	578
	RS-422 cable	585
	RS-485 cable	588
15.4	GOT Side Settings	590
	Setting communication interface (Communication settings)	590
	Communication detail settings	591
15.5	PLC Side Setting	593
	Connecting to FP0/1/2/3/5, FP-M, FPΣ, FP-X	593
	Connecting to FP7	595
15.6	Device Range that Can Be Set	596
	Panasonic Industrial Devices SUNX PLC (Panasonic MEWNET-FP)	598
	Panasonic Industrial Devices SUNX PLC (Panasonic FP-7)	599
	REVISIONS	601
	WARRANTY	603
	Copyright Notice	604

Manuals for GT Works3

The electronic manuals related to this product are installed together with the screen design software.
If you need the printed manuals, consult your local sales office.

Manuals for GT Designer3 (GOT2000)



e-Manual

e-Manual refers to the Mitsubishi Electric FA electronic book manuals that can be browsed using a dedicated tool.

e-Manual has the following features:

- Required information can be cross-searched in multiple manuals.
- Other manuals can be accessed from the links in the manual.
- Hardware specifications of each part can be found from the product figures.
- Pages that users often browse can be bookmarked.

■Screen design software-related manuals

Manual name	Manual number (Model code)	Format
GT Works3 Installation Instructions	-	PDF
GT Designer3 (GOT2000) Screen Design Manual	SH-081220ENG (1D7ML9)	PDF e-Manual
GT Converter2 Version3 Operating Manual for GT Works3	SH-080862ENG (1D7MB2)	PDF
GOT2000 Series MES Interface Function Manual for GT Works3 Version1	SH-081228ENG	PDF

■Connection manuals

Manual name	Manual number (Model code)	Format
GOT2000 Series Connection Manual (Mitsubishi Electric Products) For GT Works3 Version1	SH-081197ENG (1D7MJ8)	PDF
GOT2000 Series Connection Manual (Non-Mitsubishi Electric Products 1) For GT Works3 Version1	SH-081198ENG	PDF
GOT2000 Series Connection Manual (Non-Mitsubishi Electric Products 2) For GT Works3 Version1	SH-081199ENG	PDF
GOT2000 Series Connection Manual (Microcomputers, MODBUS/Fieldbus Products, Peripherals) For GT Works3 Version1	SH-081200ENG	PDF
GOT2000 Series Handy GOT Connection Manual For GT Works3 Version1	SH-081867ENG (1D7MS9)	PDF

■GT SoftGOT2000 manuals

Manual name	Manual number (Model code)	Format
GT SoftGOT2000 Version1 Operating Manual	SH-081201ENG	PDF e-Manual
MELSOFT GT OPC UA Client Operating Manual	SH-082174ENG	PDF

■GOT2000 series user's manuals

Manual name	Manual number (Model code)	Format
GOT2000 Series User's Manual (Hardware)	SH-081194ENG (1D7MJ5)	PDF e-Manual
GOT2000 Series User's Manual (Utility)	SH-081195ENG (1D7MJ6)	PDF e-Manual
GOT2000 Series User's Manual (Monitor)	SH-081196ENG (1D7MJ7)	PDF e-Manual

■GOT SIMPLE series user's manuals

Manual name	Manual number	Format
GOT SIMPLE Series User's Manual	JY997D52201	PDF

■Manuals related to GT Works3 add-on projects








Manual name	Manual number (Model code)	Format
GT Works3 Add-on License for GOT2000 Enhanced Drive Control (Servo) Project Data Manual (Fundamentals)	SH-082072ENG (1D7MV1)	PDF e-Manual
GT Works3 Add-on License for GOT2000 Enhanced Drive Control (Servo) Project Data Manual (Screen Details)	SH-082074ENG (1D7MV3)	PDF e-Manual














Abbreviations, Generic Terms, and Model Icons

The following shows the abbreviations, generic terms, and model icons used in Help.


GOT

■GOT2000 series

Abbreviations and generic terms			Description	Meaning of icon	
				Available	Unavailable
GT27	GT27-X	GT2715-X	GT2715-XTBA, GT2715-XTBD		-
	GT27-S	GT2712-S	GT2712-STBA, GT2712-STWA, GT2712-STBD, GT2712-STWD		
		GT2710-S	GT2710-STBA, GT2710-STBD		
		GT2708-S	GT2708-STBA, GT2708-STBD		
	GT27-V	GT2710-V	GT2710-VTBA, GT2710-VTWA, GT2710-VTBD, GT2710-VTWD		
		GT2708-V	GT2708-VTBA, GT2708-VTBD		
		GT2705-V	GT2705-VTBD		
GT25			All GT25 models		-
	GT25-W	GT2510-WX	GT2510-WXTBD, GT2510-WXTSD		-
		GT2507-W	GT2507-WTBD, GT2507-WTSD		
		GT2507T-W	GT2507T-WTSD		
	GT25-S	GT2512-S	GT2512-STBA, GT2512-STBD		-
		GT2512F-S	GT2512F-STNA, GT2512F-STND		
	GT25-V	GT2510-V	GT2510-VTBA, GT2510-VTWA, GT2510-VTBD, GT2510-VTWD		
		GT2510F-V	GT2510F-VTNA, GT2510F-VTND		
		GT2508-V	GT2508-VTBA, GT2508-VTWA, GT2508-VTBD, GT2508-VTWD		
		GT2508F-V	GT2508F-VTNA, GT2508F-VTND		
	GT2505-V	GT2505-VTBD	GT2505-VTBD		
		GT2505-VTBD	GT2505-VTBD		
	GT25HS-V Handy GOT	GT2506HS-V	GT2506HS-VTBD		-
		GT2505HS-V	GT2505HS-VTBD		-
GT23	GT23-V	GT2310-V	GT2310-VTBA, GT2310-VTBD		-
		GT2308-V	GT2308-VTBA, GT2308-VTBD		

Abbreviations and generic terms		Description	Meaning of icon		
			Available	Unavailable	
GT21		All GT21 models		-	
GT21-W	GT2107-W	GT2107-WTBD, GT2107-WTSD		-	
GT21-Q	GT2105-Q	GT2105-QTBDS, GT2105-QMBDS		-	
GT21-R	GT2104-R	GT2104-RTBD		-	
GT21-P	GT2104-P	GT2104-PMBD		-	
		GT2104-PMBDS		-	
		GT2104-PMBDS2		-	
		GT2104-PMBLS		-	
	GT2103-P	GT2103-PMBD		-	
		GT2103-PMBDS		-	
		GT2103-PMBDS2		-	
		GT2103-PMBLS		-	
	GT SoftGOT2000		GT SoftGOT2000 Version1		-

■GOT SIMPLE series

Abbreviations and generic terms		Description	Meaning of icon	
			Available	Unavailable
GS21		GS2110-WTBD, GS2107-WTBD		-

■GOT1000 series, GOT900 series, and GOT800 series

Abbreviations and generic terms		Description	Meaning of icon	
			Available	Unavailable
GOT1000 Series		GOT1000 Series	-	
GOT900 Series		GOT-A900 Series, GOT-F900 Series	-	
GOT800 Series		GOT-800 Series	-	

Communication unit

Abbreviations and generic terms	Description
Bus connection unit	GT15-QBUS, GT15-QBUS2, GT15-ABUS, GT15-ABUS2, GT15-75QBUSL, GT15-75QBUS2L, GT15-75ABUSL, GT15-75ABUS2L
Serial communication unit	GT15-RS2-9P, GT15-RS4-9S, GT15-RS4-TE
MELSECNET/H communication unit	GT15-J71LP23-25, GT15-J71BR13
CC-Link IE TSN communication unit	GT25-J71GN13-T2
CC-Link IE Controller Network communication unit	GT15-J71GP23-SX
CC-Link IE Field Network communication unit	GT15-J71GF13-T2
CC-Link communication unit	GT15-J61BT13
Wireless LAN communication unit	GT25-WLAN
Serial multi-drop connection unit	GT01-RS4-M
Connection conversion adapter	GT10-9PT5S
Field network adapter unit	GT25-FNADP
Ethernet communication unit	GT25-J71E71-100
RS-232/485 signal conversion adapter	GT14-RS2T4-9P

Option unit

Abbreviations and generic terms	Description
Printer unit	GT15-PRN
Video input unit	GT27-V4-Z (A set of GT16M-V4-Z and GT27-IF1000)
RGB input unit	GT27-R2, GT27-R2-Z (A set of GT16M-R2-Z and GT27-IF1000)
Video/RGB input unit	GT27-V4R1-Z (A set of GT16M-V4R1-Z and GT27-IF1000)
RGB output unit	GT27-ROUT, GT27-ROUT-Z (A set of GT16M-ROUT-Z and GT27-IF1000)
Digital video output unit	GT27-VHOUT
Multimedia unit	GT27-MMR-Z (A set of GT16M-MMR-Z and GT27-IF1000)
Video signal conversion unit	GT27-IF1000
External I/O unit	GT15-DIO, GT15-DIOR
Sound output unit	GT15-SOUT
SD card unit	GT21-03SDCD

Option

Abbreviations and generic terms	Description
SD card	NZ1MEM-2GBSD, NZ1MEM-4GBSD, NZ1MEM-8GBSD, NZ1MEM-16GBSD, L1MEM-2GBSD, L1MEM-4GBSD
Battery	GT11-50BAT, GT15-BAT
Protective sheet	GT27-15PSGC, GT25-12PSGC, GT25-10WPSGC, GT25-10PSGC, GT25-08PSGC, GT21-07WPSGC, GT25T-07WPSVC, GT25-05PSGC, GT25-05PSGC-2, GT21-05PSGC, GT21-04RPSGC-UC, GT21-03PSGC-UC, GT21-04PSGC-UC, GT27-15PSCC, GT25-12PSCC, GT25-10WPSCC, GT25-10PSCC, GT25-08PSCC, GT25-05PSCC, GT25-05PSCC-2, GT25-12PSCC-UC, GT25-10PSCC-UC, GT25-08PSCC-UC, GT21-07WPSCC, GT21-05PSCC, GT21-04RPSCC-UC, GT21-04PSCC-UC, GT21-03PSCC-UC, GT16H-60PSC, GT14H-50PSC
Environmental protection sheet	GT25F-12ESGS, GT25F-10ESGS, GT25F-08ESGS
Protective cover for oil	GT20-15PCO, GT20-12PCO, GT20-10PCO, GT20-08PCO, GT21-10WPCO, GT21-07WPCO, GT25T-07WPCO, GT25-05PCO, GT25-05PCO-2, GT05-50PCO, GT21-04RPCO, GT10-30PCO, GT10-20PCO
USB environmental protection cover	GT25-UCOV, GT25-05UCOV, GT21-WUCOV
Stand	GT15-90STAND, GT15-80STAND, GT15-70STAND, GT05-50STAND, GT25-10WSTAND, GT21-07WSTAND, GT25T-07WSTAND
Attachment	GT15-70ATT-98, GT15-70ATT-87, GT15-60ATT-97, GT15-60ATT-96, GT15-60ATT-87, GT15-60ATT-77, GT21-04RATT-40
Panel-mounted USB port extension	GT14-C10EXUSB-4S, GT10-C10EXUSB-5S
Connector conversion box	GT16H-CNB-42S, GT16H-CNB-37S, GT11H-CNB-37S
Emergency stop switch guard cover	GT16H-60ESCOV, GT14H-50ESCOV
Wall-mounting attachment	GT14H-50ATT

Software

■Software related to GOT

Abbreviations and generic terms	Description
GT Works3	SW1DND-GTWK3-J, SW1DND-GTWK3-E, SW1DND-GTWK3-C
GT Designer3 Version1	Screen design software GT Designer3 for GOT2000 and GOT1000 series
GT Designer3	Screen design software for GOT2000 series included in GT Works3
GT Designer3 (GOT2000)	
GT Designer3 (GOT1000)	Screen design software for GOT1000 series included in GT Works3
Speech synthesis license	GT Works Text to Speech License (SW1DND-GTVO-M)
Add-on license	GT Works3 add-on license for GOT2000 enhanced drive control (servo) project data (SW1DND-GTSV-MZ)
GT Simulator3	Screen simulator GT Simulator3 for GOT2000, GOT1000, and GOT900 series
GT SoftGOT2000	GOT2000 compatible HMI software GT SoftGOT2000
GT OPC UA Client	MELSOFT GT OPC UA Client (SW1DNN-GTOUC-MD)
GT Converter2	Data conversion software GT Converter2 for GOT1000 and GOT900 series
GT Designer2 Classic	Screen design software GT Designer2 Classic for GOT900 series
GT Designer2	Screen design software GT Designer2 for GOT1000 and GOT900 series
DU/WIN	Screen design software FX-PCS-DU/WIN for GOT-F900 series

■Software related to iQ Works

Abbreviations and generic terms	Description
iQ Works	iQ Platform compatible engineering environment MELSOFT iQ Works
MELSOFT Navigator	Integrated development environment software included in SW □ DND-IQWK (iQ Platform compatible engineering environment MELSOFT iQ Works) (□ represents a version.)
MELSOFT iQ AppPortal	SW□DND-IQAPL-M type integrated application management software (□ represents a version.)

■Other software

Abbreviations and generic terms		Description
GX Works3		SW □ DND-GXW3-E (-EA, -EAZ) type programmable controller engineering software (□ represents a version.)
GX Works2		SW □ DNC-GXW2-E (-EA, -EAZ) type programmable controller engineering software (□ represents a version.)
Controller simulator	GX Simulator3	Simulation function of GX Works3
	GX Simulator2	Simulation function of GX Works2
	GX Simulator	SW □ D5C-LLT-E (-EV) type ladder logic test tool function software package (SW5D5C-LLT (-V) or later versions) (□ represents a version.)
GX Developer		SW □ D5C-GPPW-E (-EV)/SW □ D5F-GPPW (-V) type software package (□ represents a version.)
GX LogViewer		SW □ DNN-VIEWER-E type software package (□ represents a version.)
MI Configurator		Configuration and monitor tool for Mitsubishi Electric industrial computers (SW□DNNMICONF-M) (□ represents a version.)
PX Developer		SW □ D5C-FBDQ-E type FBD software package for process control (□ represents a version.)
MT Works2		Motion controller engineering environment MELSOFT MT Works2 (SW □ DNDMTW2-E) (□ represents a version.)
MT Developer		SW□RNC-GSV type integrated start-up support software for motion controller Q series (□ represents a version.)
CW Configurator		C Controller module configuration and monitor tool (SW □ DND-RCCPU-E) (□ represents a version.)
MR Configurator2		SW □ DNC-MRC2-E type servo configuration software (□ represents a version.)
MR Configurator		MRZJW□-SETUP type servo configuration software (□ represents a version.)
FR Configurator2		Inverter setup software (SW □ DND-FRC2-E) (□ represents a version.)
FR Configurator		Inverter setup software (FR-SW □ -SETUP-WE) (□ represents a version.)
NC Configurator2		CNC parameter setting support tool (FCSB1221)
NC Configurator		CNC parameter setting support tool
FX Configurator-FP		Parameter setting, monitoring, and testing software package for FX3U-20SSCH (SW □ D5CFXSSCE) (□ represents a version.)
FX3U-ENET-L Configuration tool		FX3U-ENET-L type Ethernet module setting software (SW1D5-FXENETL-E)
RT ToolBox2		Robot program creation software (3D-11C-WINE)
RT ToolBox3		Robot program creation software (3F-14C-WINE)
MX Component		MX Component Version □ (SW □ D5C-ACT-E, SW □ D5C-ACT-EA) (□ represents a version.)
MX Sheet		MX Sheet Version □ (SW □ D5C-SHEET-E, SW □ D5C-SHEET-EA) (□ represents a version.)
CPU Module Logging Configuration Tool		CPU module logging configuration tool (SW1DNN-LLUTL-E)

License key (for GT SoftGOT2000)

Abbreviations and generic terms	Description
License key	GT27-SGTKEY-U

Others

Abbreviations and generic terms	Description
IAI	IAI Corporation
AZBIL	Azbil Corporation
OMRON	OMRON Corporation
KEYENCE	KEYENCE CORPORATION
KOYO EI	KOYO ELECTRONICS INDUSTRIES CO., LTD.
JTEKT	JTEKT Corporation
SHARP	Sharp Corporation
SHINKO	Shinko Technos Co., Ltd.
CHINO	CHINO CORPORATION
TOSHIBA	TOSHIBA CORPORATION
TOSHIBA MACHINE	TOSHIBA MACHINE CO., LTD.
PANASONIC	Panasonic Corporation
PANASONIC IDS	Panasonic Industrial Devices SUNX Co., Ltd.
HITACHI IES	Hitachi Industrial Equipment Systems Co., Ltd.
HITACHI	Hitachi, Ltd.
HIRATA	Hirata Corporation
FUJI	FUJI ELECTRIC CO., LTD.
MURATEC	Muratec products manufactured by Murata Machinery, Ltd.
YASKAWA	YASKAWA Electric Corporation
YOKOGAWA	Yokogawa Electric Corporation
RKC	RKC INSTRUMENT INC.
ALLEN-BRADLEY	Allen-Bradley products manufactured by Rockwell Automation, Inc.
CLPA	CC-Link Partner Association
GE	GE Intelligent Platforms, Inc.
HMS	HMS Industrial Networks
LS IS	LS Industrial Systems Co., Ltd.
mitsubishi india	Mitsubishi Electric India Pvt. Ltd.
ODVA	Open DeviceNet Vendor Association, Inc.
SCHNEIDER	Schneider Electric SA
SICK	SICK AG
SIEMENS	Siemens AG
SCHNEIDER EJH	Schneider Electric Japan Holdings Ltd.
PLC	Programmable controller manufactured by its respective company
Control equipment	Control equipment manufactured by its respective company
Temperature controller	Temperature controller manufactured by its respective company
Indicating controller	Indicating controller manufactured by its respective company
Controller	Controller manufactured by its respective company

MEMO

PART 1

PREPARATORY PROCEDURES FOR MONITORING

1 PREPARATORY PROCEDURES FOR MONITORING

1 PREPARATORY PROCEDURES FOR MONITORING

- Page 33 Setting the Communication Interface
- Page 50 Writing the Project Data onto the GOT
- Page 52 Option Devices for the Respective Connection
- Page 58 Connection Cables for the Respective Connection
- Page 68 Verifying GOT Recognizes Connected Equipment
- Page 70 Checking for Normal Monitoring

The following shows the procedures to be taken before monitoring and corresponding reference sections.

1. Setting the communication interface

Determine the connection type and channel No. to be used, and perform the communication setting.

☞ Page 33 Setting the Communication Interface

☞ Each chapter GOT Side Settings

2. Writing the package data

Write the project data, system application onto the GOT.

☞ Page 50 Writing the project data and OS onto the GOT

3. Verifying the package data

Verify the project data, system application are properly written onto the GOT.

☞ Page 51 Checking the project data and OS writing on GOT

4. Attaching the communication unit and connecting the cable

Mount the optional equipment and prepare/connect the connection cable according to the connection type.

☞ Page 52 Option Devices for the Respective Connection

☞ Page 58 Connection Cables for the Respective Connection

☞ Each chapter System Configuration

☞ Each chapter Connection Diagram

5. Verifying GOT recognizes connected equipment

Verify the GOT recognizes controllers on [Communication Settings] of the Utility.

☞ Page 68 Verifying GOT Recognizes Connected Equipment

6. Verifying the GOT is monitoring normally

Verify the GOT is monitoring normally using Utility, Developer, etc.

☞ Page 70 Checking for Normal Monitoring

1.1 Setting the Communication Interface

Set the communication interface of GOT and the connected equipment.


When using the GOT at the first time, make sure to set the channel of communication interface and the communication driver before writing to GOT.

Set the communication interface of the GOT at [Controller Setting] and [I/F Communication Setting] in GT Designer3.

Setting connected equipment (Channel setting)

Set the channel of the equipment connected to the GOT.

Setting



1. Select [Common] → [Controller Setting] from the menu.
2. The Controller Setting dialog box appears. Select the channel No. to be used from the list menu.
3. Refer to the following explanations for the setting.

Point

Channel No.2 to No.4

Use the channel No.2 to No.4 when using the Multi-channel function.


For details of the Multi-channel function, refer to the following.

📖 GOT2000 Series Connection Manual (Mitsubishi Electric Products) For GT Works3 Version1

Setting item

This section describes the setting items of the Manufacturer, Controller Type, Driver and I/F.

When using the channel No.2 to No.4, put a check mark at [Use CH*].



Item	Description
Use CH*	Select this item when setting the channel No.2 to No.4.
Manufacturer	Select the manufacturer of the equipment to be connected to the GOT.
Type	Select the type of the equipment to be connected to the GOT. For the settings, refer to the following. ☞ Page 35 Setting [Controller Type]
I/F	Select the interface of the GOT to which the equipment is connected. For the settings, refer to the following. ☞ Page 42 Setting [I/F]
Driver	Select the communication driver to be written to the GOT. For the settings, refer to the following. ☞ Page 34 Setting [Driver] When multiple communication drivers can be selected, this item is displayed. When only one communication driver can be selected, the driver name is displayed under [Detail Setting].
Detail Setting	Make settings for the transmission speed and data length of the communication driver. ☞ Refer to each chapter of the equipment to be connected to the GOT.

■Setting [Driver]

The displayed items for a driver differ according to the settings [Manufacturer], [Controller Type] and [I/F].

When the driver to be set is not displayed, confirm if [Manufacturer], [Controller Type] and [I/F] are correct.

For the settings, refer to the following.

☞ [Setting the communication interface] section in each chapter

■Setting [Controller Type]

The types for the selection differs depending on the PLC to be used.

For the settings, refer to the following.

Type	Model name
IAI X-SEL CONTROLLER	XSEL-J
	XSEL-K
	XSEL-KE
	XSEL-KT
	XSEL-KET
	XSEL-P
	XSEL-Q
	XSEL-JX
	XSEL-KX
	XSEL-KTX
	XSEL-PX
	XSEL-QX
	SSEL
	ASEL
	PSEL

Type	Model name
IAI ROBO CYLINDER	PCON-C
	PCON-CG
	PCON-CF
	PCON-CY
	PCON-SE
	PCON-PL
	PCON-PO
	PCON-CA
	PCON-CFA
	PCON-CB
	PCON-CFB
	ACON-C
	ACON-CG
	ACON-CY
	ACON-SE
	ACON-PL
	ACON-PO
	ACON-CB
	SCON-C
	SCON-CA
	SCON-CB
	ERC2
	EC-S3
	EC-S4
	EC-S6
	EC-S7
	EC-S6□R
	EC-S7□R
	EC-S6□AH
	EC-S7□AH
	EC-S6□AHR
	EC-S7□AHR
	EC-R6
	EC-R7
	EC-RP4
	EC-GS4
	EC-GD4
	EC-RR3
	EC-RR4
	EC-RR6
	EC-RR7
	EC-RR6□R
	EC-RR7□R
	EC-RR6□AH
	EC-RR7□AH
	EC-RR6□AHR
	EC-RR7□AHR
	EC-TC4
	EC-TW4
	EC-R6□W
	EC-R7□W

Type	Model name
AZBIL SDC/DMC Series	DMC10
	DMC50
	SDC15
	SDC25
	SDC26
	SDC35
	SDC36
	SDC20
	SDC21
	SDC30
	SDC31
	SDC40A
	SDC40B
	SDC40G
	SDC45
	SDC46
	CMS
	CMF015
	CMF050
	CML
	MQV
	MPC
	MVF
	PBC201-VN2
	AUR350C
	AUR450C
	RX
	CMC10B
	AHC2001

Type	Model name
OMRON SYSMAC	CPM1
	CPM1A
	CPM2A
	CPM2C
	CQM1
	CQM1H
	CJ1H
	CJ1G
	CJ1M
	CP1H
	CP1L
	CP1E
	C200HS
	C200H
	C200HX
	C200HG
	C200HE
	CS1H
	CS1G
	CS1D
	C1000H
	C2000H
	CV500
	CV1000
	CV2000
	CVM1
OMRON SYSMAC CS/CJ	CS1H
	CS1G
	CS1D
	CJ1H
	CJ1G
	CJ1M
	CJ2H
	CJ2M
OMRON NJ/NX	NJ501-1500
	NJ501-1400
	NJ501-1300
	NJ501-1520
	NJ501-1420
	NJ501-1320
	NJ501-1340
	NJ301-1200
	NJ301-1100
	NJ101-1000
	NJ101-9000
	NJ101-1020
	NJ101-9020
	NX1P2-1140DT
	NX1P2-1140DT1
	NX1P2-1040DT
	NX1P2-1040DT1
	NX1P2-9024DT
	NX1P2-9024DT1
	NX701-1700
	NX701-1600

Type	Model name
OMRON THERMAC/INPANEL NEO	E5AN
	E5EN
	E5CN
	E5GN
	E5ZN
KEYENCE KV-700/1000/3000/5000/7000	KV-700
	KV-1000
	KV-3000
	KV-5000
	KV-5500
	KV-7300
	KV-7500
	KV-N14□□
	KV-N24□□
	KV-N40□□
	KV-N60□□
	KV-NC32T
SHARP JW	JW-21CU
	JW-31CUH
	JW-50CUH
	JW-22CU
	JW-32CUH
	JW-33CUH
	JW-70CUH
	JW-100CUH
	JW-100CU
	Z-512J
TOSHIBA MACHINE Tcmini	TC3-01
	TC3-02
	TC5-02
	TC5-03
	TC6-00
	TC8-00
	TS2000
	TS2100


Type	Model name
KOYO KOSTAC/DL	SU-5E
	SU-6B
	SU-5M
	SU-6M
	PZ3
	D2-240
	D2-250-1
	D2-260
	D0-05AA
	D0-05AD
	D0-05AR
	D0-05DA
	D0-05DD
	D0-05DD-D
	D0-05DR
	D0-05DR-D
	D0-06DD1
	D0-06DD2
	D0-06DR
	D0-06DA
	D0-06AR
	D0-06AA
	D0-06DD1-D
	D0-06DD2-D
	D0-06DR-D
JTEKT TOYOPUC-PC Series	PC3JG-P-CPU
	PC3JG-CPU
	PC3J-CPU
	PC3JL-CPU
	PC2JC-CPU
	PC2J16P-CPU
	PC2J16PR-CPU
	PC2J-CPU
	PC2JS-CPU
	PC2JR-CPU
CHINO Controllers	LT350
	LT370
	LT450
	LT470
	DZ1000
	DZ2000
	LT230
	LT830
	DB1000
	DB2000
	GT120

Type	Model name
TOSHIBA PROSEC T/V Series	T2 (PU224)
	T3
	T3H
	T2E
	T2N
	model 2000(S2)
	model 2000(S2T)
	model 2000(S2E)
	model 3000 (S3)
TOSHIBA Unified Controller nv Series	PU811
	PUM11
	PUM12
	PUM14
PANASONIC MINAS-A4 Series	MINAS A4
	MINAS A4F
	MINAS A4L
PANASONIC INDUSTRIAL DEVICES SUNX MEWNET-FP Series	FP0-C16CT
	FP0-C32CT
	FP0R
	FP1-C24C
	FP1-C40C
	FP2
	FP2SH
	FP3
	FP5
	FP10(S)
	FP10SH
	FP-M(C20TC)
	FP-M(C32TC)
	FPΣ
	FP-X
Shinko Technos Controller Series	ACS-13A□/□,□,□C5
	JCS-33A-□/□□,C5
	JCR-33A-□/□□,C5
	JCD-33A-□/□□,C5
	JCM-33A□/□,□C5
	JIR-301-M□,C5
	PCD-33A-□/M,C5
	PC935-□/M,C5
	PC955-□/M,C5
	PC935-□/M,C
	PC955-□/M,C
	FCD-13A-□/M,C
	FCD-15A-□/M,C
	FCR-13A-□/M,C
	FCR-15A-□/M,C
	FCR-23A-□/M,C
	FIR-201-M,C
	DCL-33A-□/M,□,□C5

■Setting [I/F]

The interface differs depending on the GOT to be used.

Set the I/F according to the connection and the position of communication unit to be mounted onto the GOT.



GOT Ethernet Setting

The GOT can be connected to a different network by using the following network.

1) GOT IP Address Setting

Set the following communication port setting.

Standard port (When using GT25-W, port 1)

Set [GOT IP Address] and [Subnet Mask] in the standard port with a built-in GOT, or port 1.

Extension port (When using GT25-W, port 2)

Set [GOT IP Address] and [Subnet Mask] in the extension port (the Ethernet interface for the Ethernet communication module), or port 2 with a built-in GOT.

When using the GOT other than GT25-W, BootOS Version Z or later is required to use the extension port.

For details on writing the BootOS, refer to the following manual.

 GT Designer3 (GOT2000) Screen Design Manual

Wireless LAN

Set [GOT IP Address], [Subnet Mask], [Peripheral S/W Communication Port No.], and [Transparent Port No.] for the wireless LAN interface.

2) GOT Ethernet Common Setting

Set the following setting which is common to the standard port and the extension port, or port 1 and port 2.

- [Default Gateway]
- [Peripheral S/W Communication Port No.]
- [Transparent Port No.]

3) IP Filter Setting

By configuring the IP filter setting, the access from the specific IP address can be permitted or shut off.


GOT IP Address Setting

Set the GOT IP address.


■[Standard Port] or [Port 1]

The following shows an example for [Standard Port].

1. Select [Common] → [GOT Ethernet Setting] → [GOT IP Address Setting] from the menu to display the [GOT Ethernet Setting] window.




2. On the [Standard Port] tab, configure the following settings.

Item	Description	Range
Update GOT Ethernet standard port setting	The GOT Ethernet standard port settings are applied on GOT.	-
GOT IP Address	Set the IP address of the GOT IP Address. (Default: 192.168.3.18)	0.0.0.0 to 255.255.255.255
Subnet Mask	Set the subnet mask for the sub network. (Only for connection via router) If the sub network is not used, the default value is set. (Default: 255.255.255.0)	0.0.0.0 to 255.255.255.255
Select from GOT Setting List	Select the GOT set in [GOT Setting List] dialog.  GT Designer3 (GOT2000) Screen Design Manual	-


■[Extended Port], or [Port 2]

The following shows an example for [Extended Port].

1. Select [Common] → [GOT Ethernet Setting] → [GOT IP Address Setting] from the menu to display the [GOT Ethernet Setting] window.




2. On the [Extended Port] tab, configure the following settings.

Item	Description	Range
Update GOT Ethernet extended port setting	The GOT Ethernet extended port settings are applied on GOT.	-
Enable Ethernet extended port	Enable the ethernet extended port.	-
GOT IP Address	Set the IP address of the GOT IP Address. (Default:192.168.5.22)	0.0.0.0 to 255.255.255.255
Subnet Mask	Set the subnet mask for the sub network. (Only for connection via router) If the sub network is not used, the default value is set. (Default: 255.255.255.0)	0.0.0.0 to 255.255.255.255
Select from GOT Setting List	Select the GOT set in [GOT Setting List] dialog.  GT Designer3 (GOT2000) Screen Design Manual	-

■[Wireless LAN]

1. Select [Common] → [GOT Ethernet Setting] → [GOT IP Address Setting] from the menu to display the [GOT Ethernet Setting] window.




2. On the [Wireless LAN] tab, configure the following settings.

Item	Description	Range
Update GOT Wireless LAN I/F setting	The wireless LAN interface settings are applied on GOT.	-
Enable Wireless LAN I/F	Enable the wireless LAN.	-
GOT IP Address	Set the IP address of the wireless LAN I/F. (Default: 192.168.4.20)	0.0.0.0 to 255.255.255.255
Subnet Mask	Set the subnet mask for the sub network. (Only for connection via router) If the sub network is not used, the default value is set. (Default: 255.255.255.0)	0.0.0.0 to 255.255.255.255
Select from GOT Setting List	Select the GOT set in [GOT Setting List] dialog. GT Designer3 (GOT2000) Screen Design Manual	-
Specify port No. for Wireless LAN	Enable the port number setting for the wireless LAN separately from GOT Ethernet common setting.	-
Peripheral S/W Communication Port No.	Set the GOT port No. for the communication with the peripheral S/W. (Default: 5015)	1024 to 65534 (Except for 5011 to 5013, 49153 to 49170)
Transparent Port No.	Set the GOT port No. for the transparent function. (Default: 5014)	1024 to 65534 (Except for 5011 to 5013, 49153 to 49170)
Driver setting	Display [Detail Settings] dialog, GT Designer3 (GOT2000) Screen Design Manual	-

Point

GOT IP address


For GOT IP address of each Ethernet setting, set a value that network system is different from each other.
(When the subnet mask is [255.255.255.0])



GOT Ethernet Common Setting

Set the following setting which is common to the standard port and the extension port, or port 1 and port 2.

1. Select [Common] → [GOT Ethernet Setting] → [GOT Ethernet Common Setting] from the menu to display the [GOT Ethernet Setting] window.




2. Configure the following settings.

Item	Description	Range
Default Gateway	Set the router address of the default gateway where the GOT is connected. (Only for connection via router) (Default: 0.0.0.0)	0.0.0.0 to 255.255.255.255
Peripheral S/W Communication Port No.	Set the GOT port No. for the communication with the peripheral S/W. (Default: 5015)	1024 to 65534 (Except for 5011 to 5013, 49153 to 49170)
Transparent Port No.	Set the GOT port No. for the transparent function. (Default: 5014)	1024 to 65534 (Except for 5011 to 5013, 49153 to 49170)

IP Filter Setting

1. Select [Common] → [GOT Ethernet Setting] → [IP Filter Setting] from the menu to display the [GOT Ethernet Setting] window.



2. For the detailed settings, refer to the following manual.

📖 GT Designer3 (GOT2000) Screen Design Manual

I/F communication setting

This function displays the list of the GOT communication interfaces.
Set the channel and the communication driver to the interface to be used.

Setting

I/F Communication Setting

Standard I/F Setting

	CH No.	Driver	
I/F-1: RS422/485	1	Serial(MELSEC)	Detail Setting...
I/F-2: RS232	0	None	Detail Setting...
I/F-3: USB	9	Host (PC)	

RS232 Setting

☐ Enable the 5V power supply

Ethernet Connection Setting

	CH No.	Driver	
Ethernet	0	None	Detail Setting...

Extend I/F Setting

	CH No.	Driver	
1st	0	None	Detail Setting...
2nd	0	None	Detail Setting...
3rd	0	None	Detail Setting...

OK Cancel

1. Select [Common] → [I/F Communication Setting] from the menu.
2. The I/F Communication Setting dialog box appears. Make the settings with reference to the following explanation.

Setting item

The following describes the setting items for the standard I/F setting and extension I/F setting.


For the detailed explanations, refer to the following manual.

📖 GT Designer3 (GOT2000) Screen Design Manual

When GT2104-P or GT2103-P is selected in the GOT type setting

I/F-1: RS422/485/232(Side)
I/F-2: RS232(Back)

Item	Description										
Standard I/F Setting	<p>Set channel No. and drivers to the GOT standard interfaces.</p> <table> <tr> <td>CH No.</td><td> <p>Set the CH No. according to the intended purpose.</p> <p>0: Not used</p> <p>1 to 4: Used for connecting a controller of channel No. 1 to 4 set in Setting connected equipment (Channel setting)</p> <p>5 to 8: Used for barcode function, RFID function, remote personal computer operation function (serial)</p> <p>A: Used for the report function (with a serial printer), hard copy function (with a serial printer).</p> </td></tr> <tr> <td>Driver</td><td> <p>Set the driver for the device to be connected.</p> <ul style="list-style-type: none"> Each communication driver suitable to the channel numbers Each communication driver for connected devices </td></tr> <tr> <td>Detail Setting</td><td> <p>Set the detailed settings for the communication driver.</p> <p>📖 Refer to each chapter of the equipment to be connected to the GOT.</p> </td></tr> <tr> <td>I/F-1, I/F-2, I/F-3</td><td> <p>The communication type of the GOT standard interface is displayed.</p> </td></tr> <tr> <td>RS232 Setting</td><td> <p>To validate the 5V power supply function in RS232, mark the [Enable the 5V power supply] checkbox.</p> <p>The RS232 setting is invalid when the CH No. of [I/F-1: RS232] is [9].</p> <p>Not applicable to GT21 and GS21.</p> </td></tr> </table>	CH No.	<p>Set the CH No. according to the intended purpose.</p> <p>0: Not used</p> <p>1 to 4: Used for connecting a controller of channel No. 1 to 4 set in Setting connected equipment (Channel setting)</p> <p>5 to 8: Used for barcode function, RFID function, remote personal computer operation function (serial)</p> <p>A: Used for the report function (with a serial printer), hard copy function (with a serial printer).</p>	Driver	<p>Set the driver for the device to be connected.</p> <ul style="list-style-type: none"> Each communication driver suitable to the channel numbers Each communication driver for connected devices 	Detail Setting	<p>Set the detailed settings for the communication driver.</p> <p>📖 Refer to each chapter of the equipment to be connected to the GOT.</p>	I/F-1, I/F-2, I/F-3	<p>The communication type of the GOT standard interface is displayed.</p>	RS232 Setting	<p>To validate the 5V power supply function in RS232, mark the [Enable the 5V power supply] checkbox.</p> <p>The RS232 setting is invalid when the CH No. of [I/F-1: RS232] is [9].</p> <p>Not applicable to GT21 and GS21.</p>
CH No.	<p>Set the CH No. according to the intended purpose.</p> <p>0: Not used</p> <p>1 to 4: Used for connecting a controller of channel No. 1 to 4 set in Setting connected equipment (Channel setting)</p> <p>5 to 8: Used for barcode function, RFID function, remote personal computer operation function (serial)</p> <p>A: Used for the report function (with a serial printer), hard copy function (with a serial printer).</p>										
Driver	<p>Set the driver for the device to be connected.</p> <ul style="list-style-type: none"> Each communication driver suitable to the channel numbers Each communication driver for connected devices 										
Detail Setting	<p>Set the detailed settings for the communication driver.</p> <p>📖 Refer to each chapter of the equipment to be connected to the GOT.</p>										
I/F-1, I/F-2, I/F-3	<p>The communication type of the GOT standard interface is displayed.</p>										
RS232 Setting	<p>To validate the 5V power supply function in RS232, mark the [Enable the 5V power supply] checkbox.</p> <p>The RS232 setting is invalid when the CH No. of [I/F-1: RS232] is [9].</p> <p>Not applicable to GT21 and GS21.</p>										
Ethernet Connection Setting	<p>Set the channel number and the communication driver to the Ethernet interface with a built-in GOT.</p> <table> <tr> <td>CH No.</td><td> <p>Set the CH No. according to the intended purpose.</p> <p>0: Not used</p> <p>1 to 4: Used for connecting a controller of channel No. 1 to 4 set in Setting connected equipment (Channel setting)</p> <p>9: Used for connecting Host (PC) or Ethernet download</p> <p>A: Used for the remote personal computer operation function (Ethernet), VNC server function, gateway function, and MES interface function.</p> <p>Multi: Used for multi-channel Ethernet connection</p> </td></tr> <tr> <td>Driver</td><td> <p>Set the driver for the device to be connected.</p> <ul style="list-style-type: none"> Each communication driver suitable to the channel numbers Each communication driver for connected devices </td></tr> <tr> <td>Detail Setting</td><td> <p>Set the detailed settings for the communication driver.</p> <p>📖 Refer to each chapter of the equipment to be connected to the GOT.</p> </td></tr> </table>	CH No.	<p>Set the CH No. according to the intended purpose.</p> <p>0: Not used</p> <p>1 to 4: Used for connecting a controller of channel No. 1 to 4 set in Setting connected equipment (Channel setting)</p> <p>9: Used for connecting Host (PC) or Ethernet download</p> <p>A: Used for the remote personal computer operation function (Ethernet), VNC server function, gateway function, and MES interface function.</p> <p>Multi: Used for multi-channel Ethernet connection</p>	Driver	<p>Set the driver for the device to be connected.</p> <ul style="list-style-type: none"> Each communication driver suitable to the channel numbers Each communication driver for connected devices 	Detail Setting	<p>Set the detailed settings for the communication driver.</p> <p>📖 Refer to each chapter of the equipment to be connected to the GOT.</p>				
CH No.	<p>Set the CH No. according to the intended purpose.</p> <p>0: Not used</p> <p>1 to 4: Used for connecting a controller of channel No. 1 to 4 set in Setting connected equipment (Channel setting)</p> <p>9: Used for connecting Host (PC) or Ethernet download</p> <p>A: Used for the remote personal computer operation function (Ethernet), VNC server function, gateway function, and MES interface function.</p> <p>Multi: Used for multi-channel Ethernet connection</p>										
Driver	<p>Set the driver for the device to be connected.</p> <ul style="list-style-type: none"> Each communication driver suitable to the channel numbers Each communication driver for connected devices 										
Detail Setting	<p>Set the detailed settings for the communication driver.</p> <p>📖 Refer to each chapter of the equipment to be connected to the GOT.</p>										

Item	Description	
Extend I/F Setting	Set the communication unit attached to the extension interface of the GOT. Not applicable to GT21 and GS21.	
	CH No.	Set the CH No. according to the intended purpose. The number of channels differs depending on the GOT to be used. 0: Not used 1 to 4: Used for the controllers of channel numbers 1 to 4 set in controller setting (channel setting). 5 to 8: Used for the barcode function, the RFID function, and the remote personal computer operation function (Serial). A: Used for the video/RGB display function, multimedia function, external I/O function, operation panel function, video output function, report function, hard copy function (with a printer), and sound output function.
	Driver	Set the driver for the device to be connected. • Each communication driver suitable to the channel numbers • Each communication driver for connected devices
	Detail Setting	Set the detailed settings for the communication driver.  Refer to each chapter of the equipment to be connected to the GOT.


Point

Channel No., drivers, [RS232 Setting]

- Channel No.2 to No.4

Use the channel No.2 to No.4 when using the Multi-channel function.


For details of the Multi-channel function, refer to the following.

 GOT2000 Series Connection Manual (Mitsubishi Electric Products) For GT Works3 Version1

- Drivers

The displayed items for a driver differ according to the settings [Manufacturer], [Controller Type] and [I/F].

When the driver to be set is not displayed, confirm if [Manufacturer], [Controller Type] and [I/F] are correct.

 [Setting the communication interface] section in each chapter

Precautions

Precautions for changing model

■When devices that cannot be converted are included.

When setting of [Manufacturer] or [Controller Type] is changed, GT Designer3 displays the device that cannot be converted (no corresponding device type, or excessive setting ranges) as [??]. In this case, set the device again.

■When the changed Manufacturer or Controller Type does not correspond to the network.

The network will be set to the host station.

■When the Manufacturer or Controller Type is changed to [None]

The GT Designer3 displays the device of the changed channel No. as [??]. In this case, set the device again.

Since the channel No. is retained, the objects can be reused in other channel No. in a batch by using the [Device Batch Edit], [CH No. Batch Edit] or [Device List].


1.2 Writing the Project Data onto the GOT

Write the package data onto the GOT.

For details on writing to GOT, refer to the following manual.

📖 GT Designer3 (GOT2000) Screen Design Manual

Writing the project data and OS onto the GOT



1. Select [Package Data] for [Write Data].

The capacity of the transfer data is displayed in [Data Size]. Check that the destination drive has the sufficient available space.

2. Select [Destination Drive].
3. When the system application or the special data is required to be added to the package data or deleted, click the [Write Option] button and configure the setting in the [Write Option] dialog.
4. Click the [GOT Write] button.
5. The package data is written to the GOT.


Checking the project data and OS writing on GOT

1

Confirm if the package data is properly written onto the GOT by reading from GOT using GT Designer3.

For reading from the GOT, refer to the following manual.

📖 GT Designer3 (GOT2000) Screen Design Manual



1. Set [GOT Side] as follows.

- Select [Project Data] or [Package Data] for [Read Data].
- Select the drive where the project data or the package data is stored for [Source Drive].

2. Set [PC Side].

Set the reading destination of the project for [Destination].

To read the project data to GT Designer3, select [GT Designer3].

(When [Read Data] is [Package Data], the project data cannot be read to GT Designer3.)

To read the project data as a file, click the [...] button to set the saving format and the saving destination of the file.

3. Click the [GOT Read] button.

4. The project is read.

5. Confirm that the project data is written correctly onto the GOT.




1.3 Option Devices for the Respective Connection

The following shows the option devices to connect in the respective connection type.

For the specifications, usage and connecting procedure on option devices, refer to the respective device manual.

Communication module

Product name	Model	Specifications
Bus connection unit	GT15-QBUS	For QCPU (Q mode), motion controller CPU (Q series) Bus connection (1ch) unit standard model
	GT15-QBUS2	For QCPU (Q mode), motion controller CPU (Q series) Bus connection (2ch) unit standard model
	GT15-ABUS	For A/QnACPU, motion controller CPU (A series) Bus connection (1ch) unit standard model
	GT15-ABUS2	For A/QnACPU, motion controller CPU (A series) Bus connection (2ch) unit standard model
	GT15-75QBUSL	For QCPU (Q mode), motion controller CPU (Q series) Bus connection (1ch) unit slim model
	GT15-75QBUS2L	For QCPU (Q mode), motion controller CPU (Q series) Bus connection (2ch) unit slim model
	GT15-75ABUSL	For A/QnACPU, motion controller CPU (A series) Bus connection (1ch) unit slim model
	GT15-75ABUS2L	For A/QnACPU, motion controller CPU (A series) Bus connection (1ch) unit slim model
Serial communication unit	GT15-RS2-9P	RS-232 serial communication unit (D-sub 9-pin (male))
	GT15-RS4-9S	RS-422/485 serial communication unit (D-sub 9-pin (female))
	GT15-RS4-TE	RS-422/485 serial communication unit (terminal block)
MELSECNET/H communication unit	GT15-J71LP23-25	Optical loop unit
	GT15-J71BR13	Coaxial bus unit
MELSECNET/10 communication unit	GT15-J71LP23-25	Optical loop unit (MELSECNET/H communication unit used in the MNET/10 mode)
	GT15-J71BR13	Coaxial bus unit (MELSECNET/H communication unit used in the MNET/10 mode)
CC-Link IE TSN communication unit	GT25-J71GN13-T2	CC-Link IE TSN slave station
CC-Link IE Controller Network communication unit	GT15-J71GP23-SX	Optical loop unit
CC-Link IE Field Network communication unit	GT15-J71GF13-T2	CC-Link IE Field Network (1000BASE-T) unit
CC-Link communication unit	GT15-J61BT13	Intelligent device station unit CC-LINK Ver. 2 compatible
Ethernet communication unit	GT25-J71E71-100	Ethernet (100Base-TX) unit
Wireless LAN communication unit ^{*1}	GT25-WLAN	<ul style="list-style-type: none"> Used for the connection to the IEEE802.11b/g/n compliant, built-in antenna, access point (master unit)^{*2}, station (slave unit), personal computers, tablets, and smartphones. Compliance with Japan Radio Law^{*3}, FCC^{*4}, RE^{*6} (R&TTE^{*4}), SRR^{*5}, KC^{*5}

- *1 Data transfer in wireless LAN communication may not be as stable as that in cable communication.
A packet loss may occur depending on the surrounding environment and the installation location.
Be sure to perform a confirmation of operation before using this product.
- *2 When a wireless LAN configuration of GT Designer3 the [Operation Mode] is set to [access point], the maximum connection number is a five (recommended).
- *3 The product with hardware version A or later (manufactured in December 2013) complies with the regulation.
The product with hardware version A can be used only in Japan.
For information on how to check the hardware version, refer to the following.
 GOT2000 Series User's Manual (Hardware)
- *4 The product with hardware version B or later (manufactured from October 2014) complies with the regulation.
The product with hardware version B or later can be used in Japan, the United States, the EU member states, Switzerland, Norway, Iceland, and Liechtenstein.
For information on how to check the hardware version, refer to the following.
 GOT2000 Series User's Manual (Hardware)
- *5 The product with hardware version D or later (manufactured from May 2016) complies with the regulation.
The product with hardware version D or later can be used in Japan, the United States, the EU member states, Switzerland, Norway, Iceland, Liechtenstein, China (excluding Hong Kong, Macao, and Taiwan), and South Korea.
For information on how to check the hardware version, refer to the following.
 GOT2000 Series User's Manual (Hardware)
- *6 The product complies with the RE Directive from March 31, 2017.


Option unit

Product name	Model	Specifications
Multimedia unit	GT27-MMR-Z	For video input signal (NTSC/PAL) 1 ch, playing movie
Video input unit	GT27-V4-Z	For video input signal (NTSC/PAL) 4 ch
RGB input unit	GT27-R2 GT27-R2-Z	For analog RGB input signal 2 ch
Video/RGB input unit	GT27-V4R1-Z	For video input signal (NTSC/PAL) 4 ch, for analog RGB mixed input signal 1 ch
RGB output unit	GT27-ROUT GT27-ROUT-Z	For analog RGB output signal 1 ch
Digital video output unit	GT27-VHOUT	For digital video output, 1 channel
Sound output unit	GT15-SOUT	For sound output
External I/O unit	GT15-DIOR	For the connection to external I/O device or operation panel (Negative Common Input/Source Type Output)
	GT15-DIO	For the connection to external I/O device or operation panel (Positive Common Input/Sink Type Output)


Conversion cables

Product name	Model	Specifications
RS-485 terminal block conversion modules	FA-LTBGT2R4CBL05	RS-422/485 (Connector) ↔ RS-485 (Terminal block) Supplied connection cable dedicated for the conversion unit
	FA-LTBGT2R4CBL10	
	FA-LTBGT2R4CBL20	

Serial Multi-Drop Connection Unit

Product name	Model	Specifications
Serial multi-drop connection unit	GT01-RS4-M	GOT multi-drop connection module  GOT2000 Series Connection Manual (Mitsubishi Electric Products) For GT Works3 Version1

Field Network Adapter Unit

Product name	Model	Specifications
Field network adapter unit	GT25-FNADP	The field network adapter unit can be used with the following field networks by using the Anybus CompactCom M40 network communication module manufactured by HMS (hereinafter referred to as the communication module). Field networks: PROFIBUS DP-V1 DeviceNet How to incorporate the communication module to the field network adapter unit, and the details of the product name of the communication module, refer to the following manual.  GOT2000 Series Field Network Adapter Unit User's Manual

RS-232/485 signal conversion adapter

Product name	Model	Specifications
RS-232/485 signal conversion adapter	GT14-RS2T4-9P	RS-232 signal (D-Sub 9-pin connector) → RS-485 signal (Terminal block)

Precautions for installing units on another unit.

This section describes the precautions for installing units on another unit.

For the installation method of each unit, refer to the User's Manual for the communication unit and option unit you are using.

For the method for installing a unit on another unit, refer to the following.

☞ GOT2000 Series User's Manual (Hardware)

When using the video input unit, RGB input unit, video/RGB input unit, RGB output unit, multimedia unit, or digital video output unit

Only either one of the following option units can be mounted on the GOT.

Mount the unit on the 1st stage of the extension interface.


It cannot be used if mounted on the 2nd or higher stage.

Product name	Model
Video input unit	GT27-V4-Z
RGB input unit	GT27-R2, GT27-R2-Z
Video/RGB input unit	GT27-V4R1-Z
RGB output unit	GT27-ROUT, GT27-ROUT-Z
Multimedia unit	GT27-MMR-Z
Digital video output unit	GT27-VHOUT

When any of these units is used, the communication units and option units indicated below must be mounted on the 2nd or 3rd stage of an extension interface.

Product name	Model
Bus connection unit	GT15-QBUS2, GT15-QBUS, GT15-ABUS2, GT15-ABUS
MELSECNET/H communication unit	GT15-J71LP23-25, GT15-J71BR13
CC-Link IE TSN communication unit	GT25-J71GN13-T2
CC-Link IE Controller Network communication unit	GT15-J71GP23-SX
CC-Link IE Field Network communication unit	GT15-J71GF13-T2
CC-Link communication unit	GT15-J61BT13
Ethernet communication unit	GT25-J71E71-100
Serial communication unit	GT15-RS2-9P, GT15-RS4-9S, GT15-RS4-TE
Field network adapter unit	GT25-FNADP
Sound output unit	GT15-SOUT
External I/O unit	GT15-DIOR, GT15-DIO
Printer unit	GT15-PRN

Example) When mounting a video/RGB input unit and a MELSECNET/H communication unit



Installing GT15-75QBUSL, GT15-75QBUS2L, GT15-75ABUSL, GT15-75ABUS2L

They cannot be mounted on the video input unit, RGB input unit, video/RGB input unit, RGB output unit, multimedia unit, or digital video output unit.

When establishing the bus connection with any of the above units connected, use GT15-QBUS, GT15-QBUS2, GT15-ABUS, or GT15-ABUS2.


Installation position of a communication unit occupying two extension interfaces

The following communication unit occupying two extension interface must be installed in the 1st stage of extension interfaces. However, pay attention to the following restrictions to install the communication unit.

☞ Page 55 When using the video input unit, RGB input unit, video/RGB input unit, RGB output unit, multimedia unit, or digital video output unit

Model	Communication unit
Bus connection unit	GT15-QBUS2, GT15-ABUS2, GT15-75QBUS2L, GT15-75ABUS2L
MELSECNET/H communication unit	GT15-J71LP23-25, GT15-J71BR13
CC-Link IE TSN communication unit	GT25-J71GN13-T2
CC-Link IE Controller Network communication unit	GT15-J71GP23-SX
CC-Link IE Field Network communication unit	GT15-J71GF13-T2
CC-Link communication unit	GT15-J61BT13

Example) When installing a bus connection unit and serial communication units



Installation position of a communication unit and option unit occupying one extension interface


The following communication unit occupying two extension interface must be installed in the 1st stage of extension interfaces. However, pay attention to the following restrictions to install the communication unit and option unit.

☞ Page 55 When using the video input unit, RGB input unit, video/RGB input unit, RGB output unit, multimedia unit, or digital video output unit

☞ Page 56 Installation position of a communication unit occupying two extension interfaces

Model	Communication unit
Bus connection unit	GT15-75QBUSL, GT15-75ABUSL
Ethernet communication unit	GT25-J71E71-100
Serial communication unit	GT15-RS2-9P, GT15-RS4-9S, GT15-RS4-TE
Field network adapter unit ^{*1}	GT25-FNADP
Sound output unit	GT15-SOUT
External I/O unit	GT15-DIOR, GT15-DIO
Printer unit	GT15-PRN

*1 At the top of the field network adapter unit, each communication unit and option unit cannot be installed.



1.4 Connection Cables for the Respective Connection

To connect the GOT to a device in the respective connection type, connection cables between the GOT and a device are necessary.

For cables needed for each connection, refer to each chapter for connection.

For the dimensions of connection cables and connector shapes, refer to the following.

📖 GOT2000 Series User's Manual (Hardware)

GOT connector specifications

The following shows the connector specifications on the GOT side.

Refer to the following table when preparing connection cables by the user.

RS-232 interface



Use the following as the RS-232 interface and the RS-232 communication unit connector on the GOT. For the GOT side of the connection cable, use a connector and connector cover applicable to the GOT connector.

■Connector specifications

GOT	Hardware Version	Connector type	Connector model	Manufacturer
GT27, GT25, GT23, GT2107-W, GT2105-QTBDS, GT2105-QMBDS, GS21	-	9-pin D-sub (male) inch screw fixed type	17LE-23090-27(D4C□)	DDK Ltd.
GT15-RS2-9P	-	9-pin D-sub (male) inch screw fixed type	17LE-23090-27(D3CC)	DDK Ltd.
GT01-RS4-M	-			
GT2104-RTBD GT2104-PMBDS2 GT2103-PMBDS2	-	9-pin terminal block*1	MC1.5/9-G-3.5BK	PHOENIX CONTACT Inc

*1 The terminal block (MC1.5/9-ST-3.5 or corresponding product) of the cable side is packed together with the GT2104-RTBD, GT2103-PMBDS2.

■Connector pin arrangement

GT27, GT25, GT23, GT2107-W, GT2105-QTBDS, GT2105-QMBDS, GS21, GT15-RS2-9P, GT01-RS4-M	GT2104-RTBD, GT2103-PMBDS2
<p>GOT main part connector see from the front</p>  <p>9-pin D-sub (male)</p>	<p>See from the back of a GOT main part</p>  <p>9-pin terminal block</p>

RS-422/485 interface

Use the following as the RS-422/485 interface and the RS-422/485 communication unit connector on the GOT.
For the GOT side of the connection cable, use a connector and connector cover applicable to the GOT connector.




■Connector model

GOT	Connector type	Connector model	Manufacturer
GT27, GT25, GT23, GT2107-W, GT2105-QTBDS, GT2105-QMBDS, GS21	9-pin D-Sub (female) M2.6 millimeter screw fixed type	17LE-13090-27(D2AC)	DDK Ltd.
GT2104-PMBD GT2103-PMBD	5-pin terminal block ^{*1}	MC1.5/5-G-3.5BK	PHOENIX CONTACT Inc
GT2104-RTBD GT2104-PMBDS GT2104-PMBLS GT2103-PMBDS GT2103-PMBLS	9-pin terminal block ^{*2}	MC1.5/9-G-3.5BK	PHOENIX CONTACT Inc
GT15-RS4-9S GT01-RS4-M	9-pin D-Sub (female) M2.6 millimeter screw fixed type	17LE-13090-27(D3AC)	DDK Ltd.
GT15-RS4-TE	-	-	SL-SMT3.5/10/90F BOX

*1 The terminal block (MC1.5/5-ST-3.5 or corresponding product) of the cable side is packed together with the GT2103-PMBD.

*2 The terminal block (MC1.5/9-ST-3.5 or corresponding product) of the cable side is packed together with the GT2104-RTBD, GT2103-PMBDS, GT2103-PMBLS.

■Connector pin arrangement


GT27, GT25, GT23, GT2107-W, GT2105-QTBDS, GT2105-QMBDS, GS21, GT15-RS4-9P, GT01-RS4-M	GT2104-PMBD, GT2103-PMBD	GT2104-RTBD, GT2104-PMBDS, GT2104-PMBLS, GT2103-PMBDS, GT2103-PMBLS
<p>GOT main part connector see from the front</p>  <p>9-pin D-sub (female)</p>	<p>See from the back of a GOT main part</p>  <p>5-pin terminal block</p>	<p>See from the back of a GOT main part</p>  <p>9-pin terminal block</p>

Coaxial cableconnector connection method


The following describes the method for connecting the BNC connector (connector plug for coaxial cable) and the cable.

⚠CAUTION

- Solder the coaxial cable connectors properly.
Insufficient soldering may result in malfunctions.



- 5.** Insert the contact assembly shown in step 4 into the plug shell and screw the nut into the plug shell.



Precautions for soldering

Note the following precautions when soldering the internal conductor and contact.


- Make sure that the solder does not bead up at the soldered section.
- Make sure there are no gaps between the connector and cable insulator or they do not cut into each other.
- Perform soldering quickly so the insulation material does not become deformed.

Terminating resistors of GOT

The following shows the terminating resistor specifications on the GOT side.
When setting the terminating resistor in each connection type, refer to the following.

RS-422/485 communication unit


Set the terminating resistor using the terminating resistor setting switch.



Terminating resistor*1	Switch No.	
	1	2
100 OHM	ON	ON
Disable	OFF	OFF

*1 The default setting is "Disable".

- For RS422/485 communication unit



Rear view of RS-422/485 communication unit.


GT27

Set the terminating resistor using the terminating resistor setting switch.



Terminating resistor ^{*1}	Switch No.	
	1	2
100 OHM	ON	ON
Disable	OFF	OFF

^{*1} The default setting is "Disable".
• For GT2710-V



Terminating resistor setting switch
(inside the cover)


GT25 (except GT2510-WX, GT2507-W, and GT2505-V)

Set the terminating resistor using the terminating resistor setting switch.



Terminating resistor ^{*1}	Switch No.	
	1	2
100 OHM	ON	ON
Disable	OFF	OFF

^{*1} The default setting is "Disable".
• For GT2510-V




Terminating resistor setting switch
(inside the cover)

GT2510-WX and GT2507-W

Set the terminating resistor using the terminating resistor selector.


• For GT2510-WX

Terminating resistor selector switch
(inside the cover)



GT2505-V


Set the terminating resistor using the terminating resistor selector.



Terminating resistor selector switch


GT23

Set the terminating resistor using the terminating resistor setting switch.



Terminating resistor ^{*1}	Switch No.	
	1	2
100 OHM	ON	ON
Disable	OFF	OFF

^{*1} The default setting is "Disable".
• For GT2310-V




Terminating resistor setting switch
(inside the cover)

GT21

Set the terminating resistor using the terminating resistor setting switch.

- For GT2103-PMBD



Terminating resistor selector switch

Point

- Terminating resistor selector switch position

The position of the terminating resistor selector switch depends on the GOT type.

For the details, refer to the following.

➞ GOT2000 Series User's Manual (Hardware)

- Terminating resistor of GS21

The terminating resistor of GS21 is fixed to 330 Ω .

For the details, refer to the following.

➞ GOT SIMPLE Series User's Manual


Setting the RS-232/485 signal conversion adaptor

Set the 2-wire/4-wire terminating resistor setting switch according to the connection type.


1

Point

- Enable the 5V power supply
- Make sure to validate "Enable the 5V power supply" in the [RS232 Setting] to operate the RS-232/485 signal conversion adaptor.
- ➡ Page 47 I/F communication setting
- When validating the function using the utility function of the GOT main unit, refer to the following manual.
- ➡ GOT2000 Series User's Manual (Utility)



Setting the 2-wire/4-wire terminating resistor setting switch



Setting item	Set value	Switch No.					
		1	2	3	4	5	6
2-wire/4-wire	2-wire (1Pair)	ON	ON	-	-	-	OFF
	4-wire (2Pair)	OFF	OFF	-	-	-	OFF
Terminating resistor	110Ω	-	-	ON	OFF	OFF	OFF
	OPEN	-	-	OFF	OFF	OFF	OFF
	330Ω	-	-	OFF	ON	ON	OFF

Point

- RS-232/485 signal conversion adapter
- For details on the RS-232/485 signal conversion adapter, refer to the following manual.
- ➡ GT14-RS2T4-9P RS-232/485 Signal Conversion Adapter User's Manual

1.5 Verifying GOT Recognizes Connected Equipment


Verify the GOT recognizes controllers on [Communication Settings] of the Utility.

- Channel number of communication interface, communication drivers allocation status
- Communication unit installation status


For details on the Utility, refer to the following manual.

☞ GOT2000 Series User's Manual (Utility)

1. After powering up the GOT, touch [GOT basic set] → [Controller] from the Utility.



2. The [Communication Settings] appears.



3. Verify that the communication driver name to be used is displayed in the communication interface box to be used.
4. When the communication driver name is not displayed normally, carry out the following procedure again.

☞ Page 33 Setting the Communication Interface

1.6 Checking for Normal Monitoring


Check on the GOT

Check for errors occurring on the GOT

Presetting the system alarm to project data allows you to identify errors occurred on the GOT, PLC CPU, servo amplifier and communications.

For details on the operation method of the GOT Utility screen, refer to the following manual.

📖 GOT2000 Series User's Manual (Utility)



Point

Alarm popup display

With the alarm popup display function, alarms are displayed as a popup display regardless of whether an alarm display object is placed on the screen or not (regardless of the display screen).

Since comments can be flown from right to left, even a long comment can be displayed all.

For details of the alarm popup display, refer to the following manual.

📖 GT Designer3 (GOT2000) Screen Design Manual

Perform an I/O check

Whether the PLC can communicate with the GOT or not can be checked by the I/O check function.

If this check ends successfully, it means correct communication interface settings and proper cable connection.

Display the I/O check screen by Main Menu.


- Display the I/O check screen by [Main menu] → [Self check] → [I/O check].

For details on the I/O check, refer to the following manual:


📖 GOT2000 Series User's Manual (Utility)

1. Touch [CPU] on the I/O check screen.

Touching [CPU] executes the communication check with the connected PLC.



2. When the communication screen ends successfully, the screen on the left is displayed.




Communication monitoring function

The communication monitoring is a function that checks whether the PLC can communicate with the GOT.
If this check ends successfully, it means correct communication interface settings and proper cable connection.
Display the communication monitoring function screen by [Main Menu] → [Comm. Setting] → [Comm. Monitor].
For details on the communication monitoring function, refer to the following manual:

📖 GOT2000 Series User's Manual (Utility)

(Operation of communication monitoring function screen)



Confirming the communication state on the GOT side (For Ethernet connection)

Confirming the communication state on Windows, GT Designer3

■When using the Command Prompt of Windows

Execute a Ping command at the Command Prompt of Windows.

- When normal communication

C:\>Ping 192.168.3.18

Reply from 192.168.3.18: bytes=32 time<1ms TTL=64

- When abnormal communication


C:\>Ping 192.168.3.18

Request timed out.


■When using the [Connection Test] of GT Designer3

Select [Communication] → [Communication settings] from the menu to display [TEST].

1. Set the [PC side I/F] to the [Ethernet].
2. Specify the [GOT IP Address] of the [Communication Configuration] and click the [Test] button.



3. Check if GT Designer3 has been connected to the GOT.



■When abnormal communication

At abnormal communication, check the followings and execute the Ping command or [Connection Test] again.


- Mounting condition of Ethernet communication unit
- Cable connecting condition
- Confirmation of [Communication Settings]
- IP address of GOT specified by Ping command

Confirming the communication state on the GOT

[PING Test] can be confirmed by the Utility screen of the GOT.

For details on the operation method of the GOT Utility screen, refer to the following manual.

☞ GOT2000 Series User's Manual (Utility)



Confirming the communication state to each station (Station monitoring function)

The station monitoring function detects the faults (communication timeout) of the stations monitored by the GOT. When detecting the abnormal state, it allocates the data for the faulty station to the GOT special register (GS).

No. of faulty stations

■Ethernet connection (Except for Ethernet multiple connection)

Total No. of the faulty CPU is stored.

Device	b15 to b8	b7 to b0
GS230	(00H fixed)	No. of faulty stations

■Ethernet multiple connection

Total No. of the faulty connected equipment is stored.

Channel	Device	b15 to b8	b7 to b0
Ch1	GS280	(00H fixed)	No. of faulty stations
Ch2	GS300	(00H fixed)	No. of faulty stations
Ch3	GS320	(00H fixed)	No. of faulty stations
Ch4	GS340	(00H fixed)	No. of faulty stations




When monitoring GS230 on Numerical Display

When monitoring GS230 on Numerical Display, check [mask processing] with data operation tab as the following.

For the data operation, refer to the following manual.

📖 GT Designer3 (GOT2000) Screen Design Manual

- Numerical Display (Data Operation tab)



Faulty station information

The bit corresponding to the faulty station is set. (0: Normal, 1: Abnormal)

The bit is reset after the fault is recovered.

■Ethernet connection

Connected Ethernet Controller Setting

Ethernet setting No.

GS231 bit 0

GS231 bit 1

GS231 bit 2

GS231 bit 3

Host	Net No.	Station	Unit Type	IP Address	Port No.	Communication
1	1	1	QJ71E71/LJ71E71	192.168.3.39	5001	UDP
2	1	2	QJ71E71/LJ71E71	192.168.3.40	5001	UDP
3	1	3	AJ71QE71	192.168.3.41	5001	UDP
4	1	4	AJ71E71	192.168.3.42	5006	UDP

Device	Ethernet setting No.															
	b15	b14	b13	b12	b11	b10	b9	b8	b7	b6	b5	b4	b3	b2	b1	b0
GS231	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1
GS232	32	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17
GS233	48	47	46	45	44	43	42	41	40	39	38	37	36	35	34	33
GS234	64	63	62	61	60	59	58	57	56	55	54	53	52	51	50	49
GS235	80	79	78	77	76	75	74	73	72	71	70	69	68	67	66	65
GS236	96	95	94	93	92	91	90	89	88	87	86	85	84	83	82	81
GS237	112	111	110	109	108	107	106	105	104	103	102	101	100	99	98	97
GS238	128	127	126	125	124	123	122	121	120	119	118	117	116	115	114	113

The following shows the Ethernet setting numbers for each device in the Ethernet multiple connection.

Device				Ethernet setting No.															
Ch1	Ch2	Ch3	Ch4	b15	b14	b13	b12	b11	b10	b9	b8	b7	b6	b5	b4	b3	b2	b1	b0
GS281	GS301	GS321	GS341	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1
GS282	GS302	GS322	GS342	32	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17
GS283	GS303	GS323	GS343	48	47	46	45	44	43	42	41	40	39	38	37	36	35	34	33
GS284	GS304	GS324	GS344	64	63	62	61	60	59	58	57	56	55	54	53	52	51	50	49
GS285	GS305	GS325	GS345	80	79	78	77	76	75	74	73	72	71	70	69	68	67	66	65
GS286	GS306	GS326	GS346	96	95	94	93	92	91	90	89	88	87	86	85	84	83	82	81
GS287	GS307	GS327	GS347	112	111	110	109	108	107	106	105	104	103	102	101	100	99	98	97
GS288	GS308	GS328	GS348	128	127	126	125	124	123	122	121	120	119	118	117	116	115	114	113

■CC-Link IE TSN connection

Device	Station number															
	b15	b14	b13	b12	b11	b10	b9	b8	b7	b6	b5	b4	b3	b2	b1	b0
GS1281	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
GS1282	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
GS1283	47	46	45	44	43	42	41	40	39	38	37	36	35	34	33	32
GS1284	63	62	61	60	59	58	57	56	55	54	53	52	51	50	49	48
GS1285	79	78	77	76	75	74	73	72	71	70	69	68	67	66	65	64
GS1286	95	94	93	92	91	90	89	88	87	86	85	84	83	82	81	80
GS1287	111	110	109	108	107	106	105	104	103	102	101	100	99	98	97	96
GS1288	-	-	-	-	-	-	-	120	119	118	117	116	115	114	113	112

■Connection with the temperature controller (AZBIL temperature controller (DMC50))

Device				Station number-Sub Station															
Ch1	Ch2	Ch3	Ch4	b15	b14	b13	b12	b11	b10	b9	b8	b7	b6	b5	b4	b3	b2	b1	b0
GS281	GS301	GS321	GS341	1-15	1-14	1-13	1-12	1-11	1-10	1-9	1-8	1-7	1-6	1-5	1-4	1-3	1-2	1-1	1-0
GS282	GS302	GS322	GS342	2-15	2-14	2-13	2-12	2-11	2-10	2-9	2-8	2-7	2-6	2-5	2-4	2-3	2-2	2-1	2-0
GS283	GS303	GS323	GS343	3-15	3-14	3-13	3-12	3-11	3-10	3-9	3-8	3-7	3-6	3-5	3-4	3-3	3-2	3-1	3-0
GS284	GS304	GS324	GS344	4-15	4-14	4-13	4-12	4-11	4-10	4-9	4-8	4-7	4-6	4-5	4-4	4-3	4-2	4-1	4-0
GS285	GS305	GS325	GS345	5-15	5-14	5-13	5-12	5-11	5-10	5-9	5-8	5-7	5-6	5-5	5-4	5-3	5-2	5-1	5-0
GS286	GS306	GS326	GS346	6-15	6-14	6-13	6-12	6-11	6-10	6-9	6-8	6-7	6-6	6-5	6-4	6-3	6-2	6-1	6-0
GS287	GS307	GS327	GS347	7-15	7-14	7-13	7-12	7-11	7-10	7-9	7-8	7-7	7-6	7-5	7-4	7-3	7-2	7-1	7-0
GS288	GS308	GS328	GS348	8-15	8-14	8-13	8-12	8-11	8-10	8-9	8-8	8-7	8-6	8-5	8-4	8-3	8-2	8-1	8-0

■Connection types other than the above

The supported device differs depending on the communication driver to be used.

- Communication drivers supported by the host station only

Communication driver list		
Bus Q	Bus A/QnA	Serial(MELSEC)
AJ71QC24, MELDAS C6*	AJ71C24/UC24	CC-Link(G4)
MELSEC-FX	MELSEC-WS	OMRON SYSMAC
YASKAWA GL	YASKAWA CP9200 (H)	YASKAWA CP9300MS (MC compatible)
YASKAWA MP2000/MP900/CP9200SH	AB Control/CompactLogix	SHARP JW
TOSHIBA PROSEC T/V	HITACHI HIDIC H	HITACHI HIDIC H (Protocol2)
PANASONIC MEWNET-FP	PANASONIC MEWTOCOL-7	SIEMENS S7-200
YOKOGAWA FA500/FA-M3/STARDOM	Serial(KEYENCE)	HITACHI S10mini/S10V
FUJI MICREX-SX SPH	TOSHIBA MACHINE TCmini	SICK Flexi Soft
IAI X-SEL	PROFIBUS DP	DeviceNet

The host station uses the 0th bit at the top.

Ch1: GS281.b0

Ch2: GS301.b0

Ch3: GS321.b0

Ch4: GS341.b0

- Communication drivers supported by the other stations

Communication driver list		
CC-Link IE Controller Network	CC-Link IE Field Network	MEI Nexgenie
AB SLC500 AB 1:N connection	AB MicroLogix	AB MicroLogix(Extended)
AB DH485	SIEMENS S7-300/400	JTEKT TOYOPUC-PC
FUJI MICREX-F	GE(SNP-X)	KOYO KOSTAC/DL
LS Industrial Systems MASTER-K	Hirata HNC	IAI robocylinder
Panasonic MINAS A4	Panasonic MINAS A5	Muratec MPC
MELSERVO-J4,J3,J2S/M,JE	FREQROL 500/700/800,SENSORLESS SERVO	FREQROL 800
FREQROL(Batch monitor)	OMRON THERMAC/INPANEL NEO	OMRON Digital Temperature Controller
AZBIL SDC/DMC	AZBIL DMC50	RKC SR Mini HG (MODBUS)
FUJI Temperature Controller/Digital Controller	YOKOGAWA GREEN/UT100/UT2000/UTAdvanced	SHINKO TECHNOS CONTROLLER
CHINO Controllers (MODBUS)	MODBUS/RTU Master	

The following shows the supported devices.

Device				Station number															
Ch1	Ch2	Ch3	Ch4	b15	b14	b13	b12	b11	b10	b9	b8	b7	b6	b5	b4	b3	b2	b1	b0
GS281	GS301	GS321	GS341	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0 ^{*1}
GS282	GS302	GS322	GS342	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
GS283	GS303	GS323	GS343	47	46	45	44	43	42	41	40	39	38	37	36	35	34	33	32
GS284	GS304	GS324	GS344	63	62	61	60	59	58	57	56	55	54	53	52	51	50	49	48
GS285	GS305	GS325	GS345	79	78	77	76	75	74	73	72	71	70	69	68	67	66	65	64
GS286	GS306	GS326	GS346	95	94	93	92	91	90	89	88	87	86	85	84	83	82	81	80
GS287	GS307	GS327	GS347	111	110	109	108	107	106	105	104	103	102	101	100	99	98	97	96
GS288	GS308	GS328	GS348	127 ^{*1*2}	126 ^{*1*2}	125 ^{*1*2}	124 ^{*1*2}	123 ^{*1*2}	122 ^{*1*2}	121 ^{*1*2}	120	119	118	117	116	115	114	113	112

*1 When CC-Link IE controller network connection is not used.

*2 When CC-Link IE field network connection is not used.

For details on the GS Device, refer to the following manual.

📖 GT Designer3 (GOT2000) Screen Design Manual

Network No., station No. notification

The network No. and station No. of the GOT in Ethernet connection are stored at GOT startup.

If connected by other than Ethernet, 0 is stored.

Device				Description
CH1	CH2	CH3	CH4	
GS376	GS378	GS380	GS382	Network No. (1 to 239)
GS377	GS379	GS381	GS383	Station No. (1 to 64)

When using the station monitoring function in the CC-Link IE Field Network connection

When a submaster station is on the network, use the CC-Link IE Field Network communication unit (GT15-J71GF13-T2) with the software version C or later.

The software version is the 10th digit of the serial number described on the rating plate of the unit.

PART 2

CONNECTIONS TO NON-MITSUBISHI ELECTRIC PRODUCTS

2 CONNECTION TO IAI ROBOT CONTROLLER

3 CONNECTION TO AZBIL CONTROL EQUIPMENT

4 CONNECTION TO OMRON PLC

5 CONNECTION TO OMRON TEMPERATURE CONTROLLER

6 CONNECTION TO KEYENCE PLC

7 CONNECTION TO KOYO EI PLC

8 CONNECTION TO JTEKT PLC

9 CONNECTION TO SHARP PLC

10 CONNECTION TO SHINKO TECHNOS INDICATING CONTROLLER

11 CONNECTION TO CHINO CONTROLLER

12 CONNECTION TO TOSHIBA PLC

13 CONNECTION TO TOSHIBA MACHINE PLC

14 CONNECTION TO PANASONIC SERVO AMPLIFIER



15 CONNECTION TO PANASONIC INDUSTRIAL DEVICES SUNX PLC

2 CONNECTION TO IAI ROBOT CONTROLLER

- Page 80 Connectable Model List
- Page 82 System Configuration
- Page 97 Connection Diagram
- Page 106 GOT Side Settings
- Page 108 Robot Controller Side Setting
- Page 113 Device Range that Can Be Set
- Page 131 Precautions

2.1 Connectable Model List

The following table shows the connectable models.


Series	Model name	Clock	Communication Type	Connectable GOT	Refer to
X-SEL	XSEL-J	x	RS-232	<div>GT 27</div> <div>GT 25</div> <div>GT 23</div> <div>GT 21</div> <div>GS</div>	 Page 82 System Configuration for connecting to X-SEL, SSEL, ASEL, PSEL
	XSEL-K				
	XSEL-KE				
	XSEL-KT				
	XSEL-KET				
	XSEL-P				
	XSEL-Q				
	XSEL-JX				
	XSEL-KX				
	XSEL-KTX				
	XSEL-PX				
	XSEL-QX				
SSEL	SSEL				
ASEL	ASEL				
PSEL	PSEL				
PCON	PCON-C	x	RS-232 RS-422	<div>GT 27</div> <div>GT 25</div> <div>GT 23</div> <div>GT 21</div> <div>GS</div>	 Page 84 System Configuration for connecting to PCON, ACON, SCON, ERC2
	PCON-CG				
	PCON-CF				
	PCON-CY				
	PCON-SE				
	PCON-PL				
	PCON-PO				
	PCON-CA				
	PCON-CFA				
	PCON-CB				
	PCON-CFB				
ACON	ACON-C				
	ACON-CG				
	ACON-CY				
	ACON-SE				
	ACON-PL				
	ACON-PO				
	ACON-CB				
SCON	SCON-C				
	SCON-CA				
	SCON-CB				
ERC2	ERC2				

Series	Model name	Clock	Communication Type	Connectable GOT	Refer to
EC	EC-S3	×	RS-232 RS-422	<div>GT 27</div> <div>GT 25</div> <div>GT 23</div> <div>GT 21</div> <div>GS</div>	*1
	EC-S4				
	EC-S6				
	EC-S7				
	EC-S6□R				
	EC-S7□R				
	EC-S6□AH				
	EC-S7□AH				
	EC-S6□AHR				
	EC-S7□AHR				
	EC-R6				
	EC-R7				
	EC-RP4				
	EC-GS4				
	EC-GD4				
	EC-RR3				
	EC-RR4				
	EC-RR6				
	EC-RR7				
	EC-RR6□R				
	EC-RR7□R				
	EC-RR6□AH				
	EC-RR7□AH				
	EC-RR6□AHR				
	EC-RR7□AHR				
	EC-TC4				
	EC-TW4				
	EC-R6□W				
	EC-R7□W				












*1 Sample screen data are required for connection with EC series.
To obtain sample screen data, contact your local sales office.

2.2 System Configuration

System Configuration for connecting to X-SEL, SSEL, ASEL, PSEL



PLC			Connection cable	Max. distance	GOT		Number of connectable equipment
Model name	RS-232C adapter	Communication Type	Cable model Connection diagram number		Option device ^{*3}	Model	
X-SEL (Teaching connector)	-	RS-232	CB-ST-E1MW050 ^{*1} or (User preparing) Page 97 RS-232 connection diagram 1)	10m	- (Built into GOT)	<div>GT 27</div> <div>GT 25</div> <div>GT 23</div> <div>GT 21</div> <div>GT 21</div> <div>GS</div>	1 GOT for 1 Controller
					GT15-RS2-9P	<div>GT 27</div> <div>GT 25</div>	
					GT10-C02H-6PT9P ^{*2}	<div>GT 21</div> <div>GT 21</div> <div>GT 21</div> <div>GT 21</div> <div>GT 21</div> <div>GT 21</div>	
			CB-ST-E1MW050 ^{*1} + (User preparing) Page 98 RS-232 connection diagram 4) or (User preparing) Page 98 RS-232 connection diagram 5)	10m	- (Built into GOT)	<div>GT 21</div> <div>GT 21</div> <div>GT 21</div> <div>GT 21</div> <div>GT 21</div> <div>GT 21</div>	
X-SEL (General RS232C port connector)	-	RS-232	(User preparing) Page 97 RS-232 connection diagram 2)	10m	- (Built into GOT)	<div>GT 27</div> <div>GT 25</div> <div>GT 23</div> <div>GT 21</div> <div>GT 21</div> <div>GS</div>	
					GT15-RS2-9P	<div>GT 27</div> <div>GT 25</div>	
					GT10-C02H-6PT9P ^{*2}	<div>GT 21</div> <div>GT 21</div> <div>GT 21</div> <div>GT 21</div> <div>GT 21</div> <div>GT 21</div>	
			(User preparing) Page 98 RS-232 connection diagram 6)	10m	- (Built into GOT)	<div>GT 21</div> <div>GT 21</div> <div>GT 21</div> <div>GT 21</div> <div>GT 21</div> <div>GT 21</div>	

PLC			Connection cable	Max. distance	GOT		Number of connectable equipment
Model name	RS-232C adapter	Communication Type	Cable model Connection diagram number		Option device ^{*3}	Model	
SSEL ASEL PSEL	CB-SEL-SJ002 ^{*1}	RS-232	CB-ST-E1MW050 ^{*1}	10m	- (Built into GOT)	   	1 GOT for 1 Controller
					GT15-RS2-9P		
					GT10-C02H-6PT9P ^{*2}	 	
			CB-ST-E1MW050 ^{*1} +  Page 98 RS-232 connection diagram 4) or  Page 98 RS-232 connection diagram 5)	10m	- (Built into GOT)	 	


*1 Product manufactured by IAI Corporation. For details of the product, contact IAI Corporation.

*2 When a GT10-C02H-6PT9P unit of the sub version A or B is used, do not ground the case of the D-sub (9-pin) connector.

*3 GT25-W, GT2505-V does not support the option device.

- *1 Product manufactured by IAI Corporation. For details of the product, contact IAI Corporation.
- *2 Use ERC2-□-□-□-□-SE-□-□.
- *3 Use the following models.
ERC2-□-□-□-□-NP-□-□, ERC2-□-□-□-□-PN-□-□
- *4 When a GT10-C02H-6PT9P unit of the sub version A or B is used, do not ground the case of the D-sub (9-pin) connector.
- *5 GT25-W, GT2505-V does not support the option device.

- ERC2 (NP/PN specifications) only



Controller	Connection cable 1)*1	Terminal block	Connection cable 2)	Max. distance	SIO converter*1		Connection cable 3)		GOT		Number of connectable equipment
Model name	Cable model		Connection diagram number		Model name	Communication Type	Cable model Connection diagram number	Max. distance	Option device*4	Model I	
ERC2 (NP/PN specifications)*2	CB-ERC-PWBIO □□□ or CB-ERC-PWBIO□□□-RB	Terminal block (User preparing)	(User preparing) Page 102 RS-422/485 connection diagram 7) or (User preparing) Page 102 RS-422/485 connection diagram 8)	100m	RCB-TU-SIO-□	RS-232	RCB-CV-MW*1(0.3m) + CB-RCA-SIO050*1(5m) or (User preparing) Page 97 RS-232 connection diagram 3)	15m	- (Built into GOT)	<div><div>GT 27</div><div>GT 25</div><div>GT 23</div><div>GT 21</div><div>GT 050</div><div>GS</div></div>	1 GOT for 16 Controller
			RC □ -TU-PIO*1						(User preparing) Page 102 RS-422/485 connection diagram 9)	GT15-RS2-9P	
										GT10-C02H-6PT9P*3	
									(User preparing) Page 99 RS-232 connection diagram 8)		

*1 Product manufactured by IAI Corporation. For details of the product, contact IAI Corporation.

*2 Use the following models.


ERC2-□-□-□-□-NP-□-□, ERC2-□-□-□-□-PN-□-□











































*3 When a GT10-C02H-6PT9P unit of the sub version A or B is used, do not ground the case of the D-sub (9-pin) connector.





























*4 GT25-W, GT2505-V does not support the option device.

2

- Communication driver
- IAI ROBO CYLINDER



Controller	Terminal cable	Connection cable 1)* ¹	Junction box 4D)* ²	Connection cable 2)	GOT		Max. distance	Number of connectable equipment
Model name	Connection diagram number	Cable model	Model name	Connection diagram number	Option device)* ^{6*7}	Model		
PCON ACON SCON ERC2 (NP/PN specifications)* ⁵	 Page 100 RS-422/485 connection diagram 1)	CB-RCB-CTL002 (0.2m)	5-1473574-4	 Page 100 RS-422/485 connection diagram 3)	FA-LTBGT2R4CBL05(0.5m)* ³ FA-LTBGT2R4CBL10(1m)* ³ FA-LTBGT2R4CBL20(2m)* ³	  		
				 Page 101 RS-422/485 connection diagram 4)	- (Built into GOT)	     		
					GT15-RS4-9S	 		
					GT10-C02H-9SC	                            		

Controller	Terminal cable	Connection cable 1)* ¹	Junction box 4D)* ²	Connection cable 2)	GOT		Max. distance	Number of connectable equipment
Model name	Connection diagram number	Cable model	Model name	Connection diagram number	Option device)* ^{6*7}	Model		
ERC2 (SIO specifications)* ⁴	 Page 100 RS-422/485 connection diagram 1)	CB-ERC2-CTL001 + CB-ERC2-PWBIO □□□ or CB-ERC2-PWBIO □□□-RB	5-1473574-4	 Page 100 RS-422/485 connection diagram 3)	FA-LTBGT2R4CBL05(0.5m)* ³ FA-LTBGT2R4CBL10(1m)* ³ FA-LTBGT2R4CBL20(2m)* ³	  	100m	16 Controllers for 1 GOT
				 Page 101 RS-422/485 connection diagram 4)	- (Built into GOT)	     		
					GT15-RS4-9S	 		
					GT10-C02H-9SC	   		
				 Page 101 RS-422/485 connection diagram 5)	GT15-RS4-TE	 		
				 Page 104 RS-422/485 connection diagram 14)	- (Built into GOT)	     		

*1 Product manufactured by IAI Corporation. For details of the product, contact IAI Corporation.

*2 Product manufactured by Tyco Electronics. For details of the product, contact Tyco Electronics.

*3 Product manufactured by MITSUBISHI ELECTRIC ENGINEERING COMPANY LIMITED. For details of the product, contact MITSUBISHI ELECTRIC ENGINEERING COMPANY LIMITED.

*4 Use ERC2-□-□-□-□-SE-□-□.


*5 Use the following models.











ERC2-□-□-□-□-NP-□-□, ERC2-□-□-□-□-PN-□-□

*6 GT25-W is not compatible to the option devices other than FA-LTBGT2R4CBL□□.

*7 GT2505-V does not support the option device.

- 2



Controller	Connection cable 1)*1	Terminal block	Connection cable 2)	GOT		Max. distance	Number of connectable equipment
Model name	Cable model		Connection diagram number	Option device*4*5	Model		
ERC2 (NP/PN specifications)*3	CB-ERC-PWBIO □□□ or CB-ERC-PWBIO □□□-RB	Terminal block (User preparing)	 Page 103 RS-422/485 connection diagram 10)	FA-LTBGT2R4CBL05(0.5m)*2 FA-LTBGT2R4CBL10(1m)*2 FA-LTBGT2R4CBL20(2m)*2		100m	16 Controllers for 1 GOT
			 Page 103 RS-422/485 connection diagram 11)	- (Built into GOT)			
				GT15-RS4-9S			
				GT10-C02H-9SC			
			 Page 104 RS-422/485 connection diagram 12)	GT15-RS4-TE			
			 Page 105 RS-422/485 connection diagram 15)	- (Built into GOT)			

*1 Product manufactured by IAI Corporation. For details of the product, contact IAI Corporation.

*2 Product manufactured by MITSUBISHI ELECTRIC ENGINEERING COMPANY LIMITED. For details of the product, contact MITSUBISHI ELECTRIC ENGINEERING COMPANY LIMITED.

*3 Use the following models.


ERC2-□-□-□-□-□-NP-□-□, ERC2-□-□-□-□-□-PN-□-□

*4 GT25-W is not compatible to the option devices other than FA-LTBGT2R4CBL□□.

*5 GT2505-V does not support the option device.

When connecting to multiple controllers

■PCON, ACON, SCON, ERC2 (SIO specifications), ERC2 (NP/PN specifications)



Controller	Terminal cable	Connection cable 1)*1	Junction box 4D*2	Connection cable 2)	Connection cable 3)	GOT		Max. distance	Number of connectable equipment
Model name	Connection diagram number	Cable model	Model name	Connection diagram number	Connection diagram number	Option device*6*7	Model		
PCON ACON SCON ERC2 (NP/PN specifications)*5	(User preparing) Page 100 RS-422/485 connection diagram 1)	CB-RCB-CTL002 (0.2m)	5-1473574-4	(User preparing) Page 100 RS-422/485 connection diagram 2)	(User preparing) Page 100 RS-422/485 connection diagram 3)	FA-LTBGT2R4CBL05(0.5m)*3 FA-LTBGT2R4CBL10(1m)*3 FA-LTBGT2R4CBL20(2m)*3	GT 27 GT 23 GT 25	100m	16 Controllers for 1 GOT
					(User preparing) Page 101 RS-422/485 connection diagram 4)	- (Built into GOT)	GT 27 GT 23 GT 21 GT 25 GT 21		
						GT15-RS4-9S	GT 27 GT 25		
						GT10-C02H-9SC	GT 21 GT 25 GT 21 GT 25		
					(User preparing) Page 101 RS-422/485 connection diagram 5)	GT15-RS4-TE	GT 27 GT 25		
				(User preparing) Page 104 RS-422/485 connection diagram 14)		- (Built into GOT)	GT 21 GT 25 GT 21 GT 25		

Controller	Terminal cable	Connecti on cable 1)* ¹	Junction box 4D* ²	Connecti on cable 2)	Connecti on cable 3)	GOT		Max. dista nce	Number of connectable equipment
Model name	Connecti on diagram number	Cable model	Model name	Connecti on diagram number	Connecti on diagram number	Option device* ^{6*7}	Model		
ERC2 (SIO specifications)* ⁴	(User's manual) Page 100 RS-422/485 connection diagram 1)	CB-ERC2-CTL001 + CB-ERC2-PWBIO □□□ or CB-ERC2-PWBIO □□□ -RB	5-1473574-4	(User's manual) Page 100 RS-422/485 connection diagram 2)	(User's manual) Page 100 RS-422/485 connection diagram 3)	FA-LTBGT2R4CBL05(0.5m)* ³ FA-LTBGT2R4CBL10(1m)* ³ FA-LTBGT2R4CBL20(2m)* ³	GT 27 25 GT 23	100m	16 Controllers for 1 GOT
					(User's manual) Page 101 RS-422/485 connection diagram 4)	- (Built into GOT)	GT 27 25 GT 23 GT 21		
						GT15-RS4-9S	GT 27 25		
						GT10-C02H-9SC	GT 21 25 GT 21 25		
					(User's manual) Page 101 RS-422/485 connection diagram 5)	GT15-RS4-TE	GT 27 25		
					(User's manual) Page 104 RS-422/485 connection diagram 14)	- (Built into GOT)	GT 21 25 GT 21 25 GT 21 25		

*1 Product manufactured by IAI Corporation. For details of the product, contact IAI Corporation.

*2 Product manufactured by Tyco Electronics. For details of the product, contact Tyco Electronics.

*3 Product manufactured by MITSUBISHI ELECTRIC ENGINEERING COMPANY LIMITED. For details of the product, contact MITSUBISHI ELECTRIC ENGINEERING COMPANY LIMITED.

*4 Use ERC2-□-□-□-□-SE-□-□.


*5 Use the following models.

ERC2-□-□-□-□-NP-□-□, ERC2-□-□-□-□-PN-□-□

*6 GT25-W is not compatible to the option devices other than FA-LTBGT2R4CBL.

*7 GT2505-V does not support the option device.

■ERC2 (NP/PN specifications) only



Controller	Connection cable 1)*1	Terminal block	Connection cable 2)	GOT	Max. distance	Number of connectable equipment
Model name	Cable model		Connection diagram number	Option device*4*5	Model	
ERC2 (NP/PN specifications)*3	CB-ERC-PWBIO □□□ or CB-ERC-PWBIO □□□-RB	Terminal block (User preparing)	(User preparing) Page 103 RS-422/ 485 connection diagram 10)	FA-LTBGT2R4CBL05 (0.5m)*2 FA-LTBGT2R4CBL10 (1m)*2 FA-LTBGT2R4CBL20 (2m)*2	GT 27 GT 25 GT 23	100m 16 Controllers for 1 GOT
			(User preparing) Page 103 RS-422/ 485 connection diagram 11)	- (Built into GOT)	GT 27 GT 25 GT 23 GT 21 GT 2505	
				GT15-RS4-9S	GT 27 GT 25	
				GT10-C02H-9SC	GT 27 GT 25 GT 24 GT 25 GT 24 GT 25	
			(User preparing) Page 104 RS-422/ 485 connection diagram 12)	GT15-RS4-TE	GT 27 GT 25	
			(User preparing) Page 105 RS-422/ 485 connection diagram 15)	- (Built into GOT)	GT 27 GT 25 GT 24 GT 25 GT 24 GT 25	

*1 Product manufactured by IAI Corporation. For details of the product, contact IAI Corporation.

*2 Product manufactured by MITSUBISHI ELECTRIC ENGINEERING COMPANY LIMITED. For details of the product, contact MITSUBISHI ELECTRIC ENGINEERING COMPANY LIMITED.

*3 Use the following models.


ERC2-□-□-□-□-NP-□-□, ERC2-□-□-□-□-PN-□-□

*4 GT25-W is not compatible to the option devices other than FA-LTBGT2R4CBL□□.

*5 GT2505-V does not support the option device.

When connecting to multiple controllers (via SIO converter)

■PCON, ACON, SCON, ERC2 (SIO specifications), ERC2 (NP/PN specifications)



Cont roller	Termi nal cable	Conn ection cable 1) ^{*1}	Juncti on box 4D ^{*2}	Connec tion cable 2)	Connec tion cable 3)	Max. dist anc e	SIO converter ^{*1}		Connection cable 4)		GOT		Number of connectable equipment
	Connec tion diagram number	Cable model	Model name	Connec tion diagram number	Connec tion diagram number		Mod el nam e	Com munic ation Type	Cable model Connec tion diagram number	Max. dist anc e	Option device ^{*7}	Model	
PCON ACON SCON	(User preparing) Page 100 RS- 422/485 connection diagram 1)	CB- RCB- CTL00 2 (0.2m)	5- 147357 4-4	(User preparing) Page 100 RS- 422/485 connection diagram 2)	(User preparing) Page 100 RS- 422/485 connection diagram 2) or (User preparing) Page 101 RS- 422/485 connection diagram 6)	100m	RCB- TU- SIO-□	RS-232	RCB-CV- MW ^{*1} (0.3m) + CB-RCA- SIO050 ^{*1} (5m) or (User preparing) Page 97 RS-232 connection diagram 3) (User preparing) Page 99 RS-232 connection diagram 8)	15m	- (Built into GOT) GT15- RS2-9P GT10- C02H- 6PT9P ^{*6} - (Built into GOT)	<div>GT27</div> <div>GT23</div> <div>GT21^{50A}</div> <div>GT25</div> <div>GT21^{50W}</div> <div>GS</div> <div>GT27</div> <div>GT25</div> <div>GT21^{03P}</div> <div>GT21^{04P}</div> <div>GT21^{03P}</div> <div>GT21^{04P}</div> <div>GT21^{04R}</div> <div>GT21^{03P}</div> <div>GT21^{04P}</div> <div>GT21^{03P}</div> <div>GT21^{04P}</div>	16 Controllers for 1 GOT

Controller	Terminal cable	Connection cable 1)* ¹	Junction box 4D* ²	Connection cable 2)	Connection cable 3)	Max. distance	SIO converter* ¹		Connection cable 4)		GOT		Number of connectable equipment
Model name	Connection diagram number	Cable model	Model name	Connection diagram number	Connection diagram number		Model name	Communication Type	Cable model Connection diagram number	Max. distance	Option device * ⁷	Model	
ERC2 (NP/PN specifications)* ⁵	(User preparing) Page 100 RS-422/485 connection diagram 1)	CB-ERC-PWBIO □□□□ or CB-ERC-PWBIO □□□□-RB + Terminal block (User preparing) + (User preparing) Page 104 RS-422/485 connection diagram 13)	5-147357 4-4	(User preparing) Page 100 RS-422/485 connection diagram 2)	(User preparing) Page 100 RS-422/485 connection diagram 2) or (User preparing) Page 101 RS-422/485 connection diagram 6)	100m	RCB-TU-SIO-□	RS-232	RCB-CV-MW* ¹ (0.3m) + CB-RCA-SIO050* ¹ (5m) or (User preparing) Page 97 RS-232 connection diagram 3)	15m	- (Built into GOT) GT27 23 21 25 21 GS GT15-RS2-9P GT10-C02H-6PT9P* ⁶ - (Built into GOT) GT21 21 25 21 25 21 25 21		16 Controllers for 1 GOT

*¹ Product manufactured by IAI Corporation. For details of the product, contact IAI Corporation.

*² Product manufactured by Tyco Electronics. For details of the product, contact Tyco Electronics.

*³ When not using junction box 4D, connection cable 2) or connection cable 3), connect the controller to the SIO converter directly by the cable CR-RCB-CTL002.

*⁴ Use ERC2-□-□-□-□-SE-□-□.


*⁵ Use the following models.

ERC2-□-□-□-□-NP-□-□, ERC2-□-□-□-□-PN-□-□

*⁶ When a GT10-C02H-6PT9P unit of the sub version A or B is used, do not ground the case of the D-sub (9-pin) connector.

*⁷ GT25-W, GT2505-V does not support the option device.

■ERC2 (NP/PN specifications) only



Controller	Connection cable 1)* ¹	Terminal block	Connection cable 2)	Max. distance	SIO converter)* ¹		Connection cable 4)		GOT		Number of connectable equipment				
Model name	Cable model		Connection diagram number		Model name	Connection diagram number	Cable model Connection diagram number	Max. distance	Option device)* ⁵	Model)* ³					
ERC2 (NP/PN specific ations)* ³	CB-ERC- PWBIO □□□ or CB-ERC- PWBIO □□□- RB	Terminal block (User preparing)	(User preparing) Page 104 RS-422/485 connection diagram 13)	100m	RCB-TU- SIO-□	RS-232	RCB-CV- MW)* ¹ (0.3m) + CB-RCA-SIO050)* ¹ (5m) or (User preparing) Page 97 RS-232 connection diagram 3)	15m	- (Built into GOT)		16 Controllers for 1 GOT				
			(User preparing) Page 102 RS-422/485 connection diagram 8)												
		RC □-TU- PIO)* ¹	(User preparing) Page 102 RS-422/485 connection diagram 9)						GT15- RS2-9P)* ²						
			(User preparing) Page 99 RS-232 connection diagram 8)						GT10- C02H- 6PT9P)* ⁴						
									- (Built into GOT)						

^{*1} Product manufactured by IAI Corporation. For details of the product, contact IAI Corporation.

^{*2} Connect it to the RS-232 interface (built into GOT). It cannot be mounted on GT1655 and GT155□.

^{*3} Use the following models.

ERC2-□-□-□-□-NP-□-□, ERC2-□-□-□-□-PN-□-□

^{*4} When a GT10-C02H-6PT9P unit of the sub version A or B is used, do not ground the case of the D-sub (9-pin) connector.

^{*5} GT25-W, GT2505-V does not support the option device.

2.3 Connection Diagram


The following diagram shows the connection between the GOT and the PLC.

RS-232 cable


2

Connection diagram


■RS-232 connection diagram 1)




■RS-232 connection diagram 2)




■RS-232 connection diagram 3)




■RS-232 connection diagram 4)




■RS-232 connection diagram 5)




■RS-232 connection diagram 6)



■RS-232 connection diagram 7)



■RS-232 connection diagram 8)



Precautions when preparing a cable

■Cable length

The length of the RS-232 cable must be 10cm or less.

■GOT side connector

For the GOT side connector, refer to the following.

☞ Page 58 GOT connector specifications

■IAI Robot Controller side connector


Use the connector compatible with the IAI Robot Controller.

For details, refer to the IAI Robot Controller user's manual.


RS-422/485 cable

Connection diagram


■RS-422/485 connection diagram 1)




■RS-422/485 connection diagram 2)




■RS-422/485 connection diagram 3)




■RS-422/485 connection diagram 4)



■RS-422/485 connection diagram 5)



■RS-422/485 connection diagram 6)




■RS-422/485 connection diagram 7)

Junction box 4D side

E-CON Connector (Plug)

Model name : □-1473562-4


Terminal block (User preparing)



■RS-422/485 connection diagram 8)

SIO converter side (TB1)

Link connection Terminal block



SIO converter side (TB2)


power supply or

Emergency stop Terminal block

■RS-422/485 connection diagram 9)

SIO converter side (TB1)

Link connection Terminal block




SIO converter side (TB2)

power supply or


Emergency stop Terminal block

*1 Turn the terminator switch of a terminal block which will be a terminal to "RTON".


■RS-422/485 connection diagram 10)




■RS-422/485 connection diagram 11)




■RS-422/485 connection diagram 12)




■RS-422/485 connection diagram 13)



■RS-422/485 connection diagram 14)



■RS-422/485 connection diagram 15)



Precautions when preparing a cable

■Cable length

The maximum length of the RS-422/485 cable must be 100m or less.

■GOT side connector

For the GOT side connector, refer to the following.

☞ Page 58 GOT connector specifications

■E-CON connector (plug) (Type name: □-1473562-4)

Product manufactured by Tyco Electronics. For details of the product, contact Tyco Electronics.

Connecting terminating resistors

■GOT side

When connecting a PLC to the GOT, a terminating resistor must be connected to the GOT.

- For GT27, GT25(Except GT2505-V), GT23

Set the terminating resistor setting switch of the GOT main unit to "Disable".

- For GT2505-V, GT21

Set the terminating resistor selector to "OPEN".


For the procedure to set the terminating resistor, refer to the following.

☞ Page 62 Terminating resistors of GOT

2.4 GOT Side Settings

Setting communication interface (Communication settings)

Set the channel of the equipment to be connected to the GOT.



1. Select [Common] → [Controller Setting] from the menu.
2. In the [Controller Setting] window, select the channel No. to be used from the list menu.
3. Set the following items.
 - [Manufacturer]: [IAI]
 - [Controller Type]

When connecting to X-SEL, SSEL, ASEL, or PSEL: [IAI X-SEL Controller]

When connecting to PCON, ACON, SCON, or ERC2: [IAI ROBO CYLINDER]

- [I/F]: Interface to be used
- [Detail Setting]: Configure the settings according to the usage environment.

☞ Page 107 Communication detail settings

4. When you have completed the settings, click the [OK] button.

Point

The settings of connecting equipment can be confirmed in [I/F Communication Setting].

For details, refer to the following.

☞ Page 47 I/F communication setting

Communication detail settings

Make the settings according to the usage environment.

Property	Value
Transmission Speed(BPS)	38400
Data Bit	8 bit
Stop Bit	1 bit
Parity	None
Retry(Times)	3
Timeout Time(Sec)	3
Host Address	0
Delay Time(ms)	0

Item	Description	Range
Transmission Speed	Set this item when change the transmission speed used for communication with the connected equipment. (Default: 38400bps)	9600bps, 19200bps, 38400bps, 57600bps, 115200bps
Data Bit	Set this item when change the data length used for communication with the connected equipment. (Default: 8bits)	7bit, 8bit
Stop Bit	Specify the stop bit length for communications. (Default: 1bits)	1bit, 2bit
Parity	Specify whether or not to perform a parity check, and how it is performed during communication. (Default: None)	None Even Odd
Retry	Set the number of retries to be performed when a communication error occurs. (Default: 3time)	0 to 5times
Timeout Time	Set the time period for a communication to time out. (Default: 3sec)	1 to 30sec
Host Address	Make the settings according to the station number (station code) of the controller to be monitored. (Default: 0)	<When connecting to X-SEL, SSEL, ASEL, PSEL> 0 to 255 <When connecting to PCON, ACON, SCON, ERC2> 0 to 15
Delay Time	Set this item to adjust the transmission timing of the communication request from the GOT. (Default: 0ms)	0 to 300 (ms)

Point

- Communication interface setting by the Utility

The communication interface setting can be changed on the Utility's [Communication Settings] after writing [Communication Settings] of project data.

For details on the Utility, refer to the following manual.

 GOT2000 Series User's Manual (Utility)

- Precedence in communication settings

When settings are made by GT Designer3 or the Utility, the latest setting is effective.

2.5 Robot Controller Side Setting



IAI Robot Controller

For details of IAI Robot Controller, refer to the following manuals.

☞ IAI Robot Controller user's Manual

Connecting to X-SEL

Parameter setting

Enter the following parameters using peripheral software. When setting parameters, set the mode switch of the controller to "MANU".

Parameter	Parameter Name	Set Value ^{*4}
I/O parameter 90	Usage of SIO channel 1 ^{*1} opened to user	<ul style="list-style-type: none">• When used in "MANU" Set either of the following. 0: SEL opened program• When used in "AUTO" 2: IAI protocol B
I/O parameter 91	Station code of SIO channel 1 ^{*1} opened to user	0 to 255 153*
I/O parameter 92 ^{*2}	Baud rate type of SIO channel 1 ^{*1} opened to user	0: 9600bps* 1: 19200bps 2: 38400bps 3: 57600bps 5: 115200bps
I/O parameter 93	Data length of SIO channel 1 ^{*1} opened to user	7bit, 8bit*
I/O parameter 94	Stop bit length of SIO channel 1 ^{*1} opened to user	1bit*, 2bit
I/O parameter 95	Parity type of SIO channel 1 ^{*1} opened to user	0: None* 1: Odd 2: Even
I/O parameter 97 ^{*3}	IAI-protocol minimum response delay for SIO channel 1 ^{*1} opened to user	0 to 999(ms)
Other parameter 46	Other setting bit pattern 1	bit0 to 3 = 1 (fixed)

*1 For X-SEL(P/Q/PX/QX), the parameter becomes the SIO channel 0 opened to user.

*2 Indicates only the transmission that can be specified on the GOT side.
Specify the transmission speed to match the baud rate of the GOT.

*3 Set it only when a wait time is required before the response and transmission to the GOT request. Normally, the communication is available using default values.

*4 When using the "MANU" mode, the set value is fixed to the value with *. Adjust the settings of the GOT side to the * settings.
However, the communication setting of the PC software becomes the setting of X-SEL after the PC software for X-SEL is connected. In this case, adjust the communication setting of the GOT to the setting of the PC software.

Mode switch


■X-SEL K type

- When setting the mode switch to "MANU"

Connect the GOT to the following teaching connector.

- When setting the mode switch to "AUTO"


Connect the GOT to the following general RS232C port connector.



*1 The teaching connector and general RS232C port connector cannot be used at the same time.

■Other than X-SEL K type

Set the mode switch to "MANU" or "AUTO" and connect the GOT to the following teaching connector.



Connecting to SSEL, ASEL, PSEL

Parameter setting

Enter the following parameters using peripheral software. When setting parameters, set the mode switch of the controller to "MANU".

Parameter	Parameter Name	Set Value
I/O parameter 90	Usage of SIO channel 0 opened to user	2: IAI protocol B (fixed)
I/O parameter 91	Station code of SIO channel 0 opened to user	0 to 255
I/O parameter 92 ^{*1}	Baud rate type of SIO channel 0 opened to user	0: 9600bps 1: 19200bps 2: 38400bps 3: 57600bps 5: 115200bps
I/O parameter 93	Data length of SIO channel 0 opened to user	7bit, 8bit
I/O parameter 94	Stop bit length of SIO channel 0 opened to user	1bit, 2bit
I/O parameter 95	Parity type of SIO channel 0 opened to user	0: None 1: Odd 2: Even
I/O parameter 97 ^{*2}	IAI-protocol minimum response delay for SIO channel 0 opened to user	0 to 999(ms)
Other parameter 46	Other setting bit pattern 1	bit0 to 3 = 1 (fixed)


*1 Indicates only the transmission that can be specified on the GOT side.

Specify the transmission speed to match the baud rate of the GOT.

*2 Set it only when a wait time is required before the response and transmission to the GOT request. Normally, the communication is available using default values.

Mode switch


Set the mode switch to "AUTO" and connect the GOT to the following teaching connector.



Connecting to PCON, ACON, SCON

Axis number setting, Mode select

For controllers without the following switches, set from the setting tool (PC software).



Switch	Setting details
Axis number setting rotary switch	0 to 15
Mode selector switch	<Only the monitor> AUTO <monitor, data change> MANU

Transmission speed setting

Set the transmission speed from the setting tool (PC software).

Item	Range
SIO transmission speed ^{*1}	9600/19200/38400/57600/115200bps Default: 38400bps

^{*1} Indicates only the transmission speeds that can be set on the GOT side.
Set the same transmission speed of the GOT.

Connecting to ERC2

Axis number setting, Mode select

Set from the setting tool (PC software).

Transmission speed setting

Set the transmission speed from the setting tool (PC software).


Item	Range
SIO transmission speed ^{*1}	9600/19200/38400/57600/115200bps Default: 38400bps

^{*1} Indicates only the transmission speeds that can be set on the GOT side.
Set the same transmission speed of the GOT.

Station No.settings

Set each station number so that no station number overlaps.

The station number can be set without regard to the cable connection order. There is no problem even if station numbers are not consecutive.



Direct specification

When setting the device, specify the station number of the controller of which data is to be changed.

Model name	Specification range	Refer to
PCON, ACON, SCON	0 to 15	Page 111 Connecting to PCON, ACON, SCON
ERC2	0 to 15	Page 111 Connecting to ERC2

Indirect specification

When setting the device, indirectly specify the station number of the controller of which data is to be changed using the 16-bit GOT internal data register (GD10 to GD25).

When specifying the station No. from 100 to 115 on GT

Designer3, the value of GD10 to GD25 compatible to the station No. specification will be the station No. of the controller.

Specification station No.	Compatible device	Setting range
100	GD10	0 to 15 (If setting a value out of the range above, a timeout error occurs.)
101	GD11	
102	GD12	
103	GD13	
104	GD14	
105	GD15	
106	GD16	
107	GD17	
108	GD18	
109	GD19	
110	GD20	
111	GD21	
112	GD22	
113	GD23	
114	GD24	
115	GD25	

2.6 Device Range that Can Be Set

The device ranges of controller that can be used for GOT are as follows.


Note that the device ranges in the following tables are the maximum values that can be set in GT Designer3.

The device specifications of controllers may differ depending on the models, even though belonging to the same series. Please make the setting according to the specifications of the controller actually used.

When a non-existent device or a device number outside the range is set, other objects with correct device settings may not be monitored.

IAI robot controller (IAI X-SELController)

Setting item



Item	Description
Device	Set the device name, device number, and bit number. The bit number can be set only when specifying the bit of word device.
	Device No. Set the number of the program for which the device is used.
	Information Displays the device type and setting range which are selected in [Device].
Switch to the device dfine dialog	Device definition can be checked.

Point

Memory area for writing position data

Position data can be written to RAM or E²PROM of the controller.

- When written to RAM

Remember that written position data are cleared when power supply to the controller is turned off.

- When written to E²PROM

Written position data are not cleared even when power supply to the controller is turned off. However, there are limits in the number of writing to E²PROM. If the data is frequently updated (more than once in an hour), write the parameters to the RAM. For details, refer to the manual of the controller used.

Device

Device name		Setting Range	Device No. representation
Bit device	Input Port (IP) ^{*1}	IP000 to IP299	Decimal
	Output Port (OP)	OP300 to OP599	
	Flag (FG)	FG000:600 to FG000:899 FG001:900 to FG001:999 : FG128:900 to FG128:999	
	Point Data Clear (PCLR) ^{*2*6}	PCLR0001 to PCLR4E20	Hexadecimal
Word device	Point Data Total Count (PDT) ^{*1}	PDT0	Decimal
	String (STR) ^{*3}	STR000:300 to STR000:998 STR001:001 to STR001:299 : STR128:001 to STR128:299	Hexadecimal
	Axis Status (AXST) ^{*1}	AXST00 to AXST2F	
	Scara Axis Status 0 (Base coordinate system) (SAXS0) ^{*1}	SAXS000 to SAXS0FF	
	Scara Axis Status 1 (Selected work coordinate system) (SAXS1) ^{*1}	SAXS100 to SAXS1FF	Hexadecimal
	Scara Axis Status 2 (Reserved for system use) (SAXS2) ^{*1}	SAXS200 to SAXS2FF	
	Scara Axis Status 3 (Each axis system) (SAXS3) ^{*1}	SAXS300 to SAXS3FF	
	Version 0 (Main CPU application/) (VR0) ^{*1}	VR00:0 to VR00:F : VR0F:0 to VR0F:F	Hexadecimal
	Version 1 (Main CPU core) (VR1) ^{*1}	VR10:0 to VR10:F : VR1F:0 to VR1F:F	
	Version 2 (Driver CPU) (VR2) ^{*1}	VR20:0 to VR20:F : VR2F:0 to VR2F:F	
	Version 3 (Mount SIO) (VR3) ^{*1}	VR30:0 to VR30:F : VR3F:0 to VR3F:F	Decimal
	Program Status (PGST) ^{*1}	PGST000 to PGST511	
	System Status (SYST) ^{*1}	SYST0 to SYST6	
	Program Control (PRG) ^{*2*4}	PRG000 to PRG128	Decimal
	Alarm Reset (AR) ^{*2}	AR0	


Device name		Setting Range	Device No. representation
Word device	Software Reset (SR) ^{*2,5}	SR0	Decimal
	Drive-Source Recovery (DSR) ^{*2}	DSR0	
	Origin return (RO) ^{*7}	RO0 to RO3	
	Point number specification movement (PNM) ^{*7}	PNM0 to PNM5	
	Operation stop/Cancel (OSC) ^{*7}	OSC0 to OSC2	
Double word device	Operation-Pause Reset (OPR) ^{*2}	OPR0	Hexadecimal
	Servo (SV) ^{*7}	SV0 to SV2	
	Write to Flash ROM (FRW) ^{*7}	FRW0 to FRW1	
	Coordinate Affiliate Data 0 (CD0) ^{*1}	CD000:0 to CD000:F : CD0FF:0 to CD0FF:F	
	Coordinate Affiliate Data 1 (CD1) ^{*1}	CD100:0 to CD100:F : CD1FF:0 to CD1FF:F	Decimal
	Integer (INT)	INT000:0200 to INT000:1299 INT001:0001 to INT001:1099 : INT128:0001 to INT128:1099	
	Real (RL)	RL000:0300 to INT000:1399 RL001:0100 to INT001:1199 : INT128:0100 to INT128:1199	
	Jog/inch movement (JIM) ^{*7}	JIM0 to JIM6	
	Error Detail 0 (System error) (ER0) ^{*1}	ER000:000:00 to ER0FF:000:FF : ER000:FFF:00 to ER0FF:FFF:FF	Hexadecimal
	Error Detail 1 (Axis-specific error) (ER1) ^{*1}	ER100:000:00 to ER1FF:000:FF : ER100:FFF:00 to ER1FF:FFF:FF	
	Error Detail 2 (Program-specific error:) (ER2) ^{*1}	ER200:000:00 to ER2FF:000:FF : ER200:FFF:00 to ER2FF:FFF:FF	
	Error Detail 3 (Error in error list record) (ER3) ^{*1}	ER300:000:00 to ER3FF:000:FF : ER300:FFF:00 to ER3FF:FFF:FF	
	Error Detail 4 (Reserved for system use) (ER4) ^{*1}	ER400:000:00 to ER4FF:000:FF : ER400:FFF:00 to ER4FF:FFF:FF	Hexadecimal
	Error Detail 5 (Reserved for system use) (ER5) ^{*1}	ER500:000:00 to ER5FF:000:FF : ER500:FFF:00 to ER5FF:FFF:FF	
	Error Detail 6 (Reserved for system use) (ER6) ^{*1}	ER600:000:00 to ER6FF:000:FF : ER600:FFF:00 to ER6FF:FFF:FF	
	Error Detail 7 (Reserved for system use) (ER7) ^{*1}	ER700:000:00 to ER7FF:000:FF : ER800:FFF:00 to ER8FF:FFF:FF	
	Point Data Total Count (PD) ^{*7}	PD00 to PD9E	
	Simple Interference Check Zone Data (SD) ^{*1}	SD01:0 to SD01:F : SDFF:0 to SDFF:F	

- *1 Write disabled
- *2 Read disabled
- *3 The following restrictions are applied depending on the program number.
 - When the program number is 000, the variable number can be only even numbers.
 - When the program number is 001 to 128, the variable number can be only odd numbers.
- *4 For the program control device, the command to be sent differs depending on the write data. Write data other than the followings are processed as an internal error of GOT.
 - Write data 0: Program Exit Command(0x254)
 - Write data 1: Program Execution Command(0x253)
 - Write data 2: Program Pause Command(0x255)
 - Write data 3: Program 1 Step Execution Command(0x256)
 - Write data 4: Program Restart Command(0x257)
- *5 When performing software reset, a no response error is displayed after a non-communicating period of ten and several seconds, and then the communication is resumed.
- *6 For the word address, the value is specified only when the last digit is 1.
- *7 For the device whose obtained data No.0 is a command trigger, a request is sent to the controller when the Write or Read is input to the command trigger. It is not sent when the Clear is input.


Point

Device representation


• Flag device



• String device



• Version device



• Axis Status device

AXST00

└─ Obtained data:
 AXST00 to AXST05: Single-axis status
 00: Axis status
 Bit 7 (Reserved for system use)
 Bit 6 (Reserved for system use)
 Bit 5 (Push error detection): 0 = Not detected / 1 = Detected
 Bit 4 (Operation command successful completion):
 0 = Not yet complete / 1 = Completed successfully
 * Can be used only for completion check after
 an operation command.
 Bit 3 (Servo): 0 = OFF / 1 = ON
 Bit 1-2 (Origin return): 0 = Not yet performed
 / 1 = Returning to origin / 2 = Completed
 Bit 0 (Servo axis in use): 0 = Not in use
 / 1 = In use (moving, etc.)
 * "Servo axis in use" indicates that a given task has
 the right to use the applicable axis.
 Therefore, this bit will turn ON in the following conditions:
 - When an operation command involving
 axis movement is in progress
 (including when an axis is moving)
 - Servo is starting up from an OFF state
 - Servo is shutting down from an ON state
 (excluding emergency stop)
 - Operation axis is paused
 01: Axis sensor input status
 Bit 3 (Reserved for system use)
 Bit 2 (Origin sensor): 0 = OFF / 1 = ON
 Bit 1 (Overrun sensor): 0 = OFF / 1 = ON
 Bit 0 (Creep sensor): 0 = OFF / 1 = ON
 02: Axis error code
 03: Encoder status
 Bit 7 (Battery alarm (BA))
 Bit 6 (Battery error (BE))
 Bit 5 (Multi-rotation error (ME))
 Bit 4 (Reserved for system use)
 Bit 3 (Counter overflow (OF))
 Bit 2 (Count error (CE))
 Bit 1 (Full absolute status (FS))
 Bit 0 (Overspeed (OS))
 04: Current position (L) unit (0.001mm)
 Indicates the lower 16 bits of the current position in Hex.
 05: Current position (H) unit (0.001mm)
 Indicates the upper 16 bits of the current position in Hex.
 AXST06 to AXST11: Double axes status
 AXST42 to AXST47: Eight axes status

- Scara Axis Status device

SAXS 0 00

Obtained data:

00: Work coordinate system selection number
 01: Tool coordinate system selection number
 02: Common axis status
 Bit 7 (Reserved for system use)
 Bit 6 (Reserved for system use)
 Bit 5 (Reserved for system use)
 Bit 4 (Reserved for system use)
 Bit 2-3 (Scara axis current position coordinate system type):
 0 = Base coordinate system
 / 1 = Selected work coordinate system
 / 2 = Reserved for system use / 3 = Each axis system
 Bit 0-1: (Scara axis current arm system):
 0 = Right arm system / 1 = Left arm system
 / 2 = Indeterminable / 3 = Reserved for system use
 03: Axis pattern

Bit	-	7	6	5	4	3	2	1	0
-----	---	---	---	---	---	---	---	---	---

1st axis
 8th axis
 Reserved for system use

04 to 09: Single-axis status
 04: Axis status
 Bit 7 (Reserved for system use)
 Bit 6 (Reserved for system use)
 Bit 5 (Push error detection): 0 = Not detected / 1 = Detected
 Bit 4 (Operation command successful completion):
 0 = Not yet complete / 1 = Completed successfully
 * Can be used only for completion check after an operation command.(For positioning that includes any of the X, Y and R axes, be sure to check completion for all of the X, Y and R axes.)
 Bit 3 (Servo): 0 = OFF / 1 = ON
 Bit 1-2 (Origin return): 0 = Not yet performed
 / 1 = Returning to origin / 2 = Completed
 Bit 0 (Servo axis in use): 0 = Not in use
 / 1 = In use (moving, etc.)
 * "Servo axis in use" indicates that a given task has the right to use the applicable axis. Therefore, this bit will turn ON in the following conditions:
 - When an operation command involving axis movement is in progress (including when an axis is moving)
 - Servo is starting up from an OFF state
 - Servo is shutting down from an ON state (excluding emergency stop)
 - Operation axis is paused
 05: Axis sensor input status
 Bit 3 (Reserved for system use)
 Bit 2 (Origin sensor): 0 = OFF / 1 = ON
 Bit 1 (Overrun sensor): 0 = OFF / 1 = ON
 Bit 0 (Creep sensor): 0 = OFF / 1 = ON
 06: Axis error code
 07: Encoder status
 Bit 7 (Battery alarm (BA))
 Bit 6 (Battery error (BE))
 Bit 5 (Multi-rotation error (ME))
 Bit 4 (Reserved for system use)
 Bit 3 (Counter overflow (OF))
 Bit 2 (Count error (CE))
 Bit 1 (Full absolute status (FS))
 Bit 0 (Overspeed (OS))
 08: Current position (L) unit (0.001mm or 0.001deg)
 Indicates the lower 16 bits of the current position in Hex.
 09: Current position (H) unit (0.001mm or 0.001deg)
 Indicates the upper 16 bits of the current position in Hex.
 0A to 0E: Double axes status
 . . .
 2E to 33: Eight axes status
 34 to FF: Reserved for system use

Unit type (0 to F)
 Bit 3 (Reserved for system use) Fixed to 0
 Bit 2 (Reserved for system use) Fixed to 0
 Bit 0-1 (Scara axis current position type):
 0 = Base coordinate system
 / 1 = Selected work coordinate system
 / 2 = Reserved for system use / 3 = Each axis system

• Program Status device

PGST 000

Obtained data:
 000 to 003: Program number 1 status
 000: Status
 Bit 3 (Reserved for system use)
 Bit 2 (Reserved for system use)
 Bit 1 (Reserved for system use)
 Bit 0 (Start): 0 = Not started / 1 = Started
 001: Execution program step number
 002: Program-dependent error code
 003: Error occurrence step number
 004 to 007: Program number 2 status
 . . .
 508 to 511: Program number 128 status

- System Status device

SYST 0


Obtained data:
 0: System mode
 0 = Indeterminable / 1 = AUTO mode / 2 = MANUAL mode
 / 3 = Slave update mode / 4 = Core update mode
 1: Critical level system error number
 2: Latest system error number
 3: System status byte 1
 Bit 7 (Reserved for system use)
 Bit 6 (Battery voltage error status): 0 = No error / 1 = Error
 Bit 5 (Battery voltage low warning status): 0 = No low / 1 = Low
 Bit 4 (Power error status): 0 = Normal / 1 = Error
 Bit 3 (Emergency stop switch status):
 0 = No emergency stop / 1 = Emergency stop
 Bit 2 (Safety gate status): 0 = CLOSE / 1 = OPEN
 * X-SEL (P/Q Series) (Multi axes/Scara)/SSEL/ASEL/PSEL: Enable switch
 (Deadman switch / Enable switch) status is indicated.
 Bit 1 (TP enable switch status): 0 = ON / 1 = OFF
 * X-SEL (P/Q Series) (Multi axes/Scara)/SSEL/ASEL/PSEL:
 This bit is disabled (fixed to 0).
 Bit 0 (Operation mode switch status): 0 = AUTO / 1 = MANUAL
 4: System status byte 2
 Bit 7 (Reserved for system use)
 Bit 6 (Reserved for system use)
 Bit 5 (Program run status): 0 = Not run / 1 = Running
 Bit 4 (Restart wait status): 0 = Not waiting / 1 = Waiting
 Bit 3 (I/O interlock status): 0 = No interlock / 1 = Interlock
 Bit 2 (Servo interlock status): 0 = No interlock / 1 = Interlock
 Bit 1 (Slave parameter writing status):
 0 = Not writing / 1 = Writing
 Bit 0 (Application data flash ROM write status):
 0 = Not writing/erasing / 1 = Writing/erasing
 * When the core program is in operation (Application update mode),
 only Bit 0 is enabled. Data for System mode, Critical level
 system error number, Latest system error number,
 System status byte 1, System status byte 3 and System
 status byte 4 is disabled.
 5: System status byte 3
 Bit 7 (Reserved for system use)
 Bit 6 (Reserved for system use)
 Bit 5 (Reserved for system use)
 Bit 4 (Operation mode):
 0 = Program mode / 1 = Position mode
 Bit 3 (Reserved for system use)
 Bit 2 (System ready status): 0 = Not ready / 1 = Ready
 Bit 1 (System operation status):
 0 = Not operating in AUTO mode
 / 1 = Operating in AUTO mode
 Bit 0 (Drive-source cutoff status): 0 = Not cut off / 1 = Cut off
 6: System status byte 4
 Reserved for system use

- Coordinate Affiliate Data device


CD 0 00 : 0

Obtained data:
 0: X axis coordinate offset
 1: Y axis coordinate offset
 2: Z axis coordinate offset
 3: R axis coordinate offset
 4 to F: Reserved for system use
 Coordinate system definition data number (00 to FF)
 Work/tool coordinate system definition data number (0 to)
 Type 1 (0 to 1)
 0 = Work coordinate system definition data
 / 1 = Tool coordinate system definition data


- Servo device




• Write to Flash ROM device




• Integer device




• Real device




• Error Detaildevice(Detail 0 to Detail 7)



• Point Data Total Count device



• Simple Interference Check Zone Data device



• Jog/inch movement device

JIM 0

Obtained data:


0: Command trigger
1=Write/4=Clear

1: Axis pattern

In the case of scara, scara axis single-axis specification only is possible. (Multi-axis specification is not possible.)

In the case of scara, jog/inch commands are possible only in an all scara servo axis non-operating state.

In the case of X-SEL-PX/QX/RX/SX, scara and direct acting axis simultaneous specification are prohibited.



2: Acceleration unit (0.01G (% for each axis))

When it is zero, the parameter value is enabled.

3: Deceleration unit (0.01G (% for each axis))

When it is zero, the parameter value is enabled.

4: Speed unit (mm/sec (% for each axis))

When it is zero, the parameter value is enabled. (The safety limit value is applied depending on the mode.)

5: Inch distance unit (0.001 mm (0.001 deg for each axis))

An absolute value is specified. When it is zero, no distance is specified (= Jog).

6: Operation type

Bit3 (Reserved for system use) Fixed to 0

Bit1-2 (Jog/inch movement coordinates system (dedicated to scara))

: 0 = Base coordinate system /1 = Selected work coordinate system /2 = Selected work coordinate system /3 = Each axis system

Bit0 (jog/inch direction): 0 = Coordinate - Direction/ 1 = Coordinate + Direction


• Point number specification movement device

PNM 0

Obtained data:

0: Command trigger
1=Write/4=Clear

1: Axis pattern



2: Acceleration Unit (0.01G)

When the acceleration set value is zero, the relevant set value on the position data is enabled.

When the acceleration set value and the relevant set value on the position data are both zero, the parameter value is followed.

3: Deceleration Unit (0.01G)

When the deceleration set value is zero, the relevant set value on the position data is enabled.

When the deceleration set value and the relevant set value on the position data are both zero, the parameter value is followed.

4: Speed Unit (mm/sec)

When the speed set value is zero, the relevant set value on the position data is enabled.

When the speed set value and the relevant set value on the position data are both zero, the parameter value is followed.

(The safety limit value is applied depending on the mode.)

5: Point number

• Origin return device


RO 0

Obtained data:

0: Command trigger
1=Write/4=Clear

1: Axis pattern

In the case of XSEL-JX/KX/KTX/PX/QX series, specify the direct acting axis only.



2: End search speed Unit (mm/sec)

When it is zero, the parameter value is enabled.

3: Creep speed Unit (mm/sec)

When it is zero, the parameter value is enabled.

• Operation stop/Cancel device

OSC 0


└ Obtained data:

0: Command trigger

1=Write/4=Clear

1: Stop axis pattern

* Including during-interlock-pending servo command cancelation



2: Additional command

Bit1 - 7 (Reserved for system use): Fixed to 0

Bit0 (During-interlock-pending output (out port) (during all operation pause) cancellation instruction)

: 0 = Non-cancellation / 1 = Temporary cancellation

3: Origin return creep speed (mm/sec)

IAI robot controller (IAI PCON, ACON, SCON, ERC2 controller)

Setting item

<Signed BIN16> CH1 IAI ROBO CYLINDER

Device

R

0000

789

DE

F

456

ABC

123

0

Back

CL

Information

[Kind]

WORD

[Range]

Device:

0000-FFFF

Network

Station No.:

0

Switch to the device define dialog

OK

Cancel

Item	Description	
Device	Set the device name, device number, and bit number. The bit number can be set only when specifying the bit of word device.	
Information	Displays the device type and setting range which are selected in [Device].	
Network	Station No.	Monitors the robo cylinder of the specified station No. 0 to 15: To monitor the robo cylinder of the specified station No. 100 to 115: To set the station No. of the robo cylinder to be monitored by the value of GOT data register (GD). ^{*1}
	Switch to the device define dialog	Device definition can be checked.

^{*1} The following shows the relation between station numbers of the robo cylinder and the GOT data register.

Station No.	GOT data register (GD)	Setting range
100	GD10	0 to 15 (If setting a value out of the range above, a timeout error occurs.)
101	GD11	
:	:	
114	GD24	
115	GD25	

Device

■Device name

Device name		Setting Range	Device No. representation
Bit device	Status (S)	S0000 to SFFFF	Hexadecimal
	The bit specification of the word device	Setting range of each word device	
Word / Double word device	Register (R)	R0000 to RFFFF	Hexadecimal

■Status (S) (Bit device)

The following shows device numbers which can be set for the status and the corresponding device contents.

Status	Area name	Description	Abbreviation
0000 to 00FF	- (Reserved for system)		
0100	Device status register 1 (DSS1)	EMG status	EMGS
0101		Safety speed enabled status	SFTY
0102		Controller ready status	PWR
0103		Servo ON status	SV
0104		Missed work part in push-motion operation	PSFL
0105		Major failure status	ALMH
0106		Minor failure status	ALML
0107		Absolute error status	ABER
0108		Brake forced-release status	BKRL
0109		Cannot be used	
010A		Pause status	STP
010B		Home return status	HEND
010C		Position complete status	PEND
010D		Load cell calibration complete	CEND
010E		Load cell calibration status	CLBS
010F		Cannot be used	
0110	Device status register 2 (DSS2)	Cannot be used	
0111		Cannot be used	
0112		Load output judgment status	LOAD
0113		Torque level status	TRQS
0114		Teaching mode status	MODS
0115		Position-data load command status	TEAC
0116		Jog+ status	JOG+
0117		Jog- status	JOG-
0118		Position complete 7	PE7
0119		Position complete 6	PE6
011A		Position complete 5	PE5
011B		Position complete 4	PE4
011C		Position complete 3	PE3
011D		Position complete 2	PE2
011E		Position complete 1	PE1
011F		Position complete 0	PE0
0120	Expansion device status register (DSSE)	Emergency stop status	EMGP
0121		Motor voltage low status	MPUV
0122		Operation mode status	RMDS
0123		Cannot be used	
0124		Home return status	GHMS
0125		Push-motion operation in progress	PUSH
0126		Excitation detection status	PSNS
0127		PIO/Modbus switching status	PMSS
0128		Cannot be used	
0129		Cannot be used	
012A		Moving signal	MOVE
012B to 012F		Cannot be used	

Status	Area name	Description	Abbreviation
0130 to 0135	Position number status register, Executed program number register (Servo Press) (POSS)	Cannot be used	
0136		Position complete number status bit 512	PM512
0137		Position complete number status bit 256	PM256
0138		Position complete number status bit 128	PM128
0139		Position complete number status bit 64	PM64
013A		Position complete number status bit 32/Executed program number status bit 32	PM32
013B		Position complete number status bit 16/Executed program number status bit 16	PM16
013C		Position complete number status bit 8/Executed program number status bit 8	PM8
013D		Position complete number status bit 4/Executed program number status bit 4	PM4
013E		Position complete number status bit 2/Executed program number status bit 2	PM2
013F		Position complete number status bit 1/Executed program number status bit 1	PM1
0140	Zone status register (ZONS)	Cannot be used	
0141		Limit sensor output monitor 2	LS2
0142		Limit sensor output monitor 1	LS1
0143		Limit sensor output monitor 0	LS0
0144 to 0146		Cannot be used	
0147		Position zone output monitor	ZP
0148 to 014D		Cannot be used	
014E		Zone output monitor 2	Z2
014F		Zone output monitor 1	Z1
0150 to 015F	Input port monitor register (DIPM)	PIO connector pin numbers 20A (IN15) to 5A (IN0)	-
0160 to 016F	Output port monitor register (DOPM)	PIO connector pin numbers 16B (OUT15) to 1B (OUT0)	-
0170	Special input port monitor register (SIPM)	Cannot be used	
0171		Command pulse NP signal status	NP
0172		Cannot be used	
0173		Command pulse PP signal status	PP
0174 to 0175		Cannot be used	
0176		Cannot be used	
0177		Mode switch status	MDSW
0178		Cannot be used	
0179 to 017A		Cannot be used	
017B		Belt breakage sensor monitor	BLCT
017C		Home-check sensor monitor	HMCK
017D		Overtravel sensor	OT
017E		Creep sensor	CREP
017F		Limit sensor	LS
0180 to 0183	Expansion system status register (SSSE)	Cannot be used	
0184		Cold start level alarm	ALMC
0185 to 0186		Cannot be used	
0187		RTC in use(ERC3, ACON-CA/CB and PCON-CA/CFA/CB/CFB only)	RTC
0188 to 018F		Cannot be used	

Status	Area name	Description	Abbreviation
0190	Press program status register (Servo Press) (PPST)	Cannot be used	
0191		Waiting	WAIT
0192		While in returning operation	RTRN
0193		While in depression operation	DCMP
0194		Pressurize during the stop	PSTP
0195		While in pressurizing operation	PRSS
0196		While in probing operation	SERC
0197		While in approaching the operation	APRC
0198 to 019A		Cannot be used	
019B		Program home return during the movement	MPHM
019C		Program alarm	PALM
019D		Program finished in normal condition	PCMP
019E		While in executing program	PRUN
019F		Program home position	PORG
01A0 to 01A9	Press program judgement status register (Servo Press) (PPJD)	Cannot be used	
01AA		Load judgement NG	LJNG
01AB		Load judgement OK	LJOK
01AC		Position(distance) judgement NG	PJNG
01AD		Position(distance) judgement OK	PJOK
01AE		Total judgement NG	JDNG
01AF		Total judgement OK	JDOK
01B0 to 03FF		- (Reserved for system)	
0400	Device control register 1 (DRG1)	EMG operation specification	EMG
0401		Safety speed command	SFTY
0402		Cannot be used	
0403		Servo ON command	SON
0404 to 0406		Cannot be used	
0407		Alarm reset command	ALRS
0408		Brake forced-release command	BKRL
0409		Cannot be used	
040A		Pause command	STP
040B		Home return command	HOME
040C		Positioning start command	CSTR
040D to 040F		Cannot be used	
0410	Device control register 2 (DRG2)	Cannot be used	
0411		Jog/inch switching	JISL
0412 to 0413		Cannot be used	
0414		Teaching mode command	MOD
0415		Position data load command	TEAC
0416		Jog+ command	JOG+
0417		Jog- command	JOG-
0418		Start position 7	ST7
0419		Start position 6	ST6
041A		Start position 5	ST5
041B		Start position 4	ST4
041C		Start position 3	ST3
041D		Start position 2	ST2
041E		Start position 1	ST1
041F		Start position 0	ST0

Status	Area name	Description	Abbreviation
0420 to 0425	Expansion device control register (DRGE)	Cannot be used	
0426		Load cell calibration command	CLBR
0427		PID/Modbus switching specification	PMSL
0428 to 042B		Cannot be used	
042C		Deceleration stop	STOP
042D to 042F		Cannot be used	
0430 to 0435	Position number specification register, Program number specification register (Servo Press) (POSR)	Cannot be used	
0436		Position command bit 512	PC512
0437		Position command bit 256	PC256
0438		Position command bit 128	PC128
0439		Position command bit 64	PC64
043A		Position command bit 32/Program number command bit 32	PC32
043B		Position command bit 16/Program number command bit 16	PC16
043C		Position command bit 8/Program number command bit 8	PC8
043D		Position command bit 4/Program number command bit 4	PC4
043E		Position command bit 2/Program number command bit 2	PC2
043F		Position command bit 1/Program number command bit 1	PC1
0440 to 048F	- (Reserved for system)		
0490 to 049A	Press program control register (PPCT)	Cannot be used	
049B		Axis operation permission	ENMV
049C		Program home return movement	PHOM
049D		Search stop	SSTP
049E		Program compulsoly finish	FPST
049F		Program start	PSTR
04A0 to FFFF	- (Reserved for system)		

Register (R) (Word device/Double word device)

The following shows device numbers which can be set for the register and the corresponding device contents.

Register	Data length	Area name	Description	Abbreviation	
0000 to 04FF	- (Reserved for system)				
0500	Word	Detailed information of the alarm detected lately	Alarm detail code	ALA0	
0501	Word		Alarm address	ALA0	
0502	Word		Always 0	-	
0503	Word		Alarm code	ALC0	
0504	Word		Alarm occurrence time	ALT0	
0506 to 0CFF	- (Reserved for system)				
0D00	Word	I/O control information category	Device control register 1	DRG1	
0D01	Word		Device control register 2	DRG2	
0D03	Word		Position number specification register/Program number specification register	POSR	
0D04 to 0FFF	- (Reserved for system)				
1000 to 3FFF		Position table information (low-speed memory area)	Offset (Hex.)		
	Double word		+0000H	Target position	PCMD
	Double word		+0002H	Positioning band	INP
	Double word		+0004H	Speed command	VCMD
	Double word		+0006H	Individual zone boundary +	ZNMP
	Double word		+0008H	Individual zone boundary -	ZNLP
	Word		+000AH	Acceleration command	ACMD
	Word		+000BH	Deceleration command	DCMD
	Word		+000CH	Push-current limiting value	PPOW
	Word		+000DH	Load current threshold	LPOW
	Word		+000EH	Control flag specification	CTLF
	(Calculation of detailed device number)				
	Device number (Hex) = 1000H + (16 × Position number (0 to 767)) ^{*1} + (Offset value corresponding to the device content) H				
Example)					
Position number: 5					
Device content: Speed command (Offset value = 0004H)					
Device number (Hex) = 1000H + (16 × 5 = 80) ^{*1*2} + 0004H = 1000H + 50H ^{*2} + 0004H = 1054H					
*1 Calculated in decimal.					
*2 Converting 16 × 5 = 80 to hexadecimal results 50H.					
4000 to 83FF	- (Reserved for system)				
8400	Double word	Maintenance information (models applicable to calendar function only)	Total moving count	TLMC	
8402	Double word		Total moving distance	ODOM	
841E	Double word		Current time(SCON-CA/CAL/CB only)	TIMN	
8420	Double word		Current time(PCON-CA/CFA/CB/CFB only)	TIMN	
8422	Double word		Current time(ACON-CA/CB only)	TIMN	
842A	Double word		Total FAN driving time(SCON-CAL, SCON-CB [400W or more] only)	TFAN	
842E	Double word		Total FAN driving time(PCON-CFA/CFB only)	TFAN	
8430 to 8FFF	- (Reserved for system)				

Register	Data length	Area name	Description	Abbreviation
9000	Double word	Controller monitor information category	Current position register	PNOW
9002	Word		Present alarm code register	ALMC
9003	Word		Input port register	DIPM
9004	Word		Output port register	DOPM
9005	Word		Device status 1 register	DSS1
9006	Word		Device status 2 register	DSS2
9007	Word		Expansion device status register	DSSE
9008	Double word		System status register	STAT
900A	Double word		Current speed monitor register	VNOW
900C	Double word		Current ampere monitor register	CNOW
900E	Double word		Deviation monitor register	DEVI
9010	Double word		System timer register	STIM
9012	Word		Special input port register	SIPM
9013	Word		Zone status register	ZONS
9014	Word		Positioning complete position No. register/Executed program No. register	POSS
9015	Word		Expansion System status register	SSSE
9016 to 901D	- (Reserved for system)			
901E	Double word	Controller monitor information category	Current load(SCON-CA/CB only)	FBFC
9020	Double word	Controller monitor information category (Servo Press Type only)	Overload level monitor	OLLV
9022	Word		Press program alarm code	ALMP
9023	Word		Press program alarm generated program No.	ALMP
9024	Word		Press program status register	PPST
9025	Word		Press program judgement status register	PPJD
9026 to 97FF	- (Reserved for system)			
9800	Word	Position command category	Position movement command register	POSR
9801 to 98FF	- (Reserved for system)			
9900	Double word	Numerical value command category	Target position coordinate specification register	PCMD
9902	Double word		Positioning band specification register	INP
9904	Double word		Speed specification register	VCMD
9906	Word		Acceleration/deceleration speed specification register	ACMD
9907	Word		Push-current limiting value	PPOW
9908	Word		Control flag specification register	CTLF
9909 to FFFF	- (Reserved for system)			

2.7 Precautions

Program control device

- When Program Execution Command (0), Program Exit Command (2), or Program Restart Command (4) is written to the program control device (PRG 0), it will be a request for all programs running in the controllers.
- When unsupported write data is input to the program control device, the following error is displayed in the system alarm.

315: Device writing error.

Correct device.

Variable devices

The variable number 99 of Integer device and variable number 199 of Real device are special devices used for operations by the X-SEL controller system. Do not use these variables for general purpose.

Command trigger compatible device

- For the device whose obtained data No.0 is a command trigger, communication with the controller is performed when the Write(1)/Read(2) is set to the command trigger.

When the command trigger and setting value are written in a batch, the communication is performed based on the value set with batch write.

- When Clear(4) is set to the command trigger, the communication with the controller is not performed and the set value is initialized.
- When an unsupported set value is input to the command trigger, the following error is displayed in the system alarm.

315: Device writing error.

Correct device.

Device reserved for system use

Devices of "Reserved for system use" are devices with indefinite values. Do not write to these devices.

Write to the flash ROM

- The point data can be written to the flash ROM of the X-SEL controller. When the point data is written to the flash ROM, it is not cleared even when power supply to the controller is turned off. However, there are limits in the number of writing. For details, refer to the user's manual of X-SEL controller used.
- Never turn off the main power supply during the flash ROM write. Doing so may cause the loss of data and malfunction of controllers. For details, refer to the user's manual of X-SEL controller used.

Communication disconnection

- Writing to the flash ROM disconnects the communication with controllers until the writing is completed.
- Resetting software restarts the controllers. During this time, the communication with controllers is disconnected.

Station number setting of the IAI robot controller system

The robot controller with the station number set with the host address must be included.

 Page 107 Communication detail settings

Connection of the IAI X-SEL K type

Note the following precaution when using the controller with the mode switch set to MANU.

- After powering up the X-SEL, connecting the GOT before the PC software causes the program startup disabled (A1D alarm) on the X-SEL side.

3 CONNECTION TO AZBIL CONTROL EQUIPMENT

- Page 133 Connectable Model List
- Page 135 System Configuration
- Page 166 Connection Diagram
- Page 190 GOT Side Settings
- Page 193 Control Equipment Side Setting
- Page 205 Device Range that Can Be Set
- Page 208 Precautions

3

3.1 Connectable Model List

The following table shows the connectable models.


Series	Model name	Clock	Communication Type	Connectable model	Refer to
DMC	DMC10	×	RS-232	GT 27 GT 25 GT 23 GT 21 GS	☞ Page 135 Connecting to DMC10
			RS-485	GT 27 GT 25 GT 23 GT 21	
	DMC50	○	RS-485	GT 27 GT 25 GT 23 GT 21	☞ Page 137 Connecting to DMC50
SDC	SDC15 SDC25 SDC26 SDC35 SDC36	×	RS-232	GT 27 GT 25 GT 23 GT 21 GS	☞ Page 139 Connecting to SDC15, SDC25/26 or SDC35/36
			RS-485	GT 27 GT 25 GT 23 GT 21	
	SDC20 SDC21	×	RS-232	GT 27 GT 25 GT 23 GT 21 GS	☞ Page 141 Connecting to SDC20/21
			RS-485	GT 27 GT 25 GT 23 GT 21	
	SDC30 SDC31	×	RS-232	GT 27 GT 25 GT 23 GT 21 GS	☞ Page 144 Connecting to SDC30/31
			RS-485	GT 27 GT 25 GT 23 GT 21	
	SDC40A SDC40B SDC40G	×	RS-232	GT 27 GT 25 GT 23 GT 21 GS	☞ Page 146 Connecting to SDC40A/40B/40G
			RS-485	GT 27 GT 25 GT 23 GT 21	
	SDC45 SDC46	○	RS-232	GT 27 GT 25 GT 23 GT 21 GS	☞ Page 149 Connecting to SDC45/46
			RS-485	GT 27 GT 25 GT 23 GT 21	
CMS	CMS	×	RS-232	GT 27 GT 25 GT 23 GT 21 GS	☞ Page 151 Connecting to CMS, MQV, MPC, MVF, RX
			RS-485	GT 27 GT 25 GT 23 GT 21	
CMF	CMF015 CMF050	×	RS-232	GT 27 GT 25 GT 23 GT 21 GS	☞ Page 153 Connecting to CMF015, CMF050
			RS-485	GT 27 GT 25 GT 23 GT 21	

Series	Model name	Clock	Communication Type	Connectable model	Refer to
CML	CML	×	RS-232	GT 27 GT 25 GT 23 GT 21 GS	☞ Page 156 Connecting to CML, PBC201-VN2
			RS-485	GT 27 GT 25 GT 23 GT 21	
MQV	MQV	×	RS-232	GT 27 GT 25 GT 23 GT 21 GS	☞ Page 151 Connecting to CMS, MQV, MPC, MVF, RX
			RS-485	GT 27 GT 25 GT 23 GT 21	
MPC	MPC	×	RS-232	GT 27 GT 25 GT 23 GT 21 GS	☞ Page 151 Connecting to CMS, MQV, MPC, MVF, RX
			RS-485	GT 27 GT 25 GT 23 GT 21	
MVF	MVF	×	RS-232	GT 27 GT 25 GT 23 GT 21 GS	☞ Page 151 Connecting to CMS, MQV, MPC, MVF, RX
			RS-485	GT 27 GT 25 GT 23 GT 21	
PBZ	PBC201-VN2	×	RS-232	GT 27 GT 25 GT 23 GT 21 GS	☞ Page 156 Connecting to CML, PBC201-VN2
			RS-485	GT 27 GT 25 GT 23 GT 21	
AUR	AUR350C AUR450C	×	RS-232	GT 27 GT 25 GT 23 GT 21 GS	☞ Page 158 Connecting to AUR350C, AUR450C
			RS-485	GT 27 GT 25 GT 23 GT 21	
RX	RX	○	RS-232	GT 27 GT 25 GT 23 GT 21 GS	☞ Page 151 Connecting to CMS, MQV, MPC, MVF, RX
			RS-485	GT 27 GT 25 GT 23 GT 21	
CMC	CMC10B	×	RS-232	GT 27 GT 25 GT 23 GT 21 GS	☞ Page 160 Connecting to CMC10B
			RS-485	GT 27 GT 25 GT 23 GT 21	
AHC2001	AHC2001	○	RS-232	GT 27 GT 25 GT 23 GT 21 GS	☞ Page 162 Connecting to AHC2001
			RS-485	GT 27 GT 25 GT 23 GT 21	
NX	NX-D15 NX-D25 NX-D35 NX-DX1 NX-DX2 NX-DY NX-S01 NX-S11 NX-S12 NX-S21	×	RS-232 RS-485 (MODBUS)	GT 27 GT 25 GT 23	☞ Page 165 Connecting to NX series
	NX-D15 NX-D25 NX-D35 NX-DX1 NX-DX2 NX-DY NX-S01 NX-S11 NX-S12 NX-S21	×	Ethernet (MODBUS)	GT 27 GT 25 GT 23	☞ Page 165 Connecting to NX series

3.2 System Configuration

Connecting to DMC10

When using the Interface converter




Temperature controller	Connection cable 1)		Interface converter*1		Connection cable 2)		GOT		Number of connectable equipment
Model name	Cable model Connection diagram number	Max. distance	Model name	Communication Type	Cable model Connection diagram number	Max. distance	Option device*2	Model	
DMC10	(User preparing) Page 168 RS485 connection diagram 1)	500m	CMC10L	RS-232	(User preparing) Page 166 RS232 connection diagram 1)	15m	- (Built into GOT)	<div>GT 27</div> <div>GT 23</div> <div>GT 21</div> <div>GT 25</div> <div>GT 21</div> <div>GS</div>	Up to 15 temperature controllers for 1 GOT
							GT15-RS2-9P	<div>GT 27</div> <div>GT 25</div>	
					(User preparing) Page 167 RS232 connection diagram 3)	15m	- (Built into GOT)	<div>GT 21</div> <div>GT 21</div> <div>GT 25</div> <div>GT 25</div>	

*1 Product manufactured by Azbil Corporation. For details on the product, contact Azbil Corporation.

*2 GT25-W, GT2505-V does not support the option device.

When connecting directly



Temperature controller		Connection cable		GOT		Number of connectable equipment
Model name	Communication Type	Cable model Connection diagram number	Max. distance	Option device	Model	
DMC10	RS-485	Page 176 RS485 connection diagram 12)	500m	- (Built into GOT)	 	Up to 15 temperature controllers for 1 GOT
		Page 169 RS485 connection diagram 3)	500m ^{*1}	FA-LTBGT2R4CBL05 (0.5m) ^{*2} FA-LTBGT2R4CBL10 (1m) ^{*2} FA-LTBGT2R4CBL20 (2m) ^{*2}	 *4	
		Page 171 RS485 connection diagram 5)	500m	GT15-RS4-TE	 *3*4	
		Page 185 RS485 connection diagram 27)	500m	GT14-RS2T4-9P ^{*5}	 *6	
		Page 182 RS485 connection diagram 21)	500m	- (Built into GOT)	 *4	

*1 Including the cable length of the option devices.

*2 Product manufactured by MITSUBISHI ELECTRIC ENGINEERING COMPANY LIMITED. For details of the product, contact MITSUBISHI ELECTRIC ENGINEERING COMPANY LIMITED.

*3 Not available to GT25-W.


*4 Not available to GT2505-V.

*5 Mount it on the RS-232 interface (GOT built-in).

*6 Only available to GT2505-V.

Connecting to DMC50

When using the COM module



Temperature controller	Connection cable		COM module ^{*1}		GOT		Number of connectable equipment
Model name	Connection diagram number	Max. distance	Model name	Communication Type	Option device	Model	
DMC50CX	Page 174 RS485 connection diagram 8)	500m ^{*2}	DMC50M20X	RS-485	FA-LTBGT2R4CBL05 (0.5m) ^{*3} FA-LTBGT2R4CBL10 (1m) ^{*3} FA-LTBGT2R4CBL20 (2m) ^{*2}	 	Up to 8 COM module for 1 GOT. Up to 120 temperature controllers for 1 COM module.
	Page 174 RS485 connection diagram 9)	500m	DMC50M20X	RS-485	- (Built into GOT)	 	
					GT15-RS4-9S		
						^{*4} *5	
					GT15-RS4-TE		
	Page 186 RS485 connection diagram 28)	500m	DMC50M□20X	RS-485	GT14-RS2T4-9P ^{*6}		^{*7}
	Page 182 RS485 connection diagram 22)	500m	DMC50M□20X	RS-485	- (Built into GOT)		

^{*1} Including the cable length of the option devices.

^{*2} Product manufactured by Azbil Corporation. For details on the product, contact Azbil Corporation.

^{*3} Product manufactured by MITSUBISHI ELECTRIC ENGINEERING COMPANY LIMITED. For details of the product, contact MITSUBISHI ELECTRIC ENGINEERING COMPANY LIMITED.


^{*4} Not available to GT25-W.

^{*5} Not available to GT2505-V.

^{*6} Mount it on the RS-232 interface (GOT built-in).

^{*7} Only available to GT2505-V.

When connecting directly to one temperature controller



Temperature controller	Connection cable			GOT		Number of connectable equipment
Model name	Connection diagram number	Max. distance	Communication Type	Option device	Model	
DMC50CX	Page 175 RS485 connection diagram 10)	500m ^{*1}	RS-485	FA-LTBGT2R4CBL05 (0.5m) ^{*2} FA-LTBGT2R4CBL10 (1m) ^{*2} FA-LTBGT2R4CBL20 (2m) ^{*2}	 	Up to 1 temperature controller for 1 GOT
	Page 176 RS485 connection diagram 13)	500m	RS-485	- (Built into GOT)	 	
	Page 175 RS485 connection diagram 11)	500m	RS-485	GT15-RS4-TE	 	
	Page 186 RS485 connection diagram 29)	500m	RS-485	GT14-RS2T4-9P ^{*5}		
	Page 182 RS485 connection diagram 23)	500m	RS-485	- (Built into GOT)	 	

*1 Including the cable length of the option devices.

*2 Product manufactured by MITSUBISHI ELECTRIC ENGINEERING COMPANY LIMITED. For details of the product, contact MITSUBISHI ELECTRIC ENGINEERING COMPANY LIMITED.

*3 Not available to GT25-W.


*4 Not available to GT2505-V.

*5 Mount it on the RS-232 interface (GOT built-in).

*6 Only available to GT2505-V.

Connecting to SDC15, SDC25/26 or SDC35/36

When using the Interface converter




Temperature controller	Connection cable 1)		Interface converter ^{*1}		Connection cable 2)		GOT		Number of connectable equipment
Model name	Cable model Connection diagram number	Max. distance	Model name	Communication Type	Cable model Connection diagram number	Max. distance	Option device ^{*2}	Model	
SDC15 SDC25/26 SDC35/36	(User preparing) Page 168 RS485 connection diagram 1)	500m	CMC10L	RS-232	(User preparing) Page 166 RS232 connection diagram 1)	15m	- (Built into GOT)	<div>GT 27</div> <div>GT 25</div> <div>GT 23</div> <div>GT 21</div> <div>GT 205G</div> <div>GS</div>	Up to 31 temperature controllers for 1 GOT
							GT15-RS2-9P	<div>GT 27</div> <div>GT 25</div>	
				RS-232	(User preparing) Page 167 RS232 connection diagram 3)	15m	- (Built into GOT)	<div>GT 21</div> <div>GT 04R</div> <div>GT 03P</div> <div>GT 04P</div>	

^{*1} Product manufactured by Azbil Corporation. For details on the product, contact Azbil Corporation.

^{*2} GT25-W, GT2505-V does not support the option device.

When connecting directly



Temperature controller		Connection cable		GOT		Number of connectable equipment
Model name	Communication Type	Cable model Connection diagram number	Max. distance	Option device	Model	
SDC15 SDC25/26 SDC35/36	RS-485	Page 169 RS485 connection diagram 3)	500m ^{*1}	FA-LTBGT2R4CBL05 (0.5m) ^{*2} FA-LTBGT2R4CBL10 (1m) ^{*2} FA-LTBGT2R4CBL20 (2m) ^{*2}	 	Up to 31 temperature controllers for 1 GOT
					^{*4}	
		Page 176 RS485 connection diagram 12)	500m	- (Built into GOT)	 	
		Page 171 RS485 connection diagram 5)	500m	GT15-RS4-TE	 ^{*3*4}	
		Page 185 RS485 connection diagram 27)	500m	GT14-RS2T4-9P ^{*5}	 ^{*6}	
		Page 182 RS485 connection diagram 21)	500m	- (Built into GOT)	 	

^{*1} Including the cable length of the option devices.

^{*2} Product manufactured by MITSUBISHI ELECTRIC ENGINEERING COMPANY LIMITED. For details of the product, contact MITSUBISHI ELECTRIC ENGINEERING COMPANY LIMITED.

^{*3} Not available to GT25-W.


^{*4} Not available to GT2505-V.

^{*5} Mount it on the RS-232 interface (GOT built-in).

^{*6} Only available to GT2505-V.

Connecting to SDC20/21

When using the Interface converter


















Temperature controller	Connection cable 1)		Interface converter ^{*1}		Connection cable 2)		GOT		Number of connectable equipment
Model name	Cable model Connection diagram number	Max. distance	Model name	Communication Type	Cable model Connection diagram number	Max. distance	Option device ^{*2}	Model	
SDC20/21	(User preparing)Page 168 RS485 connection diagram 2)	500m	CMC10L	RS-232	(User preparing)Page 166 RS232 connection diagram 1)	15m	- (Built into GOT)	<div>GT27</div> <div>GT23</div> <div>GT21</div> <div>GT25</div> <div>GT21</div> <div>GS</div>	Up to 31 temperature controllers for 1 GOT
							GT15-RS2-9P	<div>GT27</div> <div>GT25</div>	
					(User preparing)Page 167 RS232 connection diagram 3)	15m	- (Built into GOT)	<div>GT21</div> <div>GT03P2</div> <div>GT04P2</div>	

^{*1} Product manufactured by Azbil Corporation. For details on the product, contact Azbil Corporation.

^{*2} GT25-W, GT2505-V does not support the option device.


When connecting directly to one temperature controller



Temperature controller		Connection cable		GOT		Number of connectable equipment
Model name	Communication Type	Cable model Connection diagram number	Max. distance	Option device *1	Model	
SDC20/21	RS-232	 Page 166 RS232 connection diagram 2)	15m	- (Built into GOT)	     	Up to 1 temperature controller for 1 GOT
				GT15-RS2-9P	 	
		 Page 167 RS232 connection diagram 4)	15m	- (Built into GOT)	   	

*1 GT25-W, GT2505-V does not support the option device.

When connecting directly to multiple temperature controllers



Temperature controller		Connection cable		GOT		Number of connectable equipment
Model name	Communication Type	Cable model Connection diagram number	Max. distance	Option device	Model	
SDC20/21	RS-485	Page 170 RS485 connection diagram 4)(4-wire)	500m ^{*1}	FA-LTBGT2R4CBL05 (0.5m) ^{*2} FA-LTBGT2R4CBL10 (1m) ^{*2} FA-LTBGT2R4CBL20 (2m) ^{*2}	 	Up to 31 temperature controllers for 1 GOT
		Page 177 RS485 connection diagram 14)(2-wire)			^{*4}	
		Page 172 RS485 connection diagram 6)(4-wire)	500m	- (Built into GOT)	 	
				GT15-RS4-9S		
					^{*3*4}	
		Page 178 RS485 connection diagram 15)(2-wire)	500m	- (Built into GOT)	 	
		Page 173 RS485 connection diagram 7)(4-wire)	500m	GT15-RS4-TE		^{*3*4}
		Page 179 RS485 connection diagram 16)(2-wire)				
		Page 187 RS485 connection diagram 30)(4-wire)	500m	GT14-RS2T4-9P ^{*5}		^{*6}
		Page 188 RS485 connection diagram 31)(2-wire)				
		Page 183 RS485 connection diagram 24)(4-wire)	500m	- (Built into GOT)		
		Page 184 RS485 connection diagram 25)(2-wire)				

*1 Including the cable length of the option devices.

*2 Product manufactured by MITSUBISHI ELECTRIC ENGINEERING COMPANY LIMITED. For details of the product, contact MITSUBISHI ELECTRIC ENGINEERING COMPANY LIMITED.

*3 Not available to GT25-W.


*4 Not available to GT2505-V.

*5 Mount it on the RS-232 interface (GOT built-in).

*6 Only available to GT2505-V.

Connecting to SDC30/31

When using the Interface converter




Temperature controller	Connection cable 1)		Interface converter ^{*1}		Connection cable 2)		GOT		Number of connectable equipment
Model name	Cable model Connection diagram number	Max. distance	Model name	Communication Type	Cable model Connection diagram number	Max. distance	Option device ^{*2}	Model	
SDC30/31	(User preparing) Page 168 RS485 connection diagram 2)	500m	CMC10L	RS-232	(User preparing) Page 166 RS232 connection diagram 1)	15m	- (Built into GOT)	<div>GT 27</div> <div>GT 25</div> <div>GT 23</div> <div>GT 21</div> <div>GT 2505</div> <div>GS</div>	Up to 31 temperature controllers for 1 GOT
							GT15-RS2-9P	<div>GT 27</div> <div>GT 25</div>	
					(User preparing) Page 167 RS232 connection diagram 3)	15m	- (Built into GOT)	<div>GT 27</div> <div>GT 25</div> <div>GT 21</div> <div>GT 2505</div> <div>GT 2505-V</div> <div>GT 2505-W</div>	

^{*1} Product manufactured by Azbil Corporation. For details on the product, contact Azbil Corporation.

^{*2} GT25-W, GT2505-V does not support the option device.

When connecting directly



3

Temperature controller		Connection cable		GOT		Number of connectable equipment
Model name	Communication Type	Cable model Connection diagram number	Max. distance	Option device	Model	
SDC30/31	RS-485	Page 170 RS485 connection diagram 4)(4-wire)	500m ^{*1}	FA-LTBGT2R4CBL05 (0.5m) ^{*2} FA-LTBGT2R4CBL10 (1m) ^{*2} FA-LTBGT2R4CBL20 (2m) ^{*2}	 	Up to 31 temperature controllers for 1 GOT
		Page 177 RS485 connection diagram 14)(2-wire)			^{*4}	
		Page 172 RS485 connection diagram 6)(4-wire)	500m	- (Built into GOT)	 	
				GT15-RS4-9S		
					^{*3*4}	
		Page 173 RS485 connection diagram 7)(4-wire)	500m	GT15-RS4-TE		
		Page 179 RS485 connection diagram 16)(2-wire)				
					^{*3*4}	
		Page 187 RS485 connection diagram 30)(4-wire)	500m	GT14-RS2T4-9P ^{*5}		
		Page 188 RS485 connection diagram 31)(2-wire)				
					^{*6}	
		Page 183 RS485 connection diagram 24)(4-wire)	500m	- (Built into GOT)	 	

^{*1} Including the cable length of the option devices.

^{*2} Product manufactured by MITSUBISHI ELECTRIC ENGINEERING COMPANY LIMITED. For details of the product, contact MITSUBISHI ELECTRIC ENGINEERING COMPANY LIMITED.

^{*3} Not available to GT25-W.


^{*4} Not available to GT2505-V.

^{*5} Mount it on the RS-232 interface (GOT built-in).

^{*6} Only available to GT2505-V.

Connecting to SDC40A/40B/40G

When using the Interface converter




Temperature controller	Connection cable 1)		Interface converter*1		Connection cable 2)		GOT		Number of connectable equipment
Model name	Cable model Connection diagram number	Max. distance	Model name	Communication Type	Cable model Connection diagram number	Max. distance	Option device*2	Model	
SDC40A/40B/40G	(User preparing) Page 168 RS485 connection diagram 2)	500m	CMC10L	RS-232	(User preparing) Page 166 RS232 connection diagram 1)	15m	- (Built into GOT)	<div>GT 27</div> <div>GT 25</div> <div>GT 23</div> <div>GT 21</div> <div>GT 21</div> <div>GS</div>	Up to 31 temperature controllers for 1 GOT
							GT15-RS2-9P	<div>GT 27</div> <div>GT 25</div>	
					(User preparing) Page 167 RS232 connection diagram 3)	15m	- (Built into GOT)	<div>GT 04R</div> <div>GT 21</div> <div>GT 03P</div> <div>GT 104P</div>	















*1 Product manufactured by Azbil Corporation. For details on the product, contact Azbil Corporation.

*2 GT25-W, GT2505-V does not support the option device.

When connecting directly to one temperature controller




3

Temperature controller		Connection cable		GOT		Number of connectable equipment
Model name	Communication Type	Cable model Connection diagram number	Max. distance	Option device ^{*1}	Model	
SDC40A/40B/40G	RS-232	 Page 166 RS232 connection diagram 2)	15m	- (Built into GOT)	     	Up to 1 temperature controller for 1 GOT
				GT15-RS2-9P	 	
		 Page 167 RS232 connection diagram 4)	15m	- (Built into GOT)	   	

*1 GT25-W, GT2505-V does not support the option device.

When connecting directly to multiple temperature controllers



Temperature controller		Connection cable		GOT		Number of connectable equipment
Model name	Communication Type	Cable model Connection diagram number	Max. distance	Option device	Model	
SDC40A/40B/40G	RS-485	(User preparing) Page 170 RS485 connection diagram 4)(4-wire)	500m ^{*1}	FA-LTBGT2R4CBL05 (0.5m) ^{*2} FA-LTBGT2R4CBL10 (1m) ^{*2} FA-LTBGT2R4CBL20 (2m) ^{*2}	GT 27 GT 23	Up to 31 temperature controllers for 1 GOT
		(User preparing) Page 177 RS485 connection diagram 14)(2-wire)			^{*4}	
		(User preparing) Page 172 RS485 connection diagram 6)(4-wire)	500m	- (Built into GOT)	GT 27 GT 23 GT 25 GT 21 ^{GT2505V}	
				GT15-RS4-9S	GT 27 GT 25	
		(User preparing) Page 178 RS485 connection diagram 15)(2-wire)	500m	- (Built into GOT)	GT 27 GT 23 GT 25 GT 21 ^{GT2505V}	
		(User preparing) Page 173 RS485 connection diagram 7)(4-wire)	500m	GT15-RS4-TE	GT 27 GT 25	
		(User preparing) Page 179 RS485 connection diagram 16)(2-wire)			^{*3*4}	
		(User preparing) Page 187 RS485 connection diagram 30)(4-wire)	500m	GT14-RS2T4-9P ^{*5}	GT 25	
		(User preparing) Page 188 RS485 connection diagram 31)(2-wire)			^{*6}	
		(User preparing) Page 183 RS485 connection diagram 24)(4-wire)	500m	- (Built into GOT)	GT 21 ^{GT24R} GT 25 ^{GT24R} GT 23 ^{GT24R} GT 21 ^{GT24R}	
		(User preparing) Page 184 RS485 connection diagram 25)(2-wire)			GT 21 ^{GT24R} GT 25 ^{GT24R} GT 23 ^{GT24R} GT 21 ^{GT24R}	

*1 Including the cable length of the option devices.

*2 Product manufactured by MITSUBISHI ELECTRIC ENGINEERING COMPANY LIMITED. For details of the product, contact MITSUBISHI ELECTRIC ENGINEERING COMPANY LIMITED.

*3 Not available to GT25-W.


*4 Not available to GT2505-V.

*5 Mount it on the RS-232 interface (GOT built-in).

*6 Only available to GT2505-V.

Connecting to SDC45/46

When using the Interface converter

























Temperature controller	Connection cable 1)		Interface converter ^{*1}		Connection cable 2)		GOT		Number of connectable equipment
Model name	Cable model Connection diagram number	Max. distance	Model name	Communication Type	Cable model Connection diagram number	Max. distance	Option device ^{*2}	Model	
SDC45/46	(User preparing) Page 180 RS485 connection diagram 17)	500m	CMC10L	RS-232	(User preparing) Page 166 RS232 connection diagram 1)	15m	- (Built into GOT)	<div>GT 27</div> <div>GT 23</div> <div>GT 21</div> <div>GT 25</div> <div>GT 21</div> <div>GS</div>	Up to 31 temperature controllers for 1 GOT
							GT15-RS2-9P	<div>GT 27</div> <div>GT 25</div>	
					(User preparing) Page 167 RS232 connection diagram 3)	15m	- (Built into GOT)	<div>GT 21</div> <div>GT 21</div> <div>GT 03P</div> <div>GT 04P</div>	

*1 Product manufactured by Azbil Corporation. For details on the product, contact Azbil Corporation.

*2 GT25-W, GT2505-V does not support the option device.

When connecting directly to multiple temperature controllers



Temperature controller		Connection cable		GOT		Number of connectable equipment
Model name	Communication Type	Cable model Connection diagram number	Max. distance	Option device	Model	
SDC45/46	RS-485	 Page 180 RS485 connection diagram 18)	500m ^{*1}	FA-LTBGT2R4CBL05 (0.5m) ^{*2} FA-LTBGT2R4CBL10 (1m) ^{*2} FA-LTBGT2R4CBL20 (2m) ^{*2}	  	Up to 31 temperature controller for 1 GOT
		 Page 181 RS485 connection diagram 19)	500m	GT15-RS4-TE	  ^{*4}	
		 Page 181 RS485 connection diagram 20)	500m	- (Built into GOT)	   	
		 Page 189 RS485 connection diagram 32)	500m	GT14-RS2T4-9P ^{*5}	 ^{*6}	
		 Page 185 RS485 connection diagram 26)	500m	- (Built into GOT)	     	

^{*1} Including the cable length of the option devices.

^{*2} Product manufactured by MITSUBISHI ELECTRIC ENGINEERING COMPANY LIMITED. For details of the product, contact MITSUBISHI ELECTRIC ENGINEERING COMPANY LIMITED.

^{*3} Not available to GT25-W.


^{*4} Not available to GT2505-V.






^{*5} Mount it on the RS-232 interface (GOT built-in).

^{*6} Only available to GT2505-V.

Connecting to CMS, MQV, MPC, MVF, RX

When using the Interface converter




Control equipment	Connection cable 1)		Interface converter ^{*1}		Connection cable 2)		GOT		Number of connectable equipment
Model name	Cable model Connection diagram number	Max. distance	Model name	Communication Type	Cable model Connection diagram number	Max. distance	Option device ^{*2}	Model	
CMS MQV MPC MVF RX	(User preparing) Page 180 RS485 connection diagram 17)	500m	CMC10L	RS-232	(User preparing) Page 166 RS232 connection diagram 1)	15m	- (Built into GOT)	 	Up to 31 control equipment for 1 GOT
							GT15-RS2-9P		
					(User preparing) Page 167 RS232 connection diagram 3)	15m	- (Built into GOT)	 	

^{*1} Product manufactured by Azbil Corporation. For details on the product, contact Azbil Corporation.

^{*2} GT25-W, GT2505-V does not support the option device.

When connecting directly to multiple control equipments



Control equipment		Connection cable		GOT		Number of connectable equipment
Model name	Communication Type	Cable model Connection diagram number	Max. distance	Option device	Model	
CMS MQV MPC MVF RX	RS-485	(User preparing) Page 180 RS485 connection diagram 18)	500m ^{*1}	FA-LTBGT2R4CBL05 (0.5m) ^{*2} FA-LTBGT2R4CBL10 (1m) ^{*2} FA-LTBGT2R4CBL20 (2m) ^{*2}	GT 27 GT 25 GT 23	Up to 1 control equipment for 1 GOT
					*4	
		(User preparing) Page 181 RS485 connection diagram 19)	500m	GT15-RS4-TE	GT 27 GT 25	
					*3*4	
		(User preparing) Page 181 RS485 connection diagram 20)	500m	- (Built into GOT)	GT 27 GT 25 GT 23 GT 2505 21	
		(User preparing) Page 189 RS485 connection diagram 32)	500m	GT14-RS2T4-9P ^{*5}	GT 25	
		(User preparing) Page 185 RS485 connection diagram 26)	500m	- (Built into GOT)	GT 04RP 21 GT 03P 21 04P R4 GT 03P 21 04P R4	

*1 Including the cable length of the option devices.

*2 Product manufactured by MITSUBISHI ELECTRIC ENGINEERING COMPANY LIMITED. For details of the product, contact MITSUBISHI ELECTRIC ENGINEERING COMPANY LIMITED.

*3 Not available to GT25-W.


*4 Not available to GT2505-V.

*5 Mount it on the RS-232 interface (GOT built-in).

*6 Only available to GT2505-V.

Connecting to CMF015, CMF050

When using the Interface converter




Control equipment	Connection cable 1)		Interface converter ^{*1}		Connection cable 2)		GOT		Number of connectable equipment
Model name	Cable model Connection diagram number	Max. distance	Model name	Communication Type	Cable model Connection diagram number	Max. distance	Option device ^{*2}	Model	
CMF015	(User preparing) Page 180 RS485 connection diagram 17)	500m	CMC10L	RS-232	(User preparing) Page 166 RS232 connection diagram 1)	15m	- (Built into GOT)		Up to 31 control equipment for 1 GOT
							GT15-RS2-9P		
					(User preparing) Page 167 RS232 connection diagram 3)	15m	- (Built into GOT)		
CMF050	(User preparing) Page 168 RS485 connection diagram 2)	500m	CMC10L	RS-232	(User preparing) Page 166 RS232 connection diagram 1)	15m	- (Built into GOT)		Up to 31 control equipment for 1 GOT
							GT15-RS2-9P		
					(User preparing) Page 167 RS232 connection diagram 3)	15m	- (Built into GOT)		

*1 Product manufactured by Azbil Corporation. For details on the product, contact Azbil Corporation.

*2 GT25-W, GT2505-V does not support the option device.

When connecting directly

■Connecting to CMF015



Control equipment		Connection cable		GOT		Number of connectable equipment
Model name	Communication Type	Cable model Connection diagram number	Max. distance	Option device	Model	
CMF015	RS-485	Page 180 RS485 connection diagram 18)	500m ^{*1}	FA-LTBGT2R4CBL05 (0.5m) ^{*2} FA-LTBGT2R4CBL10 (1m) ^{*2} FA-LTBGT2R4CBL20 (2m) ^{*2}	 	Up to 1 control equipment for 1 GOT
		Page 181 RS485 connection diagram 19)	500m	GT15-RS4-TE	 ^{*4}	
		Page 181 RS485 connection diagram 20)	500m	- (Built into GOT)	 	
		Page 189 RS485 connection diagram 32)	500m	GT14-RS2T4-9P ^{*5}	 ^{*6}	
		Page 185 RS485 connection diagram 26)	500m	- (Built into GOT)	 	

^{*1} Including the cable length of the option devices.

^{*2} Product manufactured by MITSUBISHI ELECTRIC ENGINEERING COMPANY LIMITED. For details of the product, contact MITSUBISHI ELECTRIC ENGINEERING COMPANY LIMITED.


^{*3} Not available to GT25-W.

^{*4} Not available to GT2505-V.

^{*5} Mount it on the RS-232 interface (GOT built-in).

^{*6} Only available to GT2505-V.

■Connecting to CMF050



Control equipment		Connection cable		GOT		Number of connectable equipment
Model name	Communication Type	Cable model Connection diagram number	Max. distance	Option device	Model	
CMF050	RS-485	Page 170 RS485 connection diagram 4)(4-wire)	500m ^{*1}	FA-LTBGT2R4CBL05 (0.5m) ^{*2} FA-LTBGT2R4CBL10 (1m) ^{*2} FA-LTBGT2R4CBL20 (2m) ^{*2}	 	Up to 1 control equipment for 1 GOT
		Page 177 RS485 connection diagram 14)(2-wire)			^{*4}	
		Page 172 RS485 connection diagram 6)(4-wire)	500m	- (Built into GOT)	 	
				GT15-RS4-9S		
					^{*3*4}	
		Page 178 RS485 connection diagram 15)(2-wire)	500m	- (Built into GOT)	 	
		Page 173 RS485 connection diagram 7)(4-wire)	500m	GT15-RS4-TE		
		Page 179 RS485 connection diagram 16)(2-wire)				
					^{*3*4}	
		Page 187 RS485 connection diagram 30)(4-wire)	500m	GT14-RS2T4-9P ^{*5}		
		Page 188 RS485 connection diagram 31)(2-wire)				
		Page 183 RS485 connection diagram 24)(4-wire)	500m	- (Built into GOT)	 	
		Page 184 RS485 connection diagram 25)(2-wire)				

*1 Including the cable length of the option devices.

*2 Product manufactured by MITSUBISHI ELECTRIC ENGINEERING COMPANY LIMITED. For details of the product, contact MITSUBISHI ELECTRIC ENGINEERING COMPANY LIMITED.

*3 Not available to GT25-W.


*4 Not available to GT2505-V.

*5 Mount it on the RS-232 interface (GOT built-in).

*6 Only available to GT2505-V.

Connecting to CML, PBC201-VN2

When using the Interface converter




Control equipment	Connection cable 1)		Interface converter ^{*1}		Connection cable 2)		GOT		Number of connectable equipment
Model name	Cable model Connection diagram number	Max. distance	Model name	Communication Type	Cable model Connection diagram number	Max. distance	Option device ^{*2}	Model	
CML PBC201-VN2	(User preparation) Page 168 RS485 connection diagram 2)	500m	CMC10L	RS-232	(User preparation) Page 166 RS232 connection diagram 1)	15m	- (Built into GOT)	<div>GT 27</div> <div>GT 25</div> <div>GT 23</div> <div>GT 21</div> <div>GT 05G</div> <div>GS</div>	Up to 31 control equipment for 1 GOT
							GT15-RS2- 9P	<div>GT 27</div> <div>GT 25</div>	
					(User preparation) Page 167 RS232 connection diagram 3)	15m	- (Built into GOT)	<div>GT 04P</div> <div>GT 21</div> <div>GT 03P</div> <div>GT 104P</div> <div>RS</div>	

^{*1} Product manufactured by Azbil Corporation. For details on the product, contact Azbil Corporation.

^{*2} GT25-W, GT2505-V does not support the option device.

When connecting directly



Control equipment		Connection cable		GOT		Number of connectable equipment
Model name	Communication Type	Cable model Connection diagram number	Max. distance	Option device	Model	
CML PBC201-VN2	RS-485	Page 170 RS485 connection diagram 4)(4-wire)	500m ^{*1}	FA-LTBGT2R4CBL05 (0.5m) ^{*2} FA-LTBGT2R4CBL10 (1m) ^{*2} FA-LTBGT2R4CBL20 (2m) ^{*2}	 	Up to 1 control equipment for 1 GOT
		Page 177 RS485 connection diagram 14)(2-wire)			^{*4}	
		Page 172 RS485 connection diagram 6)(4-wire)	500m	- (Built into GOT)	 	
				GT15-RS4-9S		
					^{*3} ^{*4}	
		Page 178 RS485 connection diagram 15)(2-wire)	500m	- (Built into GOT)	 	
		Page 173 RS485 connection diagram 7)(4-wire)	500m	GT15-RS4-TE		
		Page 179 RS485 connection diagram 16)(2-wire)			^{*3} ^{*4}	
		Page 187 RS485 connection diagram 30)(4-wire)	500m	GT14-RS2T4-9P ^{*5}		
		Page 188 RS485 connection diagram 31)(2-wire)			^{*6}	
		Page 183 RS485 connection diagram 24)(4-wire)	500m	- (Built into GOT)		
		Page 184 RS485 connection diagram 25)(2-wire)				

^{*1} Including the cable length of the option devices.

^{*2} Product manufactured by MITSUBISHI ELECTRIC ENGINEERING COMPANY LIMITED. For details of the product, contact MITSUBISHI ELECTRIC ENGINEERING COMPANY LIMITED.

^{*3} Not available to GT25-W.


^{*4} Not available to GT2505-V.

^{*5} Mount it on the RS-232 interface (GOT built-in).

^{*6} Only available to GT2505-V.

Connecting to AUR350C, AUR450C

When using the Interface converter




Control equipment	Connection cable 1)		Interface converter ^{*1}		Connection cable 2)		GOT		Number of connectable equipment
Model name	Cable model Connection diagram number	Max. distance	Model name	Communication Type	Cable model Connection diagram number	Max. distance	Option device ^{*2}	Model	
AUR350C AUR450C	<div><div>User preparing</div>Page 168 RS485 connection diagram 1)</div>	500m	CMC10L	RS-232	<div><div>User preparing</div>Page 166 RS232 connection diagram 1)</div>	15m	- (Built into GOT)	<div><div>GT 27</div><div>GT 23</div><div>GT 21</div></div> <div><div>GT 25</div><div>GT 21</div><div>GS</div></div>	Up to 31 control equipment for 1 GOT
								GT15-RS2-9P	
					<div><div>User preparing</div>Page 167 RS232 connection diagram 3)</div>	15m	- (Built into GOT)	<div><div>GT 04R 21</div><div>GT 03P R2</div><div>GT 04P R2</div></div>	

*1 Product manufactured by Azbil Corporation. For details on the product, contact Azbil Corporation.

*2 GT25-W, GT2505-V does not support the option device.

When connecting directly



Control equipment		Connection cable		GOT		Number of connectable equipment
Model name	Communication Type	Cable model Connection diagram number	Max. distance	Option device	Model	
AUR350C AUR450C	RS-485	Page 169 RS485 connection diagram 3)	500m ^{*1}	FA-LTBGT2R4CBL05 (0.5m) ^{*2} FA-LTBGT2R4CBL10 (1m) ^{*2} FA-LTBGT2R4CBL20 (2m) ^{*2}	 	Up to 1 control equipment for 1 GOT
		Page 171 RS485 connection diagram 5)	500m	GT15-RS4-TE	 	
		Page 176 RS485 connection diagram 12)	500m	- (Built into GOT)	 	
		Page 185 RS485 connection diagram 27)	500m	GT14-RS2T4-9P ^{*5}		
		Page 182 RS485 connection diagram 21)	500m	- (Built into GOT)	 	

*1 Including the cable length of the option devices.

*2 Product manufactured by MITSUBISHI ELECTRIC ENGINEERING COMPANY LIMITED. For details of the product, contact MITSUBISHI ELECTRIC ENGINEERING COMPANY LIMITED.

*3 Not available to GT25-W.


*4 Not available to GT2505-V.

*5 Mount it on the RS-232 interface (GOT built-in).

*6 Only available to GT2505-V.

Connecting to CMC10B

When using the Interface converter




Control equipment	Connection cable 1)		Interface converter ^{*1}		Connection cable 2)		GOT		Number of connectable equipment
Model name	Cable model Connection diagram number	Max. distance	Model name	Communication Type	Cable model Connection diagram number	Max. distance	Option device ^{*2}	Model	
CMC10B	(User preparing) Page 168 RS485 connection diagram 2)	500m	CMC10L	RS-232	(User preparing) Page 166 RS232 connection diagram 1)	15m	- (Built into GOT)	<div>GT 27</div> <div>GT 25</div> <div>GT 23</div> <div>GT 21</div> <div>GS</div>	Up to 31 control equipment for 1 GOT
							GT15-RS2-9P	<div>GT 27</div> <div>GT 25</div>	
					(User preparing) Page 167 RS232 connection diagram 3)	15m	- (Built into GOT)	<div>GT 21</div> <div>GT 25</div>	

*1 Product manufactured by Azbil Corporation. For details on the product, contact Azbil Corporation.

*2 GT25-W, GT2505-V does not support the option device.

When connecting directly to multiple control equipments



Control equipment		Connection cable		GOT		Number of connectable equipment
Model name	Communication Type	Cable model Connection diagram number	Max. distance	Option device	Model	
CMC10B	RS-485	Page 170 RS485 connection diagram 4)	500m ^{*1}	FA-LTBGT2R4CBL05 (0.5m) ^{*2} FA-LTBGT2R4CBL10 (1m) ^{*2} FA-LTBGT2R4CBL20 (2m) ^{*2}	 	Up to 1 control equipment for 1 GOT
					^{*4}	
		Page 172 RS485 connection diagram 6)	500m	- (Built into GOT)	 	
				GT15-RS4-9S		
					^{*3*4}	
		Page 173 RS485 connection diagram 7)	500m	GT15-RS4-TE		
		Page 187 RS485 connection diagram 30)	500m	GT14-RS2T4-9P ^{*5}		
					^{*6}	
		Page 183 RS485 connection diagram 24)	500m	- (Built into GOT)	 	

^{*1} Including the cable length of the option devices.

^{*2} Product manufactured by MITSUBISHI ELECTRIC ENGINEERING COMPANY LIMITED. For details of the product, contact MITSUBISHI ELECTRIC ENGINEERING COMPANY LIMITED.

^{*3} Not available to GT25-W.


^{*4} Not available to GT2505-V.

^{*5} Mount it on the RS-232 interface (GOT built-in).







































^{*6} Only available to GT2505-V.

Connecting to AHC2001

When connecting to one temperature controller



Control equipment			Connection cable		GOT		Number of connectable equipment
Model name	Communication unit	Communication Type	Cable model Connection diagram number	Max. distance	Option device	Model	
AHC2001	-	RS-232	<div>User preparing</div> Page 166 RS232 connection diagram 2)	15m	- (Built into GOT)	<div> <div>GT 27</div> <div>GT 23</div> <div>GT 21</div> </div> <div> <div>GT 25</div> <div>GT 21</div> <div>GS</div> </div>	Up to 1 temperature controllers for 1 GOT
	SCU				GT15-RS2-9P	<div> <div>GT 27</div> <div>GT 25</div> </div> <div>*3*4</div>	
			<div>User preparing</div> Page 167 RS232 connection diagram 4)	15m	- (Built into GOT)	<div> <div>GT 24</div> <div>GT 21</div> </div> <div> <div>GT 23</div> <div>GT 25</div> </div>	

Control equipment			Connection cable		GOT		Number of connectable equipment
Model name	Communication unit	Communication Type	Cable model Connection diagram number	Max. distance	Option device	Model	
AHC2001	SCU	RS-485	 Page 170 RS485 connection diagram 4)	500m ^{*1}	FA-LTBGT2R4CBL05 (0.5m) ^{*2} FA-LTBGT2R4CBL10 (1m) ^{*2} FA-LTBGT2R4CBL20 (2m) ^{*2}	  	Up to 1 temperature controllers for 1 GOT
			 Page 177 RS485 connection diagram 14)			*4	
			 Page 172 RS485 connection diagram 6)	500m	- (Built into GOT)	   	
						   	
			 Page 178 RS485 connection diagram 15)	500m	- (Built into GOT)	   	
						   	
			 Page 173 RS485 connection diagram 7)	500m	GT15-RS4-TE	 	
			 Page 179 RS485 connection diagram 16)			*3*4	
			 Page 187 RS485 connection diagram 30)(4-wire)	500m	GT14-RS2T4-9P ^{*5}		
			 Page 188 RS485 connection diagram 31)(2-wire)			*6	
			 Page 183 RS485 connection diagram 24)(4-wire)	500m	- (Built into GOT)	   	
			 Page 184 RS485 connection diagram 25)(2-wire)			 	

*1 Including the cable length of the option devices.

*2 Product manufactured by MITSUBISHI ELECTRIC ENGINEERING COMPANY LIMITED. For details of the product, contact MITSUBISHI ELECTRIC ENGINEERING COMPANY LIMITED.


*3 Not available to GT25-W.

*4 Not available to GT2505-V.

*5 Mount it on the RS-232 interface (GOT built-in).

*6 Only available to GT2505-V.

When connecting to multiple temperature controllers



Control equipment			Connection cable		GOT		Number of connectable equipment
Model name	Communication unit	Communication Type	Cable model Connection diagram number	Max. distance	Option device	Model	
AHC2001	SCU	RS-485	Page 170 RS485 connection diagram 4)	500m ^{*1}	FA-LTBGT2R4CBL05 (0.5m) ^{*2} FA-LTBGT2R4CBL10 (1m) ^{*2} FA-LTBGT2R4CBL20 (2m) ^{*2}	 	Up to 31 temperature controllers for 1 GOT
			Page 177 RS485 connection diagram 14)				
			Page 172 RS485 connection diagram 6)			 	
				500m	- (Built into GOT)	 	*3*4
					GT15-RS4-9S		
			Page 178 RS485 connection diagram 15)	500m	- (Built into GOT)	 	*3*4
			Page 173 RS485 connection diagram 7)	500m	GT15-RS4-TE		
			Page 179 RS485 connection diagram 16)				
			Page 187 RS485 connection diagram 30)(4-wire)	500m	GT14-RS2T4-9P ^{*5}		*6
			Page 188 RS485 connection diagram 31)(2-wire)				
			Page 183 RS485 connection diagram 24)(4-wire)	500m	- (Built into GOT)	 	
			Page 184 RS485 connection diagram 25)(2-wire)				

*1 Including the cable length of the option devices.

*2 Product manufactured by MITSUBISHI ELECTRIC ENGINEERING COMPANY LIMITED. For details of the product, contact MITSUBISHI ELECTRIC ENGINEERING COMPANY LIMITED.


*3 Not available to GT25-W.

*4 Not available to GT2505-V.

*5 Mount it on the RS-232 interface (GOT built-in).

*6 Only available to GT2505-V.

Connecting to NX series



Use a MODBUS/RTU or MODBUS/TCP communication driver to connect the GOT to NX series.

For the MODBUS/RTU or MODBUS/TCP connection, refer to the following manual.

☞ GOT2000 Series Connection Manual (Microcomputer/MODBUS/Peripheral Connection)

5. MODBUS/RTU MASTER CONNECTION

6. MODBUS/TCP MASTER CONNECTION

For the valid devices, refer to the following Technical News.

☞ List of Valid Devices Applicable for GOT2000 Series with MODBUS Connection (GOT-A-0070)


3.3 Connection Diagram

The following diagram shows the connection between the GOT and the control equipment.

RS-232 cable

Connection diagram


■RS232 connection diagram 1)



*1 For details on the setting method of the TERMINAL mode, refer to the following.

Page 195 Connecting to CMC10L

■RS232 connection diagram 2)




*1 Pin No. of temperature controller differs depending on model and optional function model.

Refer to the following table. The numbers in () of the following table correspond to optional function models.

Signal name	Model of temperature controller					
	SDC20		SDC21	SDC40A, SDC40B, SDC40G	AHC2001	
	(03, 05)	(10)	(04, 07, 09)		CPU	SCU
	Pin No.	Pin No.	Pin No.	Pin No.	Pin No.	Pin No.
SG	5	18	29	61	5	5
SD	17	16	27	60	3	3
RD	18	17	28	59	2	2


■RS232 connection diagram 3)



*1 For details on the setting method of the TERMINAL mode, refer to the following.

☞ Page 195 Connecting to CMC10L

■RS232 connection diagram 4)



*1 Pin No. of temperature controller differs depending on model and optional function model.

Refer to the following table. The numbers in () of the following table correspond to optional function models.

Signal name	Model of temperature controller					
	SDC20		SDC21	SDC40A, SDC40B, SDC40G	AHC2001	
	(03, 05)	(10)	(04, 07, 09)		CPU	SCU
	Pin No.	Pin No.	Pin No.	Pin No.	Pin No.	Pin No.
SG	5	18	29	61	5	5
SD	17	16	27	60	3	3
RD	18	17	28	59	2	2

Precautions when preparing a cable

■Cable length

The length of the RS-232 cable must be 15m or less.

■GOT side connector

For the GOT side connector, refer to the following.

☞ Page 58 GOT connector specifications

■AZBIL control equipment side connector


Use the connector compatible with the AZBIL control equipment side module.

For details, refer to the user's manual of the AZBIL control equipment

RS-485 cable

Connection diagram

■RS485 connection diagram 1)



*1 Pin No. of control equipment differs depending on the model. Refer to the following table.

Signal name	Model of control equipment			
	DMC10	SDC15	SDC25/26 SDC35/36	AUR350C AUR450C
	Pin No.	Pin No.	Pin No.	Pin No.
DA	4	16	22	DA
DB	5	17	23	DB
SG	6	18	24	SG


*2 Connect FG grounding to the single-sided end of a cable shield line.

*3 Set the terminal resistor to "Disable".

For details of terminating resistor settings, refer to the following.

☞ Page 195 Connecting to CMC10L

■RS485 connection diagram 2)



*1 Pin No. of control equipment differs depending on model and optional function model. Refer to the following table. The numbers in () of the following table correspond to optional function models.

Signal name	Model of control equipment									
	SDC20		SDC21	SDC30	SDC31		SDC40A/ 40B/40G	CMF050 CML	PBC201-VN2	CMC10B
	(02, 04)	(09)	(03, 06, 08)	(040, 041)	(045)	(446, 546)	Pin No.	Pin No.	Pin No.	Pin No.
RDA	17	18	27	18	18	27	59	7	14	13
RDB	18	19	28	19	19	28	60	8	15	14
SDA	15	16	25	16	16	25	57	9	12	11
SDB	16	17	26	17	17	26	58	10	13	12
SG	5	5	29	5	5	29	61	12	16	15
FG	3, 4	3, 4	3, 4	3, 4	3, 4	3, 4	3	19	3	-

*2 Terminating resistor should be provided for a Interface converter and a control equipment which will be terminals.


*3 Connect FG grounding to the single-sided end of a cable shield line.

*4 Since the Interface converter has a built-in terminating resistor, set the terminating resistor of GOT to "Enable".

For details of terminating resistor settings, refer to the following.

☞ Page 195 Connecting to CMC10L

■RS485 connection diagram 3)



*1 Pin No. of control equipment differs depending on the model. Refer to the following table.

Signal name	Model of control equipment			
	DMC10	SDC15	SDC25/26 SDC35/36	AUR350C AUR450C
	Pin No.	Pin No.	Pin No.	Pin No.
DA	4	16	22	DA
DB	5	17	23	DB
SG	6	18	24	SG


*2 Set the terminating resistor of GOT as follows.

Set the terminating resistor setting switch of the GOT main unit to "Disable".

☞ Page 189 Connecting terminating resistors

*3 Connect FG grounding to the single-sided end of a cable shield line.

■RS485 connection diagram 4)



*1 Pin No. of control equipment differs depending on model or optional function model.

Refer to the following table. The numbers in () of the following table correspond to optional function models.

Signal name	Model of control equipment						
	SDC20		SDC21	SDC30	SDC31		SDC40A/40B/40G
	(02, 04)	(09)	(03, 06, 08)	(040, 041)	(045)	(446, 546)	
	Pin No.	Pin No.	Pin No.	Pin No.	Pin No.	Pin No.	Pin No.
RDA	17	18	27	18	18	27	59
RDB	18	19	28	19	19	28	60
SDA	15	16	25	16	16	25	57
SDB	16	17	26	17	17	26	58
SG	5	5	29	5	5	29	61
FG	3, 4	3, 4	3, 4	3, 4	3, 4	3, 4	3

Signal name	Model of control equipment			
	CMF050 CML	PBC201-VN2	CMC10B	AHC2001
	Pin No.	Pin No.	Pin No.	Pin No.
RDA	7	14	13	3
RDB	8	15	14	2
SDA	9	12	11	5
SDB	10	13	12	4
SG	12	16	15	1
FG	19	3	-	-

*2 Terminating resistor should be provided for a control equipment which will be a terminal.


*3 Set the terminating resistor of GOT as follows.

Set the terminating resistor setting switch of the GOT main unit to "100 OHM".

Page 189 Connecting terminating resistors

*4 Connect FG grounding to the single-sided end of a cable shield line.

■RS485 connection diagram 5)




*1 Pin No. of Model of control equipment differs depending on the model. Refer to the following table.

Signal name	Model of control equipment			
	DMC10	SDC15	SDC25/26 SDC35/36	AUR350C AUR450C
	Pin No.	Pin No.	Pin No.	Pin No.
DA	4	16	22	DA
DB	5	17	23	DB
SG	6	18	24	SG


*2 Set the terminating resistor of GOT as follows.

Set the terminating resistor setting switch of the GOT main unit to "Disable".

 Page 189 Connecting terminating resistors

*3 Connect FG grounding to the single-sided end of a cable shield line.

■RS485 connection diagram 6)



*1 Pin No. of control equipment differs depending on model or optional function model.

Refer to the following table. The numbers in () of the following table correspond to optional function models.

Signal name	Model of control equipment						
	SDC20		SDC21	SDC30	SDC31		SDC40A/40B/40G
	(02, 04)	(09)	(03, 06, 08)	(040, 041)	(045)	(446, 546)	
	Pin No.	Pin No.	Pin No.	Pin No.	Pin No.	Pin No.	Pin No.
RDA	17	18	27	18	18	27	59
RDB	18	19	28	19	19	28	60
SDA	15	16	25	16	16	25	57
SDB	16	17	26	17	17	26	58
SG	5	5	29	5	5	29	61
FG	3, 4	3, 4	3, 4	3, 4	3, 4	3, 4	3

Signal name	Model of control equipment			
	CMF050	PBC201-VN2	CMC10B	AHC2001
	CML			
	Pin No.	Pin No.	Pin No.	Pin No.
RDA	7	14	13	3
RDB	8	15	14	2
SDA	9	12	11	5
SDB	10	13	12	4
SG	12	16	15	1
FG	19	3	-	-

*2 Terminating resistor should be provided for a control equipment which will be a terminal.

*3 Set the terminating resistor of GOT as follows.


For GT27 and GT25 (except for GT2505-V), set the terminating resistor to "Enable".

For GT2505-V and GT21, set the terminating resistor to "330 Ω".

☞ Page 189 Connecting terminating resistors

*4 Connect FG grounding to the single-sided end of a cable shield line.

■RS485 connection diagram 7)



*1 Pin No. of control equipment differs depending on model or optional function model.

Refer to the following table. The numbers in () of the following table correspond to optional function models.

Signal name	Model of control equipment						
	SDC20		SDC21	SDC30	SDC31		SDC40A/40B/40G
	(02, 04)	(09)	(03, 06, 08)	(040, 041)	(045)	(446, 546)	
	Pin No.	Pin No.	Pin No.	Pin No.	Pin No.	Pin No.	Pin No.
RDA	17	18	27	18	18	27	59
RDB	18	19	28	19	19	28	60
SDA	15	16	25	16	16	25	57
SDB	16	17	26	17	17	26	58
SG	5	5	29	5	5	29	61
FG	3, 4	3, 4	3, 4	3, 4	3, 4	3, 4	3

Signal name	Model of control equipment			
	CMF050 CML	PBC201-VN2	CMC10B	AHC2001
	Pin No.	Pin No.	Pin No.	Pin No.
RDA	7	14	13	3
RDB	8	15	14	2
SDA	9	12	11	5
SDB	10	13	12	4
SG	12	16	15	1
FG	19	3	-	-

*2 Terminating resistor should be provided for a control equipment which will be a terminal.


*3 Set the terminating resistor of GOT as follows.

Set the terminating resistor setting switch of the GOT main unit to "100 OHM".

☞ Page 189 Connecting terminating resistors

*4 Connect FG grounding to the single-sided end of a cable shield line.

■RS485 connection diagram 8)



*1 Terminating resistor should be provided for a temperature controller which will be a terminal.


*2 Set the terminating resistor of GOT as follows.

Set the terminating resistor setting switch of the GOT main unit to "100 OHM".

☞ Page 189 Connecting terminating resistors

*3 Connect FG grounding to the single-sided end of a cable shield line.

■RS485 connection diagram 9)



*1 Terminating resistor should be provided for a temperature controller which will be a terminal.

*2 Set the terminating resistor of GOT as follows.


For GT27 and GT25 (except for GT2505-V), set the terminating resistor to "Enable".

For GT2505-V and GT21, set the terminating resistor to "330 Ω".

☞ Page 189 Connecting terminating resistors

*3 Connect FG grounding to the single-sided end of a cable shield line.

■RS485 connection diagram 10)




*1 Set the terminating resistor of GOT as follows.

Set the terminating resistor setting switch of the GOT main unit to "100 OHM".

☞ Page 189 Connecting terminating resistors

*2 Connect FG grounding to the single-sided end of a cable shield line.

■RS485 connection diagram 11)




*1 Set the terminating resistor of GOT as follows.

Set the terminating resistor setting switch of the GOT main unit to "100 OHM".

☞ Page 189 Connecting terminating resistors

*2 Connect FG grounding to the single-sided end of a cable shield line.

■RS485 connection diagram 12)



*1 Pin No. of control equipment differs depending on the model. Refer to the following table.


Signal name	Model of control equipment			
	DMC10	SDC15	SDC25/26 SDC35/36	AUR350C AUR450C
	Pin No.	Pin No.	Pin No.	Pin No.
DA	4	16	22	DA
DB	5	17	23	DB
SG	6	18	24	SG

*2 For GT27 and GT25 except GT2505-V, set the terminating resistor to disable.
For GT2505-V and GT21, set the terminating resistor to OPEN.

☞ Page 189 Connecting terminating resistors

*3 Connect FG grounding to the single-sided end of a cable shield line.

■RS485 connection diagram 13)




*1 For GT27 and GT25 (except for GT2505-V), set the terminating resistor to "Enable".
For GT2505-V and GT21, set the terminating resistor to "110 Ω".

☞ Page 189 Connecting terminating resistors

*2 Connect FG grounding to the single-sided end of a cable shield line.

■RS485 connection diagram 14)



*1 Pin No. of control equipment differs depending on the model. Refer to the following table.

Signal name	Model of control equipment						
	SDC20		SDC21	SDC30	SDC31		SDC40A/40B/40G
	(02, 04)	(09)	(03, 06, 08)	(040, 041)	(045)	(446, 546)	
	Pin No.	Pin No.	Pin No.	Pin No.	Pin No.	Pin No.	Pin No.
RDA	17	18	27	18	18	27	59
RDB	18	19	28	19	19	28	60
SDA	15	16	25	16	16	25	57
SDB	16	17	26	17	17	26	58
SG	5	5	29	5	5	29	61
FG	3, 4	3, 4	3, 4	3, 4	3, 4	3, 4	3

Signal name	Model of control equipment			
	CMF050	PBC201-VN2	CMC10B	AHC2001
	CML			
	Pin No.	Pin No.	Pin No.	Pin No.
RDA	7	14	13	3
RDB	8	15	14	2
SDA	9	12	11	5
SDB	10	13	12	4
SG	12	16	15	1
FG	19	3	-	-

*2 Terminating resistor should be provided for a control equipment which will be a terminal.


*3 Set the terminating resistor of GOT as follows.

Set the terminating resistor setting switch of the GOT main unit to "100 OHM".

☞ Page 189 Connecting terminating resistors

*4 Connect FG grounding to the single-sided end of a cable shield line.

■RS485 connection diagram 15)



*1 Pin No. of control equipment differs depending on the model. Refer to the following table.

Signal name	Model of control equipment			
	SDC20		SDC21	SDC40A/40B/40G
	(02, 04)	(09)	(03, 06, 08)	
	Pin No.	Pin No.	Pin No.	Pin No.
RDA	17	18	27	59
RDB	18	19	28	60
SDA	15	16	25	57
SDB	16	17	26	58
SG	5	5	29	61
FG	3, 4	3, 4	3, 4	3

Signal name	Model of control equipment			
	CMF050 CML	PBC201-VN2	CMC10B	AHC2001
	Pin No.	Pin No.	Pin No.	Pin No.
RDA	7	14	13	3
RDB	8	15	14	2
SDA	9	12	11	5
SDB	10	13	12	4
SG	12	16	15	1
FG	19	3	-	-


*2 Terminating resistor should be provided for a control equipment which will be a terminal.

*3 For GT27 and GT25 (except for GT2505-V), set the terminating resistor to "Enable".
For GT2505-V and GT21, set the terminating resistor to "110 Ω".

☞ Page 189 Connecting terminating resistors

*4 Connect FG grounding to the single-sided end of a cable shield line.

■RS485 connection diagram 16)



*1 Pin No. of control equipment differs depending on the model. Refer to the following table.

Signal name	Model of control equipment						
	SDC20		SDC21	SDC30	SDC31		SDC40A/40B/40G
	(02, 04)	(09)	(03, 06, 08)	(040, 041)	(045)	(446, 546)	
	Pin No.	Pin No.	Pin No.	Pin No.	Pin No.	Pin No.	Pin No.
RDA	17	18	27	18	18	27	59
RDB	18	19	28	19	19	28	60
SDA	15	16	25	16	16	25	57
SDB	16	17	26	17	17	26	58
SG	5	5	29	5	5	29	61
FG	3, 4	3, 4	3, 4	3, 4	3, 4	3, 4	3

Signal name	Model of control equipment			
	CMF050 CML	PBC201-VN2	CMC10B	AHC2001
	Pin No.	Pin No.	Pin No.	Pin No.
RDA	7	14	13	3
RDB	8	15	14	2
SDA	9	12	11	5
SDB	10	13	12	4
SG	12	16	15	1
FG	19	3	-	-

*2 Terminating resistor should be provided for a control equipment which will be a terminal.


*3 Set the terminating resistor of GOT as follows.

Set the terminating resistor setting switch of the GOT main unit to "100 OHM".

☞ Page 189 Connecting terminating resistors

*4 Connect FG grounding to the single-sided end of a cable shield line.

■RS485 connection diagram 17)



*1 Pin No. of control equipment differs depending on the model. Refer to the following table

Signal name	Model of control equipment				
	SDC45/46	CMS CMF015	MQV MPC	MVF	RX
	Pin No.	Pin No.	Pin No.	Pin No.	Pin No.
DA	C10	5	7	1	1
DB	C11	6	8	2	2
SG	C12	10	9	7	3

*2 Terminating resistor should be provided for an Interface converter and a control equipment which will be terminals.


*3 Connect FG grounding to the single-sided end of a cable shield line.

*4 Since the Interface converter has a built-in terminating resistor, set the terminating resistor of GOT to "Enable".

For details of terminating resistor settings, refer to the following.

☞ Page 195 Connecting to CMC10L

■RS485 connection diagram 18)



*1 Pin No. of control equipment differs depending on the model. Refer to the following table

Signal name	Model of control equipment				
	SDC45/46	CMS CMF015	MQV MPC	MVF	RX
	Pin No.	Pin No.	Pin No.	Pin No.	Pin No.
DA	C10	5	7	1	1
DB	C11	6	8	2	2
SG	C12	10	9	7	3

*2 Terminating resistor should be provided for an Interface converter and a control equipment which will be terminals.


*3 Connect FG grounding to the single-sided end of a cable shield line.

*4 Set the terminating resistor of GOT as follows.

Set the terminating resistor setting switch of the GOT main unit to "Disable".

☞ Page 189 Connecting terminating resistors

■RS485 connection diagram 19)



*1 Pin No. of control equipment differs depending on the model. Refer to the following table

Signal name	Model of control equipment				
	SDC45/46	CMS CMF015	MQV MPC	MVF	RX
	Pin No.	Pin No.	Pin No.	Pin No.	Pin No.
DA	C10	5	7	1	1
DB	C11	6	8	2	2
SG	C12	10	9	7	3

*2 Terminating resistor should be provided for an Interface converter and a control equipment which will be terminals.


*3 Connect FG grounding to the single-sided end of a cable shield line.

*4 Set the terminating resistor of GOT as follows.

Set the terminating resistor setting switch of the GOT main unit to "Disable".

☞ Page 189 Connecting terminating resistors

■RS485 connection diagram 20)



*1 Pin No. of control equipment differs depending on the model. Refer to the following table

Signal name	Model of control equipment				
	SDC45/46	CMS CMF015	MQV MPC	MVF	RX
	Pin No.	Pin No.	Pin No.	Pin No.	Pin No.
DA	C10	5	7	1	1
DB	C11	6	8	2	2
SG	C12	10	9	7	3

*2 For GT27 and GT25 (except for GT2505-V), terminating resistor should be provided for an Interface converter and a control equipment which will be terminals.

*3 Connect FG grounding to the single-sided end of a cable shield line.


*4 Set the terminating resistor of GOT as follows.

For GT27 and GT25 (except for GT2505-V), set the terminating resistor to "Disable".

For GT2505-V and GT21, set the terminating resistor to "110 Ω".

☞ Page 189 Connecting terminating resistors

■RS485 connection diagram 21)



*1 Pin No. of control equipment differs depending on the model. Refer to the following table.

Signal name	Model of control equipment			
	DMC10	SDC15	SDC25/26 SDC35/36	AUR350C AUR450C
	Pin No.	Pin No.	Pin No.	Pin No.
DA	4	16	22	DA
DB	5	17	23	DB
SG	6	18	24	SG


*2 Set the terminating resistor setting switch to OPEN.

☞ Page 189 Connecting terminating resistors

*3 Connect FG grounding to the single-sided end of a cable shield line.

*4 The signals RSA, RSB, CSA, and CSB are not provided for GT2104-PMBD, GT2103-PMBD. Return connection is not required.

■RS485 connection diagram 22)



*1 Terminating resistor should be provided for a temperature controller which will be a terminal.

*2 Set the terminating resistor of GOT as follows.


Set the terminating resistor setting switch of the GOT main unit to "330Ω".

☞ Page 189 Connecting terminating resistors

*3 Connect FG grounding to the single-sided end of a cable shield line.

*4 The signals RSA, RSB, CSA, and CSB are not provided for GT2104-PMBD, GT2103-PMBD. Return connection is not required.

■RS485 connection diagram 23)




*1 Set the terminating resistor setting switch of the GOT main unit to "110Ω".

☞ Page 189 Connecting terminating resistors

*2 Connect FG grounding to the single-sided end of a cable shield line.

*3 The signals RSA, RSB, CSA, and CSB are not provided for GT2104-PMBD, GT2103-PMBD. Return connection is not required.

■RS485 connection diagram 24)



*1 Pin No. of control equipment differs depending on model and optional function model.

Refer to the following table. The numbers in () of the following table correspond to optional function models.

Signal name	Model of control equipment						
	SDC20		SDC21	SDC30	SDC31		SDC40A/40B/40G
	(02, 04)	(09)	(03, 06, 08)	(040, 041)	(045)	(446, 546)	
	Pin No.	Pin No.	Pin No.	Pin No.	Pin No.	Pin No.	Pin No.
RDA	17	18	27	18	18	27	59
RDB	18	19	28	19	19	28	60
SDA	15	16	25	16	16	25	57
SDB	16	17	26	17	17	26	58
SG	5	5	29	5	5	29	61
FG	3, 4	3, 4	3, 4	3, 4	3, 4	3, 4	3

Signal name	Model of control equipment			
	CMF050 CML	PBC201-VN2	CMC10B	AHC2001
	Pin No.	Pin No.	Pin No.	Pin No.
RDA	7	14	13	3
RDB	8	15	14	2
SDA	9	12	11	5
SDB	10	13	12	4
SG	12	16	15	1
FG	19	3	-	-

*2 Terminating resistor should be provided for a control equipment which will be a terminal.

*3 Set the terminating resistor of GOT as follows.


Set the terminating resistor setting switch of the GOT main unit to "330Ω".

☞ Page 189 Connecting terminating resistors

*4 Connect FG grounding to the single-sided end of a cable shield line.

*5 The signals RSA, RSB, CSA, and CSB are not provided for GT2104-PMBD, GT2103-PMBD. Return connection is not required.

■RS485 connection diagram 25)



*1 Pin No. of control equipment differs depending on the model. Refer to the following table.

Signal name	Model of control equipment			
	SDC20		SDC21	SDC40A/40B/40G
	(02, 04)	(09)	(03, 06, 08)	
	Pin No.	Pin No.	Pin No.	Pin No.
RDA	17	18	27	59
RDB	18	19	28	60
SDA	15	16	25	57
SDB	16	17	26	58
SG	5	5	29	61
FG	3, 4	3, 4	3, 4	3

Signal name	Model of control equipment			
	CMF050 CML	PBC201-VN2	CMC10B	AHC2001
	Pin No.	Pin No.	Pin No.	Pin No.
RDA	7	14	13	3
RDB	8	15	14	2
SDA	9	12	11	5
SDB	10	13	12	4
SG	12	16	15	1
FG	19	3	-	-

*2 Terminating resistor should be provided for a control equipment which will be a terminal.


*3 Set the terminating resistor setting switch of the GOT main unit to "110Ω".

☞ Page 189 Connecting terminating resistors

*4 Connect FG grounding to the single-sided end of a cable shield line.

*5 The signals RSA, RSB, CSA, and CSB are not provided for GT2104-PMBD, GT2103-PMBD. Return connection is not required.

■RS485 connection diagram 26)



*1 Pin No. of control equipment differs depending on the model. Refer to the following table.

Signal name	Model of control equipment				
	SDC45/46	CMS CMF015	MQV MPC	MVF	RX
	Pin No.	Pin No.	Pin No.	Pin No.	Pin No.
DA	C10	5	7	1	1
DB	C11	6	8	2	2
SG	C12	10	9	7	3

*2 Terminating resistor should be provided for an Interface converter and a control equipment which will be terminals.

*3 Connect FG grounding to the single-sided end of a cable shield line.


*4 Set the terminating resistor of GOT as follows.

Set the terminating resistor setting switch of the GOT main unit to "110Ω".

☞ Page 189 Connecting terminating resistors

*5 The signals RSA, RSB, CSA, and CSB are not provided for GT2104-PMBD, GT2103-PMBD. Return connection is not required.

■RS485 connection diagram 27)



*1 Pin No. of control equipment differs depending on the model. Refer to the following table.

Signal name	Model of control equipment			
	DMC10	SDC15	SDC25/26 SDC35/36	AUR350C AUR450C
	Pin No.	Pin No.	Pin No.	Pin No.
DA	4	16	22	DA
DB	5	17	23	DB
SG	6	18	24	SG

*2 Set the 2-wire/4-wire terminating resistor setting switch of the RS-232/485 signal conversion adaptor as shown below.


2-wire/4-wire: 2-wire (1Pair)

Terminating resistor: OPEN

☞ Page 67 Setting the RS-232/485 signal conversion adaptor

*3 Connect FG grounding to the single-sided end of a cable shield line.

■RS485 connection diagram 28)




*1 Terminating resistor should be provided for a temperature controller which will be a terminal.

*2 Set the 2-wire/4-wire terminating resistor setting switch of the RS-232/485 signal conversion adaptor as shown below.
2-wire/4-wire: 4-wire (2Pair)
Terminating resistor: 330 Ω

☞ Page 67 Setting the RS-232/485 signal conversion adaptor

*3 Connect FG grounding to the single-sided end of a cable shield line.

■RS485 connection diagram 29)




*1 Set the 2-wire/4-wire terminating resistor setting switch of the RS-232/485 signal conversion adaptor as shown below.
2-wire/4-wire: 2-wire (1Pair)
Terminating resistor: 110 Ω

☞ Page 67 Setting the RS-232/485 signal conversion adaptor

*2 Connect FG grounding to the single-sided end of a cable shield line.

■RS485 connection diagram 30)



*1 Pin No. of control equipment differs depending on model and optional function model.

Refer to the following table.

The numbers in () of the following table correspond to optional function models.

Signal name	Model of control equipment						
	SDC20		SDC21	SDC30	SDC31		SDC40A/40B/40G
	(02, 04)	(09)	(03, 06, 08)	(040, 041)	(045)	(446, 546)	
	Pin No.	Pin No.	Pin No.	Pin No.	Pin No.	Pin No.	Pin No.
RDA	17	18	27	18	18	27	59
RDB	18	19	28	19	19	28	60
SDA	15	16	25	16	16	25	57
SDB	16	17	26	17	17	26	58
SG	5	5	29	5	5	29	61
FG	3, 4	3, 4	3, 4	3, 4	3, 4	3, 4	3

Signal name	Model of control equipment			
	CMF050 CML	PBC201-VN2	CMC10B	AHC2001
	Pin No.	Pin No.	Pin No.	Pin No.
RDA	7	14	13	3
RDB	8	15	14	2
SDA	9	12	11	5
SDB	10	13	12	4
SG	12	16	15	1
FG	19	3	-	-

*2 Terminating resistor should be provided for a control equipment which will be a terminal.

*3 Set the 2-wire/4-wire terminating resistor setting switch of the RS-232/485 signal conversion adaptor as shown below.


2-wire/4-wire: 4-wire (2Pair)

Terminating resistor: 330 Ω

☞ Page 67 Setting the RS-232/485 signal conversion adaptor

*4 Connect FG grounding to the single-sided end of a cable shield line.

■RS485 connection diagram 31)



*1 Pin No. of control equipment differs depending on model and optional function model.
Refer to the following table.

The numbers in () of the following table correspond to optional function models.

Signal name	Model of control equipment						
	SDC20		SDC21	SDC30	SDC31		SDC40A/40B/40G
	(02, 04)	(09)	(03, 06, 08)	(040, 041)	(045)	(446, 546)	
	Pin No.	Pin No.	Pin No.	Pin No.	Pin No.	Pin No.	Pin No.
RDA	17	18	27	18	18	27	59
RDB	18	19	28	19	19	28	60
SDA	15	16	25	16	16	25	57
SDB	16	17	26	17	17	26	58
SG	5	5	29	5	5	29	61
FG	3, 4	3, 4	3, 4	3, 4	3, 4	3, 4	3

Signal name	Model of control equipment			
	CMF050 CML	PBC201-VN2	CMC10B	AHC2001
	Pin No.	Pin No.	Pin No.	Pin No.
RDA	7	14	13	3
RDB	8	15	14	2
SDA	9	12	11	5
SDB	10	13	12	4
SG	12	16	15	1
FG	19	3	-	-


*2 Terminating resistor should be provided for a control equipment which will be a terminal.

*3 Set the 2-wire/4-wire terminating resistor setting switch of the RS-232/485 signal conversion adapter as shown below.
2-wire/4-wire: 2-wire (1Pair)
Terminating resistor: 110 Ω

☞ Page 67 Setting the RS-232/485 signal conversion adaptor

*4 Connect FG grounding to the single-sided end of a cable shield line.

■RS485 connection diagram 32)



*1 Pin No. of control equipment differs depending on the model. Refer to the following table.

Signal name	Model of control equipment				
	SDC45/46	CMS CMF015	MQV MPC	MVF	RX
	Pin No.	Pin No.	Pin No.	Pin No.	Pin No.
DA	C10	5	7	1	1
DB	C11	6	8	2	2
SG	C12	10	9	7	3

*2 Terminating resistor should be provided for an Interface converter and a control equipment which will be terminals.

*3 Connect FG grounding to the single-sided end of a cable shield line.

*4 Set the 2-wire/4-wire terminating resistor setting switch of the RS-232/485 signal conversion adapter as shown below.

2-wire/4-wire: 2-wire (1Pair)

Terminating resistor: OPEN

☞ Page 67 Setting the RS-232/485 signal conversion adaptor

Precautions when preparing a cable

■Cable length

The length of the RS-485 cable must be 500m or less.

■GOT side connector

For the GOT side connector, refer to the following.

☞ Page 58 GOT connector specifications

■AZBIL control equipment side connector

Use the connector compatible with the AZBIL control equipment side module.

For details, refer to the user's manual of the AZBIL control equipment.

Connecting terminating resistors

■GOT side

Set the terminating resistor by operating the terminating resistor setting switch.

For the procedure to set the terminating resistor, refer to the following.

☞ Page 62 Terminating resistors of GOT

■AZBIL control equipment side


When connecting a AZBIL control equipment to the GOT, a terminating resistor must be connected.

☞ Page 193 Control Equipment Side Setting

3.4 GOT Side Settings

Setting communication interface (Communication settings)

Set the channel of the equipment to be connected to the GOT.



1. Select [Common] → [Controller Setting] from the menu.
2. In the [Controller Setting] window, select the channel No. to be used from the list menu.
3. Set the following items.
 - [Manufacturer]: [Azbil]
 - [Controller Type]

When connecting to DMC50 or AHC2001: [Azbil DMC50]

When connecting to models other than the above: [Azbil SDC/DMC]

- [I/F]: Interface to be used
- [Detail Setting]: Configure the settings according to the usage environment.

☞ Page 191 Communication detail settings

4. When you have completed the settings, click the [OK] button.

Point

The settings of connecting equipment can be confirmed in [I/F Communication Setting].

For details, refer to the following.

☞ Page 47 I/F communication setting

Communication detail settings

Property	Value
Transmission Speed(BPS)	9600
Data Bit	8 bit
Stop Bit	1 bit
Parity	Even
Retry(Times)	0
Timeout Time(Sec)	3
Host Address	1
Delay Time(ms)	10
Format	1

Item	Description	Range
Transmission Speed	Set this item when change the transmission speed used for communication with the connected equipment. (Default: 9600bps)	9600bps, 19200bps, 38400bps, 57600bps, 115200bps
Data Bit	Set this item when change the data length used for communication with the connected equipment. (Default: 8bits)	7bits/8bits
Stop Bit	Specify the stop bit length for communications. (Default: 1bit)	1bit/2bits
Parity	Specify whether or not to perform a parity check, and how it is performed during communication. (Default: Even)	None Even Odd
Retry	Set the number of retries to be performed when a communication error occurs. (Default: 0time)	0 to 5times
Timeout Time	Set the time period for a communication to time out. (Default: 3sec)	1 to 30sec
Host Address ^{*3*4}	Specify the host address (station No. of the GOT to which the temperature controller is connected) in the connected network. (Default: 1)	1 to 15
Delay Time	Set this item to adjust the transmission timing of the communication request from the GOT. ^{*1} (Default: 10ms)	0 to 300ms
Format ^{*2}	Select the communication format. (Default: 1) format 1: only continuous access format 2: continuous and random access	1/2

*1 Do not specify "0".

*2 Format is ignored when connecting to DMC50.

*3 Host Address is ignored when connecting to DMC10 or SDC.

*4 Host Address is valid when connecting to DMC50.

Devices to be the target of Host Address setting differ depending on the system configuration.

<When connecting to the temperature controller via COM module>

Specify the station No. of the COM module.

<When connecting to the temperature controller directly>

Specify the station No. of the temperature controller.

- Format setting

The compatible format of control equipment differs depending on model.

Model name	Compatible format
SDC20/21, SDC30/31, SDC40A/40B/40G, CMS, CMF, CML, MQV, MPC, MVF, PBC201-VN2, RX	Format 1 only
DMC10, SDC15, SDC25/26, SDC35/36, SDC45/46, AUR350C, AUR450C, CMC10B	Format 1 or Format 2
DMC50, AHC2001	The format setting is invalid.


For the continuous access and random access of the control equipment, refer to the following manual.

 User's Manual of the AZBIL control equipment

- Communication interface setting by the Utility

The communication interface setting can be changed on the Utility's [Communication setting] after writing [Communication Settings] of project data.

For details on the Utility, refer to the following manual.

 GOT2000 Series User's Manual (Utility)

- Precedence in communication settings

When settings are made by GT Designer3 or the Utility, the latest setting is effective.

3.5 Control Equipment Side Setting



AZBIL control equipment

For details of AZBIL control equipment, refer to the following manual.

☞ User's Manual of the AZBIL control equipment

Model name		Refer to
Control equipment	DMC10	☞ Page 193 Connecting to DMC10
	SDC15, SDC25/26, SDC35/36	☞ Page 194 Connecting to SDC15, SDC25/26 or SDC35/36
	SDC20/21	☞ Page 195 Connecting to SDC20/21, SDC30/31
	SDC30/31	☞ Page 195 Connecting to SDC20/21, SDC30/31
	SDC40A/40B/40G	☞ Page 194 Connecting to SDC40A/40B/40G
	DMC50	☞ Page 197 Connecting to DMC50
	SDC45/46	☞ Page 197 Connecting to SDC45/46
	CMS, CMF015	☞ Page 198 Connecting to CMS, CMF015
	CML, CMF050	☞ Page 198 Connecting to CML, CMF050
	MQV	☞ Page 198 Connecting to MQV
	MPC	☞ Page 199 Connecting to MPC
	PBC201-VN2	☞ Page 199 Connecting to PBC201-VN2
	MVF	☞ Page 199 Connecting to MVF
	AUR350C, AUR450C	☞ Page 201 Connecting to AUR350C, AUR450C
	RX	☞ Page 202 Connecting to RX
	CMC10B	☞ Page 202 Connecting to CMC10B
	AHC2001 CPU	☞ Page 203 Connecting to AHC2001 CPU
	AHC2001 SCU	☞ Page 203 Connecting to AHC2001 SCU
Interface converter	CMC10L	☞ Page 195 Connecting to CMC10L

Connecting to DMC10

Communication settings

Make the communication settings by operating the Smart Loader Package (SLP-D10) of the temperature controller.

Item	Set value
Transmission speed ^{*1}	9600bps, 19200bps
Communication mode ^{*2}	CPL
Data bit	8bits
Parity bit ^{*1}	Even, none
Stop bit	2bits
Communication minimum response time	1ms, 10ms, 100ms, 200ms
Station address ^{*3*4}	0 to F

*1 Adjust the settings with GOT settings.


*2 Set to CPL.

*3 Do not set to "0".

*4 Select the station address without overlapping with that of other units.

Station address setting

Set the station address using the rotary switch for the station address.



Connecting to SDC40A/40B/40G

Communication settings

Make the communication settings by operating the key of the temperature controller.

Item	Set value
Transmission speed ^{*1}	9600bps
Data Bit	8bits
Parity bit ^{*1}	Even, none
Stop bit	1bit, 2bits
Station address ^{*2*3}	0 to 127

*1 The transmission speed setting must be consistent with that of the GOT side.

*2 Do not set to "0".

*3 Select the station address without overlapping with that of other units.

Connecting to SDC15, SDC25/26 or SDC35/36

Communication settings

Make the communication settings by operating the key or Smart Loader Package (SLP-C35) of the temperature controller.

Item	Set value
Transmission speed ^{*1}	9600bps, 19200bps
Communication mode ^{*2}	CPL
Data bit ^{*1}	7bits, 8bits
Parity bit ^{*1}	Odd, even, none
Stop bit ^{*1}	1bit, 2bits
Communication minimum response time	1 to 250ms
Station address ^{*3*4}	0 to 127

*1 The transmission speed setting must be consistent with that of the GOT side.

*2 Set to CPL.

*3 Do not set to "0".

*4 Select the station address without overlapping with that of other units.

Connecting to SDC20/21, SDC30/31

Communication settings

Make the communication settings by operating the key of the temperature controller.

Item	Set value
Transmission speed ^{*1}	9600bps
Data bit	8bits
Parity bit	Disable
Stop bit	2bits
Station address ^{*2*3}	0 to 127

*1 The transmission speed setting must be consistent with that of the GOT side.

*2 Do not set to "0".

*3 Select the station address without overlapping with that of other units.

Connecting to CMC10L

Communication settings


Make the communication settings by operating the DIP switch of the Interface converter

Item	Set value
Transmission speed ^{*1}	9600bps, 19200bps, 38400bps
Frame length ^{*2}	9 to 15bits

*1 The transmission speed setting must be consistent with that of the GOT side.

*2 The sum of data length, parity bit and stop bit


Settings by switch



Front view of CMC10L body Rear view of CMC10L body

■Setting DIP switches

- Transmission speed settings




Transmission speed (bps)	Switch No.		
	1	2	3
9600	ON	OFF	ON
19200	OFF	ON	ON
38400	ON	ON	ON

• Frame length settings



Frame length	Switch No.		
	4	5	6
8bits	OFF	OFF	OFF
9bits	ON	OFF	OFF
10bits	OFF	ON	OFF
11bits	ON	ON	OFF
12bits	OFF	OFF	ON
13bits	ON	OFF	ON
14bits	OFF	ON	ON
15bits	ON	ON	ON


• Connecting terminating resistors



Terminating resistor	Switch No.
	8
Enable	ON
Disable	OFF

■Mode selector switch settings

Set the switch to “TERMINAL”.



Connecting to DMC50

Communication settings

Make the communication settings by operating the Smart Loader Package (SLP-D50/SLP-H21) of the temperature controller.

Item	Set value
Transmission speed ^{*1}	9600bps, 19200bps, 38400bps
Communication mode	CPL
Data bit	8bits (fixed)
Parity bit	Even (fixed)
Stop bit	1bit (fixed)
Module address ^{*2*3*4}	0 to F

*1 Adjust the settings with GOT settings.


*2 Set the module address using the rotary switch for module address.

*3 Do not set to "0".

*4 Select the module address without overlapping with that of other units.

Module address setting

Set the module address using the rotary switch for module address.



Connecting to SDC45/46

Communication settings

Make the communication settings by operating the Smart Loader Package (SLP-C45) of the temperature controller.

Item	Set value
Transmission speed ^{*1}	9600bps, 19200bps, 38400bps
Communication mode ^{*2}	CPL
Data bit	7bits, 8bits
Parity bit ^{*1}	Odd, even, none
Stop bit	1bit, 2bits
Communication minimum response time ^{*5}	1 to 250ms
Station address ^{*3*4}	0 to 120

*1 Adjust the settings with GOT settings.

*2 Set to CPL.

*3 Do not set to "0".

*4 Select the station address without overlapping with that of other units.

*5 When using the interface converter CMC10L, set the communication minimum response time to 3ms or more.

Connecting to CMS, CMF015

Communication settings

Make the communication settings by operating the key of the control equipment.

Item	Set value
Transmission speed ^{*1}	9600bps
Communication condition selection	0: 8-bit data length, Even parity, Stop bit 1
	1: 8-bit data length, Non parity, Stop bit 2
Station address ^{*2*3}	0 to 99

*1 Adjust the settings with GOT settings.

*2 Do not set to "0".

*3 Select the station address without overlapping with that of other units.

Connecting to CML, CMF050

Communication settings

Make the communication settings by operating the key of the control equipment.

Item	Set value
Transmission speed ^{*1}	9600bps
Communication condition selection ^{*1}	00: 8-bit data length, Even parity, Stop bit 1
	01: 8-bit data length, Non parity, Stop bit 2
Station address ^{*2*3}	0 to 7F

*1 Adjust the settings with GOT settings.

*2 Do not set to "0".

*3 Select the station address without overlapping with that of other units.

Connecting to MQV

Communication settings

Make the communication settings by operating the key of the control equipment.

Item	Set value
Transmission speed ^{*1}	9600bps, 19200bps, 38400bps
Communication condition selection ^{*1}	00: 8-bit data length, Even parity, Stop bit 1
	01: 8-bit data length, Non parity, Stop bit 2
Station address ^{*2*3}	0 to 127

*1 Adjust the settings with GOT settings.

*2 Do not set to "0".

*3 Select the station address without overlapping with that of other units.

Connecting to MPC

Communication settings

Make the communication settings by operating the key of the control equipment.

Item	Set value
Transmission speed ^{*1}	9600bps, 19200bps, 38400bps
Communication condition selection ^{*1}	0: 8-bit data length, Even parity, Stop bit 1
	1: 8-bit data length, Non parity, Stop bit 2
Station address ^{*2*3}	0 to 127

*1 Adjust the settings with GOT settings.

*2 Do not set to "0".

*3 Select the station address without overlapping with that of other units.

Connecting to PBC201-VN2

Communication settings

Make the communication settings by operating the key of the control equipment.

Item	Set value
Communication protocol	CPL
Transmission speed ^{*1}	9600bps, 19200bps, 38400bps, 115200bps
Communication condition selection ^{*1} (Fixed 8-bit data length)	0: Even parity, Stop bit 1
	1: Odd parity, Stop bit 1
	2: Non parity, Stop bit 2
Station address ^{*2*3}	0 to 126

*1 Adjust the settings with GOT settings.

*2 Do not set to "0".

*3 Select the station address without overlapping with that of other units.

Connecting to MVF

Communication settings

Make the communication settings by operating the switch of the control equipment.


Item	Set value
Transmission speed ^{*1}	9600bps, 19200bps
Communication condition selection ^{*1}	8-bit data length, Even parity, Stop bit 1
	8-bit data length, Non parity, Stop bit 2
Station address ^{*2*3}	0 to F

*1 Adjust the settings with GOT settings.

*2 Do not set to "0".


*3 Select the station address without overlapping with that of other units.

Settings by switch



■Transmission speed settings

Set the communication condition switch.



Transmission speed (bps)	Switch No.		
	1	2	3
9600	ON	ON	OFF
19200	ON	OFF	OFF

■Communication condition selection


Set the communication condition switch.

Communication condition	Switch No.
	4
8-bit data length, Even parity, Stop bit 1	OFF
8-bit data length, Non parity, Stop bit 2	ON

■Station address setting

Set the station address switch.

Station No. setting switch



Connecting to AUR350C, AUR450C

Communication settings

Make the communication settings by operating the Smart Loader Package (SLP-A35, SLP-A45) of the control equipment.


Item	Set value
Transmission speed*1	9600bps, 19200bps
Communication condition selection*1	8-bit data length, Even parity, Stop bit 1
	8-bit data length, Non parity, Stop bit 2
Station address*2*3	0 to F

- *1 Adjust the settings with GOT settings.
- *2 Do not set to "0".
- *3 Select the station address without overlapping with that of other units.


Station address setting

Set the station address switch.

■For AUR350C



■For AUR450C



Connecting to RX

Communication settings

Make the communication settings by operating the Smart Loader Package (SLP-RX) of the control equipment.

Item	Set value
Transmission speed ^{*1}	9600bps, 19200bps, 38400bps
Communication condition selection ^{*1}	Even parity stop 1 (8-bit data length, Even parity, Stop bit 1)
	Even parity stop 2 (8-bit data length, Even parity, Stop bit 2)
	Odd parity stop 1 (8-bit data length, Odd parity, Stop bit 1)
	Odd parity stop 2 (8-bit data length, Odd parity, Stop bit 2)
Station address ^{*2*3}	1 to 32

*1 Adjust the settings with GOT settings.

*2 Do not set to "0".

*3 Select the station address without overlapping with that of other units.

Connecting to CMC10B

Communication settings

Make the communication settings by operating the Smart Loader Package (SLP-CM1) of the control equipment.

Item	Set value
Transmission speed ^{*1}	9600bps, 19200bps
Communication format ^{*1}	0:8-bit data length, Even parity, Stop bit 1
	1:8-bit data length, Non parity, Stop bit 2
Station address ^{*2*3}	0 to 99


*1 Adjust the settings with GOT settings.

*2 Do not set to "0".

*3 Select the station address without overlapping with that of other units.

Station address setting

Set the station address switch.



Connecting to AHC2001 CPU

Communication settings

Make the communication settings by operating the Smart Loader Package (SLP-D50/SLP-H21) of the temperature controller.

Item	Set value
Transmission speed ^{*1}	9600bps, 19200bps, 38400bps, 57600bps
Communication mode ^{*2}	0: MODBUS 1: CPL
Data bit	8bits (fixed)
Parity bit	Even (fixed)
Stop bit	1bit (fixed)
Station address ^{*3}	1 to 15 ^{*4}

*1 Adjust the settings with GOT settings.

*2 Set this item to 1: CPL.

*3 Select the station address without overlapping with that of other units.

*4 The station address for AHC2001 ranges from 1 to 127. However, use station address from 1 to 15, which are the range for DMC50.

Connecting to AHC2001 SCU

Communication settings

Make the communication settings by operating the Smart Loader Package (SLP-D50/SLP-H21) of the temperature controller.

Item	Set value
Transmission speed ^{*1}	9600bps, 19200bps, 38400bps
Data bit ^{*1}	7bits, 8bits
Parity bit ^{*1}	0: None, 1: Even, 2: Odd
Stop bit ^{*1}	1bit, 2bits
Half duplex/Full duplex ^{*2}	0: Half duplex, 1: Full duplex
Space sending	0 (fixed)
Protocol setup ^{*3}	1 to 30

*1 Adjust the settings with GOT settings.


*2 Set this item to 0: Half duplex.

*3 Set this item to 2: CPL.

Station number setting

Set each station number so that no station number overlaps.

The station number can be set without regard to the cable connection order. There is no problem even if station numbers are not consecutive.



Direct specification

When setting the device, specify the station number of the control equipment of which data is to be changed.

Model name	Specification range
SDC40A/40B/40G, SDC15, SDC25/26, SDC35/36, SDC20/21, SDC30/31, CML, CMF050, MQV, MPC	1 to 127
PBC201-VN2	1 to 126
SDC45/46	1 to 120
CMS, CMF015, CMC10B	1 to 99
RX	1 to 32
DMC10, DMC50, MVF, AUR350C, AUR450C, AHC2001 ^{*1}	1 to 15

^{*1} The station number for AHC2001 ranges from 1 to 127. However, use station numbers from 1 to 15, which are the range for DMC50.

Indirect specification

When setting the device, indirectly specify the station number of the inverter of which data is to be changed using the 16-bit GOT internal data register (GD10 to GD25).

When specifying the station No. from the following table on GT Designer3, the value of GD10 to GD25 compatible to the station No. specification will be the station No. of the control equipment.

Specification station No.		Compatible device	Setting range
DMC50 AHC2001	Other than DMC50		
100	200	GD10	1 to 127: For SDC40A/40B/40G, SDC15, SDC25/26, SDC35/36, SDC20/21, SDC30/31, CML, CMF050, MQV, MPC 1 to 126: PBC201-VN2 1 to 120: SDC45/46 1 to 99: CMS, CMF015, CMC10B 1 to 32: RX 1 to 15: DMC10, DMC50, MVF, AUR350C, AUR450C, AHC2001 ^{*1} For the setting other than the above, error (dedicated device is out of range) will occur.
101	201	GD11	
102	202	GD12	
103	203	GD13	
104	204	GD14	
105	205	GD15	
106	206	GD16	
107	207	GD17	
108	208	GD18	
109	209	GD19	
110	210	GD20	
111	211	GD21	
112	212	GD22	
113	213	GD23	
114	214	GD24	
115	215	GD25	

^{*1} The station number for AHC2001 ranges from 1 to 127. However, use station numbers from 1 to 15, which are the range for DMC50.

3.6 Device Range that Can Be Set

The device ranges of controller that can be used for GOT are as follows.


Note that the device ranges in the following tables are the maximum values that can be set in GT Designer3.

The device specifications of controllers may differ depending on the models, even though belonging to the same series.


Please make the setting according to the specifications of the controller actually used.

When a non-existent device or a device number outside the range is set, other objects with correct device settings may not be monitored.

Setting item



For Azbil SDC/DMC Series



For Azbil DMC50

Item	Description	
Device	Set the device name, device number, and bit number. The bit number can be set only when specifying the bit of word device.	
Information	Displays the device type and setting range which are selected in [Device].	
Network	Set the monitor target of the set device.	
	Station	To monitor the control equipment of the specified station No. <ul style="list-style-type: none"> When Azbil SDC/DMC Series is used. 0 to 127 :To monitor the control equipment of the specified station No. 200 to 215 :To specify the station No. of the control equipment to be monitored by the value of GOT data register (GD).^{*1} When Azbil DMC50 is used. 1 to 15: To specify the station No. of the COM module or control equipment to be monitored. 100 to 115: To specify the station No. of the COM module or control equipment to be monitored, and the Sub Station of the control equipment by the value of GOT data register (GD).^{*2}
	Sub Station	Specify the sub station number of the control equipment connected to the COM module specified in [Station] to monitor it. (0 to 15)If the specified [SubStation] is 0, the COM module/control equipment specified in [Station] is monitored. For AHC2001, the sub station number is ignored.
Switch to the device define dialog	Device definition can be checked.	

^{*1} The following shows the relation between station numbers of the control equipment and the GOT data register.

Station No.	GOT data register (GD)	Setting range
200	GD10	0 to 127 (If setting a value outside the range above, a device range error occurs.)
201	GD11	
:	:	
214	GD24	
215	GD25	

*2 From the value of GD10 to 25, the upper 8bits are set for station No., and the lower 8bits for the Sub Station.
In this case, the setting of [Sub Station] is invalid.
The following shows the relation between station numbers of the control equipment and the GOT data register.

Station No.	GOT data register (GD)	Setting range
100	GD10	0x0000 to 0xFFFF
101	GD11	
:	:	
114	GD24	
115	GD25	

Example: When [Station No.] is set to 100

When [Station No.] is set to 100, the monitoring target is set based on the GD10 value.

GD10 = 0x010A

(Upper 8bits) 0x01 → Station No.: 1

(Lower 8bits) 0x0A → Sub Station: 10



Station No. and Sub Station of AZBIL DMC50

The station No. and Sub Station set when using AZBIL DMC50 correspond to NW No. and Station number of MITSUBISHI ELECTRIC PLC, respectively.

AZBIL SDC/DMC Series

Device name		Setting range	Device No. representation
Bit device	The bit specification of the word device	Setting range of each word device	—
Word device	Data (..)*1	..273 to ..31243	Decimal

*1 Only 16-bit (1-word) designation is allowed.

AZBIL DMC50/AHC2001

Device name		Setting range	Device No. representation
Double word device	Network Addresses (NA)*1	0000 to FFFF	Hexadecimal
	Parameter Addresses (PA)*1	00000 to FFFFF	Hexadecimal

*1 Only 32-bit (2-word) designation is allowed.

Network Addresses (NA)

The following shows the network address settings and definitions.

Network Addresses	Definition
0000	Network Addresses

Parameter Address (PA)

The following shows the parameter address settings and definitions.

Parameter Address	Definition
001	H/W Information
002	Date and Time Setup
021	AI Setup (High resolution type:standard inputs)
022	AI Setup (Special type)
023	AI Setup (High resolution type:option inputs)
041	AUX-IN Setup
045	AO Setup
061	DO Setup
071	TP Setup
0A1	MR20X Communication Setup
0A2	
0A3	Front Port Communication Setup
0C1	System Status
0C5	AI Alarm Log
0C3	Date and Time Display
0C4	System Alarm Log
0C6	AUX-IN Alarm Log
0E1	AI Status
0E2	AUX-IN Status
0E3	AO Status
0E5	DI Status
0E6	DO Status
0E7	TP Status
0E8	Zener Barrier Adjustment Counts
0F1	Present MR20X Communication Setup
0F2	
0F3	Front Port Active Communication Setup
103	Memory Usage Monitor
201	PID_A Options Control Action
202	PID_A Constants Proportional Band
203	PID_A Monitor SP
211	PID_CAS Options Control Action
212	PID_CAS Constants (master) Proportional Band
213	PID_CAS Constants (slave) Proportional Band
214	PID_CAS Monitor M_SP
234	Ra_PID Options Ra-PID Mode
235	Ra_PID Constants Proportional Band
236	Ra_PID Monitor SP
241	UP_PID Options Control Action
242	UP_PID Constants Proportional Band
243	UP_PID Monitor U_SP(Use SP)
301	TBL/TBR Setup Contact Point X1
C00	Pattern Setup
C01 to C63	Segment Setup
CF1	Pattern FB Monitor
801 to 9FF	Type label defined by the user

3.7 Precautions


Station number setting of the temperature controller system

- When connecting to DMC10 or SDC

Make sure to establish temperature controller system with No.1 station.

- When connecting to DMC50 or AHC2001

A COM module or temperature controller with the station number set with the host address must be included.

 Page 191 Communication detail settings


GOT clock control

Since the control equipment does not have a clock function, the settings of "time adjusting" or "time broad cast" by GOT clock control will be disabled.

Disconnecting some of multiple connected equipment

The GOT can disconnect some of multiple connected equipment by setting GOT internal device. For example, the faulty station where a communication timeout error occurs can be disconnected from connected equipment.

For details of GOT internal device setting, refer to the following manual.

 GT Designer3 (GOT2000) Screen Design Manual

When DMC50/AHC2001 and DMC10/SDC are mixed

GOT does not support connections with DMC50/AHC2001 and DMC10/SDC mixed.

Station number range for AHC2001

The station number for AHC2001 ranges from 1 to 127. However, use station numbers from 1 to 15, which are the range for DMC50.

Device range for AHC2001

The GOT only supports some devices for the AHC2001.












Use the devices within the device range for the DMC50.

4 CONNECTION TO OMRON PLC

- Page 209 Connectable Model List
- Page 211 Serial Connection
- Page 255 Ethernet Connection
- Page 268 Device Range that Can Be Set

4.1 Connectable Model List

The following table shows the connectable models.

Series	Model name	Clock	Communication Type	Connectable GOT	Refer to
SYSMAC CPM	CPM1	×	RS-232	<div>GT 27</div> <div>GT 25</div> <div>GT 23</div> <div>GT 21</div> <div>GS</div>	 Page 211 System Configuration for connecting to CPM1, CPM1A, CPM2A, CPM2C or CQM1
	CPM1A	×			
	CPM2A	○			
	CPM2C	○*3			
SYSMAC CQM1	CQM1*1	○*4	RS-232	<div>GT 27</div> <div>GT 25</div> <div>GT 23</div> <div>GT 21</div> <div>GS</div>	 Page 211 System Configuration for connecting to CPM1, CPM1A, CPM2A, CPM2C or CQM1
SYSMAC CQM1H	CQM1H	○*4*5	RS-232 RS-422	<div>GT 27</div> <div>GT 25</div> <div>GT 23</div> <div>GT 21</div> <div>GS</div>	 Page 214 System Configuration for connecting to CQM1H
SYSMAC CJ1	CJ1H	○	RS-232	<div>GT 27</div> <div>GT 25</div> <div>GT 23</div> <div>GT 21</div> <div>GS</div>	 Page 217 System Configuration for connecting to CJ1H, CJ1G, CJ1M, CJ2H, or CJ2M
	CJ1G		RS-422		
	CJ1M				
SYSMAC CJ2	CJ2H	○	RS-232	<div>GT 27</div> <div>GT 25</div> <div>GT 23</div> <div>GT 21</div> <div>GS</div>	 Page 217 System Configuration for connecting to CJ1H, CJ1G, CJ1M, CJ2H, or CJ2M
	CJ2M*9		RS-422		
SYSMAC CP1	CP1H	○	RS-232	<div>GT 27</div> <div>GT 25</div> <div>GT 23</div> <div>GT 21</div> <div>GS</div>	 Page 222 System Configuration for connecting to CP1H, CP1L, or CP1E
	CP1L		RS-422		
	CP1E(N type)*8				
SYSMAC C200HS	C200HS	○	RS-232	<div>GT 27</div> <div>GT 25</div> <div>GT 23</div> <div>GT 21</div> <div>GS</div>	 Page 225 System Configuration for connecting to C200HS, C200H, C200HX, C200HG, or C200HE
SYSMAC C200H	C200H	○*6	RS-422		
SYSMAC α	C200HX	○	RS-232	<div>GT 27</div> <div>GT 25</div> <div>GT 23</div> <div>GT 21</div> <div>GS</div>	 Page 225 System Configuration for connecting to C200HS, C200H, C200HX, C200HG, or C200HE
	C200HG		RS-422		
	C200HE*2	○*7			
SYSMAC CS1	CS1H	○	RS-232	<div>GT 27</div> <div>GT 25</div> <div>GT 23</div> <div>GT 21</div> <div>GS</div>	 Page 228 System Configuration for connecting to CS1H, CS1G, or CS1D
	CS1G		RS-422		
	CS1D				
SYSMAC C1000H	C1000H	×	RS-232	<div>GT 27</div> <div>GT 25</div> <div>GT 23</div> <div>GT 21</div> <div>GS</div>	 Page 231 System Configuration for connecting to C1000H or C2000H
SYSMAC C2000H	C2000H		RS-422		
SYSMAC CVM1/CV	CV500*10	○	RS-232	<div>GT 27</div> <div>GT 25</div> <div>GT 23</div> <div>GT 21</div> <div>GS</div>	 Page 232 System Configuration for connecting to CV500, CV1000, CV2000, or CVM1
	CV1000*10		RS-422		
	CV2000*10				
	CVM1*10	○*3			

*1 The CQM1-CPU11 is unable to communicate with GOT since the CQM1-CPU11 has no RS-232C interface.

*2 The C200HE-CPU11 does not support communication board.
Use a host Link unit.

*3 Some models do not have a clock function.

*4 The memory cassette equipped with a clock is required.

*5 The EM device of the CQM-CPU61 cannot be monitored.



*6 To use the C200H-CPU21/CPU22/CPU23, the memory cassette equipped with a clock is required.
The C200H-CPU01/CPU02/CPU03 does not support the clock function.

*7 The C200HE-CPU11 does not support the clock function.

*8 For CP1E (N type) CPU modules with 20 or less I/O points, only the direct CPU connection is available.

*9 The direct CPU connection is available for CJ2M-CPU1□ only.

*10 Use the CPU module Ver. V1 or later.


Series	Model name	Clock	Communication Type	Connectable GOT	Refer to
SYSMAC CJ1	CJ1H	○	Ethernet	<div> <div>GT 27</div> <div>GT 25</div> <div>GT 23</div> <div>GT 21</div> <div>GS</div> </div> *1	 Page 255 System Configuration for connecting to SYSMAC CJ1/CJ2/CS1 series
	CJ1G				
	CJ1M				
SYSMAC CJ2	CJ2H				
	CJ2M				
SYSMAC CS1	CS1H				
	CS1G				
	CS1D				
NJ	NJ501-1500			<div> <div>GT 27</div> <div>GT 25</div> <div>GT 23</div> <div>GT 21</div> <div>GS</div> </div>	 Page 257 System Configuration for connecting to NJ/NX series
	NJ501-1400				
	NJ501-1300				
	NJ501-1520				
	NJ501-1420				
	NJ501-1320				
	NJ501-1340				
	NJ301-1200				
	NJ301-1100				
	NJ101-1000				
NX	NJ101-9000				
	NJ101-1020				
	NJ101-9020				
	NX1P2-1140DT				
	NX1P2-1140DT1				
	NX1P2-1040DT				
	NX1P2-1040DT1				
	NX1P2-9024DT				
	NX1P2-9024DT1				
	NX701-1700				
	NX701-1600				
	NX102-1200				
	NX102-1100				
	NX102-1000				
	NX102-9000				

*1 Not compatible with the redundant Ethernet.







4.2 Serial Connection

System Configuration for connecting to CPM1, CPM1A, CPM2A, CPM2C or CQM1

When connecting to PLC or RS-232C



PLC			Connection cable		GOT		Number of connectable equipment
Model name	RS-232C adapter*1	Communication Type	Cable model Connection diagram number	Max. distance	Option device*3	Model	
CPM2A CQM1	-	RS-232	GT09-C30R20101-9P(3m) or RS-232 connection diagram 1)	15m	-(Built into GOT)	 	1 GOT for 1 PLC
					GT15-RS2-9P		
					GT10-C02H-6PT9P*2		
			RS-232 connection diagram 4)	15m	-(Built into GOT)		
CPM1 CPM1A CPM2A CPM2C	CPM1-CIF01	RS-232	GT09-C30R20101-9P(3m) or RS-232 connection diagram 1)	15m	-(Built into GOT)	 	1 GOT for 1 RS-232C adapter
					GT15-RS2-9P		
					GT10-C02H-6PT9P*2		
			RS-232 connection diagram 4)	15m	-(Built into GOT)		


PLC			Connection cable		GOT		Number of connectable equipment
Model name	RS-232C adapter ^{*1}	Communication Type	Cable model Connection diagram number	Max. distance	Option device ^{*3}	Model	
CPM2C	CPM2C-CIF01-V1	RS-232	GT09-C30R20101-9P(3m) or (User prepare) RS-232 connection diagram 1)	15m	-(Built into GOT)	  	1 GOT for 1 RS-232C adapter
					GT15-RS2-9P		
					GT10-C02H-6PT9P ^{*2}		
			(User prepare) RS-232 connection diagram 4)	15m	-(Built into GOT)		

^{*1} Product manufactured by OMRON Corporation. For details on the product, contact OMRON Corporation.

^{*2} When a GT10-C02H-6PT9P unit of the sub version A or B is used, do not ground the case of the D-sub (9-pin) connector.

^{*3} GT25-W, GT2505-V does not support the option device.

When connecting to OMRON connection cable



PLC			Connection cable		GOT		Number of connectable equipment
Model name	OMRON connection cable*1	Communication Type	Cable model Connection diagram number	Max. distance	Option device*3	Model	
CPM1A	CQM1-CIF01	RS-232	GT09-C30R20102-25S(3m) or (User preparing) RS-232 connection diagram 2)	15m	- (Built into GOT)	<div>GT 27</div> <div>GT 25</div> <div>GT 23</div> <div>GT 21</div> <div>GT 25Q</div> <div>GS</div>	1 GOT for 1 PLC
					GT15-RS2-9P	<div>GT 27</div> <div>GT 25</div>	
					GT10-C02H-6PT9P*2	<div>GT 03P</div> <div>GT 04P</div> <div>GT 04R</div> <div>GT 03P</div> <div>GT 04P</div> <div>GT 04R</div>	
			(User preparing) RS-232 connection diagram 5)	15m	- (Built into GOT)	<div>GT 04R</div> <div>GT 21</div> <div>GT 03P</div> <div>GT 04P</div> <div>GT 04R</div>	
CPM2C	CPM2C-CN111	RS-232	GT09-C30R20101-9P(3m) or (User preparing) RS-232 connection diagram 1)	15m	- (Built into GOT)	<div>GT 27</div> <div>GT 25</div> <div>GT 23</div> <div>GT 21</div> <div>GT 25Q</div> <div>GS</div>	1 GOT for 1 PLC
					GT15-RS2-9P	<div>GT 27</div> <div>GT 25</div>	
					GT10-C02H-6PT9P*2	<div>GT 03P</div> <div>GT 04P</div> <div>GT 04R</div> <div>GT 03P</div> <div>GT 04P</div> <div>GT 04R</div>	
			(User preparing) RS-232 connection diagram 4)	15m	- (Built into GOT)	<div>GT 04R</div> <div>GT 21</div> <div>GT 03P</div> <div>GT 04P</div> <div>GT 04R</div>	


*1 Product manufactured by OMRON Corporation. For details on the product, contact OMRON Corporation.

*2 When a GT10-C02H-6PT9P unit of the sub version A or B is used, do not ground the case of the D-sub (9-pin) connector.





*3 GT25-W, GT2505-V does not support the option device.

System Configuration for connecting to CQM1H

When connecting to PLC or serial communication board



PLC			Connection cable		GOT		Number of connectable equipment
Model name	Serial communication board*1	Communication Type	Cable model Connection diagram number	Max. distance	Option device*3	Model	
CQM1H	-	RS-232	GT09-C30R20101-9P(3m) or (User preparing) RS-232 connection diagram 1)	15m	- (Built into GOT)		1 GOT for 1 PLC
			(User preparing) RS-232 connection diagram 4)	15m	- (Built into GOT)		
	CQM1-SCB41	RS-232	GT09-C30R20101-9P(3m) or (User preparing) RS-232 connection diagram 1)	15m	- (Built into GOT)		
			(User preparing) RS-232 connection diagram 4)	15m	- (Built into GOT)		


PLC			Connection cable		GOT		Number of connectable equipment
Model name	Serial communication board ^{*1}	Communication Type	Cable model Connection diagram number	Max. distance	Option device ^{*3}	Model	
CQM 1H	CQM1-SCB41	RS-422	GT09-C30R40101-9P(3m) GT09-C100R40101-9P(10m) GT09-C200R40101-9P(20m) GT09-C300R40101-9P(30m) or (User preparation) RS-422 connection diagram 3)	200m	- (Built into GOT)		1 GOT for 1 serial communication board
					GT15-RS4-9S		
					GT10-C02H-9SC		
			(User preparation) RS-422 connection diagram 7)	200m	- (Built into GOT)		

*1 Product manufactured by OMRON Corporation. For details on the product, contact OMRON Corporation.

*2 When a GT10-C02H-6PT9P unit of the sub version A or B is used, do not ground the case of the D-sub (9-pin) connector.

*3 GT25-W, GT2505-V does not support the option device.

When connecting to OMRON connection cable




PLC		Connection cable		GOT		Number of connectable equipment
Model name	OMRON connection cable*1	Communication Type	Cable model Connection diagram number	Max. distance	Option device*3 Model	
CQM 1H	CQM1-CIF02	RS-232	GT09-C30R20101-9P(3m) or (User preparing) RS-232 connection diagram 1)	15m	- (Built into GOT)	1 GOT for 1 PLC
					<div> <div>GT 27</div> <div>GT 23</div> <div>GT 21^{PSD}</div> </div> <div> <div>GT 25</div> <div>GT 07W</div> <div>GS</div> </div>	
					GT15-RS2-9P <div> <div>GT 27</div> <div>GT 25</div> </div>	
					GT10-C02H-6PT9P*2 <div> <div>GT 03P</div> <div>GT 104P</div> <div>R4</div> </div> <div> <div>GT 03P</div> <div>GT 104P</div> <div>R2</div> </div>	
			(User preparing) RS-232 connection diagram 4)	15m	- (Built into GOT)	<div> <div>GT 21^{4H}</div> <div>GT 03P</div> <div>GT 104P</div> <div>R2</div> </div>

*1 Product manufactured by OMRON Corporation. For details on the product, contact OMRON Corporation.

*2 When a GT10-C02H-6PT9P unit of the sub version A or B is used, do not ground the case of the D-sub (9-pin) connector.





















*3 GT25-W, GT2505-V does not support the option device.













System Configuration for connecting to CJ1H, CJ1G, CJ1M, CJ2H, or CJ2M





































































4

PLC			Connection cable		GOT		Number of connectable equipment
Model name	Serial communication module/RS-422A converter ^{*1}	Communication Type	Cable model Connection diagram number	Max. distance	Option device ^{*3}	Model	
CJ1H CJ1G CJ1M CJ2H	-	RS-232	GT09-C30R20101-9P(3m) or (User reports) RS-232 connection diagram 1)	15m	- (Built into GOT)		1 GOT for 1 PLC
					GT15-RS2-9P		
					GT10-C02H-6PT9P ^{*2}		
			(User reports) RS-232 connection diagram 4)	15m	- (Built into GOT)		
	CJ1W-SCU21-V1 CJ1W-SCU41-V1	RS-232	GT09-C30R20101-9P(3m) or (User reports) RS-232 connection diagram 1)	15m	- (Built into GOT)		
					GT15-RS2-9P		
					GT10-C02H-6PT9P ^{*2}		
			(User reports) RS-232 connection diagram 4)	15m	- (Built into GOT)		

PLC			Connection cable		GOT		Number of connectable equipment
Model name	Serial communication module/RS-422A converter*1	Communication Type	Cable model Connection diagram number	Max. distance	Option device*3	Model	
CJ1H CJ1G CJ1M CJ2H	CJ1W-SCU31-V1 CJ1W-SCU41-V1	RS-422	GT09-C30R40101-9P(3m) GT09-C100R40101-9P(10m) GT09-C200R40101-9P(20m) GT09-C300R40101-9P(30m) or (User preparing) RS-422 connection diagram 3)	200m	- (Built into GOT)	  	1 GOT for 1 PLC
					GT15-RS4-9S		
					GT10-C02H-9SC		
			(User preparing) RS-422 connection diagram 7)	200m	- (Built into GOT)	 	
	CJ1W-CIF11	RS-422	GT09-C30R40103-5T(3m) GT09-C100R40103-5T(10m) GT09-C200R40103-5T(20m) GT09-C300R40103-5T(30m) or (User preparing) RS-422 connection diagram 4)	50m	- (Built into GOT)	  	1 GOT for 1 RS-422A converter
					GT15-RS4-9S		
					GT10-C02H-9SC		
			(User preparing) RS-422 connection diagram 8)	50m	- (Built into GOT)	 	
CJ1H CJ1G CJ1M	CJ1W-SCU21 CJ1W-SCU41	RS-232	GT09-C30R20101-9P(3m) or (User preparing) RS-232 connection diagram 1)	15m	- (Built into GOT)	  	1 GOT for each port of a serial communication module
					GT15-RS2-9P		
					GT10-C02H-6PT9P*2		
			(User preparing) RS-232 connection diagram 4)	15m	- (Built into GOT)		

PLC			Connection cable		GOT		Number of connectable equipment
Model name	Serial communication module/RS-422A converter ^{*1}	Communication Type	Cable model Connection diagram number	Max. distance	Option device ^{*3}	Model	
CJ1H CJ1G CJ1M	CJ1W-SCU41	RS-422	GT09-C30R40101-9P(3m) GT09-C100R40101-9P(10m) GT09-C200R40101-9P(20m) GT09-C300R40101-9P(30m) or (User preparing) RS-422 connection diagram 3)	200m	- (Built into GOT)		1 GOT for each port of a serial communication module
					GT15-RS4-9S		
					GT10-C02H-9SC		
			(User preparing) RS-422 connection diagram 7)	200m	- (Built into GOT)		
CJ2M-CPU1□	-	RS-232	GT09-C30R20101-9P(3m) or (User preparing) RS-232 connection diagram 1)	15m	- (Built into GOT)		1 GOT for 1 PLC
					GT15-RS2-9P		
					GT10-C02H-6PT9P ^{*2}		
			(User preparing) RS-232 connection diagram 4)	15m	- (Built into GOT)		
	CJ1W-CIF11	RS-422	GT09-C30R40103-5T(3m) GT09-C100R40103-5T(10m) GT09-C200R40103-5T(20m) GT09-C300R40103-5T(30m) or (User preparing) RS-422 connection diagram 4)	50m	- (Built into GOT)		1 GOT for 1 RS-422A converter
					GT15-RS4-9S		
					GT10-C02H-9SC		
			(User preparing) RS-422 connection diagram 8)	50m	- (Built into GOT)		

PLC			Connection cable		GOT		Number of connectable equipment
Model name	Serial communication module/RS-422A converter*1	Communication Type	Cable model Connection diagram number	Max. distance	Option device*3	Model	
CJ2M-CPU1□ CJ2M-CPU3□	CJ1W-SCU21-V1 CJ1W-SCU41-V1	RS-232	GT09-C30R20101-9P(3m) or  RS-232 connection diagram 1)	15m	- (Built into GOT)	     	1 GOT for each port of a serial communication module
					GT15-RS2-9P	 	
					GT10-C02H-6PT9P*2	   	
			 RS-232 connection diagram 4)	15m	- (Built into GOT)	   	
CJ2M-CPU1□ CJ2M-CPU3□	CJ1W-SCU31-V1 CJ1W-SCU41-V1	RS-422	GT09-C30R40101-9P(3m) GT09-C100R40101-9P(10m) GT09-C200R40101-9P(20m) GT09-C300R40101-9P(30m) or  RS-422 connection diagram 3)	200m	- (Built into GOT)	     	1 GOT for each port of a serial communication module
					GT15-RS4-9S	 	
					GT10-C02H-9SC	   	
			 RS-422 connection diagram 7)	200m	- (Built into GOT)	   	
CJ2M-CPU3□	CP1W-CIF01	RS-232	GT09-C30R20101-9P(3m) or  RS-232 connection diagram 1)	15m	- (Built into GOT)	     	1 GOT for 1 RS-232C option board
					GT15-RS2-9P	 	
					GT10-C02H-6PT9P*2	   	
			 RS-232 connection diagram 4)	15m	- (Built into GOT)	   	

PLC			Connection cable		GOT		Number of connectable equipment
Model name	Serial communication module/RS-422A converter*1	Communication Type	Cable model Connection diagram number	Max. distance	Option device*3	Model	
CJ2M-CPU3□	CP1W-CIF11	RS-422	GT09-C30R40103-5T(3m) GT09-C100R40103-5T(10m) GT09-C200R40103-5T(20m) GT09-C300R40103-5T(30m) or  RS-422 connection diagram 4)	50m	- (Built into GOT)		1 GOT for 1 RS-422A/ 485 option board
				GT15-RS4-9S			
				GT10-C02H-9SC			
			 RS-422 connection diagram 8)	50m	- (Built into GOT)		
CJ2M-CPU3□	CP1W-CIF12	RS-422	GT09-C30R40103-5T(3m) GT09-C100R40103-5T(10m) GT09-C200R40103-5T(20m) GT09-C300R40103-5T(30m) or  RS-422 connection diagram 4)	200m	- (Built into GOT)		1 GOT for 1 RS-422A/ 485 option board
				GT15-RS4-9S			
				GT10-C02H-9SC			
			 RS-422 connection diagram 8)	200m	- (Built into GOT)		


^{*1} Product manufactured by OMRON Corporation. For details on the product, contact OMRON Corporation.

^{*2} When a GT10-C02H-6PT9P unit of the sub version A or B is used, do not ground the case of the D-sub (9-pin) connector.









^{*3} GT25-W, GT2505-V does not support the option device.

System Configuration for connecting to CP1H, CP1L, or CP1E

When connecting a PLC or option board



PLC			Connection cable		GOT		Number of connectable equipment
Model name	Option board ^{*1}	Communication Type	Cable model Connection diagram number	Max. distance	Option device ^{*3}	Model	
CP1E	-	RS-232	GT09-C30R20101-9P(3m) or RS-232 connection diagram 1)	15m	- (Built into GOT)		1 GOT for 1 PLC
					GT15-RS2-9P		
					GT10-C02H-6PT9P ^{*2}		
			RS-232 connection diagram 4)	15m	- (Built into GOT)		
CP1H CP1L CP1E	CP1W-CIF01	RS-232	GT09-C30R20101-9P(3m) or RS-232 connection diagram 1)	15m	- (Built into GOT)		1 GOT for 1 RS-232C option board
					GT15-RS2-9P		
					GT10-C02H-6PT9P ^{*2}		
			RS-232 connection diagram 4)	15m	- (Built into GOT)		


PLC			Connection cable		GOT		Number of connectable equipment
Model name	Option board* ¹	Communication Type	Cable model Connection diagram number	Max. distance	Option device* ³	Model	
CP1H CP1L CP1E	CP1W-CIF11	RS-422	GT09-C30R40103-5T(3m) GT09-C100R40103-5T(10m) GT09-C200R40103-5T(20m) GT09-C300R40103-5T(30m) or (User preparing) RS-422 connection diagram 4)	50m	- (Built into GOT)		1 GOT for 1 RS-422A/485 option board
					GT15-RS4-9S		
					GT10-C02H-9SC		
			(User preparing) RS-422 connection diagram 8)	50m	- (Built into GOT)		
	CP1W-CIF12	RS-422	GT09-C30R40103-5T(3m) GT09-C100R40103-5T(10m) GT09-C200R40103-5T(20m) GT09-C300R40103-5T(30m) or (User preparing) RS-422 connection diagram 4)	200m	- (Built into GOT)		1 GOT for 1 RS-422A/485 option board
					GT15-RS4-9S		
					GT10-C02H-9SC		
			(User preparing) RS-422 connection diagram 8)	200m	- (Built into GOT)		

*1 Product manufactured by OMRON Corporation. For details on the product, contact OMRON Corporation.

*2 When a GT10-C02H-6PT9P unit of the sub version A or B is used, do not ground the case of the D-sub (9-pin) connector.

*3 GT25-W, GT2505-V does not support the option device.

When connecting to serial communication module



PLC				Connection cable		GOT		Number of connectable equipment
Model name	CJ unit adapter ^{*1}	Serial communication module ^{*1}	Communication Type	Cable model Connection diagram number	Max. distance	Option device ^{*3}	Model	
CP1H	CP1W-EXT01	CJ1W-SCU21 CJ1W-SCU41 CJ1W-SCU21-V1 CJ1W-SCU41-V1	RS-232	GT09-C30R20101-9P(3m) or (User preparing) RS-232 connection diagram 1)	15m	- (Built into GOT)		1 GOT for each port of a serial communication module
				(User preparing) RS-232 connection diagram 4)	15m	- (Built into GOT)		
		CJ1W-SCU41 CJ1W-SCU31-V1 CJ1W-SCU41-V1	RS-422	GT09-C30R40101-9P(3m) GT09-C100R40101-9P(10m) GT09-C200R40101-9P(20m) GT09-C300R40101-9P(30m) or (User preparing) RS-422 connection diagram 3)	200m	- (Built into GOT)		
				(User preparing) RS-422 connection diagram 7)	200m	- (Built into GOT)		


*1 Product manufactured by OMRON Corporation. For details on the product, contact OMRON Corporation.

*2 When a GT10-C02H-6PT9P unit of the sub version A or B is used, do not ground the case of the D-sub (9-pin) connector.

*3 GT25-W, GT2505-V does not support the option device.



















System Configuration for connecting to C200HS, C200H, C200HX, C200HG, or C200HE

When connecting to PLC or rack type host link unit



4

PLC			Connection cable		GOT		Number of connectable equipment
Model name	Rack type host link unit ^{*1}	Communication Type	Cable model Connection diagram number	Max. distance	Option device ^{*3}	Model	
C200HX C200HG C200HE	-	RS-232	GT09-C30R20101-9P(3m) or RS-232 connection diagram 1)	15m	- (Built into GOT)		1 GOT for 1 PLC
					GT15-RS2-9P		
					GT10-C02H-6PT9P ^{*2}		
			RS-232 connection diagram 4)	15m	- (Built into GOT)		
C200HS C200H C200HX C200HG C200HE	C200H-LK201-V1	RS-232	GT09-C30R20103-25P(3m) or RS-232 connection diagram 3)	15m	- (Built into GOT)		1 GOT for 1 rack type host link unit
					GT15-RS2-9P		
					GT10-C02H-6PT9P ^{*2}		
			RS-232 connection diagram 6)	15m	- (Built into GOT)		


PLC			Connection cable		GOT		Number of connectable equipment
Model name	Rack type host link unit ^{*1}	Communication Type	Cable model Connection diagram number	Max. distance	Option device ^{*3}	Model	
C200HS C200H C200HX C200HG C200HE	C200H-LK202-V1	RS-422	GT09-C30R40102-9P(3m) GT09-C100R40102-9P(10m) GT09-C200R40102-9P(20m) GT09-C300R40102-9P(30m) or  RS-422 connection diagram 2)	200m	- (Built into GOT)	     	1 GOT for 1 rack type host link unit
					GT15-RS4-9S	 	
					GT10-C02H-9SC	   	
			 RS-422 connection diagram 6)	200m	- (Built into GOT)	   	













*1 Product manufactured by OMRON Corporation. For details on the product, contact OMRON Corporation.

*2 When a GT10-C02H-6PT9P unit of the sub version A or B is used, do not ground the case of the D-sub (9-pin) connector.

*3 GT25-W, GT2505-V does not support the option device.

When connecting to a communication board



PLC			Connection cable		GOT		Number of connectable equipment
Model name	Communication board*1	Communication Type	Cable model Connection diagram number	Max. distance	Option device*4	Model	
C200HX C200HG C200HE*2	C200HW-COM02(-V1) C200HW-COM05(-V1) C200HW-COM06(-V1)	RS-232	GT09-C30R20101-9P(3m) or  RS-232 connection diagram 1)	15m	- (Built into GOT)		1 GOT for each port of a communication board
			GT15-RS2-9P				
			GT10-C02H-6PT9P*3				
			 RS-232 connection diagram 4)	15m	- (Built into GOT)		
	C200HW-COM03(-V1) C200HW-COM06(-V1)	RS-422	GT09-C30R40101-9P(3m) GT09-C100R40101-9P(10m) GT09-C200R40101-9P(20m) GT09-C300R40101-9P(30m) or  RS-422 connection diagram 3)	200m	- (Built into GOT)		
			GT15-RS4-9S				
			GT10-C02H-9SC				
			 RS-422 connection diagram 7)	200m	- (Built into GOT)		

*1 Product manufactured by OMRON Corporation. For details on the product, contact OMRON Corporation.


*2 The communication board cannot be mounted to the C2000HE-CPU11.
Use a host Link unit.

*3 When a GT10-C02H-6PT9P unit of the sub version A or B is used, do not ground the case of the D-sub (9-pin) connector.





*4 GT25-W, GT2505-V does not support the option device.

System Configuration for connecting to CS1H, CS1G, or CS1D

When connecting to a PLC or a serial communication module



PLC			Connection cable		GOT		Number of connectable equipment
Model name	Serial communication module*1 /RS-422A converter	Communication Type	Cable model Connection diagram number	Max. distance	Option device*3	Model	
CS1H CS1G CS1D	-	RS-232	GT09-C30R20101-9P(3m) or (User preparing) RS-232 connection diagram 1)	15m	-(Built into GOT)		1 GOT for 1 PLC
					GT15-RS2-9P		
					GT10-C02H-6PT9P*2		
			(User preparing) RS-232 connection diagram 4)	15m	-(Built into GOT)		
	CS1W-SCU21 CS1W-SCU21-V1	RS-232	GT09-C30R20101-9P(3m) or (User preparing) RS-232 connection diagram 1)	15m	-(Built into GOT)		1 GOT for 1 serial communication module
					GT15-RS2-9P		
					GT10-C02H-6PT9P*2		
			(User preparing) RS-232 connection diagram 4)	15m	-(Built into GOT)		


PLC			Connection cable		GOT		Number of connectable equipment
Model name	Serial communication module ^{*1} /RS-422A converter	Communication Type	Cable model Connection diagram number	Max. distance	Option device ^{*3}	Model	
CS1H CS1G CS1D	CJ1W-CIF11	RS-422	GT09-C30R40103-5T(3m) GT09-C100R40103-5T(10m) GT09-C200R40103-5T(20m) GT09-C300R40103-5T(30m) or (User preparing) RS-422 connection diagram 4)	50m	-(Built into GOT)		1 GOT for 1 RS-422A converter
					GT15-RS4-9S		
					GT10-C02H-9SC		
			(User preparing) RS-422 connection diagram 8)	50m	-(Built into GOT)		

*1 Product manufactured by OMRON Corporation. For details on the product, contact OMRON Corporation.

*2 When a GT10-C02H-6PT9P unit of the sub version A or B is used, do not ground the case of the D-sub (9-pin) connector.

*3 GT25-W, GT2505-V does not support the option device.

When connecting to a serial communication board




PLC			Connection cable		GOT		Number of connectable equipment
Model name	Serial communication board ^{*1}	Communication Type	Cable model Connection diagram number	Max. distance	Option device ^{*3}	Model	
CS1H CS1G CS1D	CS1W-SCB21 CS1W-SCB41 CS1W-SCB21-V1 CS1W-SCB41-V1	RS-232	GT09-C30R20101-9P(3m) or (User preparing) RS-232 connection diagram 1)	15m	- (Built into GOT)		1 GOT for each port of a serial communication board
					GT15-RS2-9P		
					GT10-C02H-6PT9P ^{*2}		
			(User preparing) RS-232 connection diagram 4)	15m	- (Built into GOT)		
	CS1W-SCB41 CS1W-SCB41-V1	RS-422	GT09-C30R40101-9P(3m) GT09-C100R40101-9P(10m) GT09-C200R40101-9P(20m) GT09-C300R40101-9P(30m) or (User preparing) RS-422 connection diagram 3)	200m	- (Built into GOT)		
					GT15-RS4-9S		
					GT10-C02H-9SC		
			(User preparing) RS-422 connection diagram 7)	200m	- (Built into GOT)		

*1 Product manufactured by OMRON Corporation. For details on the product, contact OMRON Corporation.

*2 When a GT10-C02H-6PT9P unit of the sub version A or B is used, do not ground the case of the D-sub (9-pin) connector.

*3 GT25-W, GT2505-V does not support the option device.

System Configuration for connecting to C1000H or C2000H



4


PLC			Connection cable		GOT		Number of connectable equipment
Model name	Rack type host link unit ^{*1}	Communication Type	Cable model Connection diagram number	Max. distance	Option device ^{*3}	Model	
C1000H C2000H	C500-LK201-V1	RS-232	GT09-C30R20103-25P(3m) or RS-232 connection diagram 3)	15m	- (Built into GOT)		1 GOT for 1 rack type host link unit
					GT15-RS2-9P		
					GT10-C02H-6PT9P ^{*2}		
			RS-232 connection diagram 6)	15m	- (Built into GOT)		
		RS-422	RS-422 connection diagram 2)	200m	- (Built into GOT)		
					GT15-RS4-9S		
					GT10-C02H-9SC		
			RS-422 connection diagram 6)	200m	- (Built into GOT)		

^{*1} Product manufactured by OMRON Corporation. For details on the product, contact OMRON Corporation.

^{*2} When a GT10-C02H-6PT9P unit of the sub version A or B is used, do not ground the case of the D-sub (9-pin) connector.

^{*3} GT25-W, GT2505-V does not support the option device.

System Configuration for connecting to CV500, CV1000, CV2000, or CVM1



PLC		Connection cable		GOT		Number of connectable equipment
Model name	Communication Type	Cable model Connection diagram number	Max. distance	Option device ^{*2}	Model	
CV500 CV1000 CV2000 CVM1	RS-232	GT09-C30R20101-9P(3m) or RS-232 connection diagram 1)	15m	- (Built into GOT)		1 GOT for 1 PLC
				GT15-RS2-9P		
				GT10-C02H-6PT9P ^{*1}		
		RS-232 connection diagram 4)	15m	- (Built into GOT)		
	RS-422	GT09-C30R40101-9P(3m) GT09-C100R40101-9P(10m) GT09-C200R40101-9P(20m) GT09-C300R40101-9P(30m) or RS-422 connection diagram 1)	200m	- (Built into GOT)		
				GT15-RS4-9S		
				GT10-C02H-9SC		
		RS-422 connection diagram 5)	200m	- (Built into GOT)		

*1 When a GT10-C02H-6PT9P unit of the sub version A or B is used, do not ground the case of the D-sub (9-pin) connector.

*2 GT25-W, GT2505-V does not support the option device.


Connection Diagram

The following diagram shows the connection between the GOT and the PLC.


RS-232 cable

■Connection diagram


- RS-232 connection diagram 1)




- RS-232 connection diagram 2)




- RS-232 connection diagram 3)




- RS-232 connection diagram 4)



- RS-232 connection diagram 5)



- RS-232 connection diagram 6)



■Precautions when preparing a cable

- Cable length

The length of the RS-232 cable must be 15m or less.

- GOT side connector

For the GOT side connector, refer to the following.

☞ Page 58 GOT connector specifications

- OMRON PLC side connector

Use the connector compatible with the OMRON PLC.

For details, refer to the OMRON PLC user's manual.




Differences in polarity between GOT and OMRON PLCs

The polarity of poles A and B in signal names is reversed between GOT and OMRON PLCs.


■Connect a cable according to the following connection diagrams.

■Connection diagram


- RS-422 connection diagram 1)




- RS-422 connection diagram 2)




- RS-422 connection diagram 3)



- RS-422 connection diagram 4)




- RS-422 connection diagram 5)




*1 The signals RSA, RSB, CSA, and CSB are not provided for GT2104-PMBD, GT2103-PMBD.

- RS-422 connection diagram 6)




*1 The signals RSA, RSB, CSA, and CSB are not provided for GT2104-PMBD, GT2103-PMBD.

- RS-422 connection diagram 7)



*1 The signals RSA, RSB, CSA, and CSB are not provided for GT2104-PMBD, GT2103-PMBD.

- RS-422 connection diagram 8)



*1 The signals RSA, RSB, CSA, and CSB are not provided for GT2104-PMBD, GT2103-PMBD.

■Precautions when preparing a cable

- Cable length

The distance between the GOT and the PLC of connection diagram 1), 2) and 3) must be 200 m or less.

The length of the RS-422 connection diagram 4) must be 50m or less.

- GOT side connector

For the GOT side connector, refer to the following.

📖 Page 58 GOT connector specifications

- OMRON PLC side connector

Use the connector compatible with the OMRON PLC.

For details, refer to the OMRON PLC user's manual.

■Setting terminating resistors

- GOT side

For GT27, GT25(Except GT2505-V), GT23

Set the terminating resistor setting switch of the GOT main unit to "Disable".

For GT2505-V, GT21

Set the terminating resistor selector to "330Ω".

For GS21

Since the terminating resistor is fixed to 330 Ω, no setting is required for the terminating resistor.

For details of terminating resistor settings, refer to the following.

📖 Page 62 Terminating resistors of GOT

- OMRON PLC side


When connecting an OMRON PLC to a GOT, a terminating resistor must be set to the OMRON PLC.

📖 OMRON PLC user's Manual

GOT Side Settings

Setting communication interface (Communication settings)

Set the channel of the equipment to be connected to the GOT.



1. Select [Common] → [Controller Setting] from the menu.
2. In the [Controller Setting] window, select the channel No. to be used from the list menu.
3. Set the following items.
 - [Manufacturer]: [OMRON]
 - [Controller Type]: [OMRON SYSMAC]
 - [I/F]: Interface to be used
 - [Detail Setting]: Configure the settings according to the usage environment.
4. When you have completed the settings, click the [OK] button.

☞ Page 239 Communication detail settings



The settings of connecting equipment can be confirmed in [I/F Communication Setting].
For details, refer to the following.

☞ Page 47 I/F communication setting

Communication detail settings

Make the settings according to the usage environment.

Property	Value
Transmission Speed(BPS)	19200
Data Bit	7 bit
Stop Bit	2 bit
Parity	Even
Retry(Times)	0
Timeout Time(Sec)	3
Host Address	0
Delay Time(ms)	0

Item	Description	Range
Transmission Speed	Set this item when change the transmission speed used for communication with the connected equipment. (Default: 19200bps)	4800bps, 9600bps, 19200bps, 38400bps, 57600bps, 115200bps
Data Bit	Set this item when change the data length used for communication with the connected equipment. (Default: 7bits)	7bit (fixed)
Stop Bit	Specify the stop bit length for communications. (Default: 2bits)	2bit (fixed)
Parity	Specify whether or not to perform a parity check, and how it is performed during communication. (Default: Even)	Even (fixed)
Retry	Set the number of retries to be performed when a communication error occurs. (Default: 0time)	0 to 5times
Timeout Time	Set the time period for a communication to time out. (Default: 3sec)	1 to 30sec
Host Address	Specify the host address (station No. of the PLC to which the GOT is connected) in the network of the GOT. (Default: 0)	0 to 31
Delay Time	Set this item to adjust the transmission timing of the communication request from the GOT. (Default: 0ms)	0 to 300 (ms)

Point

- Communication interface setting by the Utility

The communication interface setting can be changed on the Utility's [Communication Settings] after writing [Communication Settings] of project data.

For details on the Utility, refer to the following manual.

📖 GOT2000 Series User's Manual (Utility)

- Precedence in communication settings

When settings are made by GT Designer3 or the Utility, the latest setting is effective.

PLC Side Setting



OMRON PLC

For details of OMRON PLCs, refer to the following manuals.

☞ OMRON PLC user's Manual

Model name		Refer to
PLC CPU	CPM2A	☞ Page 241 Connecting to CPM2A, CQM1, CQM1H, C200Hα or RS-232C adapter
	CQM1, CQM1H	
	CS1, CJ1, CJ2	☞ Page 242 Connecting to CJ1, CJ2, CS1, CP1H, CP1L, or CP1E
	CP1H, CP1L, CP1E	☞ Page 242 Connecting to CJ1, CJ2, CS1, CP1H, CP1L, or CP1E
	C200Hα	☞ Page 241 Connecting to CPM2A, CQM1, CQM1H, C200Hα or RS-232C adapter
	CV500, CV1000, CV2000, CVM1	☞ Page 245 Connecting to CV500/CV1000/CV2000 or CVM1
RS-232C adapter	CPM1-CIF01, CPM2C-CIF01-V1	☞ Page 241 Connecting to CPM2A, CQM1, CQM1H, C200Hα or RS-232C adapter
Connection cable	CQM1-CIF01	☞ Page 246 Connecting to connection cable
	CQM1-CIF02	
	CPM2C-CN111	
Rack type host link unit	C200H-LK201-V1	☞ Page 247 Connecting to rack type host link unit
	C200H-LK202-V1	☞ Page 247 Connecting to rack type host link unit
	C500-LK201-V1	☞ Page 247 Connecting to rack type host link unit
Serial communication module	CJ1W-SCU21	☞ Page 251 Connecting to serial communication unit
	CJ1W-SCU41	
	CJ1W-SCU21-V1	
	CJ1W-SCU31-V1	
	CJ1W-SCU41-V1	
	CS1W-SCU21	
	CS1W-SCU21-V1	
Communication board	C200HW-COM02(-V1)	☞ Page 251 Connecting to communication board, serial communication board (CQM1-SCB41)
	C200HW-COM03(-V1)	
	C200HW-COM05(-V1)	
	C200HW-COM06(-V1)	
Serial communication board	CQM1-SCB41	☞ Page 251 Connecting to communication board, serial communication board (CQM1-SCB41)
	CS1W-SCB21	☞ Page 253 Connecting to serial communication board (CS1W-SCB21(-V1), CS1W-SCB41(-V1))
	CS1W-SCB21-V1	
	CS1W-SCB41	
RS-422A/485 Option board	CP1W-CIF11	☞ Page 254 Connecting to RS-422A/485 Option board
	CP1W-CIF12	
RS-422A converter	CJ1W-CIF11	☞ Page 254 Connecting to RS-422A converter

Connecting to CPM2A, CQM1, CQM1H, C200Hα or RS-232C adapter

Device settings

Write the following set values to devices of each PLC CPU and initialize each port using a peripheral tool or DM monitor.

Device name	Set value
DM6645	0001H(fixed)
DM6646	<div><div>b15 to b8b7 to b0</div><div>2)1)</div><div>1) RS-232C port transmission speed setting ^{*1*2} 02H: 4800bps 03H: 9600bps 04H: 19200bps 2) RS-232C port communication frame format 03H (fixed): The settings are: Start bit : 1 bit Data length: 7 bits Stop bit : 2 bits Parity : Even bits</div></div>
DM6647	0000 (fixed)
DM6648 ^{*3}	0000 to 0031
DM6649	0000 (fixed)

- *1 Only transmission speeds available on the GOT side are shown.
- *2 Set the same transmission speed of the RS-232C port as that of the GOT side.
- *3 Set the RS-232C port host link station No. according to the Host Address on the GOT side.

Point

Precautions for changing device values

Before changing the device values, make sure that the switch settings have been changed as follows:

CPM2A:

The communication condition switch to "individual"

Other PLC CPU:


Front panel DIP switch SW5 to "OFF"

Connecting to CJ1, CJ2, CS1, CP1H, CP1L, or CP1E

Setting DIP switches


Set the DIP switches.

■Setting on the CJ1, CJ2




Switch		Description	Settings
	SW1	Enable/disable write to user memory (UM)	OFF
	SW2	Enable/disable automatic transfer of user program at power ON	OFF
	SW3	Free	OFF
	SW4	CJ1: Peripheral port communication condition CJ2: Free	OFF
	SW5	RS-232C communication condition	OFF
	SW6	User customized DIP switch	OFF
	SW7	Type specification for simplified backup	OFF
	SW8	-	OFF

■Setting on the CS1



Switch	Description		Settings
<div> <div>ON ←</div> <div> <div>1</div><div>2</div><div>3</div><div>4</div><div>5</div><div>6</div><div>7</div><div>8</div> </div> <div> <div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div> </div> </div>	SW1	Enable/disable write to user memory (UM)	OFF
	SW2	Enable/disable automatic transfer of user program at power ON	OFF
	SW3	Programming console message display language (Japanese/English)	OFF
	SW4	Peripheral port communication condition	OFF
	SW5	RS-232C communication condition	OFF
	SW6	User customized DIP switch	OFF
	SW7	Type specification for simplified backup	OFF
	SW8	-	OFF

■Setting on the CP1H, CP1L



Switch	Description			Settings
	SW4	Option Board Slot1	According to PLC Setup.	OFF
	SW5	Option Board Slot2		OFF

■Setting on the CP1E

Settings by DIP switch are not required.

Setting PLC system settings

■CJ1, CJ2, CS1

Make the PLC system settings.

Channel	Bit	Item	Set value
160	15	Arbitrary settings ON/OFF	1H: Arbitrary settings (fixed)
	8 to 11	Serial communication mode	0H: Upper link (fixed)
	3	Data bit	0H: 7bits (fixed)
	2	Stop bit	0H: 2bits (fixed)
	0 to 1	Parity	0H: Even (fixed)
161	0 to 7	Port transmission speed ^{*1*2}	00H: 9600bps 05H: 4800bps 06H: 9600bps 07H: 19200bps 08H: 38400bps 09H: 57600bps 0AH: 115200bps
163	0 to 7	Host link station No. ^{*3}	0H to 1FH : No.00 to 31

*1 Only transmission speeds available on the GOT side are shown.

*2 Set the same port transmission speed as that of the GOT side.

*3 Set the host link station No. according to the Host Address on the GOT side.



Precautions for changing the PLC system settings

Before changing the PLC system settings, make sure that the switch settings have been changed as follows:
CJ1, CJ2, CS1: Front panel DIP switch SW5 to "OFF"

■CP1H, CP1L, CP1E

Set the PLC system settings of the option slot connected to the GOT.

Item	Set value
Mode	Host link
Parameter	7, 2, E
Baud rate ^{*1*2}	4800bps, 9600bps, 19200bps , 38400bps, 57600bps, 115200bps
Unit number ^{*3}	00 to 31

- *1 Only transmission speeds available on the GOT side are shown.
 *2 Set the same port transmission speed as that of the GOT side.
 *3 Set the host link station No. according to the Host Address on the GOT side.

Point

Precautions for changing the PLC system settings


Before changing the PLC system settings, check the setting of the front DIP switch corresponding to the option slot used at the time of communication with GOT.

☞ Page 244 Setting on the CP1H, CP1L

Connecting to CV500/CV1000/CV2000 or CVM1

Setting DIP switches

Set the DIP switches.



■Host link RS-422/232 switch



Settings	
For RS-232 communication	For RS-422 communication
RS-232 (up)	RS-422 (down)

■DIP switches

Switch No.	Settings	
	For RS-232 communication	For RS-422 communication
	6	OFF (no terminating resistor)
	5	OFF
	4	OFF
	3	OFF
	2	OFF
	1	OFF

Setting PLC system settings

Make the PLC system settings.

Item	Set value
Transmission speed ^{*1*2}	4800bps/9600bps/19200bps
Stop bit	2 stop bits (fixed)
Parity	Even (fixed)
Data bit	7bits (fixed)
Unit number ^{*3}	00 to 31

*1 Only transmission speeds available on the GOT side are shown.

*2 Set the same transmission speed of the GOT.

*3 Set the station No. according to the Host Address on the GOT side.

Connecting to connection cable

Device settings

Write the following set values to devices of each PLC CPU and initialize each port using a peripheral tool or DM monitor.

Device name	Set value				
DM6650	0001H(fixed)				
DM6651	<table><tr><td>b15 to b8</td><td>b7 to b0</td></tr><tr><td>2)</td><td>1)</td></tr></table> <p>1) RS-232C port transmission speed setting^{*1*2} 02H: 4800bps 03H: 9600bps 04H: 19200bps</p> <p>2) RS-232C port communication frame format 03H (fixed): The settings are: Start bit : 1 bit Data length: 7 bits Stop bit : 2 bits Parity : Even bits</p>	b15 to b8	b7 to b0	2)	1)
b15 to b8	b7 to b0				
2)	1)				
DM6652	0000 (fixed)				
DM6653 ^{*3}	0000 to 0031				

*1 Only transmission speeds available on the GOT side are shown.

*2 Set the same transmission speed of the peripheral port as that of the GOT side.

*3 Set the peripheral port host link station No. according to the Host Address on the GOT side.



Precautions for changing device values

Before changing the device values, make sure that the switch settings have been changed as follows:


CPM2A: The communication condition switch to "individual"

CPM2C: The communication port function switch to "OFF"

Connecting to rack type host link unit

Switch setting on C200H-LK201-V1

Set the switches accordingly.



Setting Machine No. (SW1, SW2)

Set the Machine No. within the range of 00 to 31.
Set the station No. according to the Host Address on the GOT side.



Rotary switch	Description	Settings
SW1	Machine No. upper digit ($\times 10^1$)	0 to 3
SW2	Machine No. lower digit ($\times 10^0$)	0 to 9

Setting transmission speed (SW3)

Set the same transmission speed of the GOT.



Setting ^{*1}	Settings
4	4800bps
5	9600bps
6	19200bps

^{*1} Only transmission speeds available on the GOT side are shown.

Setting command level/parity/transmission code (SW4)



Settings	Setting details		
	Command level	Parity	Transmission code
2(fixed)	Levels 1, 2 and 3 enabled	Even	ASCII 7 bits 2 stop bits

■Setting DIP switches



Switch No.	Set value
1	OFF
2	OFF
3	ON (1:N procedure)
4	OFF (no 5V power supply)


■Setting the CTS switch



Settings
0V

Switch setting on C200H-LK202-V1

Set the switches accordingly.



■Setting Machine No. (SW1, SW2)

Set the Machine No. within the range of 00 to 31.
Set the station No. according to the Host Address on the GOT side.



Rotary switch	Description	Settings
SW1	Machine No. upper digit ($\times 10^1$)	0 to 3
SW2	Machine No. lower digit ($\times 10^0$)	0 to 9

■Setting transmission speed (SW3)

Set the same transmission speed of the GOT.



Setting ^{*1}	Settings
4	4800bps
5	9600bps
6	19200bps

^{*1} Only transmission speeds available on the GOT side are shown.

■Setting command level/parity/transmission code (SW4)



Settings	Setting details		
	Command level	Parity	Transmission code
2(fixed)	Levels 1, 2 and 3 enabled	Even	ASCII 7 bits 2 stop bits

■Setting the 1:1/1:N procedure switch



Settings
OFF (1:N procedure)


■Setting the terminating resistor connection switch



Settings
ON (terminating resistor attached)

Switch setting on C500-LK201-V1

Set the switches accordingly.



■Setting host link/local



Settings
Host link

■RS-232C/RS-422 switch



Settings	
For RS-232 communication	For RS-422 communication
RS-232 (down)	RS-422 (up)

■Internal/external clock switch



Settings
Internal (up)

■Terminating resistor connection switch



Settings

Attached (down)

■CTS switch



Settings

0V (up)

■Setting SW1 (Station No., Run/Stop)

Switch No.		Settings	Description
	8	ON	Run
	7	OFF	-
	6	OFF	-
	5	Set the station No. within the range of 00 to 31. For details, refer to the following manual. OMRON PLC user's Manual	
	4		
	3		
	2		
	1		

■Setting SW2 (Transmission speed, Procedure, Level)

Switch No.		Settings	Description
	8	ON	Levels 1, 2 and 3 enabled
	7	ON	
	6	OFF	1:N procedure
	5	OFF	-
	4	*1	Transmission speed
	3		
	2		
	1		

*1 Only transmission speeds available on the GOT side are shown.

Transmission speed	Switch No.			
	SW1	SW2	SW3	SW4
4800bps	OFF	ON	ON	OFF
9600bps	ON	OFF	ON	OFF
19200bps	OFF	OFF	ON	OFF

Connecting to serial communication unit

Device settings

Write the following set values to devices of each PLC CPU and initialize each port using a peripheral tool or DM monitor.

Device name		Set value				
Port 1	Port 2					
DM(m)	DM(m+10)	8000H(fixed): The settings are: Port setting: Arbitrary setting Serial communication mode: Host link Start bit: 1bit Data bit: 7bits Stop bit: 2bits Parity: Even				
DM(m+1)	DM(m+11)	<table><tr><td>b15 to b8</td><td>b7 to b0</td></tr><tr><td>0H</td><td>1)</td></tr></table> 1) Transmission speed ^{*1*2} 00H: 9600bps 08H: 38400bps 05H: 4800bps 09H: 57600bps 06H: 9600bps 0AH: 115200bps 07H: 19200bps	b15 to b8	b7 to b0	0H	1)
b15 to b8	b7 to b0					
0H	1)					
DM(m+2)	DM(m+12)	8000H(fixed)				
DM(m+3) ^{*3}	DM(m+13) ^{*3}	8000H to 801FH				

m = 30000 + (100 × unit No.)

*1 Only transmission speeds available on the GOT side are shown.

*2 Set the same transmission speed of the GOT.

*3 Set the host link station No. according to the Host Address on the GOT side.

Connecting to communication board, serial communication board (CQM1-SCB41)

Device settings

Write the following set values to devices of each PLC CPU and initialize each port using a peripheral tool or DM monitor.

Device name		Set value	
Port B	Port A		
DM6550	DM6555	0001H(fixed)	
DM6551	DM6556	<div><div>b15 to b8b7 to b0</div><div>2)1)</div><div>1) Transmission speed^{*1*2} 02H:4800bps 03H:9600bps 04H:19200bps 2) Frame format setting 03H (fixed): The settings are: Start bit :1 bit Data length:7 bits Stop bit :2 bits Parity :Even bits</div></div>	
DM6552	DM6557	0000 (fixed)	
DM6553 ^{*3}	DM6558 ^{*3}	0000 to 0031	



*1 Only transmission speeds available on the GOT side are shown.

*2 Set the same transmission speed as that of the GOT side.

*3 Set the host link station No. according to the Host Address on the GOT side.

Setting DIP switches (C200HW-COM03(-V1) and C200HW-COM06(-V1) only)

Set the DIP switches when performing the RS-422 communications on the C200HW-COM03(-V1) and C200HW-COM06(-V1).



DIP switch		Set value
No.	Item	
SW1	RS-422/485 cable (2-wire/4-wire type) switching	4 (4-wire type)
SW2	Terminator ON/OFF	1 (no terminating resistor attached)

Connecting to serial communication board (CS1W-SCB21(-V1), CS1W-SCB41(-V1))

Device settings


Write the following set values to devices of each PLC CPU and initialize each port using a peripheral tool or DM monitor.

Device name		Set value				
Port 1	Port 2					
D32000	D32010	8000H(fixed): The settings are: Port setting: Arbitrary setting Serial communication mode: Host link Start bit: 1bit Data bit: 7bits Stop bit: 2bits Parity: Even				
D32001	D32011	<table><tr><td>b15 to b8</td><td>b7 to b0</td></tr><tr><td>0H</td><td>1)</td></tr></table> 1) Transmission speed*1*2 00H: 9600bps 08H: 38400bps 05H: 4800bps 09H: 57600bps 06H: 9600bps 0AH: 115200bps 07H: 19200bps	b15 to b8	b7 to b0	0H	1)
b15 to b8	b7 to b0					
0H	1)					
D32002	D32012	8000H(fixed)				
D32003*3	D32013*3	0000H to 0001FH				

- *1 Only transmission speeds available on the GOT side are shown.
- *2 Set the same transmission speed of the GOT.
- *3 Set the host link station No. according to the Host Address on the GOT side.

Setting the DIP switches (CS1W-SCB41(-V1) only)

Set the DIP switches when performing the RS-422 communications on the CS1W-SCB41(-V1).



DIP switch		Set value
Name	Description	
WIRE	Setting(2-wire/4-wire) Switch	4 (4-wire type)
TERM	Terminator ON/OFF switch	OFF (no terminating resistor)


Point

Precautions for changing the DM area
Before changing the DM area, make sure that the switch setting has been changed as follows.
CS1: Front panel DIP switch SW5 to "OFF"

Connecting to RS-422A/485 Option board

Setting DIP switches

Set the DIP switches.





Switch No.		Settings	Description	
	1	ON	Enable	Terminating resistance selection
	2	OFF	4-wire type	2-wire or 4-wire selection
	3	OFF	4-wire type	2-wire or 4-wire selection
	5	ON	RS control enabled	RS control selection for RD
	6	ON	RS control enabled	RS control selection for SD

Connecting to RS-422A converter

Setting DIP switches


Set the DIP switches.



Switch No.		Settings	Description	
	1	ON	Enable	Terminating resistance selection
	2	OFF	4-wire type	2-wire or 4-wire selection
	3	OFF	4-wire type	2-wire or 4-wire selection
	5	ON	RS control enabled	RS control selection for RD
	6	ON	RS control enabled	RS control selection for SD

4.3 Ethernet Connection

System Configuration for connecting to SYSMAC CJ1/CJ2/CS1 series




PLC		Connection cable		GOT		Number of connectable equipment
Series	Ethernet module ^{*3}	Cable model ^{*1}	Maximum segment length ^{*2}	Option device ^{*6}	Model	
CS1H CS1G CS1D	CS1W-ETN21 CS1W-EIP21	Twisted pair cable • 10BASE-T Shielded twisted pair cable (STP) or unshielded twisted pair cable (UTP): Category 3, 4, and 5 • 100BASE-TX Shielded twisted pair cable (STP): Category 5 and 5e	100m	- (Built into GOT)	<div>GT 27</div> <div>GT 25</div> <div>GT 23</div> <div>GT 21</div> <div>GT 04R</div> <div>GT 03P</div> <div>GT 04P</div> <div>GT 04P</div> <div>GS</div>	When PLC:GOT is N:1 The following shows the number of PLCs for 1 GOT TCP: 128 or less UDP: 128 or less When PLC:GOT is 1:N The following shows the number of GOTs for 1 PLC TCP: 16 or less ^{*4} UDP: No limit number ^{*5}
				GT25-J71E71-100	<div>GT 27</div> <div>GT 25</div>	
CS1D	CS1D-ETN21D		100m	- (Built into GOT)	<div>GT 27</div> <div>GT 25</div> <div>GT 23</div> <div>GT 21</div> <div>GT 04R</div> <div>GT 03P</div> <div>GT 04P</div> <div>GT 04P</div> <div>GS</div>	
				GT25-J71E71-100	<div>GT 27</div> <div>GT 25</div>	
CJ1H CJ1M CJ1G	CJ1W-ETN21 CS1W-EIP21		100m	- (Built into GOT)	<div>GT 27</div> <div>GT 25</div> <div>GT 23</div> <div>GT 21</div> <div>GT 04R</div> <div>GT 03P</div> <div>GT 04P</div> <div>GT 04P</div> <div>GS</div>	
				GT25-J71E71-100	<div>GT 27</div> <div>GT 25</div>	

PLC		Connection cable		GOT		Number of connectable equipment
Series	Ethernet module*3	Cable model *1	Maximum segment length*2	Option device*6	Model	
CJ2H-CPU6□-EIP CJ2M-CPU3□	-	Twisted pair cable • 10BASE-T Shielded twisted pair cable (STP) or unshielded twisted pair cable (UTP): Category 3, 4, and 5 • 100BASE-TX Shielded twisted pair cable (STP): Category 5 and 5e	100m	- (Built into GOT)	<div><div>GT27</div><div>GT25</div><div>GT23</div><div>GT21</div><div>GT21</div><div>GT21</div><div>GS</div></div>	When PLC:GOT is N:1 The following shows the number of PLCs for 1 GOT TCP: 128 or less UDP: 128 or less When PLC:GOT is 1:N The following shows the number of GOTs for 1 PLC TCP: 16 or less*4 UDP: No limit number*5
				GT25-J71E71-100	<div><div>GT27</div><div>GT25</div></div>	
				- (Built into GOT)	<div><div>GT27</div><div>GT25</div><div>GT23</div><div>GT21</div><div>GT21</div><div>GT21</div><div>GS</div></div>	
	CJ1W-ETN21 CS1W-EIP21		100m	- (Built into GOT)	<div><div>GT27</div><div>GT25</div><div>GT23</div><div>GT21</div><div>GT21</div><div>GT21</div><div>GS</div></div>	
				GT25-J71E71-100	<div><div>GT27</div><div>GT25</div></div>	
				- (Built into GOT)	<div><div>GT27</div><div>GT25</div><div>GT23</div><div>GT21</div><div>GT21</div><div>GT21</div><div>GS</div></div>	
CJ2H-CPU6□ CJ2M-CPU1□	CJ1W-ETN21 CS1W-EIP21	100m	- (Built into GOT)	<div><div>GT27</div><div>GT25</div><div>GT23</div><div>GT21</div><div>GT21</div><div>GT21</div><div>GS</div></div>		
			GT25-J71E71-100	<div><div>GT27</div><div>GT25</div></div>		

- ^{*1} The destination connected with the twisted pair cable varies with the configuration of the applicable Ethernet network system.
Connect to the Ethernet module, hub, transceiver or other system equipment corresponding to the applicable Ethernet network system.
- ^{*2} A length between a hub and a node.
The maximum distance differs depending on the Ethernet device to be used.
The following shows the number of the connectable nodes when a repeater hub is used.
• 10BASE-T: Max. 4 nodes for a cascade connection (500m)
• 100BASE-TX: Max. 2 nodes for a cascade connection (205m)
When switching hubs are used, the cascade connection between the switching hubs has no logical limit for the number of cascades.
For the limit, contact the switching hub manufacturer.
- ^{*3} Product manufactured by OMRON Corporation. For details of the product, contact OMRON Corporation.
- ^{*4} If it is connected to devices other than the GOT using the connection, the number of connectable GOTs decreases.
For details, refer to the OMRON PLC user's manual.
- ^{*5} There is no restriction for the number of GOTs. However, if the number of GOTs increases, the communication becomes high-loaded, and it may affect the communication performance.
- ^{*6} GT25-W, GT2505-V does not support the option device.

System Configuration for connecting to NJ/NX series




4

PLC		Connection cable		GOT		Number of connectable equipment		
Series	Ethernet module ^{*3}	Cable model ^{*1}	Maximum segment length ^{*2}	Option device ^{*5}	Model			
NJ501-1500 NJ501-1400 NJ501-1300 NJ501-1520 NJ501-1420 NJ501-1320 NJ501-1340 NJ301-1200 NJ301-1100 NJ101-1000 NJ101-9000 NJ101-1020 NJ101-9020	CJ1W-EIP21	Shielded twisted pair cable (STP):Category 5 and 5e	100m	- (Built into GOT)	<div><div>GT27</div><div>GT25</div><div>GT23</div><div>GT21</div><div>GT07W</div><div>GT04R</div><div>GT03P</div><div>GT04P</div><div>ET/R4</div><div>GS</div></div>	When PLC:GOT is N:1 The following shows the number of PLCs for 1 GOT 128 or less When PLC:GOT is 1:N The following shows the number of GOTs for 1 PLC <Connection: CLASS3> 128 or less ^{*4} <Connection: UCMM> 32 or less ^{*4}		
						GT25-J71E71-100	<div><div>GT27</div><div>GT25</div></div>	
NJ501-1500 NJ501-1400 NJ501-1300 NJ501-1520 NJ501-1420 NJ501-1320 NJ501-1340 NJ301-1200 NJ301-1100 NJ101-1000 NJ101-9000 NJ101-1020 NJ101-9020	-				100m	- (Built into GOT)	<div><div>GT27</div><div>GT25</div><div>GT23</div><div>GT21</div><div>GT07W</div><div>GT04R</div><div>GT03P</div><div>GT04P</div><div>ET/R4</div><div>GS</div></div>	When PLC:GOT is N:1 The following shows the number of PLCs for 1 GOT 128 or less When PLC:GOT is 1:N The following shows the number of GOTs for 1 PLC <Connection: CLASS3> 32 or less ^{*4} <Connection: UCMM> 32 or less ^{*4}
					100m	GT25-J71E71-100	<div><div>GT27</div><div>GT25</div></div>	
NX1P2-1140DT NX1P2-1140DT1 NX1P2-1040DT NX1P2-1040DT1 NX1P2-9024DT NX1P2-9024DT1								
NX701-1700 NX701-1600	-				100m	- (Built into GOT)	<div><div>GT27</div><div>GT25</div><div>GT23</div><div>GT21</div><div>GT07W</div><div>GT04R</div><div>GT03P</div><div>GT04P</div><div>ET/R4</div><div>GS</div></div>	When PLC:GOT is N:1 The following shows the number of PLCs for 1 GOT 128 or less When PLC:GOT is 1:N The following shows the number of GOTs for 1 PLC <Connection: CLASS3> 128 or less per port (Total 256 or less for 2 ports) ^{*4} <Connection: UCMM> 32 or less per port (Total 64 or less for 2 ports) ^{*4}
					GT25-J71E71-100	<div><div>GT27</div><div>GT25</div></div>		

GOT side settings

Setting communication interface (Communication settings)

Set the channel of the equipment to be connected to the GOT.



1. Select [Common] → [Controller Setting] from the menu.
2. In the [Controller Setting] window, select the channel No. to be used from the list menu.
3. Select the following items and the detail setting is displayed.
 - [Manufacturer]: [OMRON]
 - [Controller Type]: Depends on the PLC.
SYSMAC CJ1/CJ2/CS1 series: [OMRON SYSMAC]
NJ/NX series: [OMRON NJ/NX]
 - [I/F]: [Ethernet:Multi]
 - [Detail Setting]: Configure the settings according to the usage environment.
4. When you have completed the settings, click the [OK] button.

Point

The settings of connecting equipment can be confirmed in [I/F Communication Setting].

For details, refer to the following.

Page 47 I/F communication setting

Communication detail settings

■Ethernet (OMRON), Gateway


Make the settings according to the usage environment.

Property	Value
GOT Net No.	1
GOT Station	18
GOT Communication Port No.	5018
Retry(Times)	3
Startup Time(Sec)	3
Timeout Time(Sec)	3
Delay Time(ms)	0

Item	Description	Range
GOT Net No.	Set the network No. of the GOT. (Default: 1)	1 to 127
GOT Station ^{*2}	Set the station No. of the GOT. (Default: 18)	1 to 254
GOT Communication Port No. ^{*1}	Set the GOT port No. for the connection with the Ethernet module. (Default: 5018 ^{*3})	1024 to 5010, 5014 to 65534 (Except for 5011, 5012, 5013 and 49153 to 49170)
Retry	Set the number of retries to be performed when a communication timeout occurs. When receiving no response after retries, the communication times out. (Default: 3times)	0 to 5times
Startup Time	Specify the time period from the GOT startup until GOT starts the communication with the PLC CPU. (Default: 3sec)	3 to 255sec
Timeout Time	Set the time period for a communication to time out. (Default: 3sec)	1 to 90sec
Delay Time	Set the delay time for reducing the load of the network/destination PLC. (Default: 0ms)	0 to 10000 (ms)

*1 By setting of the OMRON PLC, set the same [GOT Communication Port No.] setting as that of [FINS UDP Port] of CX-Programmer.

*2 Set different values for [GOT Station] of [Detail Setting] and [Station] of [Connected Ethernet Controller Setting].

 Page 262 Connected Ethernet Controller Setting

*3 When assigning the same driver to the multiple channels, in the communication drivers set as the second and following, the default value of [GOT Communication Port No.] becomes the earliest number in the vacant numbers of No. 6000 and later.

■EtherNet/IP (OMRON NJ/NX), Gateway

Make the settings according to the usage environment.

Property	Value
GOT Net No.	1
GOT Station	18
GOT Communication Port No.	5034
Startup Time(Sec)	3
Timeout Time(Sec)	3
Delay Time(ms)	0

Item	Description	Range
GOT Net No.	Set the network No. of the GOT. (Default: 1)	1 to 239
GOT Station ^{*1}	Set the station No. of the GOT. (Default: 18)	1 to 64
GOT Communication Port No.	Set the GOT port No. for the connection with the Ethernet module. (Default: 5034 ^{*3})	1024 to 5010, 5014 to 65534 (Except for 5011, 5012, 5013 and 49153 to 49170)
Startup Time	Specify the time period from the GOT startup until GOT starts the communication with the PLC CPU. (Default: 3sec)	3 to 255sec
Timeout Time ^{*2}	Set the time period for a communication to time out. (Default: 3sec)	1 to 90sec
Delay Time	Set the delay time for reducing the load of the network/destination PLC. (Default: 0ms)	0 to 10000 (ms)

*1 Set different values for [GOT Station] of [Detail Setting] and [Station] of [Connected Ethernet Controller Setting].

☞ Page 262 Connected Ethernet Controller Setting

*2 When [CJ1W-EIP21] is set for [Unit Type] in [Connected Ethernet Controller Setting], even if [Timeout Time] is set to 10 seconds or shorter, the GOT operates with the communication timeout period of 10 seconds.

If [CJ1W-EIP21] and [OMRON NJ] are selectable for [Unit Type] in [Connected Ethernet Controller Setting], and [OMRON NJ] (built-in port connecting side) is set, the GOT also operates with the communication timeout period of 10 seconds.

☞ Page 262 Connected Ethernet Controller Setting

*3 When assigning the same driver to the multiple channels, in the communication drivers set as the second and following, the default value of [GOT Communication Port No.] becomes the earliest number in the vacant numbers of No. 6000 and later.

GOT Ethernet Setting

The GOT can be connected to a different network by configuring the following setting.

■GOT IP address setting

Set the following communication port setting.

- Standard port (When using GT25-W, port 1)
- Extension port (When using GT25-W, port 2)

■GOT Ethernet common setting

Set the following setting which is common to the standard port and the extension port, or port 1 and port 2.

- [Default Gateway]
- [Peripheral S/W Communication Port No.]
- [Transparent Port No.]

■IP filter setting


By configuring the IP filter setting, the access from the specific IP address can be permitted or shut off.

For the detailed settings, refer to the following manual.

☞ Page 43 GOT Ethernet Setting

Connected Ethernet Controller Setting

■Ethernet (OMRON), Gateway



Item	Description	Set value
Host	The host is displayed. (The host is indicated with an asterisk (*).)	-
Net No.	Set the network No. of the connected Ethernet module. (Default: 1)	1 to 127
Station ^{*1}	Set the station No. of the connected Ethernet module. (Default: 1)	1 to 254
Unit Type	OMRON (fixed)	OMRON (fixed)
IP Address	Set the IP address of the connected Ethernet module. (Default: 192.168.250.1)	PLC side IP address
Port No.	Set the port No. of the connected Ethernet module. (Default: 9600)	256 to 65534
Communication format	Select a communication protocol. (Default: UDP)	UDP, TCP

*1 Set different values for [GOT Station] of [Detail Setting] and [Station] of [Connected Ethernet Controller Setting].

Page 260 Communication detail settings



[Connected Ethernet Controller Setting] for GT21 and GS21


- Effective range of [Connected Ethernet Controller Setting]

Only [1] to [4] of [Connected Ethernet Controller Setting] can be used for GT21 and GS21.


If [5] onwards are used, the settings are invalid on GT21 and GS21.

- [Host] setting

Set [Host] within the range from [1] to [4] in [Connected Ethernet Controller Setting].



■EtherNet/IP (OMRON NJ/NX), Gateway



Item	Description	Set value
Host	The host is displayed. (The host is indicated with an asterisk (*).)	-
Net No.	Set the network No. of the connected Ethernet module. (Default: 1)	1 to 239
Station ^{*1}	Set the station No. of the connected Ethernet module. (Default: 1)	1 to 64
Unit Type	Select the device according to the connection destination. Built in Ethernet port: OMRON NJ/NX Communication unit: CJ1W-EIP21 ^{*2} (Default: OMRON NJ/NX)	OMRON NJ/NX, CJ1W-EIP21
IP Address	Set the IP address of the connected Ethernet module. (Default: 1.1.1.1)	PLC side IP address ^{*3}
Port No.	44818 (fixed)	44818 (fixed)
Communication format	TCP (fixed)	TCP (fixed)
Connection	Set the connection. (Default: UCMM)	UCMM, Class3

^{*1} Set different values for [GOT Station] of [Detail Setting] and [Station] of [Connected Ethernet Controller Setting].

☞ Page 260 Communication detail settings

^{*2} NX series does not support [CJ1W-EIP21].

^{*3} NX701 and NX102 have two built-in EtherNet/IP ports.

Set [IP Address] in [Connected Ethernet Controller Setting] in GT Designer3, according to the port number set for NX701 or NX102 to be connected.

Point

- Communication interface setting by the Utility

The communication interface setting can be changed on the Utility's [Communication setting] after writing [Communication Settings] of project data.

For details on the Utility, refer to the following manual.

☞ GOT2000 Series User's Manual (Utility)

- Precedence in communication settings

When settings are made by GT Designer3 or the Utility, the latest setting is effective.

PLC side setting

SYSMAC CJ1/CJ2/CS1 series communication settings

For the PLC communication setting, set with a software for programming apparatus (CX-Programmer Ver.3.20 or later).

■CX-Programmer setting

Item		Setting range			
		Automatic generation method (dynamic) *4	Automatic generation method (static) *4*5	IP address table method *4*6	Combined method *4*6
Ethernet module CPU highly-functional module	Global	All 1 (Default)	All 1 (Default)	All 1 (Default)	All 1 (Default)
	IP address *1	[192]. [168]. [0]. [1]*3	[192]. [168]. [0]. [1]*3	[192]. [168]. [0]. [1]	[192]. [168]. [0]. [1]
	Subnet Mask	[255]. [255]. [255]. [0]	[255]. [255]. [255]. [0]	[255]. [255]. [255]. [0]	[255]. [255]. [255]. [0]
	FINS UDP port *1	9600	9600	9600	9600
	IP address conversion	Automatic conversion method (dynamic)	Automatic conversion method (static)	IP address table method	Combined method
	IP address table	-	-	11 [192]. [168]. [0]. [18]	-
	Transmission speed	Automatic detection (Default)	Automatic detection (Default)	Automatic detection (Default)	Automatic detection (Default)
	Node IP Address dynamically change *2	Change dynamically (Default)	Change dynamically (Default)	Change dynamically (Default)	Change dynamically (Default)

*1 Set the values of [IP Address] and [Port No.] in [Connected Ethernet Controller Setting] in GT Designer3 to [IP address] and [FINS UDP Port].

*2 The Node IP Address dynamically change function is available only when the Ethernet module to be used is Ver.1.3 or later. For the setting, set in the module setting of CX-ProgrammerVer.5.0 or later or in the WEB function.

For details of Node IP Address dynamically change, refer to the following manual.

☞ OMRON PLC user's Manual

*3 Set the same lowermost bit of the [IP address] setting as that of the node setting switch of the module.

Note that the node setting switch is set in hexadecimal. Convert this hexadecimal number to decimal, and set the value to the lowermost bit of [IP Address].

*4 In GT Designer3, set the same value to [GOT Communication Port No.] in [Detail Setting] and [Port No.] in [Connected Ethernet Controller Setting].

*5 In GT Designer3, set the value of [GOT Station] in [Detail Setting] to the lowermost byte of [GOT IP address] in [GOT IP Address Setting].

*6 In GT Designer3, set the value of [IP address table] to [GOT IP address] in [GOT IP Address Setting] and to [GOT Station] in [Detail Setting].

Point

OMRON PLC (SYSMAC CJ1/CJ2/CS1 series)

For the communication between OMRON PLC (SYSMAC CJ1/CJ2/CS1 series) and GOT, use the FINS communication.

For the FINS communication, the node must be specified according to the realm of FINS. However, for the Ethernet network, the data transfer according to the IP address is required.

- Automatic conversion method (dynamic)
- Automatic conversion method (static)
- IP address table conversion method
- Combined method

The following four methods are available for converting the FINS node address to the IP address.

For details of OMRON PLCs, refer to the following manual.

☞ OMRON PLC user's Manual

Communication Setting for NJ/NX series

For the PLC communication setting, set with an automation software Sysmac Studio.

■Versions of NJ series supporting Sysmac Studio

Version of the CPU module	Version of Sysmac Studio
Ver.1.14	Ver.1.18
Ver.1.13	Ver.1.17
Ver.1.12	Ver.1.16
Ver.1.11	Ver.1.15
Ver.1.10 ^{*1}	Ver.1.13 ^{*2}
	Ver.1.12
Ver.1.09	Ver.1.10
Ver.1.08	Ver.1.09
Ver.1.07	Ver.1.08
Ver.1.06	Ver.1.07
Ver.1.05	Ver.1.06
Ver.1.04	Ver.1.05
Ver.1.03	Ver.1.04
Ver.1.02	Ver.1.03
Ver.1.01	Ver.1.02
Ver.1.00 ^{*3}	Ver.1.01
	Ver.1.00

*1 The CPU module NJ101-□□□□ does not have Ver. 1.09 or earlier.

*2 Use Sysmac Studio Ver. 1.13 or later for the CPU module NJ101-□□□□.
Sysmac Studio Ver. 1.12 or earlier cannot be used for NJ101-□□□□.

*3 The CPU module NJ301-□□□□ does not have Ver. 1.00.
Therefore, Sysmac Studio Ver. 1.01 or earlier cannot be used for NJ301-□□□□.

■Versions of NX series supporting Sysmac Studio

Version of the CPU module	Version of Sysmac Studio
Ver.1.30 ^{*1}	Ver.1.23
Ver.1.18 ^{*2}	Ver.1.22
Ver.1.16 ^{*3}	Ver.1.20
Ver.1.14	Ver.1.18
Ver.1.13 ^{*4}	Ver.1.17 ^{*5}
Ver.1.12	Ver.1.16
Ver.1.11	Ver.1.15
Ver.1.10	Ver.1.13

*1 The version of CPU module NX102-□□□□

The CPU module NX102-□□□□ does not have Ver. 1.29 or earlier.

The CPU modules NX701-□□□□ and NX1P2-□□□□□□□□ do not have Ver. 1.30.

*2 The CPU modules NX701-□□□□ and NX1P2-□□□□□□□□ do not have Ver. 1.17.

*3 The CPU modules NX701-□□□□ and NX1P2-□□□□□□□□ do not have Ver. 1.15.

*4 The CPU module NX1P2-□□□□□□□□ does not have Ver. 1.12 or earlier.

*5 Use Sysmac Studio Ver. 1.17 or later for the CPU module NX1P2-□□□□□□□□.
Sysmac Studio Ver. 1.16 or earlier cannot be used for NX1P2-□□□□□□□□.

■Setting of an automation software Sysmac Studio

Item	Description	Range
IP address *1*3	Set the IP address.	0.0.0.0 to 255.255.255.255
Subnet Mask *2*3	Set the subnet mask for the sub network. (Only for connection via router) If the sub network is not used, the default value is set. (Default: 255.255.255.0)	0.0.0.0 to 255.255.255.255

*1 Apply the same setting as [Connected Ethernet Controller Setting] of the GOT.

☞ Page 263 EtherNet/IP (OMRON NJ/NX), Gateway

*2 Apply the same setting as [GOT Ethernet Setting] of the GOT.

☞ Page 43 GOT Ethernet Setting

*3 NX701-□□□□ and NX102-□□□□ have two built-in EtherNet/IP ports that can be set individually.

Precautions

When connecting to multiple GOTs

■Setting PLC No.

When connecting two or more GOTs in the Ethernet network, set each [PLC No.] to the GOT.

☞ Page 262 Connected Ethernet Controller Setting

■Setting IP address

Do not use the IP address "192.168.0.18" when using multiple GOTs with the GOT 1000 series mixed.

A communication error may occur on the GOT with the IP address.

When setting IP address

Do not use "0" and "255" at the end of an IP address.

(Numbers of *.**.0 and *.**.255 are used by the system.)

The GOT may not monitor the controller correctly with the above numbers.

Consult with the administrator of the network before setting an IP address to the GOT and controller.

When connecting to the multiple network equipment (including GOT) in a segment

By increasing the network load, the transmission speed between the GOT and PLC may be reduced.

The following actions may improve the communication performance.

- Using a switching hub
- More high speed by 100BASE-TX (100Mbps)
- Reduction of the monitoring points on GOT

When setting Port No. of CJ1/CJ2/CS1 series

By setting of the OMRON PLC, set the same [GOT Communication Port No.] setting as that of [FINS UDP Port] of CXProgrammer.

NJ/NX series start up

When writing or reading OMRON NJ/NX tag immediately after NJ/NX series setup, a system alarm may occur.

In this case, make the time to start communication with NJ/NX series longer in [Startup Time] for the communication detail settings.

For details, refer to the following manual.

☞ GT Designer3 (GOT2000) Screen Design Manual

4.4 Device Range that Can Be Set

The device ranges of controller that can be used for GOT are as follows.

Note that the device ranges in the following tables are the maximum values that can be set in GT Designer3.


The device specifications of controllers may differ depending on the models, even though belonging to the same series.

Please make the setting according to the specifications of the controller actually used.

When a non-existent device or a device number outside the range is set, other objects with correct device settings may not be monitored.


Setting item

■Ethernet (OMRON), Gateway



Item	Description
Device	Set the device name, device number, and bit number. The bit number can be set only when specifying the bit of word device.
Information	Displays the device type and setting range which are selected in [Device].

■EtherNet/IP (OMRON NJ), Gateway



Item	Description
Device	Set the device name, device number, and bit number. The bit number can be set only when specifying the bit of word device.
Information	Displays the device type and setting range which are selected in [Device].



Setting of OMRON NJ tag

In this dialog, only GOT internal device can be set.

For setting of OMRON NJ tag, refer to the following manual.

➡ GT Designer3 (GOT2000) Screen Design Manual

OMRON PLC (SYSMAC CJ1/CJ2/CS1 series)

Device name	Setting range	Device No. representation
Bit device	I/O relay/internal auxiliary relay (...)	..000000 to ..614315
	Data link relay (LR)	LR00000 to LR19915
	Auxiliary memory relay (AR)	AR000000 to AR147115 AR1000000 to AR1153515
	Holding relay (HR)	HR00000 to HR51115
	Internal auxiliary relay/Work relay (WR)	WR00000 to WR51115
	Timer contact (TIM)	TIM0000 to TIM4095
	Counter contact (CNT)	CNT0000 to CNT4095
	The bit specification of the word device *1 (except data link relay, auxiliary memory relay, holding relay and internal auxiliary relay.)	Setting range of each word device
Word device	I/O relay/internal auxiliary relay (...)	..0000 to ..6143
	Data link relay (LR)	LR000 to LR199
	Auxiliary memory relay (AR)	AR0000 to AR1471 AR10000 to AR11535
	Holding relay (HR)	HR000 to HR511
	Internal auxiliary relay/Work relay (WR)	WR000 to WR511
	Data memory (DM)	DM00000 to DM32767
	Timer (current value) (TIM) *3*4	TIM0000 to TIM4095
	Counter (current value) (CNT) *3*4	CNT0000 to CNT4095
	Extension data memory (EM current bank)*2	EM00000 to EM32767
	Extension data memory (E0 to EC: 13banks)*2	E000000 to E032767 : E1800000 to E1832767

*1 When executing the touch switch function set during the bit specification of the word device, do not write any data to the word device through the sequence program.

*2 Writing or reading the extension data memory using multiple banks is not allowed.

*3 Timer (current value) and counter (current value) are valid within the range of 0 to 9999.
(This applies to the 16 bit/32 bit device data.)

*4 "Timer (current value)" and "Counter (current value)" are handled as BCD values by the PLC.
If the connection form between the PLC and the GOT is serial, however, they are handled as unsigned binary 16-bit data by the GOT.
Set the data type of "Monitor object" in the GOT to "Unsigned BIN16".

OMRON PLC (NJ/NX series)

When monitoring OMRON NJ/NX series, use OMRON NJ/NX tag.

For details of the OMRON NJ/NX tags that can be used, refer to the following manuals.

 GT Designer3 (GOT2000) Screen Design Manual

MEMO

5 CONNECTION TO OMRON TEMPERATURE CONTROLLER

- Page 271 Connectable Model List
- Page 272 System Configuration
- Page 285 Connection Diagram
- Page 295 GOT Side Settings
- Page 298 Temperature Controller Side Setting
- Page 303 Device Range that Can Be Set
- Page 307 Precautions

5.1 Connectable Model List

The following table shows the connectable models.



Series	Model name	Communication Type	Connectable GOT	Refer to
THERMAC NEO	E5AN E5EN E5GN E5CN(-H,-HT)	RS-232	GT 27 GT 25 GT 23 GT 21 GS	☞ Page 272 Connecting to the THERMAC NEO series
		RS-485	GT 27 GT 25 GT 23 GT 21	
	E5AN-H E5EN-H E5AN-HT E5EN-HT	RS-232 RS-422	GT 27 GT 25 GT 23 GT 21 GS	
		RS-485	GT 27 GT 25 GT 23 GT 21	
INPANEL NEO	E5ZN	RS-232 RS-485	GT 27 GT 25 GT 23 GT 21 GS	☞ Page 279 Connecting to the INPANEL NEO
E5□C	E5CC(-T,-B) E5DC E5GC E5EC(-T,-B) E5AC(-T)	RS-232	GT 27 GT 25 GT 23 GT 21 GS	☞ Page 281 Connecting to the E5□C series, E5□D series
		RS-485	GT 27 GT 25 GT 23 GT 21	
E5□D	E5CD(-B) E5ED(-B)	RS-232 RS-485	GT 27 GT 25 GT 23 GT 21	☞ Page 281 Connecting to the E5□C series, E5□D series
THERMAC R	E5AR(-T) E5ER(-T)	RS-232	GT 27 GT 25 GT 23 GT 21 GS	☞ Page 283 Connecting to the THERMAC R series
		RS-485	GT 27 GT 25 GT 23 GT 21	

5.2 System Configuration

Connecting to the THERMAC NEO series

When connecting to one temperature controller

■ When connecting to E5AN, E5EN




Temperature controller		Connection cable		GOT		Number of connectable equipment
Model name	Communication Type	Cable model Connection diagram number	Max. distance	Option device*2	Model	
E5AN E5EN	RS-232	(User preparing) Page 285 RS-232 connection diagram 1)	15m	- (Built into GOT)	<div>GT 27</div> <div>GT 23</div> <div>GT 21</div> <div>GT 25</div> <div>GT 21</div> <div>GS</div>	1 temperature controller for 1 GOT
				GT15-RS2-9P	<div>GT 27</div> <div>GT 25</div>	
				GT10-C02H-6PT9P*1	<div>GT 03P</div> <div>GT 104P</div> <div>R4</div> <div>GT 03P</div> <div>GT 104P</div> <div>R2</div>	
		(User preparing) Page 285 RS-232 connection diagram 3)	15m	- (Built into GOT)	<div>GT 21</div> <div>GT 21</div> <div>GT 03P</div> <div>GT 104P</div> <div>R2</div>	

*1 When a GT10-C02H-6PT9P unit of the sub version A or B is used, do not ground the case of the D-sub (9-pin) connector.

*2 GT25-W, GT2505-V does not support the option device.

■When connecting to E5AN-H, E5CN-H, E5EN-H, E5AN-HT, E5CN-HT, E5EN-HT




Temperature controller		Connection cable		GOT		Number of connectable equipment
Model name	Communication Type	Cable model Connection diagram number	Max. distance	Option device ^{*2}	Model	
E5AN-H E5EN-H E5AN-HT E5EN-HT E5CN-H E5CN-HT	RS-232	Page 285 RS-232 connection diagram 1)	15m	- (Built into GOT)		1 temperature controller for 1 GOT
				GT15-RS2-9P		
				GT10-C02H-6PT9P ^{*1}		
		Page 285 RS-232 connection diagram 3)	15m	- (Built into GOT)		

*1 When a GT10-C02H-6PT9P unit of the sub version A or B is used, do not ground the case of the D-sub (9-pin) connector.

*2 GT25-W, GT2505-V does not support the option device.

When connecting to multiple temperature controllers (via an interface converter)

■ When connecting to E5AN, E5EN, E5CN, E5GN




Temperature controller	Connection cable 1)		Interface converter*1		Connection cable 2)		GOT		Number of connectable equipment
Model name	Cable model Connection diagram number	Max. distance	Model name	Communication Type	Cable model Connection diagram number	Max. distance	Option device*3	Model	
E5AN E5EN E5CN E5GN	(User preparing) Page 289 RS-485 connection diagram 1)	500m	K3SC-10	RS-232	(User preparing) Page 285 RS-232 connection diagram 2)	15m	- (Built into GOT)	<div>GT 27</div> <div>GT 23</div> <div>GT 21</div> <div>GT 25</div> <div>GT 24</div> <div>GS</div>	32 temperature controllers for 1 GOT
							GT15-RS2-9P	<div>GT 27</div> <div>GT 25</div>	
							GT10-C02H-6PT9P*2	<div>GT 21</div> <div>GT 24</div> <div>GT 25</div> <div>GT 26</div> <div>GT 27</div> <div>GT 28</div> <div>GT 29</div> <div>GT 30</div> <div>GT 31</div> <div>GT 32</div> <div>GT 33</div> <div>GT 34</div> <div>GT 35</div> <div>GT 36</div> <div>GT 37</div> <div>GT 38</div> <div>GT 39</div> <div>GT 40</div> <div>GT 41</div> <div>GT 42</div> <div>GT 43</div> <div>GT 44</div> <div>GT 45</div> <div>GT 46</div> <div>GT 47</div> <div>GT 48</div> <div>GT 49</div> <div>GT 50</div> <div>GT 51</div> <div>GT 52</div> <div>GT 53</div> <div>GT 54</div> <div>GT 55</div> <div>GT 56</div> <div>GT 57</div> <div>GT 58</div> <div>GT 59</div> <div>GT 60</div> <div>GT 61</div> <div>GT 62</div> <div>GT 63</div> <div>GT 64</div> <div>GT 65</div> <div>GT 66</div> <div>GT 67</div> <div>GT 68</div> <div>GT 69</div> <div>GT 70</div> <div>GT 71</div> <div>GT 72</div> <div>GT 73</div> <div>GT 74</div> <div>GT 75</div> <div>GT 76</div> <div>GT 77</div> <div>GT 78</div> <div>GT 79</div> <div>GT 80</div> <div>GT 81</div> <div>GT 82</div> <div>GT 83</div> <div>GT 84</div> <div>GT 85</div> <div>GT 86</div> <div>GT 87</div> <div>GT 88</div> <div>GT 89</div> <div>GT 90</div> <div>GT 91</div> <div>GT 92</div> <div>GT 93</div> <div>GT 94</div> <div>GT 95</div> <div>GT 96</div> <div>GT 97</div> <div>GT 98</div> <div>GT 99</div> <div>GT 100</div>	
					(User preparing) Page 286 RS-232 connection diagram 4)	15m	- (Built into GOT)	<div>GT 21</div> <div>GT 24</div> <div>GT 25</div> <div>GT 26</div> <div>GT 27</div> <div>GT 28</div> <div>GT 29</div> <div>GT 30</div> <div>GT 31</div> <div>GT 32</div> <div>GT 33</div> <div>GT 34</div> <div>GT 35</div> <div>GT 36</div> <div>GT 37</div> <div>GT 38</div> <div>GT 39</div> <div>GT 40</div> <div>GT 41</div> <div>GT 42</div> <div>GT 43</div> <div>GT 44</div> <div>GT 45</div> <div>GT 46</div> <div>GT 47</div> <div>GT 48</div> <div>GT 49</div> <div>GT 50</div> <div>GT 51</div> <div>GT 52</div> <div>GT 53</div> <div>GT 54</div> <div>GT 55</div> <div>GT 56</div> <div>GT 57</div> <div>GT 58</div> <div>GT 59</div> <div>GT 60</div> <div>GT 61</div> <div>GT 62</div> <div>GT 63</div> <div>GT 64</div> <div>GT 65</div> <div>GT 66</div> <div>GT 67</div> <div>GT 68</div> <div>GT 69</div> <div>GT 70</div> <div>GT 71</div> <div>GT 72</div> <div>GT 73</div> <div>GT 74</div> <div>GT 75</div> <div>GT 76</div> <div>GT 77</div> <div>GT 78</div> <div>GT 79</div> <div>GT 80</div> <div>GT 81</div> <div>GT 82</div> <div>GT 83</div> <div>GT 84</div> <div>GT 85</div> <div>GT 86</div> <div>GT 87</div> <div>GT 88</div> <div>GT 89</div> <div>GT 90</div> <div>GT 91</div> <div>GT 92</div> <div>GT 93</div> <div>GT 94</div> <div>GT 95</div> <div>GT 96</div> <div>GT 97</div> <div>GT 98</div> <div>GT 99</div> <div>GT 100</div>	

*1 The interface converter is a product manufactured by OMRON Corporation. For details on the product, contact OMRON Corporation.

*2 When a GT10-C02H-6PT9P unit of the sub version A or B is used, do not ground the case of the D-sub (9-pin) connector.

*3 GT25-W, GT2505-V does not support the option device.

■When connecting to E5AN-H, E5CN-H, E5EN-H, E5AN-HT, E5CN-HT, E5EN-HT



Temperature controller	Connection cable 1)		Interface converter* ¹		Connection cable 2)		GOT		Number of connectable equipment
Model name	Cable model Connection diagram number	Max. distance	Model name	Communication Type	Cable model Connection diagram number	Max. distance	Option device* ³	Model	
E5AN-H E5EN-H E5AN-HT E5EN-HT E5CN-H E5CN-HT	(User preparing) Page 289 RS-485 connection diagram 1)	500m	K3SC-10	RS-232	(User preparing) Page 285 RS-232 connection diagram 2)	15m	- (Built into GOT)	<div>GT 27</div> <div>GT 25</div> <div>GT 23</div> <div>GT 21</div> <div>GT 2505V</div> <div>GS</div>	32 temperature controllers for 1 GOT
							GT15-RS2-9P	<div>GT 27</div> <div>GT 25</div>	
							GT10-C02H-6PT9P* ²	<div>GT 21</div> <div>GT 25</div> <div>GT 103P</div> <div>GT 104P</div> <div>GT 103P</div> <div>GT 104P</div>	
					(User preparing) Page 286 RS-232 connection diagram 4)	15m	- (Built into GOT)	<div>GT 21</div> <div>GT 25</div> <div>GT 104P</div> <div>GT 103P</div> <div>GT 104P</div> <div>GT 103P</div>	


*1 The interface converter is a product manufactured by OMRON Corporation. For details on the product, contact OMRON Corporation.

*2 When a GT10-C02H-6PT9P unit of the sub version A or B is used, do not ground the case of the D-sub (9-pin) connector.

*3 GT25-W, GT2505-V does not support the option device.

When connecting to multiple temperature controllers

■When connecting to E5AN, E5EN, E5CN, E5GN



Temperature controller		Connection cable		GOT		Number of connectable equipment
Model name	Communication Type	Cable model Connection diagram number	Max. distance	Option device	Model	
E5AN E5EN E5CN E5GN	RS-485	Page 290 RS-485 connection diagram 2)	500m	FA-LTBGT2R4CBL05 (0.5m) FA-LTBGT2R4CBL10 (1m) FA-LTBGT2R4CBL20 (2m)		31 temperature controllers for 1 GOT
		Page 291 RS-485 connection diagram 3)	500m	GT15-RS4-TE		
		Page 294 RS-485 connection diagram 6)	500m	GT14-RS2T4-9P ^{*3}		
		Page 292 RS-485 connection diagram 4)	500m	- (Built into GOT)	 	
		Page 293 RS-485 connection diagram 5)	500m	GT10-C02H-9SC		
				- (Built into GOT)	 	


*1 Not available to GT25-W.











































*2 Not available to GT2505-V.

*3 Mount it on the RS-232 interface (GOT built-in).

*4 Only available to GT2505-V.

■When connecting to E5AN-H, E5CN-H, E5EN-H, E5AN-HT, E5CN-HT, E5EN-HT



Temperature controller		Connection cable		GOT		Number of connectable equipment	
Model name	Communication Type	Cable model Connection diagram number	Max. distance	Option device	Model		
E5AN-H E5EN-H E5AN-HT E5CN-H E5CN-HT	RS-485	 Page 290 RS-485 connection diagram 2)	500m	FA-LTBGT2R4CBL05(0.5m) FA-LTBGT2R4CBL10(1m) FA-LTBGT2R4CBL20(2m)	  *3	31 temperature controllers for 1 GOT *1	
		 Page 291 RS-485 connection diagram 3)	500m	GT15-RS4-TE	  *2*3		
		 Page 294 RS-485 connection diagram 6)	500m	GT14-RS2T4-9P *4	 *5		
		 Page 292 RS-485 connection diagram 4)	500m	- (Built into GOT)	     		
			 Page 293 RS-485 connection diagram 5)	500m	GT10-C02H-9SC		   
					- (Built into GOT)		   
E5AN-H E5EN-H E5AN-HT E5EN-HT	RS-422	 Page 287 RS-422 connection diagram 1)	500m	- (Built into GOT)	     		
		 Page 287 RS-422 connection diagram 2)	500m	GT15-RS4-9S	  *2*3		
				GT10-C02H-9SC	   		
				- (Built into GOT)	   		

*1 Up to 10 temperature controllers can be connected to GS21.

*2 Not available to GT25-W.


*3 Not available to GT2505-V.

*4 Mount it on the RS-232 interface (GOT built-in).

*5 Only available to GT2505-V.

Connecting to the INPANEL NEO

When connecting to multiple temperature controllers (via interface converter)




Temperature controller	Connection cable 1)		Interface converter* ¹		Connection cable 2)		GOT		Number of connectable equipment
Model name	Cable model Connection diagram number	Max. distance	Model name	Communication Type	Cable model Connection diagram number	Max. distance	Option device* ³	Model	
E5ZN	(User preparing) Page 289 RS-485 connection diagram 1)	500m	K3SC-10	RS-232	(User preparing) Page 285 RS-232 connection diagram 2)	15m	- (Built into GOT)	<div>GT 27</div> <div>GT 25</div> <div>GT 21</div> <div>GT 07W</div> <div>GS</div>	16 temperature controllers for 1 GOT
							GT15-RS2-9P	<div>GT 27</div> <div>GT 25</div>	
							GT10-C02H-6PT09P* ²	<div>GT 03P</div> <div>GT 04P</div> <div>GT 21</div> <div>GT 07W</div> <div>GT 03P</div> <div>GT 04P</div> <div>R4</div> <div>R2</div>	
					(User preparing) Page 286 RS-232 connection diagram 4)	15m	- (Built into GOT)	<div>GT 04P</div> <div>GT 21</div> <div>GT 03P</div> <div>GT 04P</div> <div>R4</div> <div>R2</div>	

*¹ The interface converter is a product manufactured by OMRON Corporation. For details of the product, contact OMRON Corporation.

*² When a GT10-C02H-6PT9P unit of the sub version A or B is used, do not ground the case of the D-sub (9-pin) connector.

*³ GT25-W, GT2505-V does not support the option device.

When connecting to multiple temperature controllers



Temperature controller		Connection cable		GOT		Number of connectable equipment
Model name	Communication Type	Cable model Connection diagram number	Max. distance	Option device	Model	
E5ZN	RS-485	Page 290 RS-485 connection diagram 2)	500m	FA-LTBGT2R4CBL05 (0.5m) FA-LTBGT2R4CBL10 (1m) FA-LTBGT2R4CBL20 (2m)	 *2	15 temperature controllers for 1 GOT
		Page 291 RS-485 connection diagram 3)	500m	GT15-RS4-TE	 *1*2	
		Page 294 RS-485 connection diagram 6)	500m	GT14-RS2T4-9P*3	 *4	
		Page 292 RS-485 connection diagram 4)	500m	- (Built into GOT)	 	
		Page 293 RS-485 connection diagram 5)		GT10-C02H-9SC	 	
				- (Built into GOT)	 	

*1 Not available to GT25-W.


*2 Not available to GT2505-V.

*3 Mount it on the RS-232 interface (GOT built-in).

*4 Only available to GT2505-V.

Connecting to the E5□C series, E5□D series

When connecting to multiple temperature controllers (via interface converter)




Temperature controller	Connection cable 1)		Interface converter*1		Connection cable 2)		GOT		Number of connectable equipment
Model name	Cable model Connection diagram number	Max. distance	Model name	Communication Type	Cable model Connection diagram number	Max. distance	Option device*3	Model	
E5CC(-T,-B) E5DC E5GC E5EC(-T,-B) E5AC(-T)	(User preparing) Page 289 RS-485 connection diagram 1)	500m	K3SC-10	RS-232	(User preparing) Page 285 RS-232 connection diagram 2)	15m	- (Built into GOT)	<div>GT 27 25</div> <div>GT 23 21</div> <div>GT 21 050 GS</div>	32 temperature controllers for 1 GOT
							GT15-RS2-9P	<div>GT 27 25</div>	
							GT10-C02H-6PT9P*2	<div>GT 03P 2104P R4</div> <div>GT 03P 2104P R2</div>	
					(User preparing) Page 286 RS-232 connection diagram 4)	15m	- (Built into GOT)	<div>GT 04P 2104P R4</div> <div>GT 03P 2104P R2</div>	
E5CD(-B) E5ED(-B)	(User preparing) Page 285 RS-232 connection diagram 2)	15m				15m	- (Built into GOT)	<div>GT 27 25</div> <div>GT 23 21</div> <div>GT 03P 2104P R2</div>	
							GT15-RS2-9P	<div>GT 27 25</div>	

*1 The interface converter is a product manufactured by OMRON Corporation. For details of the product, contact OMRON Corporation.

*2 When a GT10-C02H-6PT9P unit of the sub version A or B is used, do not ground the case of the D-sub (9-pin) connector.

*3 GT25-W, GT2505-V does not support the option device.

When connecting to multiple temperature controllers



Temperature controller		Connection cable		GOT		Number of connectable equipment
Model name	Communication Type	Cable model Connection diagram number	Max. distance	Option device	Model	
E5CC(-T,-B) E5DC E5GC E5EC(-T,-B) E5AC(-T) E5CD(-B) E5ED(-B)	RS-485	Page 290 RS-485 connection diagram 2)	500m	FA-LTBGT2R4CBL05(0.5m) FA-LTBGT2R4CBL10(1m) FA-LTBGT2R4CBL20(2m)	 *2	31 temperature controllers for 1 GOT
		Page 291 RS-485 connection diagram 3)	500m	GT15-RS4-TE	 *1*2	
		Page 294 RS-485 connection diagram 6)	500m	GT14-RS2T4-9P*3	 *4	
		Page 292 RS-485 connection diagram 4)	500m	-(Built into GOT)	 	
				GT10-C02H-9SC		
		Page 293 RS-485 connection diagram 5)		-(Built into GOT)		
E5CD-B E5ED-B		Page 292 RS-485 connection diagram 4)	500m	GT15-RS4-9S	 *1*2	

*1 Not available to GT25-W.


*2 Not available to GT2505-V.

*3 Mount it on the RS-232 interface (GOT built-in).

*4 Only available to GT2505-V.

Connecting to the THERMAC R series

When connecting to multiple temperature controllers (via interface converter)




Temperature controller	Connection cable 1)		Interface converter* ¹		Connection cable 2)		GOT		Number of connectable equipment
Model name	Cable model	Max. distance	Model name	Communication Type	Cable model	Max. distance	Option device* ³	Model	
E5AR(-T) E5ER(-T)	(User preparing) Page 289 RS-485 connection diagram 1)	500m	K3SC-10	RS-232	(User preparing) Page 285 RS-232 connection diagram 2)	15m	- (Built into GOT)	<div>GT 27 25</div> <div>GT 23 21</div> <div>GT 21 050 GS</div>	32 temperature controllers for 1 GOT
							GT15-RS2-9P	<div>GT 27 25</div>	
							GT10-C02H-6PT9P* ²	<div>GT 03P 21 04P R4</div> <div>GT 03P 21 04P R2</div>	
					(User preparing) Page 286 RS-232 connection diagram 4)	15m	- (Built into GOT)	<div>GT 04P 21 03P R2</div>	

*¹ The interface converter is a product manufactured by OMRON Corporation. For details of the product, contact OMRON Corporation.

*² When a GT10-C02H-6PT9P unit of the sub version A or B is used, do not ground the case of the D-sub (9-pin) connector.

*³ GT25-W, GT2505-V does not support the option device.

When connecting to multiple temperature controllers



Temperature controller		Connection cable		GOT		Number of connectable equipment
Model name	Communication Type	Cable model Connection diagram number	Max. distance	Option device	Model	
E5AR(-T) E5ER(-T)	RS-485	Page 290 RS-485 connection diagram 2)	500m	FA-LTBGT2R4CBL05(0.5m) FA-LTBGT2R4CBL10(1m) FA-LTBGT2R4CBL20(2m)		31 temperature controllers for 1 GOT
					*2	
		Page 291 RS-485 connection diagram 3)	500m	GT15-RS4-TE		
					*1*2	
		Page 294 RS-485 connection diagram 6)	500m	GT14-RS2T4-9P*3		
		Page 292 RS-485 connection diagram 4)	500m	- (Built into GOT)		
				GT10-C02H-9SC		
		Page 293 RS-485 connection diagram 5)		- (Built into GOT)		

*1 Not available to GT25-W.

*2 Not available to GT2505-V.

*3 Mount it on the RS-232 interface (GOT built-in).

*4 Only available to GT2505-V.


5.3 Connection Diagram

The following diagram shows the connection between the GOT and the PLC.


RS-232 cable

Connection diagram


■RS-232 connection diagram 1)




■RS-232 connection diagram 2)



■RS-232 connection diagram 3)



■RS-232 connection diagram 4)



Precautions when preparing a cable

■Cable length

The length of the RS-232 cable must be 15m or less

■GOT side connector

For the GOT side connector, refer to the following.

☞ Page 58 GOT connector specifications

■OMRON temperature controller side connector


Use the connector compatible with the OMRON temperature controller.

For details, refer to the user's manual of the OMRON temperature controller.

RS-422 cable

Connection diagram

■RS-422 connection diagram 1)



*1 Terminating resistor of 240Ω 1/2W should be provided for a temperature controller which will be a terminal.


*2 For GT27 and GT25 (except for GT2505-V), set the terminating resistor to "Enable".

For GT2505-V and GT21, set the terminating resistor to "330 Ω".

For GS21, since the terminating resistor is fixed to 330 Ω, no setting is required for the terminating resistor.

☞ Page 62 Terminating resistors of GOT

■RS-422 connection diagram 2)



*1 Terminating resistor of 240Ω 1/2W should be provided for a temperature controller which will be a terminal.

*2 Set the terminating resistor of GOT side, which will be a terminal, to "330Ω".

☞ Page 62 Terminating resistors of GOT

*3 The signals RSA, RSB, CSA, and CSB are not provided for GT2104-PMBD, GT2103-PMBD. Return connection is not required.

Precautions when preparing a cable

■Cable length

The length of the RS-422 cable must be 500m or less.

■GOT side connector

For the GOT side connector, refer to the following.

☞ Page 58 GOT connector specifications

■OMRON temperature controller side connector

Use the connector compatible with the OMRON temperature controller.

For details, refer to the user's manual of the OMRON temperature controller.

Setting terminating resistors

■GOT side

Set the terminating resistor setting switch of the GOT main unit to "100 OHM".

For details of terminating resistor settings, refer to the following.

☞ Page 62 Terminating resistors of GOT

■OMRON temperature controller side


When connecting a OMRON temperature controller to the GOT, the terminating resistor must be connected to the OMRON temperature controller.

☞ User's Manual of the OMRON temperature controller

RS-485 cable

Connection diagram

■RS-485 connection diagram 1)




*1 Pin No. of temperature controller differs depending on the model. Refer to the following.

*2 Terminating resistor should be provided for a temperature controller and an interface converter which will be terminating resistors.

Signal name	Model of temperature controller								Interface converter (K3SC-10)
	E5AN(-H,-HT) E5EN(-H,-HT) E5CN(-H,-HT)	E5GN	E5ZN	E5CC(-T) E5EC(-T) E5AC(-T)	E5CC-B E5EC-B	E5DC	E5GC	E5AR(-T) E5ER(-T)	
	Pin No.	Pin No.	Pin No.	Pin No.	Pin No.	Pin No.	Pin No.	Pin No.	
A(-)	12	6	24	14	19 or 20	4	8	2	8
B(+)	11	5	23	13	17 or 18	3	7	1	11

■RS-485 connection diagram 2)



*1 Pin No. of temperature controller differs depending on the model.Refer to the following.


*2 Terminating resistor should be provided for a temperature controller and an interface converter which will be terminating resistors.

*3 Set the terminating resistor of GOT side, which will be a terminal, to "Enable".

☞ Page 62 Terminating resistors of GOT

Signal name	Model of temperature controller							
	E5AN(-H,-HT) E5EN(-H,-HT) E5CN(-H,-HT)	E5GN	E5ZN	E5CC(-T) E5EC(-T) E5AC(-T) E5CD E5ED	E5CC-B E5EC-B E5CD-B E5ED-B	E5DC	E5GC	E5AR(-T) E5ER(-T)
	Pin No.	Pin No.	Pin No.	Pin No.	Pin No.	Pin No.	Pin No.	Pin No.
A(-)	12	6	24	14	19 or 20	4	8	2
B(+)	11	5	23	13	17 or 18	3	7	1

■RS-485 connection diagram 3)



*1 Pin No. of temperature controller differs depending on the model. Refer to the following.


*2 Terminating resistor should be provided for a temperature controller and an interface converter which will be terminating resistors.

*3 Set the terminating resistor of GOT side, which will be a terminal, to "Enable".

☞ Page 62 Terminating resistors of GOT

Signal name	Model of temperature controller							
	E5AN(-H,-HT) E5EN(-H,-HT) E5CN(-H,-HT)	E5GN	E5ZN	E5CC(-T) E5EC(-T) E5AC(-T) E5CD E5ED	E5CC-B E5EC-B E5CD-B E5ED-B	E5DC	E5GC	E5AR(-T) E5ER(-T)
	Pin No.	Pin No.	Pin No.	Pin No.	Pin No.	Pin No.	Pin No.	Pin No.
A(-)	12	6	24	14	19 or 20	4	8	2
B(+)	11	5	23	13	17 or 18	3	7	1

■RS-485 connection diagram 4)



*1 Pin No. of temperature controller differs depending on the model. Refer to the following.

*2 Terminating resistor should be provided for a temperature controller and an interface converter which will be terminating resistors.


*3 For GT27 and GT25 (except for GT2505-V), set the terminating resistor to "Enable".

For GT2505-V and GT21, set the terminating resistor to "110 Ω".

Page 62 Terminating resistors of GOT

Signal name	Model of temperature controller							
	E5AN(-H,-HT) E5EN(-H,-HT) E5CN(-H,-HT)	E5GN	E5ZN	E5CC(-T) E5EC(-T) E5AC(-T) E5CD E5ED	E5CC-B E5EC-B E5CD-B E5ED-B	E5DC	E5GC	E5AR(-T) E5ER(-T)
	Pin No.	Pin No.	Pin No.	Pin No.	Pin No.	Pin No.	Pin No.	Pin No.
A(-)	12	6	24	14	19 or 20	4	8	2
B(+)	11	5	23	13	17 or 18	3	7	1

■RS-485 connection diagram 5)




- *1 Pin No. of temperature controller differs depending on the model. Refer to the following.
- *2 Terminating resistor should be provided for a temperature controller and an interface converter which will be terminating resistors.
- *3 Set the terminating resistor of GOT side, which will be a terminal, to "110Ω".
- Page 62 Terminating resistors of GOT

Signal name	Model of temperature controller							
	E5AN(-H,-HT) E5EN(-H,-HT) E5CN(-H,-HT)	E5GN	E5ZN	E5CC(-T) E5EC(-T) E5AC(-T) E5CD E5ED	E5CC-B E5EC-B E5CD-B E5ED-B	E5DC	E5GC	E5AR(-T) E5ER(-T)
	Pin No.	Pin No.	Pin No.	Pin No.	Pin No.	Pin No.	Pin No.	Pin No.
A(-)	12	6	24	14	19 or 20	4	8	2
B(+)	11	5	23	13	17 or 18	3	7	1

*4 The signals RSA, RSB, CSA, and CSB are not provided for GT2104-PMBD, GT2103-PMBD. Return connection is not required.

■RS-485 connection diagram 6)



*1 Pin No. of temperature controller differs depending on the model. Refer to the following.

Signal name	Model of temperature controller							
	E5AN(-H,-HT) E5EN(-H,-HT) E5CN(-H,-HT)	E5GN	E5ZN	E5CC(-T) E5EC(-T) E5AC(-T) E5CD E5ED	E5CC-B E5EC-B E5CD-B E5ED-B	E5DC	E5GC	E5AR(-T) E5ER(-T)
	Pin No.	Pin No.	Pin No.	Pin No.	Pin No.	Pin No.	Pin No.	Pin No.
A(-)	12	6	24	14	19 or 20	4	8	2
B(+)	11	5	23	13	17 or 18	3	7	1

*2 Terminating resistor should be provided for a temperature controller and the GOT which will be terminating resistors.

*3 Set the 2-wire/4-wire terminating resistor setting switch of the RS-232/485 signal conversion adaptor as shown below.

2-wire/4-wire: 2-wire (1Pair)

Terminating resistor: OPEN

☞ Page 67 Setting the RS-232/485 signal conversion adaptor

Precautions when preparing a cable

■Cable length

The length of the RS-485 cable must be 500m or less.

■GOT side connector

For the GOT side connector, refer to the following.

☞ Page 58 GOT connector specifications

■OMRON temperature controller side connector

Use the connector compatible with the OMRON temperature controller.

For details, refer to the user's manual of the OMRON temperature controller.

Setting terminating resistors

■GOT side

Set the terminating resistor setting switch of the GOT main unit to "100 OHM".

For details of terminating resistor settings, refer to the following.

☞ Page 62 Terminating resistors of GOT

■OMRON temperature controller side


When connecting a OMRON temperature controller to the GOT, the terminating resistor must be connected to the OMRON temperature controller.

☞ User's Manual of the OMRON temperature controller

5.4 GOT Side Settings

Setting communication interface (Communication settings)

Set the channel of the equipment to be connected to the GOT.



1. Select [Common] → [Controller Setting] from the menu.
2. In the [Controller Setting] window, select the channel No. to be used from the list menu.
3. Select the following items and the detail setting is displayed.
 - [Manufacturer]: [OMRON]
 - [Controller Type]: Select one of the following items according to the controller to be connected.

Series	Model of temperature controller	Controller Type
THERMAC NEO	E5AN, E5EN, E5CN, E5GN	OMRON THERMAC/INPANEL NEO or OMRON digital temperature controller
	E5AN-H, E5CN-H, E5EN-H, E5AN-HT, E5CN-HT, E5EN-HT	OMRON digital temperature controller
INPANEL NEO	E5ZN	OMRON THERMAC/INPANEL NEO or OMRON digital temperature controller
E5□C	E5CC(-T,-B), E5DC, E5GC, E5EC(-T,-B), E5AC(-T)	OMRON digital temperature controller
E5□D	E5CD(-B), E5ED(-B)	OMRON digital temperature controller
THERMAC R	E5AR(-T), E5ER(-T)	OMRON digital temperature controller

- [I/F]: Interface to be used
- [Detail Setting]: Configure the settings according to the usage environment.

☞ Page 296 Communication detail settings

4. When you have completed the settings, click the [OK] button.

Point

The settings of connecting equipment can be confirmed in [I/F Communication Setting].
For details, refer to the following.

☞ Page 47 I/F communication setting

Communication detail settings

Make the settings according to the usage environment.

OMRON THERMAC/INPANEL NEO

Property	Value
Transmission Speed(BPS)	9600
Data Bit	7 bit
Stop Bit	2 bit
Parity	Even
Retry(Times)	0
Timeout Time(Sec)	3
Delay Time(ms)	2
Format	1

Item	Description	Range
Transmission Speed	Set this item when change the transmission speed used for communication with the connected equipment. (Default: 9600bps)	9600bps, 19200bps, 38400bps, 57600bps, 115200bps
Data Bit	Set this item when change the data length used for communication with the connected equipment. (Default: 7bits)	7bits/8bits
Stop Bit	Specify the stop bit length for communications. (Default: 2bits)	1bit/2bits
Parity	Specify whether or not to perform a parity check, and how it is performed during communication. (Default: Even)	None Even Odd
Retry	Set the number of retries to be performed when a communication error occurs. (Default: 0time)	0 to 5times
Timeout Time	Set the time period for a communication to time out. (Default: 3sec)	3 to 30sec
Delay Time	Set this item to adjust the transmission timing of the communication request from the GOT. (Default: 2ms)	0 to 300 (ms)
Format	Select the communication format. (Default: 1) format 1: only continuous access format 2: continuous and random access	1, 2

OMRON Digital temperature controller

Property	Value
Transmission Speed(BPS)	9600
Data Bit	7bit
Stop Bit	2bit
Parity	Even
Retry(Times)	0
Timeout Time(Sec)	3
Host Address	1
Delay Time(ms)	2
Format	2

Item	Description	Range
Transmission Speed	Set this item when change the transmission speed used for communication with the connected equipment. (Default: 9600bps)	9600bps, 19200bps, 38400bps, 57600bps, 115200bps
Data Bit	Set this item when change the data length used for communication with the connected equipment. (Default: 7bits)	7bits/8bits
Stop Bit	Specify the stop bit length for communications. (Default: 2bits)	1bit/2bits
Parity	Specify whether or not to perform a parity check, and how it is performed during communication. (Default: Even)	None Even Odd
Retry	Set the number of retries to be performed when a communication error occurs. (Default: 0time)	0 to 5times
Timeout Time	Set the time period for a communication to time out. (Default: 3sec)	1 to 30sec
Host Address	Specify the host address (station No. of the GOT to which the temperature controller is connected) in the connected network. (Default: 1)	0 to 99
Delay Time	Set this item to adjust the transmission timing of the communication request from the GOT. (Default: 2ms)	0 to 300 (ms)
Format	Select the communication format. (Default: 2) format 1: only continuous access format 2: continuous and random access	1, 2

5

Point

- Delay Time

When connecting to the temperature controller E5ZN, set the delay time to 5ms or more.

- Format setting

Make sure to select format 1 when connecting with previous models (manufactured in December 2007 or before) of the THERMAC NEO series (E5AN, E5CN, E5EN, E5GN).


For the continuous access and random access of the temperature controller, refer to the following manual.

 User's Manual of the OMRON temperature controller

- Communication interface setting by the Utility

The communication interface setting can be changed on the Utility's [Communication Settings] after writing [Communication Settings] of project data.

For details on the Utility, refer to the following manual.

 GOT2000 Series User's Manual (Utility)

- Precedence in communication settings

When settings are made by GT Designer3 or the Utility, the latest setting is effective.

5.5 Temperature Controller Side Setting



OMRON temperature controller

For details of OMRON temperature controller, refer to the following manual.

User's Manual of the OMRON temperature controller

Model name		Refer to
Temperature controller	E5AN, E5EN, E5CN, E5GN	Page 298 Connecting E5AN, E5EN, E5CN, E5GN
	E5AN-H, E5CN-H, E5EN-H, E5AN-HT, E5CN-HT, E5EN-HT	Page 298 Connecting E5AN-H, E5CN-H, E5EN-H, E5AN-HT, E5CN-HT, E5EN-HT
	E5ZN	Page 299 Connecting E5ZN
	E5CC(-T,-B), E5DC, E5GC, E5EC(-T,-B), E5AC(-T)	Page 299 Connecting E5CC(-T,-B), E5DC, E5GC, E5EC(-T,-B), E5AC(-T)
	E5CD(-B), E5ED(-B)	Page 299 Connecting E5CD(-B), E5ED(-B)
	E5AR(-T), E5ER(-T)	Page 300 Connecting E5AR(-T), E5ER(-T)
Interface converter	K3SC-10	Page 300 Connection to interface converter (K3SC-10)

Connecting E5AN, E5EN, E5CN, E5GN

Set the communication data by operating the key of the temperature controller.

Item	Set value
Protocol	CompoWay/F (Sysway)
Transmission speed*1	9600bps, 19200bps
Data bit*1	8 bits, 7 bits
Parity bit*1	Odd, Even, None
Stop bit*1	1bit, 2bits
Communication unit No.*2	0 to 99
CMWT (Communications writing)*3	ON

*1 Adjust the settings with GOT settings.

*2 Select the communication unit No. without overlapping with that of other units.

*3 When changing the device values of the temperature controller from the GOT, turn ON CMWT (Communications writing) in advance.

Connecting E5AN-H, E5CN-H, E5EN-H, E5AN-HT, E5CN-HT, E5EN-HT

Set the communication data by operating the key of the temperature controller.

Item	Set value
Protocol	CompoWay/F (Sysway)
Transmission speed*1	9600bps, 19200bps, 38400bps, 57600bps
Data bit*1	8 bits, 7 bits
Parity bit*1	Odd, Even, None
Stop bit*1	1bit, 2bits
Communication unit No.*2	0 to 99
CMWT (Communications writing)*3	ON

*1 Adjust the settings with GOT settings.

*2 Select the communication unit No. without overlapping with that of other units.

*3 When changing the device values of the temperature controller from the GOT, turn ON CMWT (Communications writing) in advance.

Connecting E5ZN

Set the communication data by operating the key of the temperature controller.

Item	Set value
Protocol	CompoWay/F (Sysway)
Transmission speed* ¹	9600bps, 38400bps
Data bit* ¹	8 bits, 7 bits
Parity bit* ¹	Odd, Even, None
Stop bit* ¹	1bit, 2bits
Communication unit No.* ²	0 to 15
CMWT (Communications writing)* ³	ON

*¹ Adjust the settings with GOT settings.

*² Select the communication unit No. without overlapping with that of other units.

*³ When changing the device values of the temperature controller from the GOT, turn ON CMWT (Communications writing) in advance.

Connecting E5CC(-T,-B), E5DC, E5GC, E5EC(-T,-B), E5AC(-T)

Set the communication data by operating the key of the temperature controller.

Item	Set value
Protocol	CompoWay/F (Sysway)
Transmission speed* ¹	9600bps, 19200bps, 38400bps, 57600bps
Data bit* ¹	8 bits, 7 bits
Parity bit* ¹	Odd, Even, None
Stop bit* ¹	1bit, 2bits
Communication unit No.* ²	0 to 99
CMWT (Communications writing)* ³	ON

*¹ Adjust the settings with GOT settings.

*² Select the communication unit No. without overlapping with that of other units.

*³ When changing the device values of the temperature controller from the GOT, turn ON CMWT (Communications writing) in advance.

Connecting E5CD(-B), E5ED(-B)

Configure the communication data settings by operating the keys of the temperature controller.

Item	Set value
Protocol	CompoWay/F (Sysway)
Transmission speed* ¹	9600bps, 19200bps, 38400bps, 57600bps, 115200bps
Data bit* ¹	8 bits, 7 bits
Parity bit* ¹	Odd, Even, None
Stop bit* ¹	1 bit, 2 bits
Communication unit No.* ²	0 to 99
CMWT (Communications writing)* ³	ON

*¹ Adjust the settings with GOT settings.

*² Select the communication unit No. without overlapping with that of other units.

*³ When changing the device values of the temperature controller from the GOT, turn on CMWT (Communications writing) in advance.

Connecting E5AR(-T), E5ER(-T)

Set the communication data by operating the key of the temperature controller.

Item	Set value
Protocol	CompoWay/F (Sysway)
Transmission speed* ¹	9600bps, 19200bps, 38400bps, 57600bps
Data bit* ¹	8 bits, 7 bits
Parity bit* ¹	Odd, Even, None
Stop bit* ¹	1bit, 2bits
Communication unit No.* ²	0 to 99
CMWT (Communications writing)* ³	ON

*¹ Adjust the settings with GOT settings.

*² Select the communication unit No. without overlapping with that of other units.

*³ When changing the device values of the temperature controller from the GOT, turn ON CMWT (Communications writing) in advance.

Connection to interface converter (K3SC-10)

Communication settings


Make the communication settings by operating the DIP switch of the temperature controller.

Item	Set value
Transmission speed* ¹	19200bps, 38400bps
Data bit* ¹	7 bits, 8 bits
Parity bit* ¹	Odd, Even, None
Stop bit* ¹	1bit, 2bits
Communication Type	RS-232↔RS485
Echo back* ²	With, Without


*¹ Adjust the settings with GOT settings.

*² Set to "Without".

Settings by DIP switch




■Transmission speed settings



Transmission speed (bps)	Switch No.		
	1	2	3
1200	ON	OFF	OFF
2400	OFF	ON	OFF
4800	ON	ON	OFF
9600	OFF	OFF	OFF
19200	ON	OFF	ON
38400	OFF	ON	ON

■Settings of data length, parity bit, stop bit, master/slave device and echoback




Setting item	Set value	Switch No.							
		4	5	6	7	8	9	0	
Data bit	7bits	OFF							
	8bits	ON							
Stop bit	2bits		OFF						
	1bit		ON						
Parity	Even			OFF	OFF				
	Odd			ON	OFF				
	None			OFF	ON				
Communication Type	RS232↔RS422					OFF	ON		
	RS-232↔RS485					OFF	OFF		
Echo back	Without								OFF
	With								ON

Station No. settings

Set each station number so that no station number overlaps.

The station number can be set without regard to the cable connection order. There is no problem even if station numbers are not consecutive.



Direct specification

When setting the device, specify the station number of the temperature controller of which data is to be changed.

Model name	Specification range
E5AN, E5EN, E5CN, E5GN	0 to 99
E5ZN	0 to 15

Indirect specification

When setting the device, indirectly specify the station number of the temperature controller of which data is to be changed using the 16-bit GOT internal data register (GD10 to GD25).

When specifying the station No. from 100 to 115 on GT Designer3, the value of GD10 to GD25 compatible to the station No. specification will be the station No. of the temperature controller.

Specification station NO.	Compatible device	Setting range
100	GD10	0 to 99: For E5AN, E5EN, E5CN or E5GN 0 to 15: For E5ZN For the setting other than the above, error (dedicated device is out of range) will occur.
101	GD11	
102	GD12	
103	GD13	
104	GD14	
105	GD15	
106	GD16	
107	GD17	
108	GD18	
109	GD19	
110	GD20	
111	GD21	
112	GD22	
113	GD23	
114	GD24	
115	GD25	

All station specification

Target station differs depending on write-in operation or read-out operation.

- For write-in operation, all station will be a target.
- For read-out operation, only one station will be a target.

5.6 Device Range that Can Be Set

The device ranges of controller that can be used for GOT are as follows.

Note that the device ranges in the following tables are the maximum values that can be set in GT Designer3.

The device specifications of controllers may differ depending on the models, even though belonging to the same series.

Please make the setting according to the specifications of the controller actually used.

When a non-existent device or a device number outside the range is set, other objects with correct device settings may not be monitored.

Setting item

- For OMRON THERMAC/INPANEL NEO

- For OMRON Digital Temperature Controller

Item	Description	
Device	Set the device name, device number, and bit number. The bit number can be set only when specifying the bit of word device.	
Information	Displays the device type and setting range which are selected in [Device].	
Network	All	Select this item when writing data to all temperature connected. During monitoring, the temperature controller of station No.0 is monitored. (When writing the data in numerical input, the data is written to all connected temperature controllers during input, and the temperature controller of station No. 0 is monitored during other than input (displaying).)
	Station No.	Select this item when monitoring the temperature controller of the specified station No. After selecting, set the station No. in the following range. 0 to 99: To monitor the temperature controller of the specified station No. 100 to 115: To specify the station No. of the temperature controller to be monitored by the value of GOT data register (GD). ^{*1}

*1 The following table shows the relation between station numbers of the temperature controller and the GOT data register.

Station No.	GOT data register (GD)	Setting range
100	GD10	0 to 99 (If setting a value outside the range above, a device range error occurs.)
101	GD11	
:	:	
114	GD24	
115	GD25	

OMRON temperature controller (OMRON THERMAC/INPANEL NEO)

Device name		Setting range	Device No. representation
Bit device	Status (S) ^{*1}	S0000 to S0031 S0100 to S0131	Decimal + Decimal
Word device	Operation command (A) ^{*2}	A0000 to A000C	Hexadecimal
Double word device	Variable area 0 (C0) ^{*1*3}	C00000 to C00006 C00100 to C00106	Decimal + Hexadecimal
	Variable area 1 (C1) ^{*3}	C10000 to C1001C C10100 to C1011C	
	Variable area 3 (C3) ^{*3}	C30000 to C3003E C30100 to C3013E	

*1 Only reading is possible.

*2 Only writing is possible.
Numerical input cannot be used.
Use a word switch for writing.

*3 Only 32-bit (2-word) designation is allowed.


5

Point

Device settings of OMRON temperature controller (OMRON THERMAC/INPANEL NEO)


- When setting the (S)

Make settings for status by a channel number (Decimal) and a bit position (Decimal).



- When setting variable area (0), variable area (1) and variable area (3)

Make setting for variable areas by a channel number (Decimal) and address (Hexadecimal).



OMRON temperature controller (OMRON digital temperature controller)

Device name		Setting range	Device No. representation
Bit device	Status (SC0) ^{*1}	SC0000000 to SC0FFFF31	Hexadecimal + Decimal
	Status (SC4) ^{*1}	SC4000000 to SC4FFFF31	
Word device	Operation command (A) ^{*2}	A0000 to A00FF	Hexadecimal
Double word device	Variable area C0 (C0) ^{*1*3}	C00000 to C0FFFF	
	Variable area C1 (C1) ^{*3}	C10000 to C1FFFF	
	Variable area C3 (C3) ^{*3}	C30000 to C3FFFF	
	Variable area C4 (C4) ^{*3}	C40000 to C4FFFF	
	Variable area C5 (C5) ^{*3}	C50000 to C5FFFF	
	Variable area C6 (C6) ^{*3}	C60000 to C6FFFF	
	Variable area C7 (C7) ^{*3}	C70000 to C7FFFF	
	Variable area C8 (C8) ^{*3}	C80000 to C8FFFF	
	Variable area C9 (C9) ^{*3}	C90000 to C9FFFF	
	Variable area CA (CA) ^{*3}	CA0000 to CAFFFF	
	Variable area CB (CB) ^{*3}	CB0000 to CBFFFF	
	Variable area CC (CC) ^{*3}	CC0000 to CCFFFF	
	Variable area CD (CD) ^{*3}	CD0000 to CDFFFF	
	Variable area CE (CE) ^{*3}	CE0000 to CEFFFF	
	Variable area CF (CF) ^{*3}	CF0000 to CFFFFF	
	Variable area D0 (D0) ^{*3}	D00000 to D0FFFF	
	Variable area D1 (D1) ^{*3}	D10000 to D1FFFF	
	Variable area D2 (D2) ^{*3}	D20000 to D2FFFF	
	Variable area D3 (D3) ^{*3}	D30000 to D3FFFF	
	Variable area D8 (D8) ^{*3}	D80000 to D8FFFF	
	Variable area D9 (D9) ^{*3}	D90000 to D9FFFF	
	Variable area DA (DA) ^{*3}	DA0000 to DAFFFF	

*1 Only reading is possible.

*2 Only writing is possible.

Numerical input cannot be used.

Use a word switch for writing.


*3 Only 32-bit (2-word) designation is allowed.



Device settings of OMRON temperature controller(OMRON digital temperature controller)

- When setting the (SC0), (SC4)

Make settings for status by a address number(Hexadecimal) and a bit position(Decimal).



- Address number of status (SC0)

The following explains an address number with an example of E5□C series.

<For status (1)>

Address number: [0001]

(Example) Device set value: SC0000100

<For status (2)>

Address number: [0011]

(Example) Device set value: SC0001100

5.7 Precautions

Station number setting of the temperature controller system

Make sure to establish temperature controller system with No.1 station.

GOT clock control

Since the temperature controller does not have a clock function, the settings of [time adjusting] or [Broadcast] by GOT clock control will be disabled.

Disconnecting some of multiple connected equipment

The GOT can disconnect some of multiple connected equipment by setting GOT internal device. For example, the faulty station where a communication timeout error occurs can be disconnected from connected equipment.

For details of GOT internal device setting, refer to the following manual.

📖 GT Designer3 (GOT2000) Screen Design Manual

MEMO




6 CONNECTION TO KEYENCE PLC

- Page 309 Connectable Model List
- Page 311 Serial Connection
- Page 341 Ethernet Connection
- Page 348 Device Range that Can Be Set

6.1 Connectable Model List

The following table shows the connectable models.


Series	Model name	Clock	Communication Type	Connectable GOT	Refer to
KV-7000	KV-7500 KV-7300	○	RS-232	GT 27 GT 25 GT 23 GT 21 GS	☞ Page 311 Connecting to KV-7500, KV-7300
			RS-422		
			RS-485	GT 27 GT 25 GT 23 GT 21	
			Ethernet	GT 27 GT 25 GT 23 GT 21 GS	
KV-5000	KV-5500 KV-5000	○	RS-232	GT 27 GT 25 GT 23 GT 21 GS	☞ Page 314 Connecting to KV-5500, KV-5000
			RS-422		
			RS-485	GT 27 GT 25 GT 23 GT 21	
			Ethernet	GT 27 GT 25 GT 23 GT 21 GS	
KV-3000	KV-3000	○	RS-232	GT 27 GT 25 GT 23 GT 21 GS	☞ Page 316 Connecting to KV-3000
			RS-422		
			RS-485	GT 27 GT 25 GT 23 GT 21	
			Ethernet	GT 27 GT 25 GT 23 GT 21 GS	
KV-1000	KV-1000	○	RS-232	GT 27 GT 25 GT 23 GT 21 GS	☞ Page 319 Connecting to KV-1000
			RS-422		
			RS-485	GT 27 GT 25 GT 23 GT 21	
			Ethernet	GT 27 GT 25 GT 23 GT 21 GS	
KV-700	KV-700	○	RS-232	GT 27 GT 25 GT 23 GT 21 GS	☞ Page 322 Connecting to KV-700
			RS-422		
			RS-485	GT 27 GT 25 GT 23 GT 21	
			Ethernet	GT 27 GT 25 GT 23 GT 21 GS	

Series	Model name	Clock	Communication Type	Connectable GOT	Refer to
KV Nano	KV-N14□□	○	RS-232	<div>GT 27</div> <div>GT 25</div> <div>GT 23</div> <div>GT 21</div> <div>GS</div>	 Page 325 Connecting to KV-N14□□, KV-N24□□, KV-N40□□, KV-N60□□, KV-NC32T
			RS-422		
			RS-485		
	KV-N24□□ KV-N40□□ KV-N60□□ KV-NC32T	○	RS-232	<div>GT 27</div> <div>GT 25</div> <div>GT 23</div> <div>GT 21</div> <div>GS</div>	 Page 325 Connecting to KV-N14□□, KV-N24□□, KV-N40□□, KV-N60□□, KV-NC32T
			RS-422		
			RS-485	<div>GT 27</div> <div>GT 25</div> <div>GT 23</div> <div>GT 21</div>	 Page 341 Connecting to KV-700, KV-1000, KV-3000, KV-5000, KV-5500, KV-7300, KV-7500, KV-N24□□, KV-N40□□, KV-N60□□, KV-NC32T
			Ethernet	<div>GT 27</div> <div>GT 25</div> <div>GT 23</div> <div>GT 21</div> <div>GS</div>	

Connecting to KV-7500, KV-7300


Communication driver

Serial (KEYENCE)













6

*2 GT25-W, GT2505-V does not support the option device.

When connecting to multi-communication unit



PLC			Connection cable		GOT		Number of connectable equipment
Model name	Multi-communication unit*1	Communication Type	Cable model Connection diagram number	Max. distance	Option device*3	Model	
KV-7500 KV-7300	KV-L20V (port 1) KV-L21V (port 1)	RS-232	GT09-C30R21102-9S(3m) or (User preparing) RS-232 connection diagram 2)	15m	- (Built into GOT)		1 GOT for 1 multi-communication unit
					GT15-RS2-9P		
					GT10-C02H-6PT9P*2		
			(User preparing) RS-232 connection diagram 5)	15m	- (Built into GOT)		

PLC			Connection cable		GOT		Number of connectable equipment
Model name	Multi-communication unit ^{*1}	Communication Type	Cable model Connection diagram number	Max. distance	Option device ^{*3}	Model	
KV-7500 KV-7300	KV-L20V (port 2) KV-L21V (port 2)	RS-232	GT09-C30R21103-3T(3m) or (User preparing) RS-232 connection diagram 3)	15m	- (Built into GOT)		1 GOT for 1 multi-communication unit
					GT15-RS2-9P		
					GT10-C02H-6PT9P ^{*2}		
			(User preparing) RS-232 connection diagram 6)	15m	- (Built into GOT)		
		RS-422	GT09-C30R41101-5T(3m) GT09-C100R41101-5T(10m) GT09-C200R41101-5T(20m) GT09-C300R41101-5T(30m) or (User preparing) RS-422 connection diagram 1)	500m	- (Built into GOT)		
					GT15-RS4-9S		
					GT10-C02H-9SC		
			(User preparing) RS-422 connection diagram 2)	500m	- (Built into GOT)		
		RS-485	(User preparing) RS-485 connection diagram 1)	500m	- (Built into GOT)		
					GT15-RS4-9S		
					GT10-C02H-9SC		
			(User preparing) RS-485 connection diagram 2)	500m	- (Built into GOT)		



^{*1} The multi-communication unit is a product manufactured by KEYENCE CORPORATION.

For details of the product, contact KEYENCE CORPORATION.







^{*2} When a GT10-C02H-6PT9P unit of the sub version A or B is used, do not ground the case of the D-sub (9-pin) connector.

^{*3} GT25-W, GT2505-V does not support the option device.

Connecting to KV-5500, KV-5000



PLC			Connection cable		GOT		Number of connectable equipment
Model name	Multi-communication unit ^{*1}	Communication Type	Cable model Connection diagram number	Max. distance	Option device ^{*3}	Model	
KV-5500 KV-5000	KV-L20V (port 1)	RS-232	GT09-C30R21102-9S(3m) or RS-232 connection diagram 2)	15m	- (Built into GOT)		1 GOT for 1 multi-communication unit
					GT15-RS2-9P		
					GT10-C02H-6PT9P ^{*2}		
			RS-232 connection diagram 5)	15m	- (Built into GOT)		
	KV-L20V (port 2)	RS-232	GT09-C30R21103-3T(3m) or RS-232 connection diagram 3)	15m	- (Built into GOT)		
					GT15-RS2-9P		
					GT10-C02H-6PT9P ^{*2}		
			RS-232 connection diagram 6)	15m	- (Built into GOT)		

PLC			Connection cable		GOT		Number of connectable equipment
Model name	Multi-communication unit* ¹	Communication Type	Cable model Connection diagram number	Max. distance	Option device* ³	Model	
KV-5500 KV-5000	KV-L20V (port 2)	RS-422	GT09-C30R41101-5T(3m) GT09-C100R41101-5T(10m) GT09-C200R41101-5T(20m) GT09-C300R41101-5T(30m) or (User preparing) RS-422 connection diagram 1)	500m	- (Built into GOT)		1 GOT for 1 multi-communication unit
					GT15-RS4-9S		
					GT10-C02H-9SC		
				(User preparing) RS-422 connection diagram 2)	500m	- (Built into GOT)	
		RS-485	(User preparing) RS-485 connection diagram 1)	500m	- (Built into GOT)		
					GT15-RS4-9S		
					GT10-C02H-9SC		
				(User preparing) RS-485 connection diagram 2)	500m	- (Built into GOT)	


*1 The multi-communication unit is a product manufactured by KEYENCE CORPORATION.
For details of the product, contact KEYENCE CORPORATION.

*2 When a GT10-C02H-6PT9P unit of the sub version A or B is used, do not ground the case of the D-sub (9-pin) connector.

*3 GT25-W, GT2505-V does not support the option device.

Connecting to KV-3000

When connecting to a PLC




PLC		Connection cable			GOT		Number of connectable equipment
Model name	Communication Type	Cable model Connection diagram number	Conversion connector ^{*1}	Max. distance	Option device ^{*3}	Model	
KV-3000	RS-232	GT09-C30R21101-6P or (User preparing) RS-232 connection diagram 1)	-	15m	- (Built into GOT)		1 GOT for 1 PLC
					GT15-RS2-9P		
					GT10-C02H-6PT9P ^{*2}		
		(User preparing) RS-232 connection diagram 4)	-	15m	- (Built into GOT)		
		OP-26487 ^{*1}	OP-26486	2.5m	- (Built into GOT)		
					GT15-RS2-9P		
					GT10-C02H-6PT9P ^{*2}		





























^{*1} The cable and conversion connector are products manufactured by KEYENCE CORPORATION.
For details of the product, contact KEYENCE CORPORATION.









^{*2} When a GT10-C02H-6PT9P unit of the sub version A or B is used, do not ground the case of the D-sub (9-pin) connector.

^{*3} GT25-W, GT2505-V does not support the option device.

When connecting to multi-communication unit



PLC			Connection cable		GOT		Number of connectable equipment
Model name	Multi-communication unit*1	Communication Type	Cable model Connection diagram number	Max. distance	Option device*3	Model	
KV-3000	KV-L20V (port 1)	RS-232	GT09-C30R21102-9S(3m) or (User preparing) RS-232 connection diagram 2)	15m	- (Built into GOT)	   	1 GOT for 1 multi-communication unit
					GT15-RS2-9P	 	
					GT10-C02H-6PT9P*2	   	
			(User preparing) RS-232 connection diagram 5)	15m	- (Built into GOT)	   	
	KV-L20V (port 2)	RS-232	GT09-C30R21103-3T(3m) or (User preparing) RS-232 connection diagram 3)	15m	- (Built into GOT)	   	
					GT15-RS2-9P	 	
					GT10-C02H-6PT9P*2	   	
			(User preparing) RS-232 connection diagram 6)	15m	- (Built into GOT)	   	


PLC			Connection cable		GOT		Number of connectable equipment
Model name	Multi-communication unit ^{*1}	Communication Type	Cable model Connection diagram number	Max. distance	Option device ^{*3}	Model	
KV-3000	KV-L20V (port 2)	RS-422	GT09-C30R41101-5T(3m) GT09-C100R41101-5T(10m) GT09-C200R41101-5T(20m) GT09-C300R41101-5T(30m) or (User prepare) RS-422 connection diagram 1)	500m	- (Built into GOT)		1 GOT for 1 multi-communication unit
					GT15-RS4-9S		
					GT10-C02H-9SC		
			(User prepare) RS-422 connection diagram 2)	500m	- (Built into GOT)		
	KV-L20V (port 2)	RS-485	(User prepare) RS-485 connection diagram 1)	500m	- (Built into GOT)		1 GOT for 1 multi-communication unit
					GT15-RS4-9S		
					GT10-C02H-9SC		
			(User prepare) RS-485 connection diagram 2)	500m	- (Built into GOT)		

*1 The multi-communication unit is a product manufactured by KEYENCE CORPORATION.
For details of the product, contact KEYENCE CORPORATION.

*2 When a GT10-C02H-6PT9P unit of the sub version A or B is used, do not ground the case of the D-sub (9-pin) connector.


*3 GT25-W, GT2505-V does not support the option device.





















When connecting to PLC











*3 GT25-W, GT2505-V does not support the option device.

When connecting to multi-communication unit



PLC			Connection cable		GOT		Number of connectable equipment
Model name	Multi-communication unit* ¹	Communication Type	Cable model Connection diagram number	Max. distance	Option device* ³	Model	
KV-1000	KV-L20R, KV-L20V (port 1)	RS-232	GT09-C30R21102-9S(3m) or () RS-232 connection diagram 2)	15m	- (Built into GOT)	   	1 GOT for 1 multi-communication unit
					GT15-RS2-9P		
					GT10-C02H-6PT9P* ²	 	
			() RS-232 connection diagram 5)	15m	- (Built into GOT)	 	
	KV-L20R, KV-L20V (port 2)	RS-232	GT09-C30R21103-3T(3m) or () RS-232 connection diagram 3)	15m	- (Built into GOT)	   	
					GT15-RS2-9P		
					GT10-C02H-6PT9P* ²	 	
					() RS-232 connection diagram 6)	15m	


PLC			Connection cable		GOT		Number of connectable equipment
Model name	Multi-communication unit ^{*1}	Communication Type	Cable model Connection diagram number	Max. distance	Option device ^{*3}	Model	
KV-1000	KV-L20R, KV-L20V (port 2)	RS-422	GT09-C30R41101-5T(3m) GT09-C100R41101-5T(10m) GT09-C200R41101-5T(20m) GT09-C300R41101-5T(30m) or (User prepare) RS-422 connection diagram 1)	500m	- (Built into GOT)		1 GOT for 1 multi-communication unit
					GT15-RS4-9S		
					GT10-C02H-9SC		
			(User prepare) RS-422 connection diagram 2)	500m	- (Built into GOT)		
		RS-485	(User prepare) RS-485 connection diagram 1)	500m	- (Built into GOT)		
					GT15-RS4-9S		
					GT10-C02H-9SC		
			(User prepare) RS-485 connection diagram 2)	500m	- (Built into GOT)		

*1 The multi-communication unit is a product manufactured by KEYENCE CORPORATION.
For details of the product, contact KEYENCE CORPORATION.

*2 When a GT10-C02H-6PT9P unit of the sub version A or B is used, do not ground the case of the D-sub (9-pin) connector.



*3 GT25-W, GT2505-V does not support the option device.

When connecting to PLC











*3 GT25-W, GT2505-V does not support the option device.

When connecting to multi-communication unit



PLC			Connection cable		GOT		Number of connectable equipment
Model name	Multi-communication unit ^{*1}	Communication Type	Cable model Connection diagram number	Max. distance	Option device ^{*3}	Model	
KV-700	KV-L20R, KV-L20, KV-L20V (port 1)	RS-232	GT09-C30R21102-9S(3m) or (User preparing) RS-232 connection diagram 2)	15m	- (Built into GOT)		1 GOT for 1 multi-communication unit
					GT15-RS2-9P		
					GT10-C02H-6PT9P ^{*2}		
			(User preparing) RS-232 connection diagram 5)	15m	- (Built into GOT)		
	KV-L20R, KV-L20, KV-L20V (port 2)	RS-232	GT09-C30R21103-3T(3m) or (User preparing) RS-232 connection diagram 3)	15m	- (Built into GOT)		
					GT15-RS2-9P		
					GT10-C02H-6PT9P ^{*2}		
			(User preparing) RS-232 connection diagram 6)	15m	- (Built into GOT)		

PLC			Connection cable		GOT		Number of connectable equipment
Model name	Multi-communication unit ^{*1}	Communication Type	Cable model Connection diagram number	Max. distance	Option device ^{*3}	Model	
KV-700	KV-L20R, KV-L20, KV-L20V (port 2)	RS-422	GT09-C30R41101-5T(3m) GT09-C100R41101-5T(10m) GT09-C200R41101-5T(20m) GT09-C300R41101-5T(30m) or (User prepare) RS-422 connection diagram 1)	500m	- (Built into GOT)		1 GOT for 1 multi-communication unit
					GT15-RS4-9S		
					GT10-C02H-9SC		
			(User prepare) RS-422 connection diagram 2)	500m	- (Built into GOT)		
	KV-L20R, KV-L20, KV-L20V (port 2)	RS-485	(User prepare) RS-485 connection diagram 1)	500m	- (Built into GOT)		
					GT15-RS4-9S		
					GT10-C02H-9SC		
			(User prepare) RS-485 connection diagram 2)	500m	- (Built into GOT)		


*1 The conversion connector and multi-communication unit are products manufactured by KEYENCE CORPORATION.
For details of the product, contact KEYENCE CORPORATION.

*2 When a GT10-C02H-6PT9P unit of the sub version A or B is used, do not ground the case of the D-sub (9-pin) connector.

*3 GT25-W, GT2505-V does not support the option device.

Connecting to KV-N14□□, KV-N24□□, KV-N40□□, KV-N60□□, KV-NC32T

When connecting to PLC




PLC		Connection cable			GOT		Number of connectable equipment
Model name	Communication Type	Cable model Connection diagram number	Conversion connector ^{*1}	Max. distance	Option device ^{*3}	Model	
KV-N14□□ KV-N24□□ KV-N40□□ KV-N60□□ KV-NC32T	RS-232	GT09-C30R21101-6P or (User preparing) RS-232 connection diagram 1)	-	15m	- (Built into GOT)		1 GOT for 1 PLC
					GT15-RS2-9P		
					GT10-C02H-6PT9P ^{*2}		
		(User preparing) RS-232 connection diagram 4)	-	15m	- (Built into GOT)		
		OP-26487 ^{*1}	OP-26486	2.5m	- (Built into GOT)		
					GT15-RS2-9P		
					GT10-C02H-6PT9P ^{*2}		























^{*1} The cable, conversion connector, and multi-communication unit are products manufactured by KEYENCE CORPORATION. For details of the product, contact KEYENCE CORPORATION.













^{*2} When a GT10-C02H-6PT9P unit of the sub version A or B is used, do not ground the case of the D-sub (9-pin) connector.

^{*3} GT25-W, GT2505-V does not support the option device.

Connecting to serial communication cassette or serial adapter



PLC			Connection cable		GOT		Number of connectable equipment		
Model name	Serial communication cassette, serial adapter *1	Commu nication Type	Cable model Connection diagram number	Max. distance	Option device *3	Model			
KV-N14□□ KV-N24□□ KV-N40□□ KV-N60□□ KV-NC32T	KV-N10L, KV-NC10L, KV-NC20L (port 1)	RS-232	GT09-C30R21102-9S(3m) or  RS-232 connection diagram 2)	15m	- (Built into GOT)	   	1 GOT for 1 serial communication cassette or serial adapter		
					GT15-RS2-9P				
					GT10-C02H-6PT9P *2	 R4		 R2	
			 RS-232 connection diagram 5)	15m	- (Built into GOT)	  R2			
			KV-NC32T	KV-NC20L (port 2)	 RS-232 connection diagram 7)	15m		- (Built into GOT)	   
								GT15-RS2-9P	
GT10-C02H-6PT9P *2	 R4	 R2							
 RS-232 connection diagram 8)	15m	- (Built into GOT)			  R2				

PLC			Connection cable		GOT		Number of connectable equipment
Model name	Serial communication cassette, serial adapter ^{*1}	Communication Type	Cable model Connection diagram number	Max. distance	Option device ^{*3}	Model	
KV-N14□□ KV-N24□□ KV-N40□□ KV-N60□□ KV-NC32T	KV-N11L, KV-NC20L (port 2)	RS-422	 RS-422 connection diagram 3)	500m	- (Built into GOT)		1 GOT for 1 serial communication cassette or serial adapter
							
							
			 RS-422 connection diagram 4)	500m	- (Built into GOT)		
		RS-485	 RS-485 connection diagram 3)	500m	- (Built into GOT)		
							
							
			 RS-485 connection diagram 4)	500m	- (Built into GOT)		

^{*1} The serial communication cassette and serial adapter are products manufactured by KEYENCE CORPORATION.
For details of the product, contact KEYENCE CORPORATION.

^{*2} When a GT10-C02H-6PT9P unit of the sub version A or B is used, do not ground the case of the D-sub (9-pin) connector.

^{*3} GT25-W, GT2505-V does not support the option device.


Connection Diagram

The following diagram shows the connection between the GOT and the PLC.


RS-232 cable

■Connection diagram


- RS-232 connection diagram 1)




- RS-232 connection diagram 2)




- RS-232 connection diagram 3)




• RS-232 connection diagram 4)




• RS-232 connection diagram 5)




• RS-232 connection diagram 6)



- RS-232 connection diagram 7)



- RS-232 connection diagram 8)



■Precaution when preparing a cable

- Cable length

The length of the RS-232 cable must be within 15m.

- GOT side connector

For the GOT side connector, refer to the following.

☞ Page 58 GOT connector specifications

- KEYENCE PLC side connector


Use the connector compatible with the KEYENCE PLC side module.

For details, refer to the KEYENCE PLC user's manual.


RS-422 cable

■ Connection diagram

- RS-422 connection diagram 1)




- RS-422 connection diagram 2)




*1 The signals RSA, RSB, CSA, and CSB are not provided for GT2104-PMBD, GT2103-PMBD. Return connection is not required.

- RS-422 connection diagram 3)



*1 Turn on the terminating resistor selector.

- RS-422 connection diagram 4)



*1 Turn on the terminating resistor selector.

■Precautions when preparing a cable

- Cable length

The length of the RS-422 cable must be 500m or less

- GOT side connector

For the GOT side connector, refer to the following.

☞ Page 58 GOT connector specifications

- KEYENCE PLC side connector

Use the connector compatible with the KEYENCE PLC side module.

For details, refer to the KEYENCE PLC user's manual.

■Connecting terminating resistors

- GOT side

When connecting a KEYENCE PLC to the GOT, a terminating resistor must be connected to the GOT.

For GT27, GT25(Except GT2505-V), GT23

Set the terminating resistor setting switch of the GOT main unit to "Disable".

For GT2505-V, GT21

Set the terminating resistor selector to "330Ω".

For GS21

Since the terminating resistor is fixed to 330 Ω, no setting is required for the terminating resistor.


For the procedure to set the terminating resistor, refer to the following.

☞ Page 62 Terminating resistors of GOT


RS-485 cable

■ Connection diagram

- RS-485 connection diagram 1)




- RS-485 connection diagram 2)




*1 The signals RSA, RSB, CSA, and CSB are not provided for GT2104-PMBD, GT2103-PMBD. Return connection is not required.

- RS-485 connection diagram 3)



*1 Turn on the terminating resistor selector.

- RS-485 connection diagram 4)



*1 Turn on the terminating resistor selector.

■Precautions when preparing a cable

- Cable length

The length of the RS-485 cable must be 500m or less

- GOT side connector

For the GOT side connector, refer to the following.

☞ Page 58 GOT connector specifications

- KEYENCE PLC side connector

Use the connector compatible with the KEYENCE PLC side module.

For details, refer to the KEYENCE PLC user's manual.

■Connecting terminating resistors

- GOT

For GT27, GT25(Except GT2505-V), GT23

Set the terminating resistor setting switch of the GOT main unit to "Enable".

For GT2505-V, GT21

Set the terminating resistor selector to "330Ω".

For GS21

Since the terminating resistor is fixed to 330 Ω, no setting is required for the terminating resistor.

For the procedure to set the terminating resistor, refer to the following.

☞ Page 62 Terminating resistors of GOT

- KEYENCE PLC


Connect the terminating resistor on the KEYENCE PLC side when connecting a GOT to a KEYENCE PLC.

☞ Page 337 PLC Side Setting

GOT Side Settings

Setting communication interface (Communication settings)

Set the channel of the equipment to be connected to the GOT.



1. Select [Common] → [Controller Setting] from the menu.
2. In the [Controller Setting] window, select the channel No. to be used from the list menu.
3. Set the following items.
 - [Manufacturer]: [KEYENCE]
 - [Controller Type]: [KEYENCE KV-700/1000/3000/5000/7000]
 - [I/F]: Interface to be used
 - [Detail Setting]: Configure the settings according to the usage environment.

☞ Page 336 Communication detail settings
4. When you have completed the settings, click the [OK] button.

Point

The settings of connecting equipment can be confirmed in [I/F Communication Setting].

For details, refer to the following.

☞ Page 47 I/F communication setting

Communication detail settings

Make the settings according to the usage environment.

Property	Value
Transmission Speed(BPS)	9600
Data Bit	8 bit
Stop Bit	1 bit
Parity	Even
Retry(Times)	0
Timeout Time(Sec)	3
Host Address	0
Delay Time(ms)	0
Station No. Selection	No

Item	Contents	Range
Transmission Speed	Set this item when change the transmission speed used for communication with the connected equipment. (Default: 9600bps)	9600bps, 19200bps, 38400bps, 57600bps, 115200bps
Data Bit	Set this item when change the data length used for communication with the connected equipment. (Default: 8bits)	7bits/8bits
Stop Bit	Specify the stop bit length for communications. (Default: 1bit)	1bit/2bits
Parity	Specify whether or not to perform a parity check, and how it is performed during communication. (Default: Even)	None Even Odd
Retry	Set the number of retries to be performed when a communication error occurs. (Default: 0time)	0 to 5times
Timeout Time	Set the time period for a communication to time out. (Default: 3sec)	1 to 30sec
Host Address	Specify the host address (station No. of the PLC to which the GOT is connected) in the network of the GOT. (Default: 0)	0 to 9
Delay Time	Set this item to adjust the transmission timing of the communication request from the GOT. (Default: 0ms)	0 to 300ms
Station No. Selection	Specify whether to use the station No. during communication. (Default: None)	Yes or No

Point

- Communication interface setting by the Utility

The communication interface setting can be changed on the Utility's [Communication Settings] after writing [Communication Settings] of project data. For details on the Utility, refer to the following manual.

☞ GOT2000 Series User's Manual (Utility)

- Precedence in communication settings

When settings are made by GT Designer3 or the Utility, the latest setting is effective.

PLC Side Setting



KEYENCE PLC

For details of KEYENCE PLC, refer to the following manual.

📖 KEYENCE PLC user's Manual

Model name		Reference
PLC CPU	KV-7300	📖 Page 337 Connecting KV-7300, KV-3000, KV-1000
	KV-3000	📖 Page 337 Connecting KV-7300, KV-3000, KV-1000
	KV-1000	📖 Page 337 Connecting KV-7300, KV-3000, KV-1000
	KV-700	📖 Page 337 Connecting to KV-700
	KV-N14□□	📖 Page 338 Connecting to KV-N14□□, KV-N24□□, KV-N40□□, KV-N60□□, KV-NC32T
	KV-N24□□	📖 Page 338 Connecting to KV-N14□□, KV-N24□□, KV-N40□□, KV-N60□□, KV-NC32T
	KV-N40□□	📖 Page 338 Connecting to KV-N14□□, KV-N24□□, KV-N40□□, KV-N60□□, KV-NC32T
	KV-N60□□	📖 Page 338 Connecting to KV-N14□□, KV-N24□□, KV-N40□□, KV-N60□□, KV-NC32T
	KV-NC32T	📖 Page 338 Connecting to KV-N14□□, KV-N24□□, KV-N40□□, KV-N60□□, KV-NC32T
Multi-communication unit	KV-L20R	📖 Page 338 Connecting to KV-L20R, KV-L20, KV-L20V, KV-L21V
	KV-L20	
	KV-L20V	
	KV-L21V	
Serial communication cassette	KV-N10L	📖 Page 340 Connecting to KV-N10L, KV-N11L, KV-NC10L, KV-NC20L
	KV-N11L	
Serial adapter	KV-NC10L	
	KV-NC20L	

6

Connecting KV-7300, KV-3000, KV-1000

Setting items	Set value
Communication mode *2	KV mode (Upper link)
Transmission Speed	9600 to 115200 bps*1
Data bit	8bits
Parity bit	Even
Stop bit	1bit

*1 There is no transmission speed setting on the PLC side. The transmission speed of the PLC side is automatically adjusted to that of the GOT side.

*2 The communication mode setting is not available for KV-3000 and KV-1000.

Connecting to KV-700

Setting items	Set value
Transmission Speed	9600bps
Data bit	8bits
Parity bit	Even
Stop bit	1bit

Connecting to KV-N14□□, KV-N24□□, KV-N40□□, KV-N60□□, KV-NC32T

Setting items	Set value
Communication mode	KV mode (Upper link)
Transmission speed *1*2	9600bps, 19200bps, 38400bps, 57600bps, 115200bps
Data bit	8bits
Parity bit	Even
Stop bit	1bit

*1 Only transmission speeds available on the GOT side are shown.

*2 The transmission speed setting must be consistent with that of the GOT side.

For the transmission speed setting on the GOT side, refer to the following.

☞ Page 335 Setting communication interface (Communication settings)

Connecting to KV-L20R, KV-L20, KV-L20V, KV-L21V

■Communication settings

Setting items	Set value
Communication mode	KV mode (Upper link)
Transmission speed*1*2	4800bps, 9600bps, 19200bps, 38400bps, 57600bps, 115200bps
Data bit	8bits
Parity bit	Even
Stop bit	1bit
Station No.*3	0 to 9

*1 Only transmission speeds available on the GOT side are shown.

*2 The transmission speed setting must be consistent with that of the GOT side.

For the transmission speed setting on the GOT side, refer to the following.

☞ Page 335 Setting communication interface (Communication settings)

*3 Set the station No. according to the host address on the GOT side.


For the Host Address setting on the GOT side, refer to the following.

☞ Page 335 Setting communication interface (Communication settings)


■Setting DIP switches

Set the DIP switches.

- When using KV-L20R or KV-L20



- RS232/RS422/RS485 switch (For port 2)
(For KV-L20R)



Settings	
For RS-232 communication	For RS-422 communication
RS-232C	RS-422A 485(4)

(For KV-L20)



Settings	
For RS-232 communication	For RS-422 communication
RS-232C	RS-422A


- Terminator setting switch

Set when carrying out RS-422 communication.




Settings	
When multi-communication unit is a terminal	When multi-communication unit is not a terminal
ON	OFF

- When using KV-L20, KV-L21V



- Terminator setting switch

Set when carrying out RS-422 communication.



Settings	
When multi-communication unit is a terminal	When multi-communication unit is not a terminal
ON	OFF

Connecting to KV-N10L, KV-N11L, KV-NC10L, KV-NC20L

Setting items	Set value
Communication mode	KV mode (Upper link)
Transmission speed *1*2	9600bps, 19200bps, 38400bps, 57600bps, 115200bps
Data bit	8bits
Parity bit	Even
Stop bit	1bit

*1 Only transmission speeds available on the GOT side are shown.



*2 The transmission speed setting must be consistent with that of the GOT side.

For the transmission speed setting on the GOT side, refer to the following.





Page 335 Setting communication interface (Communication settings)

6.3 Ethernet Connection

Connecting to KV-700, KV-1000, KV-3000, KV-5000, KV-5500, KV-7300, KV-7500, KV-N24□□, KV-N40□□, KV-N60□□, KV-NC32T



PLC Series	Ethernet module ^{*3}	Connection cable Cable model ^{*1}	Maximum segment length ^{*2}	GOT Option device ^{*4}	Model ^{*3}	Number of connectable equipment
KV-5000 KV-7500	-	Twisted pair cable ^{*1} • 10BASE-T Shielded twisted pair cable (STP) or unshielded twisted pair cable (UTP): Category 3, 4, and 5 • 100BASE-TX Shielded twisted pair cable (STP): Category 5 and 5e	100m	- (Built into GOT) GT25-J71E71-100	<div> <div>GT 27</div> <div>GT 25</div> <div>GT 23</div> <div>GT 21</div> <div>GS</div> </div> <div> <div>GT 27</div> <div>GT 25</div> </div>	When PLC:GOT is N:1 The following shows the number of PLCs for 1 GOT <For GT27, GT25> TCP: 128 or less UDP: 128 or less <For GT21, GS21> TCP: 4 or less UDP: 4 or less
KV-700 KV-1000 KV-3000 KV-5000 KV-5500 KV-7300 KV-7500	KV-LE20V KV-LE21V		100m	- (Built into GOT) GT25-J71E71-100	<div> <div>GT 27</div> <div>GT 25</div> <div>GT 23</div> <div>GT 21</div> <div>GS</div> </div> <div> <div>GT 27</div> <div>GT 25</div> </div>	When PLC:GOT is 1:N The following shows the number of GOTs for 1 PLC TCP: 15 or less UDP: 1 or less
KV-7300 KV-7500	KV-EP21V		100m	- (Built into GOT) GT25-J71E71-100	<div> <div>GT 27</div> <div>GT 25</div> <div>GT 23</div> <div>GT 21</div> <div>GS</div> </div> <div> <div>GT 27</div> <div>GT 25</div> </div>	


PLC Series	Ethernet module ^{*3}	Connection cable Cable model ^{*1}	Maximum segment length ^{*2}	GOT Option device ^{*4}	Model ^{*3}	Number of connectable equipment
KV-N24□□ KV-N40□□ KV-N60□□	KV-N1 + KV-NC1EP	Twisted pair cable ^{*1} • 10BASE-T Shielded twisted pair cable (STP) or unshielded twisted pair cable (UTP): Category 3, 4, and 5 • 100BASE-TX Shielded twisted pair cable (STP): Category 5 and 5e	100m	- (Built into GOT)		When PLC:GOT is N:1 The following shows the number of PLCs for 1 GOT <For GT27, GT25> TCP: 128 or less UDP: 128 or less <For GT21, GS21> TCP: 4 or less UDP: 4 or less
				GT25-J71E71-100		When PLC:GOT is 1:N The following shows the number of GOTs for 1 PLC TCP: 15 or less UDP: 1 or less
KV-NC32T	KV-NC1EP		100m	- (Built into GOT)		When PLC:GOT is 1:N The following shows the number of GOTs for 1 PLC TCP: 15 or less UDP: 1 or less
				GT25-J71E71-100		

- *1 The destination connected with the twisted pair cable varies with the configuration of the applicable Ethernet network system. Connect to the Ethernet module, hub, transceiver or other system equipment corresponding to the applicable Ethernet network system. Use cables, connectors, and hubs that meet the IEEE802.3 10BASE-T/100BASE-TX standards. When using a hub for connecting, use a straight cable.
- *2 A length between a hub and a node.
The maximum distance differs depending on the Ethernet device to be used.
The following shows the number of the connectable nodes when a repeater hub is used.
• 10BASE-T: Max. 4 nodes for a cascade connection (500m)
• 100BASE-TX: Max. 2 nodes for a cascade connection (205m)
When switching hubs are used, the cascade connection between the switching hubs has no logical limit for the number of cascades. For the limit, contact the switching hub manufacturer.
- *3 Product manufactured by KEYENCE CORPORATION. For details of the product, contact KEYENCE CORPORATION.
- *4 GT25-W, GT2505-V does not support the option device.

GOT side settings

Setting communication interface (Communication settings)

Set the channel of the equipment to be connected to the GOT.



1. Select [Common] → [Controller Setting] from the menu.
 2. In the [Controller Setting] window, select the channel No. to be used from the list menu.
 3. Set the following items.
 - [Manufacturer]: [KEYENCE]
 - [Controller Type]: [KEYENCE KV-700/1000/3000/5000/7000]
 - [I/F]: Interface to be used
 - [Detail Setting]: Configure the settings according to the usage environment.
- ☞ Page 344 Communication detail settings
4. When you have completed the settings, click the [OK] button.

Point

The settings of connecting equipment can be confirmed in [I/F Communication Setting].
For details, refer to the following.

☞ Page 47 I/F communication setting


Communication detail settings

Make the settings according to the usage environment.

Property	Value
GOT Net No.	1
GOT Station	18
GOT Communication Port No.	5025
Retry(Times)	3
Startup Time(Sec)	3
Timeout Time(Sec)	3
Delay Time(ms)	0

Item	Description	Range
GOT Net No.	Set the network No. of the GOT. (Default: 1)	1 to 239
GOT Station*1	Set the station No. of the GOT. (Default: 18)	1 to 254
GOT Communication Port No.	Set the GOT port No. for the connection with the Ethernet module. (Default: 5025*2)	1024 to 5010, 5014 to 65534 (Except for 5011, 5012, 5013, and 49153 to 49170)
Retry	Set the number of retries to be performed when a communication timeout occurs. When receiving no response after retries, the communication times out. (Default: 3times)	0 to 5times
Startup Time	Specify the time period from the GOT startup until GOT starts the communication with the PLC CPU. (Default: 3sec)	3 to 255sec
Timeout Time	Set the time period for a communication to time out. (Default: 3sec)	1 to 90sec
Delay Time	Set the delay time for reducing the load of the network/destination PLC. (Default: 0ms)	0 to 10000 (ms)

*1 Set different values for [GOT Station] of [Detail Setting] and [Station] of [Connected Ethernet Controller Setting].

 Page 345 Connected Ethernet Controller Setting

*2 When assigning the same driver to the multiple channels, in the communication drivers set as the second and following, the default value of [GOT Communication Port No.] becomes the earliest number in the vacant numbers of No. 6000 and later.

GOT Ethernet Setting

The GOT can be connected to a different network by configuring the following setting.

■GOT IP address setting

Set the following communication port setting.

- Standard port (When using GT25-W, port 1)
- Extension port (When using GT25-W, port 2)

■GOT Ethernet common setting

Set the following setting which is common to the standard port and the extension port, or port 1 and port 2.

- [Default Gateway]
- [Peripheral S/W Communication Port No.]
- [Transparent Port No.]


■IP filter setting

By configuring the IP filter setting, the access from the specific IP address can be permitted or shut off.

For the detailed settings, refer to the following manual.

 Page 43 GOT Ethernet Setting

Connected Ethernet Controller Setting



Item	Description	Set value
Host	The host is displayed. (The host is indicated with an asterisk (*).)	-
Net No.	Set the network No. of the connected Ethernet module. (Default: blank)	1 to 239
Station *1	Set the station No. of the connected Ethernet module. (Default: blank)	1 to 254
Unit Type	KEYENCE (fixed)	KEYENCE (fixed)
IP Address	Set the IP address of the connected Ethernet module. (Default: 192.168.0.10)	PLC side IP address
Port No.	Set the port No. of the connected Ethernet module. (Default: 8501)	PLC side port No.
Communication	UDP, TCP (Default: UDP)	Adjust the settings with the PLC settings.

*1 Set different values for [GOT Station] of [Detail Setting] and [Station] of [Connected Ethernet Controller Setting].

☞ Page 344 Communication detail settings

6

Point

- Communication interface setting by the Utility

The communication interface setting can be changed on the Utility's [Communication setting] after writing [Communication Settings] of project data.

For details on the Utility, refer to the following manual.

☞ GOT2000 Series User's Manual (Utility)

- Precedence in communication settings

When settings are made by GT Designer3 or the Utility, the latest setting is effective.

[Connected Ethernet Controller Setting] for GT21 and GS21


- Effective range of [Connected Ethernet Controller Setting]

Only [1] to [4] of [Connected Ethernet Controller Setting] can be used for GT21 and GS21.

If [5] onwards are used, the settings are invalid on GT21 and GS21.

- [Host] setting

Set [Host] within the range from [1] to [4] in [Connected Ethernet Controller Setting].



PLC side setting



KEYENCE PLC
For details of KEYENCE PLC, refer to the following manual.
 KEYENCE PLC user's Manual

KV-5000, KV-7500 (Built in Ethernet) setting

Set the communication mode, IP address and port No. by the unit editor of KV STUDIO.

Item	Description	Range
Communication mode	Ethernet	-
IP address*1	Set the IP address.	0.0.0.0 to 255.255.255.255
Port No.*1 (Host link)	Set the port No.	256 to 65534

*1 Apply the same setting as [Connected Ethernet Controller Setting] of the GOT.
 Page 345 Connected Ethernet Controller Setting

KV-LE21V, KV-LE20V, KV-EP21V, KV-NC1EP setting

Set the IP address and port No. by the unit editor of KV STUDIO.

Item	Description	Range
IP address*1	Set the IP address.	0.0.0.0 to 255.255.255.255
Port No.*1 (Host link)	Set the port No.	256 to 65534

*1 Apply the same setting as [Connected Ethernet Controller Setting] of the GOT.
 Page 345 Connected Ethernet Controller Setting

6.4 Device Range that Can Be Set

The device ranges of controller that can be used for GOT are as follows.


Note that the device ranges in the following tables are the maximum values that can be set in GT Designer3.

The device specifications of controllers may differ depending on the models, even though belonging to the same series.

Please make the setting according to the specifications of the controller actually used.

When a non-existent device or a device number outside the range is set, other objects with correct device settings may not be monitored.

Setting item



Item	Description	
Device	Set the device name, device number, and bit number. The bit number can be set only when specifying the bit of word device.	
Information	Displays the device type and its setting range selected in [Device].	
Network	Set the station number of the controller to be monitored.	
	Host	Select this item for monitoring the host controller.
	Other	Select this item for monitoring other controllers. After selecting, set the station number of the controller to be monitored. NWNo.: Set the network No. Station No.: Set the station No.

Point

Device settings of KEYENCE PLC

- Device terminology

The following shows the device terminology types available for KEYENCE PLCs.

KEYENCE terminology

XYM terminology


In GT Designer3, devices are represented in the KEYENCE terminology.

For details of KEYENCE PLC, refer to the following manual.

🔑 KEYENCE PLC user's Manual

- Setting setting procedure for relays (...), internal auxiliary relays (MR), latch relays (LR) and control relays(CR).

Make settings for status by a channel number and a bit position.



KV-700, 1000, 3000, 5000, 7000, and KV Nano

In GT Designer3, devices are represented in the KEYENCE terminology.

Device name		Setting range	Device No. representation
Bit device	Relay (...)	..00000 to ..99915	Decimal
	Internal auxiliary relay (MR)	MR00000 to MR399915	
	Latch relay (LR)	LR00000 to LR99915	
	Control relay (CR)	CR0000 to CR7915	
	Link relay (B) ^{*2}	B0000 to B7FFF	Hexadecimal
	Work relay (VB) ^{*2}	VB0000 to VBF9FF	
	Timer (Contact) (T) ^{*1*2}	T0000 to T3999	Decimal
	Counter (Contact) (C) ^{*1*2}	C0000 to C3999	
	High-speed counter comparator (Contact) (CTC) ^{*2*3*6}	CTC0 to CTC3	
	The bit specification of the word device (except Control memory, Temporary data memory, Work memory, Index register)	Setting range of each word device	-
Word device	Data memory (DM)	DM00000 to DM65534	Decimal
	Extension data memory (EM)	EM00000 to EM65534	
	Extension data memory 2 (FM)	FM00000 to FM32767	
	File register (ZF)	ZF000000 to ZF524287	
	Link register (W)	W0000 to W7FFF	Hexadecimal
	Control memory (CM)	CM00000 to CM11998	Decimal
	Temporary data memory (TM)	TM000 to TM511	
	Work memory (VM)	VM00000 to VM63999	
	Index register (Z) ^{*7}	Z1 to Z12	
	The word specification of the bit device (except Timer (Contact), Counter (Contact), High-speed counter comparator (Contact))	Setting range of each bit device	-
Double word device	Timer (Current value) (TC) ^{*2*4}	TC0000 to TC3999	-
	Timer (Set value) (TS) ^{*2*4}	TS0000 to TS3999	
	Counter (Current value) (CC) ^{*2*4}	CC0000 to CC3999	
	Counter (Set value) (CS) ^{*2*4}	CS0000 to CS3999	
	High-speed counter (Current value) (CTH) ^{*2*4}	CTH0 to CTH1	
	High-speed counter comparator (Set value) (CTC) ^{*2*4}	CTC0 to CTC3	
	Index register (DZ)	DZ01 to DZ12	
	Digital trimmer (TRM) ^{*4*5}	TRM0 to TRM7	

*1 Monitoring or writing is not possible in the continuous device designation mode.

*2 Monitoring by GOT is possible only when a device is used in the sequence program.

*3 When writing, only the reset of the contact is possible.

*4 Only 32-bit (2-word) designation is allowed.

*5 Only reading is possible.

*6 Monitoring or writing to continuous devices is not possible.

*7 With KV-3000 and KV-5000, Z devices cannot be specified as 32-bit (2 words) data. Use DZ devices.

MEMO

7 CONNECTION TO KOYO EI PLC

- Page 351 Connectable Model List
- Page 352 System Configuration
- Page 368 Connection Diagram
- Page 374 GOT Side Settings
- Page 376 PLC Side Setting
- Page 384 Device Range that Can Be Set
- Page 386 Precautions

7.1 Connectable Model List

The following table shows the connectable models.


Series	Model name	Clock ^{*1}	Communication Type	Connectable GOT	Refer to
KOSTAC SU Series	SU-5E	×	RS232	<div>GT 27</div> <div>GT 25</div> <div>GT 23</div>	Page 352 Connecting to SU-5E or SU-6B
	SU-6B	○	RS422		
	SU-5M	○	RS232	<div>GT 27</div> <div>GT 25</div> <div>GT 23</div>	Page 355 Connecting to SU-5M or SU-6M
	SU-6M	○	RS422		
DirectLOGIC 05 Series	D0-05AA	×	RS232 RS422	<div>GT 27</div> <div>GT 25</div> <div>GT 23</div>	Page 358 Connecting to DirectLOGIC 05 series
	D0-05AD	×			
	D0-05AR	×			
	D0-05DA	×			
	D0-05DD	×			
	D0-05DD-D	×			
	D0-05DR	×			
	D0-05DR-D	×			
DirectLOGIC 06 Series	D0-06DD1	○	RS232 RS422	<div>GT 27</div> <div>GT 25</div> <div>GT 23</div>	Page 361 Connecting to DirectLOGIC 06 series
	D0-06DD2	○			
	D0-06DR	○			
	D0-06DA	○			
	D0-06AR	○			
	D0-06AA	○			
	D0-06DD1-D	○			
	D0-06DD2-D	○			
	D0-06DR-D	○			
DirectLOGIC 205 Series	D2-240	○	RS232 RS422	<div>GT 27</div> <div>GT 25</div> <div>GT 23</div>	Page 364 Connecting to D2-240, D2-250-1 or D2-260
	D2-250-1	○			
	D2-260	○			
PZ series	PZ3	×	RS232 RS422	<div>GT 27</div> <div>GT 25</div> <div>GT 23</div>	Page 366 Connecting to PZ

*1 The GOT can only read the clock data. In the clock setting, though the adjust is available, the broadcast is not available.

7.2 System Configuration

Connecting to SU-5E or SU-6B


When connecting to one PLC



PLC			Connection cable		GOT		Number of connectable equipment
Model name	Host link module ^{*1}	Communication Type	Cable model Connection diagram number	Max. distance	Option device ^{*2}	Model	
SU-5E/6B (general communication port)	-	RS-232	(User preparing) Page 368 RS-232 connection diagram 1)	15m	- (Built into GOT)	GT 27 GT 25 GT 23	1 PLC for 1 GOT
					GT15-RS2-9P	GT 27 GT 25	
		RS-422	(User preparing) Page 369 RS-422 connection diagram 1)	1000m	- (Built into GOT)	GT 27 GT 25 GT 23	
					GT15-RS4-9S	GT 27 GT 25	
SU-5E/6B	U-01DM	RS-232	(User preparing) Page 368 RS-232 connection diagram 1)	15m	- (Built into GOT)	GT 27 GT 25 GT 23	1 host link module for 1 GOT
					GT15-RS2-9P	GT 27 GT 25	
		RS-422	(User preparing) Page 370 RS-422 connection diagram 3)	1200m	- (Built into GOT)	GT 27 GT 25 GT 23	
					GT15-RS4-9S	GT 27 GT 25	

- *1 The data communications module is manufactured by KOYO ELECTRONICS INDUSTRIES CO., LTD. For details of the product, contact KOYO ELECTRONICS INDUSTRIES CO., LTD.
- *2 GT25-W, GT2505-V does not support the option device.

When connecting to multiple PLCs



PLC			Connection cable		GOT		Number of connectable equipment
Model name	Host link module ^{*1}	Communication Type	Cable model Connection diagram number	Max. distance	Option device ^{*3}	Model	
SU-5E/6B	-	RS-422	(User preparing) Page 371 RS-422 connection diagram 5)	1000m	- (Built into GOT)	GT 27 GT 25 GT 23	90 PLCs for 1 GOT ^{*2}
					GT15-RS4-9S	GT 27 GT 25	
SU-5E/6B	U-01DM	RS-422	(User preparing) Page 372 RS-422 connection diagram 7)	1200m	- (Built into GOT)	GT 27 GT 25 GT 23	90 host link module for 1 GOT ^{*2}
					GT15-RS4-9S	GT 27 GT 25	

*1 The data communications module is manufactured by KOYO ELECTRONICS INDUSTRIES CO., LTD. For details of the product, contact KOYO ELECTRONICS INDUSTRIES CO., LTD.


*2 When the number of links exceeds 30, use a transmission line conversion unit D-01CV per 30 links. For details, refer to the following manual.

☞ KOYO EI PLC user's Manual













*3 GT25-W, GT2505-V does not support the option device.

Connecting to SU-5M or SU-6M

When connecting to one PLC




PLC			Connection cable		GOT		Number of connectable equipment
Model name	Host link module ^{*1}	Communication Type	Cable model Connection diagram number	Max. distance	Option device ^{*2}	Model	
SU-5M/6M (general communication port 1)	-	RS-232	(User preparing) Page 368 RS-232 connection diagram 1)	15m	- (Built into GOT)	GT 27 GT 23	1 PLC for 1 GOT
					GT15-RS2-9P	GT 27 GT 25	
		RS-422	(User preparing) Page 369 RS-422 connection diagram 1)	1000m	- (Built into GOT)	GT 27 GT 23	
					GT15-RS4-9S	GT 27 GT 25	
SU-5M/6M (general communication port 2)	-	RS-232	Z-20JP (Programmable connecting cable) + S-9CNS1(Conversion connector) ^{*1}	3m	- (Built into GOT)	GT 27 GT 23	
					GT15-RS2-9P	GT 27 GT 25	
SU-5M/6M (general communication port 3)	-	RS-422	(User preparing) Page 369 RS-422 connection diagram 2)	1000m	- (Built into GOT)	GT 27 GT 23	
					GT15-RS4-9S	GT 27 GT 25	

PLC			Connection cable		GOT		Number of connectable equipment
Model name	Host link module ^{*1}	Communication Type	Cable model Connection diagram number	Max. distance	Option device ^{*2}	Model	
SU-5M/6M	U-01DM	RS-232	 Page 368 RS-232 connection diagram 1)	15m	- (Built into GOT)	  	1 host link module for 1 GOT
					GT15-RS2-9P	 	
		RS-422	 Page 370 RS-422 connection diagram 3)	1200m	- (Built into GOT)	  	
					GT15-RS4-9S	 	

^{*1} The programmable connecting cable and conversion connector are products manufactured by KOYO ELECTRONICS INDUSTRIES CO., LTD.
For details of the product, contact KOYO ELECTRONICS INDUSTRIES CO., LTD.

^{*2} GT25-W, GT2505-V does not support the option device.

When connecting to multiple PLCs



PLC			Connection cable		GOT		Number of connectable equipment
Model name	Host link module ^{*1}	Communication Type	Cable model Connection diagram number	Max. distance	Option device ^{*3}	Model	
SU-5M/6M (general communication port 1)	-	RS-422	(User preparing) Page 371 RS-422 connection diagram 5)	1000m	- (Built into GOT)	GT 27 GT 25 GT 23	90 PLCs for 1 GOT ^{*2}
					GT15-RS4-9S	GT 27 GT 25	
SU-5M/6M (general communication port 3)	-	RS-422	(User preparing) Page 371 RS-422 connection diagram 6)	1000m	- (Built into GOT)	GT 27 GT 25 GT 23	
					GT15-RS4-9S	GT 27 GT 25	
SU-5M/6M	U-01DM	RS-422	(User preparing) Page 372 RS-422 connection diagram 7)	1200m	- (Built into GOT)	GT 27 GT 25 GT 23	90 host link module for 1 GOT ^{*2}
					GT15-RS4-9S	GT 27 GT 25	

*1 The data communications module is manufactured by KOYO ELECTRONICS INDUSTRIES CO., LTD.
For details of the product, contact KOYO ELECTRONICS INDUSTRIES CO., LTD.


*2 When the number of links exceeds 30, use a transmission line conversion unit D-01CV per 30 links.
For details, refer to the following manual.























☞ KOYO EI PLC user's Manual

*3 GT25-W, GT2505-V does not support the option device.

Connecting to DirectLOGIC 05 series


When connecting to one PLC









PLC			Connection cable		GOT		Number of connectable equipment
Model name	Data communications module ^{*2}	Communication Type	Cable model Connection diagram number	Max. distance	Option device ^{*3}	Model	
Direct LOGIC 05 (communication port 1) (communication port 2)	-	RS-232	Z-20JP (Programmable connecting cable) + S-9CNS1(Conversion connector) ^{*1}	3m	- (Built into GOT)	  	1 PLC for 1 GOT
					GT15-RS2-9P	 	
Direct LOGIC 05	D0-DCM (port 1)	RS-232	Z-20JP (Programmable connecting cable) + S-9CNS1(Conversion connector) ^{*1}	3m	- (Built into GOT)	  	1 data communication module for 1 GOT
					GT15-RS2-9P	 	
Direct LOGIC 05	D0-DCM (port 2)	RS-232	 Page 368 RS-232 connection diagram 2)	15m	- (Built into GOT)	  	
					GT15-RS2-9P	 	
		RS-422	 Page 370 RS-422 connection diagram 4)	1000m	- (Built into GOT)	  	
					GT15-RS4-9S	 	


- *1 The programmable connecting cable and conversion connector are products manufactured by KOYO ELECTRONICS INDUSTRIES CO., LTD.
For details of the product, contact KOYO ELECTRONICS INDUSTRIES CO., LTD.
- *2 The data communications module is manufactured by KOYO ELECTRONICS INDUSTRIES CO., LTD.
For details of the product, contact KOYO ELECTRONICS INDUSTRIES CO., LTD.
- *3 GT25-W, GT2505-V does not support the option device.

When connecting to multiple PLCs



PLC			Connection cable		GOT		Number of connectable equipment
Model name	Data communications module ^{*1}	Communication Type	Cable model Connection diagram number	Max. distance	Option device ^{*3}	Model	
Direct LOGIC 05	D0-DCM (port 2)	RS-422	 Page 372 RS-422 connection diagram 8)	1000m	- (Built into GOT)	  	90 data communication module for 1 GOT ^{*2}
					GT15-RS4-9S	 	


^{*1} The data communications module is manufactured by KOYO ELECTRONICS INDUSTRIES CO., LTD.
For details of the product, contact KOYO ELECTRONICS INDUSTRIES CO., LTD.

^{*2} When the number of links exceeds 30, use a transmission line conversion unit D-01CV per 30 links.
For details, refer to the following manual.
 KOYO EI PLC user's Manual

^{*3} GT25-W, GT2505-V does not support the option device.

Connecting to DirectLOGIC 06 series

When connecting to one PLC



PLC			Connection cable		GOT		Number of connectable equipment
Model name	Data communications module *1	Communication Type	Cable model Connection diagram number	Max. distance	Option device *3	Model	
Direct LOGIC 06 (communication port 1)	-	RS-232	Z-20JP (Programmable connecting cable) + S-9CNS1(Conversion connector)*2	3m	-(Built into GOT)	GT 27 GT 23 GT 25	1 PLC for 1 GOT
					GT15-RS2-9P	GT 27 GT 25	
Direct LOGIC 06 (communication port 2)	-	RS-232	(User's Page 368 RS-232 connection diagram 2)	15m	-(Built into GOT)	GT 27 GT 23 GT 25	
					GT15-RS2-9P	GT 27 GT 25	
	-	RS-422	(User's Page 370 RS-422 connection diagram 4)	1000m	-(Built into GOT)	GT 27 GT 23 GT 25	
					GT15-RS4-9S	GT 27 GT 25	


PLC			Connection cable		GOT		Number of connectable equipment
Model name	Data communications module ^{*1}	Communication Type	Cable model Connection diagram number	Max. distance	Option device ^{*3}	Model	
Direct LOGIC 06	D0-DCM (port 1)	RS-232	Z-20JP (Programmable connecting cable) + S-9CNS1(Conversion connector) ^{*2}	3m	- (Built into GOT)	<div>GT 27</div> <div>GT 25</div> <div>GT 23</div>	1 data communication module for 1 GOT
					GT15-RS2-9P	<div>GT 27</div> <div>GT 25</div>	
Direct LOGIC 06	D0-DCM (port 2)	RS-232	<div>User property</div> Page 368 RS-232 connection diagram 2)	15m	- (Built into GOT)	<div>GT 27</div> <div>GT 25</div> <div>GT 23</div>	
					GT15-RS2-9P	<div>GT 27</div> <div>GT 25</div>	
		RS-422	<div>User property</div> Page 370 RS-422 connection diagram 4)	1000m	- (Built into GOT)	<div>GT 27</div> <div>GT 25</div> <div>GT 23</div>	
					GT15-RS4-9S	<div>GT 27</div> <div>GT 25</div>	













*1 The data communications module is manufactured by KOYO ELECTRONICS INDUSTRIES CO., LTD.
For details of the product, contact KOYO ELECTRONICS INDUSTRIES CO., LTD.

*2 The programmable connecting cable and conversion connector are products manufactured by KOYO ELECTRONICS INDUSTRIES CO., LTD.
For details of the product, contact KOYO ELECTRONICS INDUSTRIES CO., LTD.


*3 GT25-W, GT2505-V does not support the option device.

When connecting to multiple PLCs



PLC			Connection cable		GOT		Number of connectable equipment
Model name	Data communication module ^{*1}	Communication Type	Cable model Connection diagram number	Max. distance	Option device ^{*3}	Model	
Direct LOGIC 06 (communication port 2)	-	RS-422	 Page 372 RS-422 connection diagram 8)	1000m	- (Built into GOT)	  	90 PLCs for 1 GOT ^{*2}
					GT15-RS4-9S	 	
Direct LOGIC 06	D0-DCM (port 2)	RS-422	 Page 372 RS-422 connection diagram 8)	1000m	- (Built into GOT)	  	90 data communication module for 1 GOT ^{*2}
					GT15-RS4-9S	 	


^{*1} The data communications module is manufactured by KOYO ELECTRONICS INDUSTRIES CO., LTD.
For details of the product, contact KOYO ELECTRONICS INDUSTRIES CO., LTD.

^{*2} When the number of links exceeds 30, use a transmission line conversion unit D-01CV per 30 links.
For details, refer to the following manual.
 KOYO EI PLC user's Manual

^{*3} GT25-W, GT2505-V does not support the option device.

Connecting to D2-240, D2-250-1 or D2-260

When connecting to one PLC




PLC			Connection cable		GOT		Number of connectable equipment
Model name	Data communications module *1	Communication Type	Cable model Connection diagram number	Max. distance	Option device *2	Model	
D2-240 D2-250-1 D2-260 (communication port 2)	-	RS-232	(User property) Page 368 RS-232 connection diagram 2)	3m	-(Built into GOT)	GT 27 GT 25 GT 23	1 PLC for 1 GOT
					GT15-RS2-9P	GT 27 GT 25	
D2-250-1 D2-260 (communication port 2)	-	RS-422	(User property) Page 370 RS-422 connection diagram 4)	1000m	-(Built into GOT)	GT 27 GT 25 GT 23	
					GT15-RS4-9S	GT 27 GT 25	
D2-240 D2-250-1 D2-260	D2-DCM	RS-232	(User property) Page 368 RS-232 connection diagram 1)	15m	-(Built into GOT)	GT 27 GT 25 GT 23	1 data communication module for 1 GOT
					GT15-RS2-9P	GT 27 GT 25	
		RS-422	(User property) Page 370 RS-422 connection diagram 3)	1200m	-(Built into GOT)	GT 27 GT 25 GT 23	
					GT15-RS4-9S	GT 27 GT 25	

*1 The programmable connecting cable and conversion connector are products manufactured by KOYO ELECTRONICS INDUSTRIES CO., LTD.

For details of the product, contact KOYO ELECTRONICS INDUSTRIES CO., LTD.

*2 GT25-W, GT2505-V does not support the option device.

When connecting to multiple PLCs



PLC			Connection cable		GOT		Number of connectable equipment
Model name	Data communications module ^{*1}	Communication Type	Cable model Connection diagram number	Max. distance	Option device ^{*3}	Model	
D2-250-1 D2-260 (communication port 2)	-	RS-422	Page 372 RS-422 connection diagram 8)	1000m	-(Built into GOT)	 	90 PLCs for 1 GOT ^{*2}
					GT15-RS4-9S	 	
D2-240 D2-250-1 D2-260	D2-DCM	RS-422	Page 372 RS-422 connection diagram 7)	1200m	-(Built into GOT)	 	90 data communication module for 1 GOT ^{*2}
					GT15-RS4-9S	 	

^{*1} The data communications module is manufactured by KOYO ELECTRONICS INDUSTRIES CO., LTD.
For details of the product, contact KOYO ELECTRONICS INDUSTRIES CO., LTD.


^{*2} When the number of links exceeds 30, use a transmission line conversion unit D-01CV per 30 links.
For details, refer to the following manual.

KOYO EI PLC user's Manual

^{*3} GT25-W, GT2505-V does not support the option device.

Connecting to PZ


When connecting to one PLC









PLC		Connection cable		GOT		Number of connectable equipment
Model name	Communication Type	Cable model Connection diagram number	Max. distance	Option device ^{*1}	Model	
PZ (general communication port 2)	RS-232	(User preparing) Page 368 RS-232 connection diagram 2)	15m	- (Built into GOT)	<div>GT 27</div> <div>GT 25</div> <div>GT 23</div>	1 PLC for 1 GOT
				GT15-RS2-9P	<div>GT 27</div> <div>GT 25</div>	
	RS-422	(User preparing) Page 370 RS-422 connection diagram 4)	1000m	- (Built into GOT)	<div>GT 27</div> <div>GT 25</div> <div>GT 23</div>	
				GT15-RS4-9S	<div>GT 27</div> <div>GT 25</div>	

*1 GT25-W, GT2505-V does not support the option device.

When connecting to multiple PLCs



PLC		Connection cable		GOT		Number of connectable equipment
Model name	Communication Type	Cable model Connection diagram number	Max. distance	Option device ^{*2}	Model	
PZ (general communication port 2)	RS-422	 Page 372 RS-422 connection diagram 8)	1000m	- (Built into GOT)	  	90 PLCs for 1 GOT ^{*1}
				GT15-RS4-9S	 	

^{*1} When the number of links exceeds 30, use a transmission line conversion unit D-01CV per 30 links.
For details, refer to the following manual.

 KOYO EI PLC user's Manual

^{*2} GT25-W, GT2505-V does not support the option device.


7.3 Connection Diagram

The following diagram shows the connection between the GOT and the PLC.

RS-232 cable

Connection diagram

■RS-232 connection diagram 1)




*1 GT27: CD, GT23:NC

*2 Connect FG grounding to the appropriate part of a cable shield line.

*3 For U-01DM and D2-DCM, the signal name will be +5V.

■RS-232 connection diagram 2)



*1 GT27: CD, GT23:NC

*2 Connect FG grounding to the appropriate part of a cable shield line.

Precautions when preparing a cable

■Cable length

The length of the RS-232 cable must be 15m or less.

■GOT side connector

For the GOT side connector, refer to the following.

☞ Page 58 GOT connector specifications

■KOYO EI PLC side connector


Use the connector compatible with the KOYO EI PLC side.

For details, refer to the KOYO EI PLC user's manual.

RS-422 cable

Connection diagram


■RS-422 connection diagram 1)



*1 Connect FG grounding to the appropriate part of a cable shield line.

*2 Connect a terminating resistor (approximately 150Ω) to the PLC at a terminal station.


■RS-422 connection diagram 2)



*1 Connect FG grounding to the appropriate part of a cable shield line.

*2 Connect a terminating resistor (approximately 150Ω) to the PLC at a terminal station.


■RS-422 connection diagram 3)



*1 Connect FG grounding to the appropriate part of a cable shield line.

*2 Connect a terminating resistor (approximately 150Ω) to the PLC at a terminal station.


■RS-422 connection diagram 4)



*1 Connect FG grounding to the appropriate part of a cable shield line.

*2 Connect a terminating resistor (approximately 100 to 500Ω) to the PLC to be a terminal.

■RS-422 connection diagram 5)



*1 Connect FG grounding to the appropriate part of a cable shield line.


*2 Connect a terminating resistor (approximately 150Ω) to the PLC at a terminal station.

When the number of links exceeds 30, use a transmission line conversion unit D-01CV per 30 links.

For details, refer to the following manual.

☞ KOYO EI PLC user's Manual

■RS-422 connection diagram 6)



*1 Connect FG grounding to the appropriate part of a cable shield line.


*2 Connect a terminating resistor (approximately 150Ω) to the PLC at a terminal station.

When the number of links exceeds 30, use a transmission line conversion unit D-01CV per 30 links.

For details, refer to the following manual.

☞ KOYO EI PLC user's Manual

■RS-422 connection diagram 7)



*1 Connect FG grounding to the appropriate part of a cable shield line.


*2 Connect a terminating resistor (approximately 150Ω) to the PLC at a terminal station.

When the number of links exceeds 30, use a transmission line conversion unit D-01CV per 30 links.

For details, refer to the following manual.

☞ KOYO EI PLC user's Manual

■RS-422 connection diagram 8)



*1 Connect FG grounding to the appropriate part of a cable shield line.

*2 Connect a terminating resistor (approximately 100 to 500Ω) to the PLC to be a terminal.

When the number of links exceeds 30, use a transmission line conversion unit D-01CV per 30 links.

For details, refer to the following manual.

☞ KOYO EI PLC user's Manual

Precautions when preparing a cable

■Cable length

The maximum length of the RS-422 cable differs according to the specifications of the KOYO EI PLC side module.

For details, refer to the following manual.

📖 KOYO EI PLC user's Manual

■GOT side connector

For the GOT side connector, refer to the following.

📖 Page 58 GOT connector specifications

■KOYO EI PLC side connector

Use the connector compatible with the KOYO EI PLC side.

For details, refer to the KOYO EI PLC user's manual.

Connecting terminating resistors

■GOT side

- For GT27, GT25(Except GT2505-V), GT23

Set the terminating resistor setting switch of the GOT main unit to "Disable".

- For GT2505-V

Set the terminating resistor selector to "330Ω".

For the procedure to set the terminating resistor, refer to the following.

📖 Page 62 Terminating resistors of GOT

■KOYO EI PLC


To connect a KOYO EI PLC to a GOT, a terminating resistor must be set to the KOYO EI PLC.

📖 KOYO EI PLC user's Manual

7.4 GOT Side Settings

Setting communication interface (Communication settings)

Set the channel of the equipment to be connected to the GOT.



1. Select [Common] → [Controller Setting] from the menu.
2. In the [Controller Setting] window, select the channel No. to be used from the list menu.
3. Set the following items.
 - [Manufacturer]: [KOYO]
 - [Controller Type]: [KOYO KOSTAC/DL]
 - [I/F]: Interface to be used
 - [Detail Setting]: Configure the settings according to the usage environment.

☞ Page 375 Communication detail settings
4. When you have completed the settings, click the [OK] button.

Point

The settings of connecting equipment can be confirmed in [I/F Communication Setting].
For details, refer to the following.

☞ Page 47 I/F communication setting

Communication detail settings

Make the settings according to the usage environment.

Property	Value
Transmission Speed(BPS)	9600
Data Bit	8 bit
Stop Bit	1 bit
Parity	Odd
Retry(Times)	3
Timeout Time(Sec)	3
Host Address	1
Delay Time(ms)	0

Item	Description	Range
Transmission Speed	Set this item when change the transmission speed used for communication with the connected equipment. (Default: 9600bps)	9600bps, 19200bps, 38400bps, 57600bps, 115200bps
Data Bit	Set this item when change the data length used for communication with the connected equipment. (Default: 8bits)	7bits/8bits
Stop Bit	Specify the stop bit length for communications. (Default: 1bit)	1bit/2bits
Parity	Specify whether or not to perform a parity check, and how it is performed during communication. (Default: Odd)	None Even Odd
Retry	Set the number of retries to be performed when a communication error occurs. (Default: 3times)	0 to 5times
Timeout Time	Set the time period for a communication to time out. (Default: 3sec)	1 to 50sec
Delay Time	Set this item to adjust the transmission timing of the communication request from the GOT. (Default: 0ms)	0 to 300ms
Host Address	Specify the host address (station No. of the GOT to which the PLC is connected) in the connected network. (Default: 1)	1 to 90


7

Point

- Communication interface setting by the Utility

The communication interface setting can be changed on the Utility's [Communication Settings] after writing [Communication Settings] of project data.

For details on the Utility, refer to the following manual.

 GOT2000 Series User's Manual (Utility)

- Precedence in communication settings

When settings are made by GT Designer3 or the Utility, the latest setting is effective.

7.5 PLC Side Setting



KOYO EI PLC

For details of KOYO EI PLCs, refer to the following manuals.

☞ KOYO EI PLC user's Manual

PLC CPU

Model name		Refer to
KOSTAC SU Series	SU-5E/6B	☞ Page 377 Connecting to SU-5E/6B
	SU-5M/6M	☞ Page 378 Connecting to SU-5M/6M
DirectLOGIC 05 Series DirectLOGIC 06 Series		☞ Page 378 Connecting to DirectLOGIC 05 series or DirectLOGIC 06 series
DirectLOGIC 205 Series		☞ Page 379 Connecting to DirectLOGIC 205 series
PZ series		☞ Page 379 Connecting to PZ Series

Data Communications Module

Model name		Refer to
Host Link Module	U-01DM	☞ Page 380 Connecting to U-01DM
Data Communications Module	D0-DCM	☞ Page 382 Connecting to D0-DCM
	D2-DCM	☞ Page 382 Connecting to D2-DCM

Connecting to SU-5E/6B


Communication settings

Make the following settings using the programmer system parameter setting.

Item	Set value
Station No.	1 to 90
Transmission mode	HEX
Parity	NONE, ODD
Data bit	8 bit (Fixation)
Stop bit	1 bit (Fixation)

Setting DIP switches

Set the transmission speed using the CPU DIP switch.



CPU DIP switch



Item	Set value	Switch No.	
		3	4
Transmission speed*1	9600bps	ON	OFF
	19200bps	ON	ON


*1 Indicates only the transmission speeds that can be set on the GOT side.
Set the same transmission speed of the GOT.
For the transmission speed setting on the GOT side, refer to the following.
➡ Page 374 Setting communication interface (Communication settings)

Connecting to SU-5M/6M

Communication settings

Make the following settings using the programmer system parameter setting.

Item	Set value
Protocol	CCM
Response delay time	0ms
Timeout Time	800ms/960ms/1200ms/1600ms/4000ms/8000ms/16000ms/40000ms
Station No.	1 to 90
Transmission mode	HEX
Stop bit	1bit, 2bits
Data bit	8bits (Fixed)
Parity	NONE, ODD, EVEN
Transmission speed ^{*1}	9600bps, 19200bps, 38400bps


- *1 Indicates only the transmission speeds that can be set on the GOT side.
Set the same transmission speed of the GOT.
For the transmission speed setting on the GOT side, refer to the following.
 Page 374 Setting communication interface (Communication settings)

Connecting to DirectLOGIC 05 series or DirectLOGIC 06 series

Communication settings

Make the following settings using the programmer system parameter setting.

Item	Set value
Protocol	CCM NET (DirectNET)
Timeout	780ms or more
RTS On Delay Time	0ms ^{*1}
RTS Off Delay Time	0ms ^{*1}
Station No.	1 to 90
Transmission speed ^{*2}	9600bps, 19200bps, 38400bps
Stop bit	1bit, 2bits
Parity	NONE, ODD, EVEN
Communication format	HEX


- *1 To use a PLC with multidrop, set the "RTS on delay time" to 5ms or more and the "RTS off delay time" to 2ms or more.
- *2 Indicates only the transmission speeds that can be set on the GOT side.
Set the same transmission speed of the GOT.
For the transmission speed setting on the GOT side, refer to the following.
 Page 374 Setting communication interface (Communication settings)

Connecting to DirectLOGIC 205 series

Communication settings

Make the following settings using the programmer system parameter setting.

Item	Set value
Protocol	CCM NET (DirectNET)
Station No.	1 to 90
Transmission speed*1	9600bps, 19200bps, 38400bps
Data bit	8bits (fixed)
Stop bit	1bit (fixed)
Parity	NONE, ODD
Self-diagnostic mode	OFF
Response delay time	0ms
Peer to Peer	OFF
Master/Slave	Slave
Timeout	Enable
Transmission mode	HEX
MODBUS	OFF


- *1 Indicates only the transmission speeds that can be set on the GOT side.
Set the same transmission speed of the GOT.
For the transmission speed setting on the GOT side, refer to the following.
 Page 374 Setting communication interface (Communication settings)

Connecting to PZ Series

Communication settings

Make the following settings using the programmer system parameter setting.


Item	Set value
Protocol	CCM NET
Timeout	800ms/960ms/1200ms/1600ms/4000ms/8000ms/16000ms/40000ms
Response delay time	0ms
Station No.	1 to 90
Communication format	HEX
Transmission speed*1	9600bps, 19200bps, 38400bps
Stop bit	1bit
Parity	NONE, ODD

- *1 Indicates only the transmission speeds that can be set on the GOT side.
Set the same transmission speed of the GOT.
For the transmission speed setting on the GOT side, refer to the following.
 Page 374 Setting communication interface (Communication settings)


Connecting to U-01DM

Setting switches

Make the communication settings using each setting switch.




■Address selection switch(SW2, SW3)



Switch No.	Settings	Setting details
SW2	Code higher rank (10 ¹ figures)	01 to 5A
SW3	Code low rank (10 ⁰ figures)	

■Communication and the DIP switch for a setup of a protocol(SW4)



Setting item	Set value	Switch No.							
		1	2	3	4	5	6	7	8
Transmission speed*1	9600bps	OFF	ON	ON					
	19200bps	ON	ON	ON					
	38400bps	OFF	OFF	OFF					
Parity	ODD				ON				
	NONE				OFF				
Self-diagnostic	OFF					OFF			
Response delay time	0ms						OFF	OFF	OFF

*1 Indicates only the transmission speeds that can be set on the GOT side.

Set the same transmission speed of the GOT.

For the transmission speed setting on the GOT side, refer to the following.

☞ Page 374 Setting communication interface (Communication settings)

■Communication and the DIP switch for a setup of a protocol(SW5)



Item	Set value	Switch No.			
		1	2	3	4
Peer to Peer	OFF	OFF			
M/S	Slave		OFF		
TOUT existence	Enable			OFF	
ASCII/HEX	HEX				OFF

Connecting to D0-DCM

Communication settings

Write the following communication settings to the specified register using the programmer. For details of the register, refer to the following manual.

📖 KOYO EI PLC user's Manual

Item	Set value
Transmission mode	HEX
Protocol	DirectNet
Station No.	1 to 90
Transmission speed*1	9600bps, 19200bps, 38400bps, 57600bps, 115200bps
Parity	NONE, ODD, EVEN (Only communication port 2)
RTS On Delay Time (Only communication port 2)	0ms
RTS Off Delay Time (Only communication port 2)	0ms
Timeout (Only communication port 2)	800ms/960ms/1200ms/1600ms/4000ms/8000ms/16000ms/40000ms
485 mode selection (Only communication port 2)	RS232, RS422/485 4 line type
Data bit (Only communication port 2)	8bits, 7bits
Stop bit (Only communication port 2)	1bit, 2bits
The timeout between characters (Only communication port 2)	0 to 9999ms
The completion of a setting	Default use, A preset value is effective
Reset timeout	Invalid, Effective

*1 Indicates only the transmission speeds that can be set on the GOT side.
Set the same transmission speed of the GOT.
For the transmission speed setting on the GOT side, refer to the following.
📖 Page 374 Setting communication interface (Communication settings)

Connecting to D2-DCM

Communication settings

Make the following settings using the programmer.


Item	Set value
Station No.	1 to 90
Transmission speed*1	9600bps, 19200bps, 38400bps
Data bit	8bits (fixed)
Stop bit	1bit (fixed)
Parity	NONE, ODD
Self-diagnostic mode	OFF
Response delay time	0ms
Peer to Peer	OFF
Master/Slave	Slave
Timeout	Enable
Transmission mode	HEX
MODBUS	OFF

*1 Indicates only the transmission speeds that can be set on the GOT side.
Set the same transmission speed of the GOT.
For the transmission speed setting on the GOT side, refer to the following.
📖 Page 374 Setting communication interface (Communication settings)

Station No. settings

Set each station number so that no station number overlaps.

The station number can be set without regard to the cable connection order. There is no problem even if station numbers are not consecutive.



Direct specification

Specify the station No. of the PLC to be changed when setting device.

Specification range

1 to 90

7.6 Device Range that Can Be Set

The device ranges of controller that can be used for GOT are as follows.


Note that the device ranges in the following tables are the maximum values that can be set in GT Designer3.

The device specifications of controllers may differ depending on the models, even though belonging to the same series.

Please make the setting according to the specifications of the controller actually used.

When a non-existent device or a device number outside the range is set, other objects with correct device settings may not be monitored.

Setting item



Item	Description	
Device	Set the device name, device number, and bit number. The bit number can be set only when specifying the bit of word device.	
Information	Displays the device type and setting range which are selected in [Device].	
Network	Set the monitor target of the set device.	
	Station No.	Select this item when monitoring the PLC of the specified station No.

KOYO EI PLC (KOYO KOSTAC/DL)

Device name		Setting range	Device No. representation
Bit device	Input (I) ^{*5}	I0 to I1777	Octal
	Output (Q) ^{*5}	Q0 to Q1777	
	Link relay (GI)	GI0 to GI3777	
	Link output (GQ)	GQ0 to GQ3777	
	Internal relay (M)	M0 to M3777	
	Stage (S)	S0 to S1777	
	Timer (T)	T0 to T377	
	Counter (C)	C0 to C377	
	Special relay (SP) ^{*1}	SP0 to SP777	
Word device	Timer (current value) (R)	R0 to R377	
	Preparatory register (R) ^{*5}	R400 to R677	
	Special register 1 (R) ^{*1*5}	R700 to R777	
	Timer (current value) (R) ^{*3}	R1000 to R1377	
	Data register 1 (R) ^{*2*5}	R1400 to R7377	
	Special register 2 (R) ^{*1*4*5}	R7400 to R7777	
	Data register 2 (R) ^{*5}	R10000 to R36777	
	Special register 3 (R) ^{*1*5}	R37000 to R37777	
	Link relay (R)	R40000 to R40177	
	Link output (R)	R40200 to R40377	
	Input (R)	R40400 to R40477	
	Output (R)	R40500 to R40577	
	Internal relay (R)	R40600 to R40777	
	Stage (R)	R41000 to R41077	
	Timer (R)	R41100 to R41117	
	Counter (R)	R41140 to R41157	
	Special relay (R)	R41200 to R41237	

*1 Read-only device for KOSTAC SU series

*2 The GOT cannot write data to R7377 for the SU-5M and SU-6M.

*3 For Direct Logic 05 series and Direct Logic 06 series, devices from R1200 to R1377 are used as V-memory 2.

*4 The GOT cannot write data to devices from R7766 to R7774 (calendar area).

*5 The device names differ according to the series.

The following shows the device names for each series.

KOSTAC SU PZ	Direct Logic 05 Direct Logic 06	Direct Logic 205
Input	Input relay	Input
Output	Output relay	Output
Preparatory register	V-memory 1	Data register 1
Special register 1	System parameter 1	System parameter 1
Data register 1	V-memory 2	Data register 2
Special register 2	System parameter 2	System parameter 2
Data register 2	V-memory 3	Data register 3
Special register 3	System parameter 4	System parameter 4

7.7 Precautions

GOT clock control

The GOT clock function is available only for the PLC with a calendar function. Note: Although the "time adjusting" and "time broadcast" functions can be selected on the GOT, the "time broadcast" function is not available. Do not select the "time broadcast" function. If both of the functions are selected, not only the "time broadcast" function but also the "time adjusting" function will be disabled.

8 CONNECTION TO JTEKT PLC

- Page 387 Connectable Model List
- Page 388 System Configuration
- Page 396 Connection Diagram
- Page 400 GOT Side Settings
- Page 402 PLC Side Setting
- Page 408 Device Range that Can Be Set
- Page 410 Precautions

8.1 Connectable Model List

The following table shows the connectable models.


Model name	Model type	Clock	Communication Type	Connectable GOT	Refer to
PC3JG-P	TIC-6088	○	RS-232 RS-422	GT 27 GT 25 GT 23	☞ Page 388 Connecting to PC3JG, PC3JG-P, PC3JD or PC3JD-C
PC3JG	TIC-6125				
PC3JD	TIC-5642				
PC3JD-C	TIC-6029				
PC3J ^{*1}	TIC-5339	○	RS-232 RS-422	GT 27 GT 25 GT 23	☞ Page 390 Connecting to PC3J or PC3JL
PC3JL	TIC-5783				
PC2J	THC-2764	○	RS-232 RS-422	GT 27 GT 25 GT 23	☞ Page 392 Connecting to PC2J, PC2JS or PC2JR
PC2JS	THC-2994				
PC2JR	THC-5053				
PC2JC	THC-5070	○	RS-232 RS-422	GT 27 GT 25 GT 23	☞ Page 394 Connecting to PC2JC, PC2J16P or PC2J16PR
PC2J16P	THC-5169				
PC2J16PR	THC-5173				

*1 Use PC3J of the version 2.1 or later.

8.2 System Configuration

Connecting to PC3JG, PC3JG-P, PC3JD or PC3JD-C

For the RS-422 connection




PLC			Connection cable 1)	Connection cable 2)	Max. distance	GOT		Number of connectable equipment
Model name	Link unit ^{*1}	Communication Type	Cable model Connection diagram number	Cable model Connection diagram number		Option device ^{*2}	Model	
PC3JG PC3JG-P PC3JD PC3JD-C	PC/CMP2-LINK (THU-5139)	RS-422	(User preparing) Page 398 RS-422 connection diagram 4)	GT09-C30R41201-6C(3m) GT09-C100R41201-6C(10m) GT09-C200R41201-6C(20m) GT09-C300R41201-6C(30m) or (User preparing) Page 399 RS-422 connection diagram 7)	500m	- (Built into GOT)	GT 27 GT 25 GT 23	32 PLCs for 1 GOT
						GT15-RS4-9S	GT 27 GT 25	

*1 The link unit is a product manufactured by JTEKT Corporation. For details of the product, contact JTEKT Corporation.

*2 GT25-W, GT2505-V does not support the option device.

For the RS-232 connection (via an interface converter)



PLC		Connection cable 1)		RS-232/RS-422 interface converter*2		Connection cable 2)		GOT		Number of connectable equipment
Model name	Link unit*1	Cable model Connection diagram number	Max. distance	Model name	Communication Type	Cable model Connection diagram number	Max. distance	Option device*3	Model	
PC3JG PC3JG-P PC3JD PC3JD-C	-	(User preparing) Page 397 RS-422 connection diagram 1)	500m	TXU-2051	RS-232	GT09-C30R21201-25P(3m) or (User preparing) Page 396 RS-232 connection diagram 1)	15m	- (Built into GOT)	GT 27 GT 25 GT 23	32 PLCs for 1 GOT
								GT15-RS2-9P	GT 27 GT 25	
	PC/CMP-LINK (THU-2755) 2PORT-LINK (THU-2927)	(User preparing) Page 397 RS-422 connection diagram 2)	500m	TXU-2051	RS-232	GT09-C30R21201-25P(3m) or (User preparing) Page 396 RS-232 connection diagram 1)	15m	- (Built into GOT)	GT 27 GT 25 GT 23	
								GT15-RS2-9P	GT 27 GT 25	
	PC/CMP2-LINK (THU-5139)	(User preparing) Page 398 RS-422 connection diagram 3)	500m	TXU-2051	RS-232	GT09-C30R21201-25P(3m) or (User preparing) Page 396 RS-232 connection diagram 1)	15m	- (Built into GOT)	GT 27 GT 25 GT 23	
								GT15-RS2-9P	GT 27 GT 25	


*1 The link unit is a product manufactured by JTEKT Corporation. For details of the product, contact JTEKT Corporation.

*2 The interface converter is a product manufactured by JTEKT Corporation. For details of the product, contact JTEKT Corporation.

*3 GT25-W, GT2505-V does not support the option device.

Connecting to PC3J or PC3JL

For the RS-422 connection




PLC			Connection cable 1)	Connection cable 2)	Max. distance	GOT		Number of connectable equipment
Model name	Link unit ^{*1}	Communication Type	Cable model Connection diagram number	Cable model Connection diagram number		Option device ^{*2}	Model	
PC3J PC3JL	-	RS-422	(User preparing) Page 398 RS-422 connection diagram 6)	GT09-C30R41201-6C(3m) GT09-C100R41201-6C(10m) GT09-C200R41201-6C(20m) GT09-C300R41201-6C(30m) or (User preparing) Page 399 RS-422 connection diagram 7)	500m	- (Built into GOT)	GT 27 GT 25 GT 23	32 PLCs for 1 GOT
						GT15-RS4-9S	GT 27 GT 25	
	PC/CMP2-LINK (THU-5139)	RS-422	(User preparing) Page 398 RS-422 connection diagram 4)	GT09-C30R41201-6C(3m) GT09-C100R41201-6C(10m) GT09-C200R41201-6C(20m) GT09-C300R41201-6C(30m) or (User preparing) Page 399 RS-422 connection diagram 7)	500m	- (Built into GOT)	GT 27 GT 25 GT 23	
						GT15-RS4-9S	GT 27 GT 25	

*1 The link unit is a product manufactured by JTEKT Corporation. For details of the product, contact JTEKT Corporation.

*2 GT25-W, GT2505-V does not support the option device.

For the RS-232 connection (via interface converter)



PLC		Connection cable 1)		RS-232/RS-422 interface converter*2		Connection cable 2)		GOT		Number of connectable equipment
Model name	Link unit*1	Cable model Connection diagram number	Max. distance	Model name	Communication Type	Cable model Connection diagram number	Max. distance	Option device*3	Model	
PC3J PC3JL	-	(User preparing) Page 397 RS-422 connection diagram 1)	500m	TXU-2051	RS-232	GT09-C30R21201-25P(3m) or (User preparing) Page 396 RS-232 connection diagram 1)	15m	- (Built into GOT)	GT 27 GT 25 GT 23	32 PLCs for 1 GOT
		(User preparing) Page 398 RS-422 connection diagram 5)	500m					GT15-RS2-9P	GT 27 GT 25	
		(User preparing) Page 397 RS-422 connection diagram 2)	500m					- (Built into GOT)	GT 27 GT 25 GT 23	
		(User preparing) Page 398 RS-422 connection diagram 4)	500m					GT15-RS2-9P	GT 27 GT 25	
	PC/CMP2-LINK (THU-5139)	(User preparing) Page 397 RS-422 connection diagram 2)	500m	TXU-2051	RS-232	GT09-C30R21201-25P(3m) or (User preparing) Page 396 RS-232 connection diagram 1)	15m	- (Built into GOT)	GT 27 GT 25 GT 23	
								GT15-RS2-9P	GT 27 GT 25	


*1 The link unit is a product manufactured by JTEKT Corporation. For details of the product, contact JTEKT Corporation.

*2 The interface converter is a product manufactured by JTEKT Corporation. For details of the product, contact JTEKT Corporation.

*3 GT25-W, GT2505-V does not support the option device.

Connecting to PC2J, PC2JS or PC2JR

For the RS-422 connection




PLC			Connection cable 1)	Connection cable 2)	Max. distance	GOT		Number of connectable equipment
Model name	Link unit ^{*1}	Communication Type	Cable model Connection diagram number	Cable model Connection diagram number		Option device ^{*2}	Model	
PC2J PC2JS PC2JR	PC/CMP2-LINK (THU-5139)	RS-422	(User preparing) Page 398 RS-422 connection diagram 4)	GT09-C30R41201-6C(3m) GT09-C100R41201-6C(10m) GT09-C200R41201-6C(20m) GT09-C300R41201-6C(30m) or (User preparing) Page 399 RS-422 connection diagram 7)	500m	- (Built into GOT)	GT27 GT25 GT23	32 PLCs for 1 GOT
						GT15-RS4-9S	GT27 GT25	

*1 The link unit is a product manufactured by JTEKT Corporation. For details of the product, contact JTEKT Corporation.

*2 GT25-W, GT2505-V does not support the option device.

For the RS-232 connection (via interface converter)



PLC		Connection cable 1)		RS-232/RS-422 interface converter*2		Connection cable 2)		GOT		Number of connectable equipment
Model name	Link unit*1	Cable model Connection diagram number	Max. distance	Model name	Communication Type	Cable model Connection diagram number	Max. distance	Option device*3	Model	
PC2J PC2JS PC2JR	PC/CMP-LINK (THU-2755) 2PORT-LINK (THU-2927)	Page 397 RS-422 connection diagram 2)	500m	TXU-2051	RS-232	GT09-C30R21201-25P(3m) or Page 396 RS-232 connection diagram 1)	15m	- (Built into GOT)	 	32 PLCs for 1 GOT
								GT15-RS2-9P		
	PC/CMP2-LINK (THU-5139)	Page 398 RS-422 connection diagram 3)	500m	TXU-2051	RS-232	GT09-C30R21201-25P(3m) or Page 396 RS-232 connection diagram 1)	15m	- (Built into GOT)	 	
								GT15-RS2-9P		



*1 The link unit is a product manufactured by JTEKT Corporation. For details of the product, contact JTEKT Corporation.

*2 The interface converter is a product manufactured by JTEKT Corporation. For details of the product, contact JTEKT Corporation.

*3 GT25-W, GT2505-V does not support the option device.

Connecting to PC2JC, PC2J16P or PC2J16PR

For the RS-422 connection




PLC			Connection cable 1)	Connection cable 2)	Max. distance	GOT		Number of connectable equipment
Model name	Link unit ^{*1}	Communication Type	Cable model Connection diagram number	Cable model Connection diagram number		Option device ^{*2}	Model	
PC2JC PC2J16P PC2J16PR	PC/CMP2-LINK (THU-5139)	RS-422	(User preparing) Page 398 RS-422 connection diagram 4)	(User preparing) Page 399 RS-422 connection diagram 7)	500m	- (Built into GOT)	GT 27 GT 25 GT 23	32 PLCs for 1 GOT
						GT15-RS4-9S	GT 27 GT 25	

^{*1} The link unit is a product manufactured by JTEKT Corporation. For details of the product, contact JTEKT Corporation.

^{*2} GT25-W, GT2505-V does not support the option device.

For the RS-232 connection (via interface converter)



PLC		Connection cable 1)		RS-232/RS-422 interface converter*2		Connection cable 2)		GOT		Number of connectable equipment
Model name	Link unit*1	Cable model Connection diagram number	Max. distance	Model name	Communication Type	Cable model Connection diagram number	Max. distance	Option device*3	Model	
PC2JC PC2J16P PC2J16PR	-	(User preparing) Page 397 RS-422 connection diagram 1)	500m	TXU-2051	RS-232	GT09-C30R21201-25P(3m) or (User preparing) Page 396 RS-232 connection diagram 1)	15m	- (Built into GOT)	GT 27 GT 25 GT 23	32 PLCs for 1 GOT
								GT15-RS2-9P	GT 27 GT 25	
	PC/CMP-LINK (THU-2755) 2PORT-LINK (THU-2927)	(User preparing) Page 397 RS-422 connection diagram 2)	500m	TXU-2051	RS-232	GT09-C30R21201-25P(3m) or (User preparing) Page 396 RS-232 connection diagram 1)	15m	- (Built into GOT)	GT 27 GT 25 GT 23	
								GT15-RS2-9P	GT 27 GT 25	
	PC/CMP2-LINK (THU-5139)	(User preparing) Page 398 RS-422 connection diagram 3)	500m	TXU-2051	RS-232	GT09-C30R21201-25P(3m) or (User preparing) Page 396 RS-232 connection diagram 1)	15m	- (Built into GOT)	GT 27 GT 25 GT 23	
								GT15-RS2-9P	GT 27 GT 25	

*1 The link unit is a product manufactured by JTEKT Corporation. For details of the product, contact JTEKT Corporation.

*2 The interface converter is a product manufactured by JTEKT Corporation. For details of the product, contact JTEKT Corporation.

*3 GT25-W, GT2505-V does not support the option device.


8.3 Connection Diagram

The following diagram shows the connection between the GOT and the PLC.

RS-232 cable

Connection diagram

■RS-232 connection diagram 1)



Precautions when preparing a cable

■Cable length

The length of the RS-232 cable must be 15m or less.

■GOT side connector

For the GOT side connector, refer to the following.

☞ Page 58 GOT connector specifications

■JTEKT PLC side connector

Use the connector compatible with the JTEKT PLC side module.


For details, refer to the JTEKT PLC user's manual.

RS-422 cable

Connection diagram

■RS-422 connection diagram 1)


(For PC3JG-P/PC3JG/PC3JD/PC3JD-C)



*1 Terminating resistors should not be provided for a PLC and an RS-232/RS-422 interface converter which will be terminals.

*2 Connect FG grounding to the appropriate part of a cable shield line.


(For PC3J/PC3JL)



*3 Terminating resistors should not be provided for a PLC and an RS-232/RS-422 interface converter which will be terminals.

*4 Connect FG grounding to the appropriate part of a cable shield line.


(For PC2JC/PC2J16P, PC2J16PR)



*5 Terminating resistors should not be provided for a PLC and an RS-232/RS-422 interface converter which will be terminals.

*6 Connect FG grounding to the appropriate part of a cable shield line.


■RS-422 connection diagram 2)



*1 Terminating resistors should not be provided for a PLC and an RS-232/RS-422 interface converter which will be terminals.

*2 Connect FG grounding to the appropriate part of a cable shield line.


■RS-422 connection diagram 3)



*1 Terminating resistors should not be provided for a PLC and an RS-232/RS-422 interface converter which will be terminals.

*2 Connect FG grounding to the appropriate part of a cable shield line.


■RS-422 connection diagram 4)



*1 Terminating resistors should not be provided for a PLC and an RS-232/RS-422 interface converter which will be terminals.

*2 Connect FG grounding to the appropriate part of a cable shield line.


■RS-422 connection diagram 5)



*1 Terminating resistors should not be provided for a PLC and an RS-232/RS-422 interface converter which will be terminals.

*2 Connect FG grounding to the appropriate part of a cable shield line.


■RS-422 connection diagram 6)



*1 Terminating resistors should not be provided for a PLC and an RS-232/RS-422 interface converter which will be terminals.

*2 Connect FG grounding to the appropriate part of a cable shield line.

■RS-422 connection diagram 7)



- *1 Terminating resistors should not be provided for a PLC and an RS-232/RS-422 interface converter which will be terminals.
- *2 Set the terminating resistor of GOT side which will be a terminal.
- ☞ Page 399 Connecting terminating resistors
- *3 Connect FG grounding to the appropriate part of a cable shield line.

Precautions when preparing a cable

■Cable length

The maximum length of the RS-422 cable must be 500m or less.

■GOT side connector

For the GOT side connector, refer to the following.

☞ Page 58 GOT connector specifications

■JTEKT PLC side connector

Use the connector compatible with the JTEKT PLC side module.

For details, refer to the JTEKT PLC user's manual.

Connecting terminating resistors

■GOT side

- For GT27, GT25(Except GT2505-V), GT23

Set the terminating resistor setting switch of the GOT main unit to "Disable".

- For GT2505-V

Set the terminating resistor selector to "330Ω".


For the procedure to set the terminating resistor, refer to the following.

☞ Page 62 Terminating resistors of GOT

8.4 GOT Side Settings

Setting communication interface (Communication settings)

Set the channel of the equipment to be connected to the GOT.



1. Select [Common] → [Controller Setting] from the menu.
2. In the [Controller Setting] window, select the channel No. to be used from the list menu.
3. Set the following items.
 - [Manufacturer]: [JTEKT]
 - [Controller Type]: [JTEKT TOYOPUC-PC]
 - [I/F]: Interface to be used
 - [Detail Setting]: Configure the settings according to the usage environment.

☞ Page 401 Communication detail settings
4. When you have completed the settings, click the [OK] button.

Point

The settings of connecting equipment can be confirmed in [I/F Communication Setting].
For details, refer to the following.

☞ Page 47 I/F communication setting

Communication detail settings

Make the settings according to the usage environment.

Property	Value
Transmission Speed(BPS)	19200
Data Bit	8 bit
Stop Bit	1 bit
Parity	Even
Retry(Times)	0
Timeout Time(Sec)	3
Host Address	00
Delay Time(ms)	1
Format	1

Item	Description	Range
Transmission Speed	Set this item when change the transmission speed used for communication with the connected equipment. (Default: 19200bps)	9600bps, 19200bps, 38400bps, 57600bps, 115200bps
Data Bit	Set this item when change the data length used for communication with the connected equipment. (Default: 8bits)	7bits/8bits
Stop Bit	Specify the stop bit length for communications. (Default: 1bit)	1bit/2bits
Parity	Specify whether or not to perform a parity check, and how it is performed during communication. (Default: Even)	None Even Odd
Retry	Set the number of retries to be performed when a communication error occurs. (Default: 0time)	0 to 5times
Timeout Time	Set the time period for a communication to time out. (Default: 3sec)	3 to 30sec
Host Address	Specify the host address (station No. of the GOT to which the PLC is connected) in the connected network. (Default: 00)	00 to 37 (Octal)
Delay Time	Set this item to adjust the transmission timing of the communication request from the GOT. (Default: 0)	0 to 300ms
Format	Select the communication format. (Default: 1) format 1: PC3J extended function in compliant format 2: PC3J extended function compliant	1/2

Point

• Format setting

The compatible format of PLC differs depending on model.

Model name	Compatible format
PC2J, PC2JS, PC2JR, PC2JC, PC2J16P, PC2J16PR	Format 1 only
PC3JG, PC3JG-P, PC3JD, PC3JD-C, PC3J, PC3JL	Format 1 or Format 2

For details of PC3J extended function, refer to the following manual.

☞ JTEKT PLC user's manual

• Communication interface setting by the Utility

The communication interface setting can be changed on the Utility's [Communication Settings] after writing [Communication Settings] of project data.

For details on the Utility, refer to the following manual.

☞ GOT2000 Series User's Manual (Utility)

• Precedence in communication settings

When settings are made by GT Designer3 or the Utility, the latest setting is effective.

8.5 PLC Side Setting



JTEKT PLC

For details of JTEKT PLCs, refer to the following manuals.

JTEKT PLC user's manual

Model name		Refer to
PLC CPU	PC3JG, PC3JG-P, PC3JD, PC3JD-C, PC3J, PC3JL, PC2J, PC2JS, PC2JR	Page 402 Connecting to PC3JG, PC3JD, PC3JD-C, PC3JG-P, PC3J, PC3JL, PC2J, PC2JS or PC2JR
	PC2JC	Page 403 Connecting to PC2JC
	PC2J16P, PC2J16RR	Page 404 Connecting to PC2J16P or PC2J16PR
RS-232/RS-422 interface converter	RS-232/RS-422 interface converter	Page 405 RS-232/RS-422 interface converter setting
Link unit	PC/CMP-LINK	Page 406 Link unit setting
	2PORT-LINK	
	PC/CMP2-LINK	

Connecting to PC3JG, PC3JD, PC3JD-C, PC3JG-P, PC3J, PC3JL, PC2J, PC2JS or PC2JR

Communication settings

Make the communication settings using the PLC peripheral device (PCwin).

Item	Set value
Transmission speed* ¹	9600bps, 19200bps, 38400bps
Data bit* ¹	8bits, 7bits
Parity bit	Even (fixed)
Stop bit* ¹	1bit, 2bits
Station No.* ²	0 to 37 (Octal)
2-wire/4-wire type* ³	2-wire type or 4-wire type

*¹ Adjust the settings with GOT settings.

*² Avoid duplication of the station No. with any of the other units.

*³ Make the settings referring to the following connection diagram.

Page 397 RS-422 cable

Connecting to PC2JC

Communication settings

Make the communication settings using each setting switch.

For the detail settings, refer to the following manual.


 JTEKT PLC user's manual

Item	Set value
Transmission speed*1	9600bps, 19200bps
Data bit*1	8bits, 7bits
Stop bit*1	1bit, 2bits
Station No.*1	0 to 37 (Octal)

*1 Adjust the settings with GOT settings.

Settings by switch

Make the communication settings using each setting switch.



Setting of the station No.

Set the station No. between 00 and 37 (Octal).

Switch name	Station number setting
SW3	Upper digit
SW4	Lower digit

Transmission speed settings

Switch name	Switch position	Transmission speed (bps)
SW2	1	19200
	2	9600

Settings of data length and stop bit length

Switch name	Setting item	Set value	Switch No.	
			2	1
SW5	Data bit	8bits	OFF	
		7bits	ON	
	Stop bit length	2bits		OFF
		1bit		ON

Connecting to PC2J16P or PC2J16PR

Communication settings

Make the communication settings using each setting switch.

For the detail settings, refer to the following manual.


☞ JTEKT PLC user's manual

Item	Set value
Transmission speed*1	9600bps, 19200bps
Data bit*1	8bits, 7bits
Stop bit*1	1bit, 2bits
Station No.*1	0 to 37 (Octal)
Selection of module type	Computer link

*1 Adjust the settings with GOT settings.

Settings by switch

Make the communication settings using each setting switch.



■Setting of the station No.

Set the station No. between 00 and 37 (Octal).

Switch name	Station number setting
SW2	Upper digit
SW3	Lower digit

■Transmission speed settings

Switch name	Switch position	Transmission speed (bps)
SW4	1	19200
	2	9600

■Settings of data length, stop bit length and module type


Switch name	Setting item	Set value	Switch No.			
			4	3	2	
SW5	Data bit	8bits	OFF			
		7bits	ON			
	Stop bit length	2bits		OFF		
		1bit		ON		
	Module type	Computer link				OFF

RS-232C/RS-422 interface converter setting

Communication settings


Make the communication settings by the setting switch of the RS-232C/RS-422 interface converter.

Item	Set value
Transmission speed*1	9600bps, 19200bps
2-wire/4-wire type*2	2-wire type or 4-wire type
Echo back	OFF

- *1 Adjust the settings with GOT settings.
*2 Set referring to the RS-422 connection diagram. For details, refer to the following.
 Page 397 RS-422 cable

Settings by switch

Make the communication settings by each setting switch of the RS-232C/RS-422 interface converter.




■Transmission speed settings



BAUD
RATE


Transmission speed (bps)	Switch position
9600	2
19200	1

■Mode setting switch



Mode	Switch position
2-wire type	2W-AUTO
4-wire type	4 WIRES

■Echoback setting switch



ECHO
BACK

Setting	Switch position
OFF	OFF

Link unit setting

Communication settings

Make the communication settings using each setting switch of the link unit.

For the detail settings, refer to the following manual.

☞ User's Manual of the JTEKT link unit


Item	Set value
Transmission speed* ¹	9600bps, 19200bps
Data bit* ¹	8bits, 7bits
Stop bit* ¹	1bit, 2bits
Station No.* ¹	0 to 37 (Octal)
Selection of module type	Computer link
Selection of 2-wire type or 4- wire type* ²	2-wire type or 4-wire type

*¹ Adjust the settings with GOT settings.

*² Set referring to the RS-422 connection diagram.For details, refer to the following.

☞ Page 397 RS-422 cable

Settings by switch



■Setting of the station No.

Set the station No. between 00 and 37 (Octal).

Switch name	Station number setting
SW1	Upper digit
SW2	Lower digit

■Transmission speed settings

Switch name	Switch position	Transmission speed (bps)
SW3	2	9600
	1	19200


■Data length, stop bit length, module type and 2-wire/4-wire type communication selection setting

Switch name	Setting item	Set value	Switch No.			
			4	3	2	1
SW4	Data bit	8bits	OFF			
		7bits	ON			
	Stop bit length	2bits		OFF		
		1bit		ON		
	Module type	PLC link unit			OFF	
		Computer link			ON	
	2-wire type/4- wire type communication selection ^{*1}	2-wire type communication				OFF
		4-wire type communication				ON

^{*1} The setting is available only for the link unit (Model: PC/CMP2-LINK).

Station number setting

Set each station number so that no station number overlaps.
The station number can be set without regard to the cable connection order. There is no problem even if station numbers are not consecutive.



Direct specification

Specify the station No. of the PLC to be changed when setting device.

Specification range
00 to 37 (Octal)

8.6 Device Range that Can Be Set

The device ranges of controller that can be used for GOT are as follows.


Note that the device ranges in the following tables are the maximum values that can be set in GT Designer3.

The device specifications of controllers may differ depending on the models, even though belonging to the same series.

Please make the setting according to the specifications of the controller actually used.

When a non-existent device or a device number outside the range is set, other objects with correct device settings may not be monitored.

Setting item



Item	Description	
Device	Set the device name, device number, and bit number. The bit number can be set only when specifying the bit of word device.	
	Program No.	Sets the number of the program for which the device is set.
Information	Displays the device type and setting range which are selected in [Device].	
Network	Set the monitor target of the set device.	
	Station No.	Set this item when monitoring the PLC of the specified station No. (octal)

Point

Program number setting (when PC3JG, PC3J or PC3JD is used)

Setting of a program number is allowed for the devices indicated below.

Internal relay (M), keep relay (K), link relay (L), special relay (V), edge detection (P), timer (T), counter (C), data register (D), link register (R), special register (S), current value register (N)

JTEKT PLC (JTEKT TOYOPUC-PLC)

Device name		Setting range	Device No. representation
Bit device	Input (X) ^{*1}	X000 to X7FF	Hexadecimal
	Output (Y) ^{*1}	Y000 to Y7FF	
	Link relay (L)	L000 to L7FF	
	Internal relay (M)	M000 to M7FF	
	Keep relay (K)	K000 to K2FF	
	Edge detection (P)	P000 to P1FF	
	Timer (T) ^{*1}	T000 to T1FF	
	Counter (C) ^{*1}	C000 to C1FF	
	Special relay (V)	V000 to V0FF	
	Extended input (EX) ^{*1}	EX000 to EX7FF	
	Extended output (EY) ^{*1}	EY000 to EY7FF	
	Extended internal relay (EM)	EM0000 to EM1FFF	
	Extended keep-relay (EK)	EK000 to EKFFF	
	Extended special relay (EV)	EV000 to EVFFF	
	Extended timer (ET) ^{*1}	ET000 to ET7FF	
	Extended counter (EC) ^{*1}	EC000 to EC7FF	
	Extended link relay (EL)	EL0000 to EL1FFF	
	Extended edge detection (EP)	EP000 to EPFFF	
	Extended input 2 (GX) ^{*1*3}	GX0000 to GXFFFF	
	Extended output 2 (GY) ^{*1*3}	GY0000 to GYFFFF	
Word device	Extended internal relay (GM) ^{*3}	GM0000 to GMFFFF	Hexadecimal
	The bit specification of the word device (except extended buffer register, setup value register)	Setting range of each word device	
	Data register (D)	D0000 to D2FFF	
	Link register (R)	R0000 to R07FF	
	Current value register (N)	N0000 to N01FF	
	Special register (S)	S0000 to S03FF	
	File register (B)	B0000 to B1FFF	
	Extended present value register (EN)	EN0000 to EN07FF	
	Extended setup value register (H)	H0000 to H07FF	
	Extended special register (ES)	ES0000 to ES07FF	
	Extended data register (U)	U0000 to U7FFF	
	Extended buffer register (EB) ^{*3}	EB00000 to EB07FFF EB08000 to EB0FFFF EB10000 to EB17FFF EB18000 to EB1FFFF	
	Setup value register (TCS) ^{*2}	TCS0000 to TCS01FF	
	The word specification of the bit device	Setting range of each bit device	

*1 Overlapped device designation of an input (X, EX, GX) and an output (Y, EY, GY), or a timer (T, ET) and a counter (C, EC) is not allowed.(Example: X0000 and Y0000, EX0000 and EY0000)

*2 To store a setting value of T (timer) or C (counter), use TCS.

Setting value of a timer and a counter is stored in TCS.

(TCS cannot be used if a timer or a counter is not in a program.)


*3 GX, GY, GM and EB can be used only in the PC3JG separate mode.

Access to GX, GY, GM and EB through a link module is not possible.

8.7 Precautions

Station No. settings of the PLC side


In the system configuration, the PLC with the station number set with the host address must be included. For details of host address setting, refer to the following.

 Page 400 Setting communication interface (Communication settings)

GOT clock control

The GOT clock function is available only for the PLC with the station number set with the host address.

For details of host address setting, refer to the following.

 Page 400 Setting communication interface (Communication settings)

System configuration

If the system is configured by mixing the PC3J extended function compliant PLC with the PC3J extended function noncompliant PLC, normal communication may not be performed. Unify the PLCs into PC3J extended function compliant or PC3J extended function noncompliant to configure the system.

System alarm

The system alarm can be displayed only for the PLC set with a host address. When connected to the PC3J extended function compliant PLC, only the system alarm of program No. 1 can be displayed.

9 CONNECTION TO SHARP PLC

- Page 411 Connectable Model List
- Page 412 System Configuration
- Page 416 Connection Diagram
- Page 419 GOT Side Settings
- Page 421 PLC Side Setting
- Page 428 Device Range that Can Be Set

9.1 Connectable Model List



The following table shows the connectable models.



















Model name	Clock	Communication Type	Connectable GOT	Refer to
JW-21CU	×	RS-422	GT 27 GT 25 GT 23	Page 412 Connecting to JW-21CU or JW-22CU
JW-22CU	○	RS-232 RS-422		
JW-31CUH	×	RS-422	GT 27 GT 25 GT 23	Page 413 Connecting to JW-31CUH, JW-32CUH or JW-33CUH
JW-32CUH	○	RS-232		
JW-33CUH	○	RS-422		
JW-50CUH	×	RS-422	GT 27 GT 25 GT 23	Page 414 Connecting to JW-50CUH, JW-70CUH, JW-100CUH or JW-100CU
JW-70CUH	○*1	RS-232		
JW-100CUH	○*1	RS-422		
JW-100CU	○			
Z-512J	○	RS-232 RS-422	GT 27 GT 25 GT 23	Page 415 Connecting to Z-512J

*1 When the link unit (ZW-10CM) is used in JW-70CUH/100CUH, the clock function is not available.

9.2 System Configuration

Connecting to JW-21CU or JW-22CU























PLC			Connection cable	Max. distance	GOT		Number of connectable equipment
Model name	Link unit ^{*1}	Communication Type	Cable model Connection diagram number		Option device ^{*2}	Model	
JW-22CU	-	RS-232	GT09-C30R20601-15P(3m) or  Page 416 RS-232 connection diagram 1)	Differs according to PLC side specifications.	- (Built into GOT)	  	1 GOT for 1 PLC
					GT15-RS2-9P	 	
			GT09-C30R40601-15P(3m) GT09-C100R40601-15P(10m) GT09-C200R40601-15P(20m) GT09-C300R40601-15P(30m) or  Page 417 RS-422 connection diagram 1)	Differs according to PLC side specifications.	- (Built into GOT)	  	
					GT15-RS4-9S	 	
JW-21CU JW-22CU	JW-21CM	RS-422	GT09-C30R40603-6T(3m) GT09-C100R40603-6T(10m) GT09-C200R40603-6T(20m) GT09-C300R40603-6T(30m) or  Page 417 RS-422 connection diagram 3)	Differs according to PLC side specifications.	- (Built into GOT)	  	
					GT15-RS4-9S	 	

^{*1} The link unit is a product manufactured by SHARP Corporation.
For details of this product, contact SHARP Corporation.

^{*2} GT25-W, GT2505-V does not support the option device.

Connecting to JW-31CUH, JW-32CUH or JW-33CUH



PLC			Connection cable	Max. distance	GOT		Number of connectable equipment
Model name	Link unit ^{*1}	Communication Type	Cable model Connection diagram number		Option device ^{*2}	Model	
JW-32CUH JW-33CUH	-	RS-232	GT09-C30R20602-15P(3m) or  Page 416 RS-232 connection diagram 2)	Differs according to PLC side specifications.	- (Built into GOT)	  	1 GOT for 1 PLC
					GT15-RS2-9P	 	
		RS-422	GT09-C30R40602-15P(3m) GT09-C100R40602-15P(10m) GT09-C200R40602-15P(20m) GT09-C300R40602-15P(30m) or  Page 417 RS-422 connection diagram 2)	Differs according to PLC side specifications.	- (Built into GOT)	  	
					GT15-RS4-9S	 	
JW-31CUH JW-32CUH JW-33CUH	JW-21CM	RS-422	GT09-C30R40603-6T(3m) GT09-C100R40603-6T(10m) GT09-C200R40603-6T(20m) GT09-C300R40603-6T(30m) or  Page 417 RS-422 connection diagram 3)	Differs according to PLC side specifications.	- (Built into GOT)	  	
					GT15-RS4-9S	 	



*1 Use the link unit supporting JW-31CUH, JW-32CUH or JW-33CUH.



















The link unit is a product manufactured by SHARP Corporation.

For details of this product, contact SHARP Corporation.

*2 GT25-W, GT2505-V does not support the option device.

Connecting to JW-50CUH, JW-70CUH, JW-100CUH or JW-100CU
















PLC			Connection cable	Max. distance	GOT		Number of connectable equipment
Model name	Link unit ^{*1}	Communication Type	Cable model Connection diagram number		Option device ^{*2}	Model	
JW-70CUH JW-100CUH JW-100CU	-	RS-232	GT09-C30R20601-15P(3m) or  Page 416 RS-232 connection diagram 1)	Differs according to PLC side specifications.	- (Built into GOT)	  	1 GOT for 1 PLC
					GT15-RS2-9P	 	
		RS-422	GT09-C30R40601-15P(3m) GT09-C100R40601-15P(10m) GT09-C200R40601-15P(20m) GT09-C300R40601-15P(30m) or  Page 417 RS-422 connection diagram 1)	Differs according to PLC side specifications.	- (Built into GOT)	  	
					GT15-RS4-9S	 	
JW-50CUH JW-70CUH JW-100CUH JW-100CU	JW-10CM ZW-10CM	RS-422	GT09-C30R40603-6T(3m) GT09-C100R40603-6T(10m) GT09-C200R40603-6T(20m) GT09-C300R40603-6T(30m) or  Page 417 RS-422 connection diagram 3)	Differs according to PLC side specifications.	- (Built into GOT)	  	
					GT15-RS4-9S	 	

*1 The link unit is a product manufactured by SHARP Corporation.
For details of this product, contact SHARP Corporation.

*2 GT25-W, GT2505-V does not support the option device.

Connecting to Z-512J



PLC		Connection cable	Max. distance	GOT		Number of connectable equipment
Model name	Communication Type	Cable model Connection diagram number		Option device ^{*1}	Model	
Z-512J	RS-232	GT09-C30R20602-15P(3m) or  Page 416 RS-232 connection diagram 2)	Differs according to PLC side specifications.	- (Built into GOT)	  	1 GOT for 1 PLC
				GT15-RS2-9P	 	
	RS-422	GT09-C30R40602-15P(3m) GT09-C100R40602-15P(10m) GT09-C200R40602-15P(20m) GT09-C300R40602-15P(30m) or  Page 417 RS-422 connection diagram 2)	Differs according to PLC side specifications.	- (Built into GOT)	  	
				GT15-RS4-9S	 	

*1 GT25-W, GT2505-V does not support the option device.


9.3 Connection Diagram

The following diagram shows the connection between the GOT and the PLC.

RS-232 cable


Connection diagram

■RS-232 connection diagram 1)



*1 GT27: CD, GT23: NC

■RS-232 connection diagram 2)



*1 GT27: CD, GT23: NC

Precautions when preparing a cable

■Cable length

The maximum length of the RS-232 cable differs according to the specifications of the SHARP PLC.

For details, refer to the following manual.

📖 SHARP PLC user's Manual

■GOT side connector

For the GOT side connector, refer to the following.

📖 Page 58 GOT connector specifications


■SHARP PLC side connector

Use the connector compatible with the SHARP PLC side module.

For details, refer to the SHARP PLC user's manual.


Connection diagram

■RS-422 connection diagram 1)




*1 Connect the terminating resistor at pin 6 with pin 13 (RXD) only at the terminal station.
(Valid for JW-70CUH and JW-100CUH. The terminating resistor does not exist in JW-22CU and JW-100CU.)

■RS-422 connection diagram 2)



■RS-422 connection diagram 3)



*1 Two SHIELD terminals are provided for JW-10CM and ZW-10CM. Connect to either SHIELD terminal.

Precautions when preparing a cable

■Cable length

The maximum length of the RS-422 cable differs according to the specifications of the SHARP PLC.

For details, refer to the following manual.

📖 SHARP PLC user's Manual

■GOT side connector

For the GOT side connector, refer to the following.

📖 Page 58 GOT connector specifications

■SHARP PLC side connector

Use the connector compatible with the SHARP PLC side module.

For details, refer to the SHARP PLC user's manual.

Connecting terminating resistors

■GOT side

- For GT27, GT25(Except GT2505-V), GT23

Set the terminating resistor setting switch of the GOT main unit to "Disable".

- For GT2505-V

Set the terminating resistor selector to "330Ω".

For the procedure to set the terminating resistor, refer to the following.

📖 Page 62 Terminating resistors of GOT

■SHARP PLC side

Connect the terminating resistor on the SHARP PLC side when connecting a GOT to a SHARP PLC.

The PLC CPUs and the modules on the PLC CPU side requiring a terminating resistor are shown below.

- JW-22CU

Turn "ON" the terminating resistor setting switch (SW1) on the back of JW-22CU to validate the terminating resistor.

- JW-70CUH and JW-100CUH

Connect the pin 6 (terminating resistor) of the communication port connection connector with the pin 13 (RXD) only at the terminal station to validate the terminating resistor.


- JW-21CM, JW-10CM and ZW-10CM

Turn "ON" the terminator switch (SW7) on the front panel only at the terminal station to validate the terminating resistor.

9.4 GOT Side Settings

Setting communication interface (Communication settings)

Set the channel of the equipment to be connected to the GOT.



1. Select [Common] → [Controller Setting] from the menu.
2. In the [Controller Setting] window, select the channel No. to be used from the list menu.
3. Set the following items.
 - [Manufacturer]: [SHARP]
 - [Controller Type]: [SHARP JW]
 - [I/F]: Interface to be used
 - [Detail Setting]: Configure the settings according to the usage environment.

☞ Page 420 Communication detail settings
4. When you have completed the settings, click the [OK] button.

Point

The settings of connecting equipment can be confirmed in [I/F Communication Setting].
For details, refer to the following.

☞ Page 47 I/F communication setting

Communication detail settings

Make the settings according to the usage environment.

Property	Value
Transmission Speed(BPS)	19200
Data Bit	7 bit
Stop Bit	2 bit
Parity	Even
Retry(Times)	0
Startup Time(Sec)	3
Timeout Time(Sec)	3
Delay Time(ms)	0

Item	Description	Range
Transmission Speed	Set this item when change the transmission speed used for communication with the connected equipment. (Default: 19200bps)	4800bps, 9600bps, 19200bps
Data Bit	Set this item when change the data length used for communication with the connected equipment. (Default: 7bits)	7bit (fixed)
Stop Bit	Specify the stop bit length for communications. (Default: 2bit)	2bit (fixed)
Parity	Specify whether or not to perform a parity check, and how it is performed during communication. (Default: Even)	Even (fixed)
Retry	Set the number of retries to be performed when a communication error occurs. (Default: 0time)	0 to 5times
Startup Time	Specify the time period from the GOT startup until GOT starts the communication with the PLC CPU. (Default: 3sec)	3 to 30sec
Timeout Time ^{*1}	Set the time period for a communication to time out. (Default: 3sec)	3 to 30sec
Delay Time	Set this item to adjust the transmission timing of the communication request from the GOT. (Default: 0ms)	0 to 300ms

^{*1} When connecting to the communication port or link module, set [Delay Time] of the GOT side to 30 ms or more.

Point

- Communication interface setting by the Utility

The communication interface setting can be changed on the Utility's [Communication Settings] after writing [Communication Settings] of project data.

For details on the Utility, refer to the following manual.

📖 GOT2000 Series User's Manual (Utility)

- Precedence in communication settings

When settings are made by GT Designer3 or the Utility, the latest setting is effective.

9.5 PLC Side Setting



SHARP PLC

For details of the SHARP PLC, refer to the following manual.

SHARP PLC user's Manual

Model name		Refer to
PLC CPU	JW-22CU	Page 422 Connecting to JW-22CU, JW-70CUH, JW-100CUH or JW-100CU
	JW-32CUH, JW-33CUH	Page 423 Connecting to JW-32CUH, JW-33CUH or Z-512J
	JW-70CUH, JW-100CUH, JW-100CU	Page 422 Connecting to JW-22CU, JW-70CUH, JW-100CUH or JW-100CU
	Z-512J	Page 423 Connecting to JW-32CUH, JW-33CUH or Z-512J
Link unit	JW-21CM	Page 424 Connecting to the link unit (JW-21CM)
	JW-10CM, ZW-10CM	Page 426 Connecting to the link unit (JW-10CM or ZW-10CM)

Connecting to JW-22CU, JW-70CUH, JW-100CUH or JW-100CU

System memory setting

Set the system memory.


System memory No.	Item	Set value					
#236	Transmission speed, parity and stop bit	<div>D7 D6 D5 D4 D3 D2 to D0</div> <table><tr><td>0</td><td>0</td><td>(3)</td><td>(2)</td><td>(1)</td></tr></table> <div>(1) Transmission speed ^{*1} ^{*2} 000: 19200bps 001: 9600bps 010: 4800bps (2) Parity 10 (fixed): Even (3) Stop bit 1 (fixed): 2 bits</div>	0	0	(3)	(2)	(1)
0	0	(3)	(2)	(1)			
#237	Station No.	1: Station No. 1 (fixed)					

- *1 Indicates only the transmission speeds that can be set on the GOT side.
*2 Set the same transmission speed of the GOT.
For the transmission speed setting on the GOT side, refer to the following.
📖 Page 419 Setting communication interface (Communication settings)

Terminating resistor setting switch (For JW-22CU only)

Set the terminating resistor setting switch.

■When using KV-L20R or KV-L20



Settings	
For RS-232 communication	RS-422 communication
OFF (no terminating resistor)	ON (terminating resistor attached)

Connecting to JW-32CUH, JW-33CUH or Z-512J

Settings for connecting to communication port 1 (PG/COMM1 port)

Set the system memory.

System memory No.	Item	Set value
#234	Transmission speed, parity and stop bit	<div> D7 D6 D5 D4 D3 D2 to D0 <div> 0 0 (3) (2) (1) </div> </div> <p>(1) Transmission speed *1 *2 000: 19200bps 001: 9600bps 010: 4800bps</p> <p>(2) Parity 10 (fixed): Even</p> <p>(3) Stop bit 1 (fixed): 2 bits</p>
#235	Station No.	1: Station No. 1 (fixed)

*1 Indicates only the transmission speeds that can be set on the GOT side.

*2 Set the same transmission speed of the GOT.

For the transmission speed setting on the GOT side, refer to the following.

 Page 419 Setting communication interface (Communication settings)

Settings for connecting to communication port 2 (PG/COMM2 port)


Set the system memory.

System memory No.	Item	Set value
#236	Transmission speed, parity and stop bit	<div> D7 D6 D5 D4 D3 D2 to D0 <div> 0 0 (3) (2) (1) </div> </div> <p>(1) Transmission speed *1 *2 000: 19200bps 001: 9600bps 010: 4800bps</p> <p>(2) Parity 10 (fixed): Even</p> <p>(3) Stop bit 1 (fixed): 2 bits</p>
#237	Station No.	1: Station No. 1 (fixed)

*1 Indicates only the transmission speeds that can be set on the GOT side.

*2 Set the same transmission speed of the GOT.


For the transmission speed setting on the GOT side, refer to the following.

 Page 419 Setting communication interface (Communication settings)

Connecting to the link unit (JW-21CM)

Switch setting of the link unit (JW-21CM)

Make setting for each switch.



Module No. switch (SW8)

The module No. switch is not used for communication with the GOT.

Terminator switch(SW7)


LT



Settings	Setting details
ON*1	Terminating resistor validated


*1 Turn on only for the terminal station.

Station number setting switch(SW1,SW2)



Switch No.	Settings	Setting details
SW1	Station No. lower digit (10 ⁰ digit)	1 (fixed)
SW2	Station No. upper digit (10 ¹ digit)	0 (fixed)

■Operation mode setting switch(SW3)




Switch No.	Settings	Setting details
SW3-1	OFF (fixed)	Invalid
SW3-2	ON (fixed)	4-wire type
SW3-3	OFF (fixed)	Invalid
SW3-4	ON (fixed)	Even

■Transmission speed setting switch (SW4)

Set the same transmission speed of the GOT.

For the transmission speed setting on the GOT side, refer to the following.


☞ Page 419 Setting communication interface (Communication settings)



Setting ^{*1}	Setting details
0	19200bps
1	9600bps
2	4800bps

*1 Indicates only the transmission speeds that can be set on the GOT side.


■Function setting switch(SW0)



Settings	Setting details
4 (fixed)	Computer link

Connecting to the link unit (JW-10CM or ZW-10CM)

Switch setting of link unit (JW-10CM and ZW-10CM)




Function setting switch(SW0)



Settings	Setting details
4 (fixed)	Computer link (command mode)

Station number switch(SW1,SW2)



Switch No.	Settings	Setting details
SW1	Station No. lower digit (10 ⁰ digit)	1 (fixed)
SW2	Station No. upper digit (10 ¹ digit)	0 (fixed)

Operation mode setting switch(SW3)



Switch No.	Settings	Setting details
SW3-1	OFF (fixed)	Invalid
SW3-2	ON (fixed)	4-wire type
SW3-3	OFF (fixed)	Invalid
SW3-4	ON (fixed)	Even

■Transmission speed setting switch (SW4)

Set the same transmission speed of the GOT.

For the transmission speed setting on the GOT side, refer to the following.

☞ Page 419 Setting communication interface (Communication settings)

SW4



Setting ^{*1}	Setting details
0	19200bps
1	9600bps
2	4800bps

^{*1} Indicates only the transmission speeds that can be set on the GOT side.

■Terminator switch(SW7)

SW7



Settings	Setting details
ON ^{*2}	Terminating resistor validated

^{*1} Set to ON only for the terminal station.

9.6 Device Range that Can Be Set

The device ranges of controller that can be used for GOT are as follows.


Note that the device ranges in the following tables are the maximum values that can be set in GT Designer3.

The device specifications of controllers may differ depending on the models, even though belonging to the same series.

Please make the setting according to the specifications of the controller actually used.

When a non-existent device or a device number outside the range is set, other objects with correct device settings may not be monitored.


Setting item



Item	Description
Device	Set the device name, device number, and bit number. The bit number can be set only when specifying the bit of word device.
Information	Displays the device type and setting range which are selected in [Device].


Point

- Device settings of SHARP PLC
- When setting a register as a bit device
- Registers
- Set the type (first 2 digits) and the address.



File register


Set the file number and the address.



When setting a register and memory as a word device.


I/O relay

Set a combination of the device address (multiple of 16)+bit address format (fixed to 0).



Registers and file register

Set the device address (multiple of 16).



- Monitoring the timer (T) and the counter (C)

Address setting

Be sure not to set the same address range for the timer (T) and the counter (C).

Even if these addresses are overlapped, GOT displays no error.

GOT monitors them according to the address instead of the device name.


Therefore, if a device which is invalid for the SHARP PLC side parameter is set using GT Designer3, GOT monitors other device (a device corresponding to the address range of the set device).

Example:

Content in SHARP PLC parameter setting

T0000 to T1000
C1001 to C1777

Content in GT Designer3
parameter setting



Even if GT Designer3 is
set to "C0000", GOT will
also monitor "T0000".

Contact writing into timer (T) and the counter (C)

Writing the contact for the timer (T) and the counter (C) can only be done while the CPU is in RUN (while the timer and counter is in operation).

SHARP PLC (SHARP JW)

Device name		Setting range	Device No. representation
Bit device	I/O relay	..00000 to ..15777 ..20000 to ..75777	Octal
	Timer (Contact) (T)	T0000 to T1777	
	Counter (Contact) (C)	C0000 to C1777	
	The bit specification of the word device	Setting range of each word device	-
Word device	Timer (Current value) (T)	T0000 to T1777	Octal
	Counter (Current value) (C)	C0000 to C1777	
	Register (09 to E7)	09000 to 09776	
		19000 to 19776	
		29000 to 29776	
		39000 to 39776	
		49000 to 49776	
		59000 to 59776	
		69000 to 69776	
		79000 to 79776	
		89000 to 89776	
		99000 to 99776	
		E0000 to E0776	
		E1000 to E1776	
		E2000 to E2776	
		E3000 to E3776	
		E4000 to E4776	
		E5000 to E5776	
		E6000 to E6776	
		E7000 to E7776	
	File register (1 to 7)	1000000 to 1177776	
		2000000 to 2177776	
		3000000 to 3177776	
		4000000 to 4177776	
		5000000 to 5177776	
		6000000 to 6177776	
		7000000 to 7177776	

9.7 Precautions

Connecting to the communication port or link module

When connecting to the communication port or link module, 30 ms or more is required for the send delay time.

In the communication detail settings, set [Delay Time] to 30 ms or more.

If a communication timeout error occurs even when [Delay Time] is set to 30 ms or more, adjust the following settings so that no communication timeout error occurs.

- [Retry]
- [Startup Time]
- [Timeout Time]

For details on each setting, refer to the following.

 Page 420 Communication detail settings

MEMO




















































10 CONNECTION TO SHINKO TECHNOS INDICATING CONTROLLER

10

- Page 433 Connectable Model List
- Page 435 System Configuration
- Page 440 Connection Diagram
- Page 448 GOT Side Settings
- Page 450 Indicating Controller Side Setting
- Page 453 Device Range that Can Be Set
- Page 456 Precautions

10.1 Connectable Model List

The following table shows the connectable models.

Series	Model name	Clock	Communication Type	Connectable GOT	Refer to
ACS-13A Series	ACS-13A□/□,□, C5*2	×	RS-232 RS-485	  	 Page 435 Connecting to ACS-13A, JC, JCM-33A, JIR-301-M, PCD-300 Series, PC-900 Series (PC-955-[]/M,C5, PC-935-[]/M,C5)
JC Series	JCS-33A-□/□□, C5*2	×	RS-232 RS-485	  	 Page 435 Connecting to ACS-13A, JC, JCM-33A, JIR-301-M, PCD-300 Series, PC-900 Series (PC-955-[]/M,C5, PC-935-[]/M,C5)
	JCR-33A-□/□□, C5*2				
	JCD-33A-□/□□, C5*2				
JCM-33A Series	JCM-33A□/□,□ C5*2	×	RS-232 RS-485	  	 Page 435 Connecting to ACS-13A, JC, JCM-33A, JIR-301-M, PCD-300 Series, PC-900 Series (PC-955-[]/M,C5, PC-935-[]/M,C5)
JIR-301-M Series	JIR-301-M□, C5*2	×	RS-232 RS-485	  	 Page 435 Connecting to ACS-13A, JC, JCM-33A, JIR-301-M, PCD-300 Series, PC-900 Series (PC-955-[]/M,C5, PC-935-[]/M,C5)
PCD-300 Series	PCD-33A-□/M, C5*2	×	RS-232 RS-485	  	 Page 435 Connecting to ACS-13A, JC, JCM-33A, JIR-301-M, PCD-300 Series, PC-900 Series (PC-955-[]/M,C5, PC-935-[]/M,C5)
PC-900 Series	PC935-□/M, C5*2	×	RS-232 RS-485	  	 Page 435 Connecting to ACS-13A, JC, JCM-33A, JIR-301-M, PCD-300 Series, PC-900 Series (PC-955-[]/M,C5, PC-935-[]/M,C5)
	PC955-□/M, C5*2				
	PC935-□/M, C*1	×	RS-232	  	 Page 437 Connecting to FCD-100, FCR-100, FCR-23A, FIR Series, PC-900 Series (PC-955[]/M,C, PC-935-[]/M,C)
	PC955-□/M, C*1				
FCD-100 Series*1	FCD-13A-□/M,C	×	RS-232	  	 Page 437 Connecting to FCD-100, FCR-100, FCR-23A, FIR Series, PC-900 Series (PC-955[]/M,C, PC-935-[]/M,C)
	FCD-15A-□/M,C				
FCR-100 Series*1	FCR-13A-□/M,C	×	RS-232	  	 Page 437 Connecting to FCD-100, FCR-100, FCR-23A, FIR Series, PC-900 Series (PC-955[]/M,C, PC-935-[]/M,C)
	FCR-15A-□/M,C				
FCR-23A Series*1	FCR-23A-□/M,C	×	RS-232	  	 Page 437 Connecting to FCD-100, FCR-100, FCR-23A, FIR Series, PC-900 Series (PC-955[]/M,C, PC-935-[]/M,C)
	FCR-23A-□/M,C5			  	
FIR Series*1	FIR-201-M,C	×	RS-232	  	 Page 437 Connecting to FCD-100, FCR-100, FCR-23A, FIR Series, PC-900 Series (PC-955[]/M,C, PC-935-[]/M,C)
DCL-33A Series	DCL-33A-□/M,□, C5*2	×	RS-232 RS-485	  	 Page 438 When connecting to DCL-33A Series

*1 Only the indicating controller equipped with RS-232 communication function can be connected.

*2 The indicating controller of the following version or later can be connected.


Series	Model name	Version
ACS-13A Series	ACS-13A□/□,□, C5	Products manufactured in October 2007 or later (Indicating controllers with the serial numbers 07Axxxxxx, 07Kxxxxxx, and 07Xxxxxxx or later) (The first two digits of the serial numbers show the last two digits of the year.)
JC Series	JCS-33A-□/□□, C5	
	JCR-33A-□/□□, C5	
	JCD-33A-□/□□, C5	
JCM-33A Series	JCM-33A-□/□,□, C5	
JIR-301-M Series	JIR-301-M□, C5	
PCD-300 Series	PCD-33A-□/M, C5	
PC-900 Series	PC935-□/M, C5	
	PC955-□/M, C5	
DCL-33A Series	DCL-33A-□/M,□, C5	


10.2 System Configuration

Connecting to ACS-13A, JC, JCM-33A, JIR-301-M, PCD-300 Series, PC-900 Series (PC-955-[]/M,C5, PC-935-[]/M,C5)

10

For the RS-232 connection (via interface converter)




Indicating controller		Connection cable 1)		Commu nication convert er ^{*1}	Connection cable 2)		GOT		Number of connectable equipment
Model name	Commu nication Type	Cable model Connection diagram number	Max. distan ce		Cable model Connection diagram number	Max. dista nce	Option device ^{*2}	Model	
ACS13A JC JCM-33A JIR-301-M PCD-300 Series PC-955-[]/M,C5 PC-935-[]/M,C5	RS-232	 Page 441 RS-485 connection diagram 1)	1,200m	IF-400	RS-232C CFP-C2 ^{*1}	15m	- (Built into GOT)	GT 27 GT 25 GT 23	31 indicating controllers for 1 GOT
							GT15-RS2-9P	GT 27 GT 25	

^{*1} The communication converter is a product manufactured by Shinko Technos Co., Ltd. For details of the product, contact Shinko Technos Co., Ltd.

^{*2} GT25-W, GT2505-V does not support the option device.

For the RS-485 connection



Indicating controller		Connection cable		GOT		Number of connectable equipment
Model name	Communication Type	Cable model Connection diagram number	Max. distance	Option device	Model	
ACS13A JC JCM-33A JIR-301-M PCD-300 Series PC-955-□/M,C5 PC-935-□/M,C5	RS-485	(User preparing) Page 445 RS-485 connection diagram 7)	500m	- (Built into GOT)	GT 27 GT 25 GT 23	31 indicating controllers for 1 GOT
		(User preparing) Page 441 RS-485 connection diagram 2)	500m	GT15-RS4-TE	GT 27 GT 25 *1*2	
		(User preparing) Page 444 RS-485 connection diagram 6)	500m	FA-LTBGT2R4CBL05 (0.5m) FA-LTBGT2R4CBL10 (1m) FA-LTBGT2R4CBL20 (2m)	GT 27 GT 25 GT 23 *2	
		(User preparing) Page 446 RS-485 connection diagram 8)	500m	GT14-RS2T4-9P *3	GT 25 *4	


*1 Not available to GT25-W.








*2 Not available to GT2505-V.

*3 Mount it on the RS-232 interface (GOT built-in).

*4 Only available to GT2505-V.

Connecting to FCD-100, FCR-100, FCR-23A, FIR Series, PC-900 Series (PC-955[]/M,C, PC-935-[]/M,C)




Indicating controller ^{*1}		Connection cable		GOT		Number of connectable equipment
Model name	Communication Type	Cable model Connection diagram number	Max. distance	Option device ^{*2}	Model	
FCD-100 FCR-100 FCR-23A FIR Series PC-955-□/M,C PC-935-□/M,C	RS-232	GT09-C30R21401-4T(3m) or  Page 440 RS-232 connection diagram 1)	15m	- (Built into GOT)	   	31 indicating controllers for 1 GOT
				GT15-RS2-9P	 	

^{*1} Only the indicating controller equipped with RS-232 communication function can be connected.

^{*2} GT25-W, GT2505-V does not support the option device.

When connecting to DCL-33A Series

For the RS-232 connection (via communication converter)

















Indicating controller		Connection cable 1)		Commu nication convert er*1	Connection cable 2)		GOT		Number of connectable equipment
Model name	Commu nication Type	Cable model Connection diagram number	Max. distan ce		Cable model Connection diagram number	Max. distan ce	Option device*2	Model	
DCL-33A Series	RS-232	RS485-CPP*1	1,200m	IF-400	RS-232CCFP-C2*1	15m	- (Built into GOT)	GT 27 GT 25 GT 23	31 indicating controllers for 1 GOT
							GT15-RS2-9P	GT 27 GT 25	

*1 Product manufactured by Shinko Technos Co., Ltd. For details of the product, contact Shinko Technos Co., Ltd.

*2 GT25-W, GT2505-V does not support the option device.

For the RS-485 connection



Indicating controller		Connection cable 1)	Connection cable 2)	Max. distance	GOT		Number of connectable equipment
Model name	Communication Type	Cable model Connection diagram number	Cable model Connection diagram number		Option device	Model	
DCL-33A Series	RS-485	RS-485 CPP ^{*1}	 Page 443 RS-485 connection diagram 5)	500m	- (Built into GOT)	  	31 indicating controllers for 1 GOT
			 Page 442 RS-485 connection diagram 3)	500m	GT15-RS4-TE	  *2*3	
			 Page 442 RS-485 connection diagram 4)	500m	FA-LTBGT2R4CBL05 (0.5m) FA-LTBGT2R4CBL10 (1m) FA-LTBGT2R4CBL20 (2m)	   *3	
			 Page 446 RS-485 connection diagram 9)	500m	GT14-RS2T4-9P ^{*4}	 *5	

*1 Product manufactured by Shinko Technos Co., Ltd. For details of the product, contact Shinko Technos Co., Ltd.

*2 Not available to GT25-W.

*3 Not available to GT2505-V.

*4 Mount it on the RS-232 interface (GOT built-in).

*5 Only available to GT2505-V.


10.3 Connection Diagram

The following diagram shows the connection between the GOT and the PLC.

RS-232 cable

Connection diagram

■RS-232 connection diagram 1)



*1 Connect FG grounding to the appropriate part of a cable shield line.


Precautions when preparing a cable

■Cable length

The length of the RS-232 cable must be 15m or less.

■GOT side connector

For the GOT side connector, refer to the following.

 Page 58 GOT connector specifications

■Shinko Technos indicating controller side connector


Use the connector compatible with the Shinko Technos indicating controller side.

For details, refer to the user's manual of the Shinko Technos indicating controller.

RS-485 cable

Connection diagram

■RS-485 connection diagram 1)



*1 Pin No. of communication converter differs depending on the model.
Refer to the following table.


Signal name	Model of indicating controller								
	JCS-33A	JCR-33A	JCD-33A	JCM-33A	JIR-301-M	ACS-13A	PCD-33A	PC-955	PC-935
	Pin No.	Pin No.	Pin No.	Pin No.	Pin No.	Pin No.	Pin No.	Pin No.	Pin No.
YA(-)	13	11	11	10	11	16	11	11	11
YB(+)	14	14	14	13	14	17	14	12	12
SG	15	17	17	14	17	18	17	16	16

*2 Connect FG grounding to the appropriate part of a cable shield line.

*3 For details of the terminating resistor specifications, refer to the following manual.

☞ User's Manual of the Shinko Technos indicating controller

■RS-485 connection diagram 2)



*1 Pin No. of communication converter differs depending on the model.
Refer to the following table.

Signal name	Model of indicating controller								
	JCS-33A	JCR-33A	JCD-33A	JCM-33A	JIR-301-M	ACS-13A	PCD-33A	PC-955	PC-935
	Pin No.	Pin No.	Pin No.	Pin No.	Pin No.	Pin No.	Pin No.	Pin No.	Pin No.
YA(-)	13	11	11	10	11	16	11	11	11
YB(+)	14	14	14	13	14	17	14	12	12
SG	15	17	17	14	17	18	17	16	16

*2 Connect FG grounding to the appropriate part of a cable shield line.


*3 For details of the terminating resistor specifications, refer to the following manual.

☞ User's Manual of the Shinko Technos indicating controller

*4 Set the terminating resistor of GOT side which will be a terminal.

☞ Page 447 Connecting terminating resistors

■RS-485 connection diagram 3)



*1 Set the terminating resistor of The GOT side.


☞ Page 447 Connecting terminating resistors

*2 For details of the pin assignment, refer to the following manual.

☞ User's Manual of the Shinko Technos indicating controller

*3 Connect FG grounding to the appropriate part of a cable shield line.

■RS-485 connection diagram 4)



*1 Set the terminating resistor of GOT side.


☞ Page 447 Connecting terminating resistors

*2 For details of the pin assignment, refer to the following manual.

☞ User's Manual of the Shinko Technos indicating controller

*3 Connect FG grounding to the appropriate part of a cable shield line.

■RS-485 connection diagram 5)



*1 Set the terminating resistor of GOT side.


☞ Page 447 Connecting terminating resistors

*2 For details of the pin assignment, refer to the following manual.

☞ User's Manual of the Shinko Technos indicating controller

*3 Connect FG grounding to the appropriate part of a cable shield line.

■RS-485 connection diagram 6)



*1 Pin No. of communication converter differs depending on the model. Refer to the following table.

Signal name	Model of indicating controller								
	JCS-33A	JCR-33A	JCD-33A	JCM-33A	JIR-301-M	ACS-13A	PCD-33A	PC-955	PC-935
	Pin No.	Pin No.	Pin No.	Pin No.	Pin No.	Pin No.	Pin No.	Pin No.	Pin No.
YA(-)	13	11	11	10	11	16	11	11	11
YB(+)	14	14	14	13	14	17	14	12	12
SG	15	17	17	14	17	18	17	16	16

*2 Connect FG grounding to the appropriate part of a cable shield line.


*3 For details of the terminating resistor specifications, refer to the following manual.

☞ User's Manual of the Shinko Technos indicating controller

*4 Set the terminating resistor of GOT side which will be a terminal.

☞ Page 447 Connecting terminating resistors

■RS-485 connection diagram 7)



*1 Pin No. of communication converter differs depending on the model. Refer to the following table.

Signal name	Model of indicating controller								
	JCS-33A	JCR-33A	JCD-33A	JCM-33A	JIR-301-M	ACS-13A	PCD-33A	PC-955	PC-935
	Pin No.	Pin No.	Pin No.	Pin No.	Pin No.	Pin No.	Pin No.	Pin No.	Pin No.
YA(-)	13	11	11	10	11	16	11	11	11
YB(+)	14	14	14	13	14	17	14	12	12
SG	15	17	17	14	17	18	17	16	16

*2 Connect FG grounding to the appropriate part of a cable shield line.


*3 For details of the terminating resistor specifications, refer to the following manual.

☞ User's Manual of the Shinko Technos indicating controller

*4 Set the terminating resistor of GOT side which will be a terminal.

☞ Page 447 Connecting terminating resistors

■RS-485 connection diagram 8)




*1 Pin No. of communication converter differs depending on the model.
Refer to the following table.

Signal name	Model of indicating controller								
	JCS-33A	JCR-33A	JCD-33A	JCM-33A	JIR-301-M	ACS-13A	PCD-33A	PC-955	PC-935
	Pin No.	Pin No.	Pin No.	Pin No.	Pin No.	Pin No.	Pin No.	Pin No.	Pin No.
YA(-)	13	11	11	10	11	16	11	11	11
YB(+)	14	14	14	13	14	17	14	12	12
SG	15	17	17	14	17	18	17	16	16

- *2 Connect FG grounding to the appropriate part of a cable shield line.
- *3 For details of the terminating resistor specifications, refer to the following manual.
☞ User's Manual of the Shinko Technos indicating controller
- *4 Set the 2-wire/4-wire terminating resistor setting switch of the RS-232/485 signal conversion adaptor as shown below.
2-wire/4-wire: 2-wire (1Pair)
Terminating resistor: 110 Ω
☞ Page 67 Setting the RS-232/485 signal conversion adaptor

■RS-485 connection diagram 9)



- *1 Set the 2-wire/4-wire terminating resistor setting switch of the RS-232/485 signal conversion adaptor as shown below.
2-wire/4-wire: 2-wire (1Pair)
Terminating resistor: 110 Ω
☞ Page 67 Setting the RS-232/485 signal conversion adaptor
- *2 For details of the pin assignment, refer to the following manual.
☞ User's Manual of the Shinko Technos indicating controller
- *3 Connect FG grounding to the appropriate part of a cable shield line.


Precautions when preparing a cable

■Cable length

- The length of the RS-485 cable used for direct connecting the indicating controller to the communication converter
The length of the RS-485 cable must be 1200m or less.
- The length of the RS-485 cable used for direct connecting the indicating controller to GOT
The length of the RS-485 cable must be 500m or less.

■GOT side connector

For the GOT side connector, refer to the following.

 Page 58 GOT connector specifications

■Shinko Technos indicating controller side connector

Use the connector compatible with the Shinko Technos indicating controller side.
For details, refer to the user's manual of the Shinko Technos indicating controller.

Connecting terminating resistors

■GOT side

- For GT27, GT25(Except GT2505-V), GT23

Set the terminating resistor setting switch of the GOT main unit to "Enable".

- For GT2505-V


Set the terminating resistor selector to "110Ω".

For the procedure to set the terminating resistor, refer to the following.

 Page 62 Terminating resistors of GOT

■Shinko Technos indicating controller side


When connecting a Shinko Technos indicating controller to the GOT, a terminating resistor must be connected to the Shinko Technos indicating controller.

 User's Manual of the Shinko Technos indicating controller

10.4 GOT Side Settings

Setting communication interface (Communication settings)

Set the channel of the equipment to be connected to the GOT.



1. Select [Common] → [Controller Setting] from the menu.
2. In the [Controller Setting] window, select the channel No. to be used from the list menu.
3. Set the following items.
 - [Manufacturer]: [Shinko Technos]
 - [Controller Type]: [Shinko Technos Controller]
 - [I/F]: Interface to be used
 - [Detail Setting]: Configure the settings according to the usage environment.
4. When you have completed the settings, click the [OK] button.

☞ Page 449 Communication detail settings

Point

The settings of connecting equipment can be confirmed in [I/F Communication Setting].
For details, refer to the following.

☞ Page 47 I/F communication setting

Communication detail settings

Make the settings according to the usage environment.

Property	Value
Transmission Speed(BPS)	9600
Data Bit	7 bit
Stop Bit	1 bit
Parity	Even
Retry(Times)	0
Timeout Time(Sec)	3
Host Address	0
Delay Time(ms)	5

Item	Description	Range
Transmission Speed	Set this item when change the transmission speed used for communication with the connected equipment. (Default: 9600bps)	9600bps, 19200bps, 38400bps, 57600bps, 115200bps
Data Bit	Set this item when change the data length used for communication with the connected equipment. (Default: 7bits)	7bits/8bits
Stop Bit	Specify the stop bit length for communications. (Default: 1bit)	1bit/2bits
Parity	Specify whether or not to perform a parity check, and how it is performed during communication. (Default: Even)	None Even Odd
Retry	Set the number of retries to be performed when a communication error occurs. (Default: 0time)	0 to 5times
Timeout Time	Set the time period for a communication to time out. (Default: 3sec)	3 to 30sec
Host Address	Specify the host address (station No. of the GOT to which the indicating controller is connected) in the connected network. (Default: 0)	0 to 94
Delay Time	Set this item to adjust the transmission timing of the communication request from the GOT. (Default: 5ms)	0 to 300ms

Point

- Communication interface setting by the Utility

The communication interface setting can be changed on the Utility's [Communication Settings] after writing [Communication Settings] of project data.

For details on the Utility, refer to the following manual.

 GOT2000 Series User's Manual (Utility)

- Precedence in communication settings

When settings are made by GT Designer3 or the Utility, the latest setting is effective.

10.5 Indicating Controller Side Setting



- Shinko Technos indicating controller

For details of Shinko Technos indicating controller, refer to the following manual.

☞ User's Manual of the Shinko Technos indicating controller

- Communication converter

For details on communication settings of the communication converter, refer to the following manual.

☞ User's Manual of communication converter

Model name		Refer to
Indicating controller	ACS-13A, DCL-33A, JC, JCM-33A, JIR-301-M, PCD-300 Series, PC-900 Series (PC-955-□/M,C5, PC-935-□/M,C5)	☞ Page 450 Connecting to ACS-13A, DCL- 33A, JC, JCM-33A, JIR-301- M, PCD-300 Series, PC-900 Series (PC-955-[]/M,C5, PC- 935-[]/M,C5)
	FCD-100, FCR-100, FCR-23A, FIR Series, PC-900 Series (PC-955-□/M,C, PC-935-□/M,C)	☞ Page 450 Connecting to FCD-100, FCR- 100, FCR-23A, FIR Series, PC-900 Series (PC-955-[]/ M,C, PC-935-[]/M,C)
Communication converter	IF-400	☞ Page 451 Connecting to communication converter (IF-400)

Connecting to ACS-13A, DCL- 33A, JC, JCM-33A, JIR-301- M, PCD-300 Series, PC-900 Series (PC-955-[]/M,C5, PC- 935-[]/M,C5)

Communication settings

Make the communication settings by operating the key of the indicating controller.

Item	Set value
Transmission speed*1	9600bps, 19200bps
Data bit	7bits (fixed)
Parity bit	Even (fixed)
Stop bit	1bit (fixed)
Station No. *2*3	0 to 95
Communication protocol	Shinko protocol

*1 Adjust the settings with GOT settings.

*2 Avoid duplication of the station No. with any of the other units.

*3 When setting the "95" to the station No., the read-out of data cannot be performed.

Connecting to FCD-100, FCR- 100, FCR-23A, FIR Series, PC-900 Series (PC-955-[]/ M,C, PC-935-[]/M,C)

Communication settings

Make the communication settings by operating the key of the indicating controller.

Item	Set value
Transmission speed*1	9600bps, 19200bps
Data bit	7bits (fixed)
Parity bit	Even (fixed)
Stop bit	1bit (Fixed)
Station No. *1*2	0 to 95
Communication protocol	Shinko protocol

*1 Adjust the settings with GOT settings.

*2 When setting the "95" to the station No., the read-out of data cannot be performed.

Connecting to communication converter (IF-400)

Communication settings

Make the communication settings by operating the key of the communication converter.

Item	Set value
Transmission speed ^{*1}	9600bps, 19200bps
Sending/Receiving switching period ^{*2}	1 character, 2 character

*1 Adjust the settings with GOT and the indicating controller settings.


*2 The setting of 1 character is recommended.

10

Station No. settings

Set each station number so that no station number overlaps.

The station number can be set without regard to the cable connection order. There is no problem even if station numbers are not consecutive.



Direct specification

When setting the device, specify the station number of the indicating controller of which data is to be changed.

Specification range

0 to 94

Indirect specification

When setting the device, indirectly specify the station number of the indicating controller of which data is to be changed using the 16-bit GOT internal data register (GD10 to GD25).

When specifying the station No. from 100 to 115 on GT Designer3, the value of GD10 to GD25 compatible to the station No. specification will be the station No. of the indicating controller.

Specification station NO.	Compatible device	Setting range
100	GD10	0 to 94 For the setting other than the above, error (dedicated device is out of range) will occur.
101	GD11	
102	GD12	
103	GD13	
104	GD14	
105	GD15	
106	GD16	
107	GD17	
108	GD18	
109	GD19	
110	GD20	
111	GD21	
112	GD22	
113	GD23	
114	GD24	
115	GD25	

All station specification

Target station differs depending on write-in operation or read-out operation.

- For write-in operation, all station will be a target.

In the WORD BIT write-in operation, only the indicating controller whose station No. is the same as host address is applicable.

For details of host address setting, refer to the following.

☞ Page 448 Setting communication interface (Communication settings)

- In the read-out operation, only the indicating controller whose station No. is the same as host address is applicable.

For details of host address setting, refer to the following.

☞ Page 448 Setting communication interface (Communication settings)

10.6 Device Range that Can Be Set

The device ranges of controller that can be used for GOT are as follows.


Note that the device ranges in the following tables are the maximum values that can be set in GT Designer3.

The device specifications of controllers may differ depending on the models, even though belonging to the same series.

Please make the setting according to the specifications of the controller actually used.

When a non-existent device or a device number outside the range is set, other objects with correct device settings may not be monitored.

Setting item



Item	Description
Device	Set the device name, device number, and bit number. The bit number can be set only when specifying the bit of word device.
	Memory No.*1 Set the memory number (None, 0 to 7) of the device to be monitored.
Information	Displays the device type and setting range which are selected in [Device].
Network	Set the monitor target of the set device.
	<div>All</div> Select this item when writing data to all the indicating controllers connected. During monitoring, the indicating controller which is set for [Host Address] of the communication detail setting is monitored. (When writing the data in numerical input, the data is written to all connected indicating controllers during input, and the indicating controller that is set for [Host Address] is monitored during other than input (displaying).)
	<div>Station No.</div> Select this item when monitoring the indicating controller of the specified station No. After selecting, set the station No. of the indicating controller in the following range. 0 to 94: To monitor the indicating controller of the specified station No. 95: Same as the setting of [All]. 100 to 115: To specify the station No. of the indicating controller to be monitored by the value of GOT data register (GD).*2

*1 The device name is displayed as follows when the memory number (0 to 7) is set.

Memory No.	Displayed device name
None	Device Number
0	M0/Device Number
1	M1/Device Number
2	M2/Device Number
3	M3/Device Number
4	M4/Device Number
5	M5/Device Number
6	M6/Device Number
7	M7/Device Number

*2 The following shows the relation between station numbers of the indicating controller and the GOT data register.

Station No.	GOT data register (GD)	Setting range
100	GD10	0 to 94 (If setting a value outside the range above, a device range error occurs.)
101	GD11	
:	:	
114	GD24	
115	GD25	

SHINKO indicating controller (Shinko Technos Controller)

Device name		Setting range	Device No. representation
Bit device	The bit specification of the word device ^{*1}	Setting range of each word device	-
Word device	Data item (..)	..0001 to ..7901	Hexadecimal

^{*1} As bit specification of a word device is performed after the GOT reads the value, do not change the value with the indicating controller during this period.

10

10.7 Precautions

Station number settings of indicating controller

In the system configuration, the indicating controller with the station number set with the host address must be included.

For details of host address setting, refer to the following.

☞ Page 448 Setting communication interface (Communication settings)

GOT clock control

Since the indicating controller does not have a clock function, the settings of [time adjusting] or [time broad cast] by GOT clock control will be disabled.

When using the communication converter IF-400

When using the communication converter IF-400, some communication error may occur. Set the number of retries to more than one time.

Disconnecting some of multiple connected equipment

The GOT can disconnect some of multiple connected equipment by setting GOT internal device. For example, the faulty station where a communication timeout error occurs can be disconnected from connected equipment.

For details of GOT internal device setting, refer to the following manual.

☞ GT Designer3 (GOT2000) Screen Design Manual





11 CONNECTION TO CHINO CONTROLLER

- Page 457 Connectable Model List
- Page 458 System Configuration
- Page 469 Connection Diagram
- Page 483 GOT Side Settings
- Page 485 Controller Side Setting
- Page 496 Device Range that Can Be Set
- Page 498 Precautions


11

11.1 Connectable Model List

The following table shows the connectable models.

Series	Model name*1	Clock	Communication Type	Connectable GOT	Refer to
LT230 Series	LT230	×	RS-232 RS-485	<div>GT27</div> <div>GT25</div> <div>GT23</div>	 Page 458 Connecting to LT230, LT300, LT400, LT830, DZ1000, DZ2000, DB1000, DB2000 series
LT300 Series	LT350	×	RS-232 RS-422 RS-485		
	LT370				
LT400 Series	LT450	×			
	LT470				
LT830 Series	LT830	×			
DZ1000 Series	DZ1000	×	RS-232 RS-422 RS-485		
DZ2000 Series	DZ2000	×			
DB1000 Series	DB1000	×			
DB2000 Series	DB2000	×			
KP Series	KP1000 KP2000	×	RS-232 RS-422 RS-485	<div>GT27</div> <div>GT25</div> <div>GT23</div>	 Page 461 Connecting to KP1000, KP2000, AL3000, AH3000 series
AL3000 Series	AL3000	×			
AH3000 Series	AH3000	×			
SE3000 Series	SE3000	×	RS-232 RS-422 RS-485	<div>GT27</div> <div>GT25</div> <div>GT23</div>	 Page 464 Connecting to SE3000, JU, KE3000, LE5000 series
JU Series	JU	×	RS-422 RS-485		
KE Series	KE3000	×			
LE5000 Series	LE5000	×			
GT120 Series	GT120	×	RS-232 RS-485	<div>GT27</div> <div>GT25</div> <div>GT23</div>	 Page 467 Connecting to GT120 Series


*1 From the models of controller, select the detailed model name which supports each communication type. For details of CHINO controller detailed model names, refer to the following catalog.

 Catalog of CHINO controllers











11.2 System Configuration

Connecting to LT230, LT300, LT400, LT830, DZ1000, DZ2000, DB1000, DB2000 series

When connecting to controller



Indicating controller		Connection cable		GOT		Number of connectable equipment
Model name	Communication Type	Cable model Connection diagram number	Max. distance	Option device	Model	
LT300 LT400 DZ1000 DZ2000 DB1000 DB2000	RS-232	Page 469 RS232 connection diagram 1)	15m	- (Built into GOT)	 	1 controller for 1 GOT
				GT15-RS2-9P	 *1*2	
	RS-422	Page 471 RS422 connection diagram 2)	1200m	- (Built into GOT)	 	31 controllers for 1 GOT
				GT15-RS4-9S	 *1*2	
		Page 472 RS422 connection diagram 3)	1200m	GT14-RS2T4-9P *3	 *4	

Indicating controller		Connection cable		GOT		Number of connectable equipment
Model name	Communication Type	Cable model Connection diagram number	Max. distance	Option device	Model	
LT230 LT300 LT400 LT830 DZ1000 DZ2000 DB1000 DB2000	RS-485	 Page 474 RS485 connection diagram 1)	1200m	FA-LTBGTR4CBL05 (0.5m) FA-LTBGTR4CBL10 (1m) FA-LTBGTR4CBL20 (2m)	   *2	31 controllers for 1 GOT
		 Page 476 RS485 connection diagram 3)	1200m	GT15-RS4-TE	  *1*2	
		 Page 481 RS485 connection diagram 12)	1200m	- (Built into GOT)	 	


*1 Not available to GT25-W.

*2 Not available to GT2505-V.

*3 Connect it to the RS-232 interface (built in the GOT).

*4 Only available to GT2505-V.

When connecting to converter




Indicating controller	Connection cable 1)		Converter ^{*1}		Connection cable 2)		GOT		Number of connectable equipment
Model name	Cable model Connection diagram number	Max. distance	Model name	Communication Type	Cable model Connection diagram number	Max. distance	Option device ^{*2}	Model	
LT300 LT400 DZ1000 DZ2000 DB1000 DB2000	(User manual) Page 470 RS422 connection diagram 1)	1200m	SC8-10	RS-232	(User manual) Page 469 RS232 connection diagram 1)	15m	- (Built into GOT)	GT 27 GT 25 GT 23	31 controllers for 1 GOT
							GT15-RS2-9P	GT 27 GT 25 GT 23	
LT230 LT300 LT400 LT830 DZ1000 DZ2000 DB1000 DB2000	(User manual) Page 475 RS485 connection diagram 2)	1200m	SC8-10	RS-232	(User manual) Page 469 RS232 connection diagram 1)	15m	- (Built into GOT)	GT 27 GT 25 GT 23	
							GT15-RS2-9P	GT 27 GT 25 GT 23	

*1 The converter is a product manufactured by CHINO corporation. For details of the product, contact CHINO corporation.

*2 GT25-W, GT2505-V does not support the option device.

Connecting to KP1000, KP2000, AL3000, AH3000 series

When connecting to controller



Indicating controller		Connection cable 1)	Connection cable 2)	Max. distance	GOT		Number of connectable equipment
Model name	Communication Type	Cable model ^{*1} Connection diagram number	Cable model ^{*1} Connection diagram number		Option device	Model	
KP1000 KP2000 AL3000 AH3000	RS-232	-	RZ-CRS6□□ or (User preparing) Page 469 RS232 connection diagram 1)	15m	- (Built into GOT)	GT 27 GT 25 GT 23	1 controller for 1 GOT
					GT15-RS2-9P	GT 27 GT 25 *2*3	
	RS-422	RZ-CRA1□□	(User preparing) Page 471 RS422 connection diagram 2)	1200m	- (Built into GOT)	GT 27 GT 25 GT 23	31 controllers for 1 GOT
					GT15-RS4-9S	GT 27 GT 25 *2*3	
		(User preparing) Page 471 RS422 connection diagram 2)	1200m	-	- (Built into GOT)	GT 27 GT 25 GT 23	
					GT15-RS4-9S	GT 27 GT 25 *2*3	
	RS-485	RZ-CRA1□□	(User preparing) Page 470 RS422 connection diagram 1)	1200m	FA-LTBGTR2CBL05 (0.5m) FA-LTBGTR2CBL10 (1m) FA-LTBGTR2CBL20 (2m)	GT 27 GT 25 GT 23	31 controllers for 1 GOT
						*3	
		RZ-LEC□□□	(User preparing) Page 476 RS485 connection diagram 3)	1200m	GT15-RS4-TE	GT 27 GT 25 *2*3	
		(User preparing) Page 481 RS485 connection diagram 12)	1200m	- (Built into GOT)	GT 27 GT 25		

*1 Product manufactured by CHINO corporation. For details of the product, contact CHINO corporation.


*2 Not available to GT25-W.

*3 Not available to GT2505-V.

*4 Connect it to the RS-232 interface (built in the GOT).

*5 Only available to GT2505-V.

When connecting to converter




Indica ting contro ller	Connection cable 1)	Connection cable 2)	Max. distance	Converter ^{*1}		Connection cable 3)		GOT		Number of connectable equipment
	Model name	Cable model ^{*1} Connection diagram number		Model name	Commu nication Type	Cable model Connection diagram number	Max. distance	Option device ^{*2}	Model	
KP1000 KP2000 AL3000 AH3000	RZ-CRA1□□ or (User preparing) Page 470 RS422 connection diagram 1)	RZ-CRA2□□ or (User preparing) Page 470 RS422 connection diagram 1)	1200m	SC8-10	RS-232	RZ-CRS6□ or (User preparing) Page 469 RS232 connection diagram 1)	15m	- (Built into GOT)	GT 27 GT 25 GT 23	31 controllers for 1 GOT
								GT15-RS2-9P	GT 27 GT 25	
	RZ-LEC□□□ or (User preparing) Page 475 RS485 connection diagram 2)	RZ-LEC□□□ (only KP1000, KP2000) RZ-LED□□□ (only AL3000, AH3000) or (User preparing) Page 475 RS485 connection diagram 2)	1200m	SC8-10	RS-232	RZ-CRS6□ or (User preparing) Page 469 RS232 connection diagram 1)	15m	- (Built into GOT)	GT 27 GT 25 GT 23	
								GT15-RS2-9P	GT 27 GT 25	







*1 Product manufactured by CHINO corporation. For details of the product, contact CHINO corporation.
























*2 GT25-W, GT2505-V does not support the option device.

Connecting to SE3000, JU, KE3000, LE5000 series

When connecting to controller



Indicating controller		Connection cable 1)	Connection cable 2)	Max. distance	GOT		Number of connectable equipment
Model name	Communication Type	Cable model*1 Connection diagram number	Cable model*1 Connection diagram number		Option device	Model	
SE3000	RS-232	--	RZ-CRS6□□ or  Page 469 RS232 connection diagram 1)	15m	- (Built into GOT)	  	1 controller for 1 GOT
					GT15-RS2-9P	  *4*5	

Indicating controller		Connection cable 1)	Connection cable 2)	Max. distance	GOT		Number of connectable equipment
Model name	Communication Type	Cable model* ¹ Connection diagram number	Cable model* ¹ Connection diagram number		Option device	Model	
SE3000 JU KE3000 LE5000	RS-422	RZ-CRA1□□* ²	 Page 471 RS422 connection diagram 2)	1200m	- (Built into GOT)	  	31 controllers for 1 GOT
					GT15-RS4-9S	  *4*5	
		 Page 471 RS422 connection diagram 2)	1200m	- (Built into GOT)	  		
				GT15-RS4-9S	  *4*5		
		 Page 472 RS422 connection diagram 3)	1200m	GT14-RS2T4-9P * ⁶	 *7		
RS-485		RZ-LEC□□□* ² or RZ-CSS1Z2* ³	 Page 479 RS485 connection diagram 9)	1200m	FA-LTBGTR2CBL05 (0.5m) FA-LTBGTR2CBL10 (1m) FA-LTBGTR2CBL20 (2m)	   *5	31 controllers for 1 GOT
						 Page 479 RS485 connection diagram 9)	
		RZ-LEC□□□* ² or RZ-CSS1Z2* ³	 Page 480 RS485 connection diagram 10)	1200m	GT15-RS4-TE	  *4*5	
						 Page 482 RS485 connection diagram 13)	

*1 Product manufactured by CHINO corporation. For details of the product, contact CHINO corporation.

*2 RZ-CRA1□□ and RZ-LEC□□□ can be used in SE3000, JU or LE5000 series only.

*3 RZ-CSS1Z2 can be used in JU series only.


*4 Not available to GT25-W.

*5 Not available to GT2505-V.

*6 Connect it to the RS-232 interface (built in the GOT).

*7 Only available to GT2505-V.

When connecting to converter



Indicating controller	Connection cable 1)	Connection cable 2)	Max. distance	Converter ^{*1}		Connection cable 3)		GOT		Number of connectable equipment
Model name	Cable model ^{*1} Connection diagram number	Cable model ^{*1} Connection diagram number		Model name	Communication Type	Cable model Connection diagram number	Max. distance	Option device ^{*4}	Model	
SE3000 JU KE3000 LE5000	RZ-CRA1□□ ^{*2} or Page 470 RS422 connection diagram 1)	RZ-CRA2□□ ^{*2} or Page 470 RS422 connection diagram 1)	1200m	SC8 -10	RS-232	RZ-CRS6□ or Page 469 RS232 connection diagram 1)	15m	- (Built into GOT)	 	31 controllers for 1 GOT
								GT15-RS2-9P		
	RZ-LEC□□□ (only SE3000, JU, LE5000) or RZ-CSS1Z2 ^{*3} or Page 480 RS485 connection diagram 11)	RZ-LEC□□□ (only JU, LE5000) or RZ-LED□□□ (only SE3000) or Page 480 RS485 connection diagram 11)	1200m	SC8 -10	RS-232	RZ-CRS6□ or Page 469 RS232 connection diagram 1)	15m	- (Built into GOT)	 	
								GT15-RS2-9P		

*1 Product manufactured by CHINO corporation. For details of the product, contact CHINO corporation.


*2 RZ-CRA1□□ and RZ-CRA2□□ can be used in SE3000, JU or LE5000 series only.

*3 RZ-CSS1Z2 can be used in JU series only.

*4 GT25-W, GT2505-V does not support the option device.

Connecting to GT120 Series

When connecting to controller




Indicating controller		Connection cable 1)	Connection cable 2)	Max. distance	GOT		Number of connectable equipment
Model name	Communication Type	Cable model Connection diagram number	Cable model Connection diagram number		Option device *1*2	Model	
GT120	RS-485	GT8-CDD(60mm) or (User preparing) Page 476 RS485 connection diagram 4)	(User preparing) Page 477 RS485 connection diagram 5)	1200m	- (Built into GOT)	GT 27 GT 25 GT 23	31 controllers for 1 GOT
			(User preparing) Page 477 RS485 connection diagram 6)	1200m		GT 27 GT 25 GT 23	
			(User preparing) Page 478 RS485 connection diagram 7)	1200m		GT 27 GT 25	

*1 GT25-W is not compatible to the option devices other than FA-LTBGT2R4CBL□□.

*2 GT2505-V does not support the option device.

When connecting to converter



Indicating controller	Connection cable 1)	Connection cable 2)	Max. distance	Converter ^{*1}		Connection cable 3)		GOT		Number of connectable equipment
	Model name Cable model Connection diagram number	Cable model Connection diagram number		Model name	Communication Type	Cable model Connection diagram number	Max. distance	Option device ^{*2}	Model	
GT120	GT8-CDD(60mm) or <small>(User setting)</small> Page 476 RS485 connection diagram 4)	GT8-CDM(3m) or <small>(User setting)</small> Page 478 RS485 connection diagram 8)	1200m	SC8-10	RS-232	<small>(User setting)</small> Page 469 RS232 connection diagram 1)	15m	- (Built into GOT)	<small>GT 27</small> <small>GT 25</small> <small>GT 23</small>	31 controllers for 1 GOT
								GT15-RS2-9P	<small>GT 27</small> <small>GT 25</small>	

*1 The converter is a product manufactured by CHINO corporation. For details of the product, contact CHINO corporation.

*2 GT25-W, GT2505-V does not support the option device.


11.3 Connection Diagram

The following diagram shows the connection between the GOT and the PLC.

RS-232 cable

Connection diagram

■RS232 connection diagram 1)



*1 Terminal number of the controller and the converter differ depending on the model. Refer to the following table.

Signal name	Controller					Converter
	LT300	LT400	DZ1000, DZ2000	DB1000	DB2000	SC8-10
	Terminal No.	Terminal No.	Terminal No.	Terminal No.	Terminal No.	Terminal No.
SD	11	11	19	13	27	2
RD	13	13	21	12	26	1
SG	15	15	23	14	28	3

Signal name	Controller				
	KP1000	KP2000		SE3000	AL3000 AH3000
	Terminal No.	Terminal No.*2		Terminal name	Terminal name
		R*3, B*3, C*3, D*3	B*3, E*3		
SD	13	27	30	SD	SD
RD	12	26	29	RD	RD
SG	14	28	31	SG	SG

*2 For KP2000 series, the terminal No. differs according to the model.

*3 This indicates the symbols of the position 10) (third zone) of the following models.

Model: KP2 4) 5) 6) 7) 8) 9) 10) – 12) 13) 14)

For the symbol B, two terminal numbers are available. Select as necessary.

Precautions when preparing a cable

■Cable length

The length of the RS-232 cable must be 15m or less.

■GOT side connector

For the GOT side connector, refer to the following.

☞ Page 58 GOT connector specifications

■CHINO controller side connector


Use the connector compatible with the CHINO controller side module.

For details, refer to the user's manual of the CHINO controller.

RS-422 cable

Connection diagram

■RS422 connection diagram 1)



*1 Pin No. of controller differs depending on the model. Refer to the following table.

Signal name	Controller type				
	LT300	LT400	DZ1000, DZ2000	DB1000	DB2000
	Terminal No.	Terminal No.	Terminal No.	Terminal No.	Terminal No.
SDA	11	11	19	14	28
SDB	12	12	20	15	29
RDA	13	13	21	12	26
RDB	14	14	22	13	27
SG	15	15	23	16	30

Signal name	Controller type							
	KP1000	KP2000		SE3000	AL3000 AH3000	JU	KE3000	LE5000
	Terminal No.	Terminal No.*2		Terminal name	Terminal name	Terminal No.	Terminal name	Terminal name
		A*3	C*3, F*3					
SDA	14	28	31	SDA	SDA	1	SDA	SDA
SDB	15	29	32	SDB	SDB	2	SDB	SDB
RDA	12	26	29	RDA	RDA	3	RDA	RDA
RDB	13	27	30	RDB	RDB	4	RDB	RDB
SG	16	30	28	SG	SG	5	SG	SG

*2 For KP2000 series, the terminal No. differs according to the model.


*3 This indicates the symbols of the position 10) (third zone) of the following models.
Model: KP2 4) 5) 6) 7) 8) 9) 10) – 12) 13) 14)

*4 Terminating resistor should be provided for a controller which will be a terminal.

*5 Set the Communication Type switch of the converter to RS-422.

*6 Do not connect SG of the controller and SG of the converter.

■RS422 connection diagram 2)



*1 Pin No. of controller differs depending on the model. Refer to the following table.

Signal name	Controller type				
	LT300	LT400	DZ1000, DZ2000	DB1000	DB2000
	Terminal No.	Terminal No.	Terminal No.	Terminal No.	Terminal No.
SDA	11	11	19	14	28
SDB	12	12	20	15	29
RDA	13	13	21	12	26
RDB	14	14	22	13	27
SG	15	15	23	16	30

Signal name	Controller type							
	KP1000	KP2000		SE3000	AL3000 AH3000	JU	KE3000	LE5000
	Terminal No.	Terminal No.*2		Terminal name	Terminal name	Terminal No.	Terminal name	Terminal name
		A*3	C*3, F*3					
SDA	14	28	31	SDA	SDA	1	SDA	SDA
SDB	15	29	32	SDB	SDB	2	SDB	SDB
RDA	12	26	29	RDA	RDA	3	RDA	RDA
RDB	13	27	30	RDB	RDB	4	RDB	RDB
SG	16	30	28	SG	SG	5	SG	SG

*2 For KP2000 series, the terminal No. differs according to the model.

*3 This indicates the symbols of the position 10) (third zone) of the following models.

Model: KP2 4) 5) 6) 7) 8) 9) 10) – 12) 13) 14)


*4 Terminating resistor should be provided for a controller which will be a terminal.

*5 Set the terminating resistor of GOT side.

☞ Page 473 Connecting terminating resistors

*6 When connecting to DB1000 or DB200 Series, connect SG of the controller and SG of the GOT.

■RS422 connection diagram 3)



*1 Pin No. of controller differs depending on the model. Refer to the following table.

Signal name	Controller type				
	LT300	LT400	DZ1000, DZ2000	DB1000	DB2000
	Terminal No.	Terminal No.	Terminal No.	Terminal No.	Terminal No.
SDA	11	11	19	14	28
SDB	12	12	20	15	29
RDA	13	13	21	12	26
RDB	14	14	22	13	27
SG	15	15	23	16	30

Signal name	Controller type							
	KP1000	KP2000		SE3000	AL3000 AH3000	JU	KE3000	LE5000
	Terminal No.	Terminal No. *2		Terminal name	Terminal name	Terminal No.	Terminal name	Terminal name
		A *3	C *3, F *3					
SDA	14	28	31	SDA	SDA	1	SDA	SDA
SDB	15	29	32	SDB	SDB	2	SDB	SDB
RDA	12	26	29	RDA	RDA	3	RDA	RDA
RDB	13	27	30	RDB	RDB	4	RDB	RDB
SG	16	30	28	SG	SG	5	SG	SG

*2 For KP2000 series, the terminal No. differs according to the model.

*3 This indicates the symbols of the position 10) (third zone) of the following models.

Model: KP2 4) 5) 6) 7) 8) 9) 10) – 12) 13) 14)

*4 Terminating resistor should be provided for a controller which will be a terminal.

*5 Set the 2-wire/4-wire terminating resistor setting switch of the RS-232/485 signal conversion adaptor as shown below.

2-wire/4-wire: 4-wire (2 pairs)

Terminating resistor: 330Ω

☞ Page 67 Setting the RS-232/485 signal conversion adaptor

*6 When connecting to DB1000 or DB200 Series, connect SG of the controller and SG of the GOT.

Precautions when preparing a cable

■Cable length

The length of the RS-422 cable must be 1200m or less.

■GOT side connector

For the GOT side connector, refer to the following.

☞ Page 58 GOT connector specifications

■CHINO controller side connector

Use the connector compatible with the CHINO controller side module.

For details, refer to the user's manual of the CHINO controller.

Connecting terminating resistors

■GOT side

- For GT27, GT25(Except GT2505-V), GT23

Set the terminating resistor setting switch of the GOT main unit to "Enable".

- For GT2505-V

Set the terminating resistor selector to "330Ω".

For the procedure to set the terminating resistor, refer to the following.

☞ Page 62 Terminating resistors of GOT

■CHINO controller side


When connecting a CHINO controller to the GOT, a terminating resistor must be connected to the CHINO controller.

☞ User's Manual of the CHINO controller

RS-485 cable

Connection diagram

■RS485 connection diagram 1)



*1 Pin No. of controller differs depending on the model. Refer to the following table.

Signal name	Controller type						
	LT230	LT300	LT400	LT830	DZ1000, DZ2000	DB1000	DB2000
	Terminal No.	Terminal No.	Terminal No.	Terminal No.	Terminal No.	Terminal No.	Terminal No.
SA	6	11	11	6	19	12	26
SB	7	12	12	7	20	13	27
SG	8	15	15	8	23	14	28

Signal name	Controller type			
	KP1000	KP2000		AL3000 AH3000
	Terminal No.	Terminal No. ^{*2}		Terminal name
		S ^{*3} , E ^{*3} , F ^{*3} , G ^{*3}	D ^{*3} , G ^{*3}	
SA	12	26	29	SA
SB	13	27	30	SB
SG	14	28	31	SG

*2 For KP2000 series, the terminal No. differs according to the model.

*3 This indicates the symbols of the position 10) (third zone) of the following models.

Model: KP2 4) 5) 6) 7) 8) 9) 10) – 12) 13) 14)

For the symbol G, two terminal numbers are available. Select as necessary.


*4 Terminating resistor should be provided for a controller which will be a terminal.

*5 Set the terminating resistor of GOT side.

☞ Page 473 Connecting terminating resistors

*6 When connecting to DB1000 or DB200 Series, connect SG of the controller and SG of the GOT.

■RS485 connection diagram 2)



*1 Pin No. of controller differs depending on the model. Refer to the following table.

Signal name	Controller type						
	LT230	LT300	LT400	LT830	DZ1000, DZ2000	DB1000	DB2000
	Terminal No.	Terminal No.	Terminal No.	Terminal No.	Terminal No.	Terminal No.	Terminal No.
SA	6	11	11	6	19	12	26
SB	7	12	12	7	20	13	27
SG	8	15	15	8	23	14	28

Signal name	Controller type			
	KP1000	KP2000		AL3000 AH3000
	Terminal No.	Terminal No. ^{*2}		Terminal name
		S ^{*3} , E ^{*3} , F ^{*3} , G ^{*3}		
		D ^{*3} , G ^{*3}		
SA	12	26		SA
SB	13	27		SB
SG	14	28		SG

*2 For KP2000 series, the terminal No. differs according to the model.

*3 This indicates the symbols of the position 10) (third zone) of the following models.

Model: KP2 4) 5) 6) 7) 8) 9) 10) – 12) 13) 14)


For the symbol G, two terminal numbers are available. Select as necessary.

*4 Terminating resistor should be provided for a controller which will be a terminal.

*5 Set the Communication Type switch of the converter to RS-485.

*6 Do not connect SG of the controller and SG of the GOT.

■RS485 connection diagram 3)



*1 Pin No. of controller differs depending on the model. Refer to the following table.

Signal name	Controller type						
	LT230	LT300	LT400	LT830	DZ1000, DZ2000	DB1000	DB2000
	Terminal No.	Terminal No.	Terminal No.	Terminal No.	Terminal No.	Terminal No.	Terminal No.
SA	6	11	11	6	19	12	26
SB	7	12	12	7	20	13	27
SG	8	15	15	8	23	14	28

Signal name	Controller type			
	KP1000	KP2000		AL3000 AH3000
	Terminal No.	Terminal No. ^{*2}		Terminal name
		S ^{*3} , E ^{*3} , F ^{*3} , G ^{*3}	D ^{*3} , G ^{*3}	
SA	12	26	29	SA
SB	13	27	30	SB
SG	14	28	31	SG

*2 For KP2000 series, the terminal No. differs according to the model.

*3 This indicates the symbols of the position 10) (third zone) of the following models.

Model: KP2 4) 5) 6) 7) 8) 9) 10) – 12) 13) 14)

For the symbol G, two terminal numbers are available. Select as necessary.


*4 Terminating resistor should be provided for a controller which will be a terminal.

*5 Set the terminating resistor of GOT side.

☞ Page 473 Connecting terminating resistors

*6 When connecting to DB1000 or DB200 Series, connect SG of the controller and SG of the GOT.


■RS485 connection diagram 4)



*1 For details of the pin assignment, refer to the following manual.

☞ User's Manual of the CHINO controller

■RS485 connection diagram 5)




*1 Set the terminating resistor of GOT side.

☞ Page 473 Connecting terminating resistors

*2 For details of the pin assignment, refer to the following manual.

☞ User's Manual of the CHINO controller

■RS485 connection diagram 6)




*1 Set the terminating resistor of GOT side.

☞ Page 473 Connecting terminating resistors

*2 For details of the pin assignment, refer to the following manual.


☞ User's Manual of the CHINO controller

■RS485 connection diagram 7)




- *1 Set the terminating resistor of GOT side.
➡ Page 473 Connecting terminating resistors
- *2 For details of the pin assignment, refer to the following manual.
➡ User's Manual of the CHINO controller

■RS485 connection diagram 8)



- *1 Set the Communication Type switch of the converter to RS-485.
- *2 For details of the pin assignment, refer to the following manual.
➡ User's Manual of the CHINO controller

■RS485 connection diagram 9)



*1 Pin No. of controller differs depending on the model. Refer to the following table.

Signal name	Controller type			
	SE3000	JU	KE3000	LE5000
	Terminal name	Terminal No.	Terminal name	Terminal name
RDA	RDA	3	RDA	RDA
RDB	RDB	4	RDB	RDB
SDA	SDA	1	SDA	SDA
SDB	SDB	2	SDB	SDB
SG	SG	5	SG	SG


*2 Terminating resistor should be provided for a controller which will be terminating resistors.

*3 Set the terminating resistor of The GOT side.

☞ Page 473 Connecting terminating resistors

*4 Do not connect SG of the controller and SG of the GOT.

■RS485 connection diagram 10)




*1 Pin No. of controller differs depending on the model. Refer to the following table.

Signal name	Controller type			
	SE3000	JU	KE3000	LE5000
	Terminal name	Terminal No.	Terminal name	Terminal name
RDA	RDA	3	RDA	RDA
RDB	RDB	4	RDB	RDB
SDA	SDA	1	SDA	SDA
SDB	SDB	2	SDB	SDB
SG	SG	5	SG	SG

*2 Terminating resistor should be provided for a controller which will be terminating resistors.

*3 Set the Communication Type switch of the converter to RS-485.

■RS485 connection diagram 11)



*1 Pin No. of controller differs depending on the model. Refer to the following table.

Signal name	Controller type			
	SE3000	JU	KE3000	LE5000
	Terminal name	Terminal No.	Terminal name	Terminal name
RDA	RDA	3	RDA	RDA
RDB	RDB	4	RDB	RDB
SDA	SDA	1	SDA	SDA
SDB	SDB	2	SDB	SDB
SG	SG	5	SG	SG


*2 Terminating resistor should be provided for a controller which will be terminating resistors.

*3 Set the terminating resistor of The GOT side.

☞ Page 473 Connecting terminating resistors

*4 Do not connect SG of the controller and SG of the GOT.

■RS485 connection diagram 12)



*1 Pin No. of controller differs depending on the model. Refer to the following table.

Signal name	Controller type						
	LT230	LT300	LT400	LT830	DZ1000, DZ2000	DB1000	DB2000
	Terminal No.	Terminal No.	Terminal No.	Terminal No.	Terminal No.	Terminal No.	Terminal No.
SA	6	11	11	6	19	12	26
SB	7	12	12	7	20	13	27
SG	8	15	15	8	23	14	28

Signal name	Controller type			
	KP1000	KP2000		AL3000 AH3000
	Terminal No.	Terminal No. *2		Terminal name
		S *3, E *3, F *3, G *3		
		D *3, G *3		
SA	12	26		SA
SB	13	27		SB
SG	14	28		SG

*2 For KP2000 series, the terminal No. differs according to the model.

*3 This indicates the symbols of the position 10) (third zone) of the following models.

Model: KP2 4) 5) 6) 7) 8) 9) 10) - 12) 13) 14)

For the symbol G, two terminal numbers are available. Select as necessary.


*4 Terminating resistor should be provided for a controller which will be terminating resistors.

*5 Set the terminating resistor of The GOT side.

☞ Page 473 Connecting terminating resistors

*6 When connecting to DB1000 or DB200 Series, connect SG of the controller and SG of the GOT.

■RS485 connection diagram 13)



*1 Pin No. of controller differs depending on the model. Refer to the following table.

Signal name	Controller type			
	SE3000	JU	KE3000	LE5000
	Terminal name	Terminal No.	Terminal name	Terminal name
RDA	RDA	3	RDA	RDA
RDB	RDB	4	RDB	RDB
SDA	SDA	1	SDA	SDA
SDB	SDB	2	SDB	SDB
SG	SG	5	SG	SG

*2 Terminating resistor should be provided for a controller which will be terminating resistors.

*3 Set the terminating resistor of The GOT side.

☞ Page 473 Connecting terminating resistors

*4 Do not connect SG of the controller and SG of the GOT.

Precautions when preparing a cable

■Cable length

The maximum length of the RS-485 cable must be 1,200m or less.

■GOT side connector

For the GOT side connector, refer to the following.

☞ Page 58 GOT connector specifications

■CHINO controller side connector

Use the connector compatible with the CHINO controller side module.

For details, refer to the user's manual of the CHINO controller.

Connecting terminating resistors

■GOT side

- For GT27, GT25(Except GT2505-V), GT23

Set the terminating resistor setting switch of the GOT main unit to "Enable".

- For GT2505-V

Set the terminating resistor selector to "110Ω".

☞ Page 62 Terminating resistors of GOT

■CHINO controller side


When connecting a CHINO controller to the GOT, a terminating resistor must be connected to the CHINO controller.

☞ User's Manual of the CHINO controller

11.4 GOT Side Settings

Setting communication interface (Communication settings)

Set the channel of the equipment to be connected to the GOT.



1. Select [Common] → [Controller Setting] from the menu.
2. In the [Controller Setting] window, select the channel No. to be used from the list menu.
3. Set the following items.
 - [Manufacturer]: [CHINO]
 - [Controller Type]: [CHINO Controllers]
 - [I/F]: Interface to be used
 - [Detail Setting]: Configure the settings according to the usage environment.

☞ Page 484 Communication detail settings
4. When you have completed the settings, click the [OK] button.

Point

The settings of connecting equipment can be confirmed in [I/F Communication Setting].
For details, refer to the following.

☞ Page 47 I/F communication setting

Communication detail settings

Make the settings according to the usage environment.

Property	Value
Transmission Speed(BPS)	9600
Data Bit	8 bit
Stop Bit	1 bit
Parity	None
Retry(Times)	3
Timeout Time(Sec)	3
Host Address	1
Delay Time(ms)	5
Format	1

Item	Description	Range
Transmission Speed	Set this item when change the transmission speed used for communication with the connected equipment. (Default: 9600bps)	9600bps, 19200bps, 38400bps, 57600bps, 115200bps
Data Bit	Set this item when change the data length used for communication with the connected equipment. (Default: 8bits)	7bits/8bits
Stop Bit	Specify the stop bit length for communications. (Default: 1bit)	1bit/2bits
Parity	Specify whether or not to perform a parity check, and how it is performed during communication. (Default: None)	None Even Odd
Retry	Set the number of retries to be performed when a communication error occurs. (Default: 3times)	0 to 5times
Timeout Time	Set the time period for a communication to time out. (Default: 1sec)	1 to 30sec
Host Address	Specify the host address (station No. of the GOT to which the controller is connected) in the connected network. (Default: 1)	1 to 99
Delay Time	Set this item to adjust the transmission timing of the communication request from the GOT. (Default: 5ms)	0 to 300ms
Format	Select the communication format. (Default: 1) Format 1: Accessible to LT230/300/400/830, DZ1000/2000, Not accessible to GT120 Format 2: Accessible to GT120	1/2

Point

- Format

When connecting to GT120, specify format 2.

- Delay Time


When connecting to the following models, set the send delay time to 30ms or more.

Model name
DZ1000, DZ2000

- Communication interface setting by the Utility

The communication interface setting can be changed on the Utility's [Communication Settings] after writing [Communication Settings] of project data.

For details on the Utility, refer to the following manual.

 GOT2000 Series User's Manual (Utility)

- Precedence in communication settings

When settings are made by GT Designer3 or the Utility, the latest setting is effective.

11.5 Controller Side Setting



- CHINO controller

For details of CHINO controller, refer to the following manual.

☞ User's Manual of the CHINO controller

- Converter

For details on communication settings of the converter, refer to the following manual.

☞ User's Manual for converter

Model name		Refer to
Controller	LT230, LT300	☞ Page 485 Connecting to LT230, LT300 Series
	LT400, LT830	☞ Page 486 Connecting to LT400, LT830 Series
	DZ1000, DZ2000	☞ Page 486 Connecting to DZ1000, DZ2000 Series
	DB1000, DB2000	☞ Page 487 Connecting to DB1000, DB2000 Series
	GT120	☞ Page 487 Connecting to GT120 Series
	KP1000, KP2000	☞ Page 488 Connecting to KP1000, KP2000
	AL3000, AH3000	☞ Page 488 Connecting to AL3000, AH3000
	SE3000	☞ Page 489 Connecting to SE3000
	JU	☞ Page 490 Connecting to JU
	KE3000	☞ Page 491 Connecting to KE3000
	LE5000	☞ Page 492 Connecting to LE5000
Converter	SC8-10	☞ Page 493 Connecting to converter SC8-10

Connecting to LT230, LT300 Series

Key Lock setting

To write the Digital and the Analog parameters, set the Key Lock setting to Lock 4.

Communication settings

Set the communication settings with controller key operation.

Item	Set value
Protocol	rTU: MODBUS RTU
Function	Com: Upper communication
Station No.*1	1 to 99
Transmission speed*2	9600bps, 19200bps
Character*2 (Bit length, Parity bit, Stop bit)	5: 8bit, None, 1bit 6: 8bit, None, 2bit 7: 8bit, Even, 1bit 8: 8bit, Even, 2bit 9: 8bit, Odd, 1bit 10: 8bit, Odd, 2bit

*1 Avoid duplication of the station No. with any of the other units.

*2 Adjust the settings with GOT settings.

Connecting to LT400, LT830 Series

Key Lock setting

To write the Digital and the Analog parameters, set the following Key Lock setting

- LT400: Lock4
- LT830: Lock3

Communication settings

Set the communication settings with controller key operation.

Item	Set value
Protocol	rtU: MODBUS RTU
Function	Com: Upper communication
Station No.*1	1 to 99
Transmission speed*2	9600bps, 19200bps
Character*2 (Bit length, Parity bit, Stop bit)	8N1: 8bit, None, 1bit 8N2: 8bit, None, 2bit 8E1: 8bit, Even, 1bit 8E2: 8bit, Even, 2bit 8O1: 8bit, Odd, 1bit 8O2: 8bit, Odd, 2bit

*1 Avoid duplication of the station No. with any of the other units.

*2 Adjust the settings with GOT settings.

Connecting to DZ1000, DZ2000 Series

Key Lock setting

To write the Digital and the Analog parameters, set the Key Lock setting to Lock 2.

Communication settings

Set the communication settings with controller key operation.

Item	Set value
Protocol	rtU: MODBUS RTU
Function	Com: Upper communication
Station No.*1	1 to 31
Transmission speed*2	9600bps, 19200bps
Data bit	8bits (fixed)
Stop bit	1bit (fixed)
Parity bit	None (fixed)

*1 Avoid duplication of the station No. with any of the other units.

*2 Adjust the settings with GOT settings.

Connecting to DB1000, DB2000 Series

Communication settings

Set the communication settings with controller key operation.

Item	Set value
Protocol	MODBUS (RTU)
Function	Com: Upper communication
Station No.*1	01 to 99
Transmission speed*2	9600bps, 19200bps, 38400bps
Character	7BIT/EVEN/STOP1 7BIT/EVEN/STOP2 7BIT/ODD/STOP1 7BIT/ODD/STOP2 8BIT/NON/STOP1 8BIT/NON/STOP2 8BIT/EVEN/STOP1 8BIT/EVEN/STOP2 8BIT/ODD/STOP1 8BIT/ODD/STOP2

*1 Avoid duplication of the station No. with any of the other units.

*2 Adjust the settings with GOT settings.

Connecting to GT120 Series

Key Lock setting

To write the Digital and the Analog parameters, set the Key Lock setting to Lock 3.

Communication settings

Release the controller lock function in advance and set the following communication settings.

After completing the communication settings, set the Key Lock setting to Lock 3.

Item	Set value
Communication protocol	comr: MODBUS RTU
Station No.*1	1 to 95
Transmission speed*2	96: 9600bps 192: 19200bps
Data bit	8bits (fixed)
Stop bit*2	1bit, 2bits
Parity bit*2	nonE: None EVEN: Even odd: Odd

*1 Avoid duplication of the station No. with any of the other units.

*2 Adjust the settings with GOT settings.

Connecting to KP1000, KP2000

Key Lock setting

To write the Digital and the Analog parameters, set the Key Lock setting.

Communication settings

Set the communication settings with controller key operation.

Item	Set value
Protocol	MODBUS (RTU)
Function	COM
Station No.* ¹	1 to 99
Transmission speed* ²	2400bps, 4800bps, 9600bps, 19200bps, 38400bps
Character* ² (Bit length, Parity bit, Stop bit)	8BIT/NON/STOP1 8BIT/NON/STOP2 8BIT/EVEN/STOP1 8BIT/EVEN/STOP2 8BIT/ODD/STOP1 8BIT/ODD/STOP2

*¹ Avoid duplication of the station No. with any of the other units.

*² Adjust the settings with GOT settings.

Connecting to AL3000, AH3000

Key Lock setting

To write the Digital and the Analog parameters, set the Key Lock setting.

Communication settings

Set the communication settings with controller key operation.

Item	Set value
Protocol	MODBUS
Transmission code	rtu
Communication type	RS232C, RS-422A, RS-485
Station No.* ¹	1 to 31
Transmission speed* ²	2400bps, 4800bps, 9600bps, 19200bps
Character* ² (Bit length, Parity bit, Stop bit)	[8N1]: 8bit, None, 1bit [8N2]: 8bit, None, 2bit [8E1]: 8bit, Even, 1bit [8E2]: 8bit, Even, 2bit [8O1]: 8bit, Odd, 1bit [8O2]: 8bit, Odd, 2bit

*¹ Avoid duplication of the station No. with any of the other units.

*² Adjust the settings with GOT settings.

Connecting to SE3000

Key Lock setting

To write the Digital and the Analog parameters, set the Key Lock setting.

Communication settings


Make the communication settings using the engineering software package (PASS)

Item	Set value
Protocol	MODBUS RTU
Station No. *1*3	1 to 31
Transmission speed*2*3	9600bps, 19200bps
Data bit	8bits (fixed)
Parity bit*2	Even, Odd, Non
Stop bit*2	1bit, 2bits
Transmission code	Binary (fixed)
Error check	CRC-16 (fixed)

- *1 Avoid duplication of the station No. with any of the other units.
*2 Adjust the settings with GOT settings.
*3 Station No. and Transmission speed can also be set by switch SW1.

Setting by Switch (SW1)

Station No. and Transmission speed can be set.




■Station No.

SW1-1	SW1-2	SW1-3	SW1-4	SW1-5	Station No.
OFF	OFF	OFF	OFF	OFF	1
ON	OFF	OFF	OFF	OFF	1
OFF	ON	OFF	OFF	OFF	2
ON	ON	OFF	OFF	OFF	3
:					
:					
ON	OFF	ON	ON	ON	29
OFF	ON	ON	ON	ON	30
ON	ON	ON	ON	ON	31

■Transmission speed

SW1-6	SW1-7	communication port	Transmission speed
OFF	OFF	Upper communication	9600bps
OFF	ON	Upper communication	19200bps
ON	OFF	ENG	-
ON	ON	User setting inhibited	

Setting by Switch (SW2)



SW2	
Front side (Terminal side)	Rear side (DIN rail side)
RS232C	RS422A/485

Connecting to JU

Key Lock setting

To write the Digital and the Analog parameters, set the Key Lock setting.

Communication settings

Set the communication settings with controller key operation.

Item	Set value
Protocol	rtU
Station No.*1	1 to 99
Transmission speed*2	9600bps, 19200bps
Character*2 (Bit length, Parity bit, Stop bit)	[8N1]: 8bit, None, 1bit [8N2]: 8bit, None, 2bit [8E1]: 8bit, Even, 1bit [8E2]: 8bit, Even, 2bit [8O1]: 8bit, Odd, 1bit [8O2]: 8bit, Odd, 2bit

*1 Avoid duplication of the station No. with any of the other units.

*2 Adjust the settings with GOT settings.


Connecting to KE3000

Key Lock setting

To write the Digital and the Analog parameters, set the Key Lock setting.

Communication settings

Make the communication settings by operating the switches SW2 and SW3 of the module.



■Setting by SW2

Item	Set value	SW2-2	SW2-3
Transmission code ^{*2}	MODBUS RTU	OFF	-
Transmission speed ^{*1}	9600bps	-	OFF
	19200bps	-	ON
Transmission character structure ^{*2}	8bits, None, 1bit (fixed)	-	-

^{*1} Adjust the settings with GOT settings.

^{*2} When the transmission code is MODBUS RTU, the setting of the transmission character structure is fixed.

■Setting by SW3

Set the station No. as follows.

SW3-4	SW3-5	SW3-6	SW3-7	SW3-8	Station No. ^{*1}
OFF	OFF	OFF	OFF	OFF	1
ON	OFF	OFF	OFF	OFF	1
OFF	ON	OFF	OFF	OFF	2
ON	ON	OFF	OFF	OFF	3
:					
:					
ON	OFF	ON	ON	ON	29
OFF	ON	ON	ON	ON	30
ON	ON	ON	ON	ON	31

^{*1} Avoid duplication of the station No. with any of the other units.

Connecting to LE5000

Key Lock setting

To write the Digital and the Analog parameters, set the Key Lock setting.

Communication settings

Set the communication settings with controller key operation.

Item	Set value
RTU/ASCII	RTU
Station No.* ¹	1 to 99
Transmission speed* ²	9600bps, 19200bps
Character* ² (Bit length, Parity bit, Stop bit)	[8N1]: 8bit, None, 1bit [8N2]: 8bit, None, 2bit [8E1]: 8bit, Even, 1bit [8E2]: 8bit, Even, 2bit [8O1]: 8bit, Odd, 1bit [8O2]: 8bit, Odd, 2bit

*¹ Avoid duplication of the station No. with any of the other units.

*² Adjust the settings with GOT settings.

Connecting to converter SC8-10


Communication settings

Make the communication settings using setting switches.

Item	Set value
Transmission speed select switch ^{*1}	9600bps, 19200bps
Communication type switch	RS-485, RS-422

^{*1} Adjust the settings with GOT and controller settings.

Settings by switch



■Transmission speed setting



Setting item	Set value	Switch No.			
		1	2	3	4
Transmission speed	9600bps	OFF	ON	OFF	OFF
	19200bps	OFF	OFF	ON	OFF

■Communication type setting




RS-485 ↔ RS-422A

Setting item
RS-485/RS-422

Station number setting

Set each station number so that no station number overlaps.

The station number can be set without regard to the cable connection order. There is no problem even if station numbers are not consecutive.



Direct specification

When setting the device, specify the station number of the controller of which data is to be changed.

Model name	Specification range	Refer to
LT230, LT300, LT400, LT830	1 to 99	☞ Page 485 Connecting to LT230, LT300 Series ☞ Page 486 Connecting to LT400, LT830 Series
DZ1000, DZ2000	1 to 31	☞ Page 486 Connecting to DZ1000, DZ2000 Series
DB1000, DB2000	1 to 99	☞ Page 487 Connecting to DB1000, DB2000 Series
GT120	1 to 95	☞ Page 487 Connecting to GT120 Series
KP1000, KP2000	1 to 99	☞ Page 488 Connecting to KP1000, KP2000
AL3000, AH3000	1 to 31	☞ Page 488 Connecting to AL3000, AH3000
SE3000	1 to 31	☞ Page 489 Connecting to SE3000
JU	1 to 99	☞ Page 490 Connecting to JU
KE3000	1 to 31	☞ Page 491 Connecting to KE3000
LE5000	1 to 99	☞ Page 492 Connecting to LE5000

Indirect specification

When setting the device, indirectly specify the station number of the controller of which data is to be changed using the 16-bit GOT internal data register (GD10 to GD25).

When specifying the station No. from 100 to 115 on GT Designer3, the value of GD10 to GD25 compatible to the station No. specification will be the station No. of the controller.

Specification station NO.	Compatible device	Setting range
100	GD10	1 to 99: LT230, LT300, LT400, LT830, DB1000, DB2000, KP1000, KP2000, JU, LE5000 1 to 31: DZ1000, DZ2000, AL3000, AH3000, KE3000, SE3000 1 to 95: GT120 For the setting other than the above, error (dedicated device is out of range) will occur.
101	GD11	
102	GD12	
103	GD13	
104	GD14	
105	GD15	
106	GD16	
107	GD17	
108	GD18	
109	GD19	
110	GD20	
111	GD21	
112	GD22	
113	GD23	
114	GD24	
115	GD25	

All station specification

Target station differs depending on write-in operation or read-out operation.

- For write-in operation, all station will be a target.
- For read-out operation, only one station will be a target.
- All station specification is not available for KE3000. Do not use the all station specification for systems which include KE3000.

11.6 Device Range that Can Be Set

The device ranges of controller that can be used for GOT are as follows.


Note that the device ranges in the following tables are the maximum values that can be set in GT Designer3.

The device specifications of controllers may differ depending on the models, even though belonging to the same series.

Please make the setting according to the specifications of the controller actually used.

When a non-existent device or a device number outside the range is set, other objects with correct device settings may not be monitored.

Setting item



Item	Description	
Device	Set the device name, device number, and bit number. The bit number can be set only when specifying the bit of word device.	
Information	Displays the device type and setting range which are selected in [Device].	
Network	Set the monitor target of the set device.	
	All	Select this item when writing data to all controllers connected. During monitoring, the controller which is set for [Host Address] of the communication detail settings is monitored. (When inputting data with the numerical input function, data is written to all the connected controllers during input. The controller set for [Host Address] is monitored during other than input (displaying).)
	Station No.	Select this item when monitoring the controller of the specified station No. After selecting, set the station No. of the controller in the following range. 1 to 99: To monitor the controller of the specified station No. 100 to 115: To specify the station No. of the controller to be monitored by the value of GOT data register (GD). ^{*1}

^{*1} The following shows the relation between station numbers of the controller and the GOT data register.

Station No.	GOT data register (GD)	Setting range
100	GD10	1 to 99 (If setting a value outside the range above, a device range error occurs.)
101	GD11	
:	:	
114	GD24	
115	GD25	

Point

Device settings of CHINO controller

Devices are set with reference numbers.

For parameters corresponding to each reference number, refer to the manual of the controller to be used.

CHINO controller (CHINO Controllers)

Device name		Setting range	Device No. representation
Bit device	Digital parameter (0)	00001 to 09999	Decimal
	Digital input data (1)*1	10001 to 19999	
Word device	Analog input data (3)*1	30001 to 39999	Decimal
	Analog parameter (4)	40001 to 49999	

*1 Only reading is possible.

11.7 Precautions

Station number settings of temperature controller

In the system configuration, the controller with the station number set with the host address must be included.

For details of host address setting, refer to the following.

☞ Page 483 Setting communication interface (Communication settings)

GOT clock control

Since the controller does not have a clock function, the settings of [time adjusting] or [time broad cast] by GOT clock control will be disabled.

Disconnecting some of multiple connected equipment

The GOT can disconnect some of multiple connected equipment by setting GOT internal device. For example, the faulty station where a communication timeout error occurs can be disconnected from connected equipment.

For details of GOT internal device setting, refer to the following manual.





☞ GT Designer3 (GOT2000) Screen Design Manual

12 CONNECTION TO TOSHIBA PLC

- Page 499 Connectable Model List
- Page 500 Serial Connection
- Page 510 Ethernet Connection
- Page 516 Device Range that Can Be Set


12.1 Connectable Model List































The following table shows the connectable models.

Series	Model name	Clock	Communication Type	Connectable GOT	Refer to
PROSECT Series	T2 (PU224)	○	RS-422	<div>GT 27</div> <div>GT 25</div> <div>GT 23</div>	 Page 500 System configuration for connecting to PROSEC T series
	T3	○			
	T3H	○			
	T2E	○	RS-232 RS-422		
	T2N	○			
PROSECV Series	model 2000(S2)	○	RS-422	<div>GT 27</div> <div>GT 25</div> <div>GT 23</div>	 Page 502 System configuration for connecting to PROSEC V series
	model 2000(S2T)	○			
	model 2000(S2E)	○			
	model 3000 (S3)	○			
Unified Controller nv Series (Controller type1)	PU811	○	Ethernet	<div>GT 27</div> <div>GT 25</div> <div>GT 23</div>	 Page 510 System configuration for connecting to Unified Controller nv Series
Unified Controller nv Series (Controller type1 light)	PUM11	○	Ethernet	<div>GT 27</div> <div>GT 25</div> <div>GT 23</div>	 Page 510 System configuration for connecting to Unified Controller nv Series
	PUM12	○			
	PUM14	○			

12.2 Serial Connection


System configuration for connecting to PROSEC T series















PLC		Connection cable		GOT		Number of connectable equipment
Model name	Communication Type	Cable model Connection diagram number	Max. distance	Option device *1	Model	
T2 (PU224) T3 T3H	RS-422	GT09-C30R40501-15P(3m) GT09-C100R40501-15P(10m) GT09-C200R40501-15P(20m) GT09-C300R40501-15P(30m) or  RS422 connection diagram 1)	1km	- (Built into GOT)	  	1 GOT for 1 PLC
				GT15-RS4-9S	 	
T2E	RS-232	GT09-C30R40102-9P(3m) or  RS232 connection diagram 1)	15m	- (Built into GOT)	  	
				GT15-RS2-9P	 	
	RS-422	GT09-C30R40502-6C(3m) GT09-C100R40502-6C(10m) GT09-C200R40502-6C(20m) GT09-C300R40502-6C(30m) or  RS422 connection diagram 2)	1km	- (Built into GOT)	  	
				GT15-RS4-9S	 	
T2N	RS-232	GT09-C30R20502-15P(3m) or  RS232 connection diagram 2)	15m	- (Built into GOT)	  	
				GT15-RS2-9P	 	
	RS-422	GT09-C30R40503-15P(3m) GT09-C100R40503-15P(10m) GT09-C200R40503-15P(20m) GT09-C300R40503-15P(30m) or  RS422 connection diagram 3)	1km	- (Built into GOT)	  	
				GT15-RS4-9S	 	

*1 GT25-W, GT2505-V does not support the option device.

System configuration for connecting to PROSEC V series



PLC		Connection cable		GOT		Number of connectable equipment
Model name	Communication Type	Cable model Connection diagram number	Max. distance	Option device ^{*1}	Model	
model 2000 (S2) model 2000 (S2T) model 2000 (S2E)	RS-422	GT09-C30R40502-6C(3m) GT09-C100R40502-6C(10m) GT09-C200R40502-6C(20m) GT09-C300R40502-6C(30m) or  RS422 connection diagram 2)	1km	- (Built into GOT)	  	1 GOT for 1 PLC
				GT15-RS4-9S	 	
model 3000 (S3)	RS-422	GT09-C30R40501-15P(3m) GT09-C100R40501-15P(10m) GT09-C200R40501-15P(20m) GT09-C300R40501-15P(30m) or  RS422 connection diagram 1)	1km	- (Built into GOT)	  	
				GT15-RS4-9S	 	

*1 GT25-W, GT2505-V does not support the option device.


Connection Diagram

The following diagram shows the connection between the GOT and the PLC.


RS-232 cable

■Connection diagram

- RS232 connection diagram 1)



- RS232 connection diagram 2)



■Precautions when preparing a cable

- Cable length

The length of the RS-232 cable must be 15m or less.

- GOT side connector

For the GOT side connector, refer to the following.

☞ Page 58 GOT connector specifications

- TOSHIBA PLC side connector


Use the connector compatible with the TOSHIBA PLC.

For details, refer to the TOSHIBA PLC user's manual.


RS-422 cable

■ Connection diagram


- RS422 connection diagram 1)



- RS422 connection diagram 2)



- RS422 connection diagram 3)



■Precautions when preparing a cable

- Cable length

The length of the RS-422 cable must be 1km or less.

- GOT side connector

For the GOT side connector, refer to the following.

☞ Page 58 GOT connector specifications

- TOSHIBA PLC side connector

Use the connector compatible with the TOSHIBA PLC.

For details, refer to the TOSHIBA PLC user's manual.

■Setting terminating resistors

- GOT side

1) For GT27, GT25(Except GT2505-V), GT23

Set the terminating resistor setting switch of the GOT main unit to "Disable".

2) For GT2505-V

Set the terminating resistor selector to "330Ω".

For details of terminating resistor settings, refer to the following.

☞ Page 62 Terminating resistors of GOT

- TOSHIBA PLC side

When connecting an TOSHIBA PLC to a GOT, a terminating resistor must be set to the TOSHIBA PLC.

For the setting of the terminating resistor, refer to the following manual.

☞ TOSHIBA PLC user's Manual

T2 (PU224), T2N, T3, T3H, model 3000 (S3)

Connect the terminating resistor (1/2W-120Ω) across RXA and RXB.


T2E, model 2000 (S2, S2T)

Short across the RXA and TERM terminals.

GOT Side Settings

Setting communication interface (Communication settings)

Set the channel of the equipment to be connected to the GOT.



1. Select [Common] → [Controller Setting] from the menu.
2. In the [Controller Setting] window, select the channel No. to be used from the list menu.
3. Set the following items.
 - [Manufacturer]: [TOSHIBA]
 - [Controller Type]: [TOSHIBA PROSEC T/V]
 - [I/F]: Interface to be used
 - [Detail Setting]: Configure the settings according to the usage environment.

☞ Page 507 Communication detail settings

4. When you have completed the settings, click the [OK] button.

Point

The settings of connecting equipment can be confirmed in [I/F Communication Setting].
For details, refer to the following.

☞ Page 47 I/F communication setting

Communication detail settings

Make the settings according to the usage environment.

Property	Value
Transmission Speed(BPS)	9600
Data Bit	7 bit
Stop Bit	2 bit
Parity	Even
Retry(Times)	0
Timeout Time(Sec)	3
Delay Time(ms)	0

Item	Description	Range
Transmission Speed	Set this item when change the transmission speed used for communication with the connected equipment. (Default: 9600bps)	4800bps, 9600bps, 19200bps, 38400bps, 57600bps, 115200bps
Data Bit	Set this item when change the data length used for communication with the connected equipment. (Default: 7bits)	7bit, 8bit
Stop Bit	Specify the stop bit length for communications. (Default: 2bit)	1bit, 2bit
Parity	Specify whether or not to perform a parity check, and how it is performed during communication. (Default: Even)	None, Even, Odd
Retry	Set the number of retries to be performed when a communication error occurs. (Default: 0time)	0 to 5times
Timeout Time	Set the time period for a communication to time out. (Default: 3sec)	1 to 30sec
Delay Time	Set this item to adjust the transmission timing of the communication request from the GOT. (Default: 0ms)	0 to 300 (ms)

Point

- Communication interface setting by the Utility

The communication interface setting can be changed on the Utility's [Communication Settings] after writing [Communication Settings] of project data.

For details on the Utility, refer to the following manual.

☞ GOT2000 Series User's Manual (Utility)

- Precedence in communication settings

When settings are made by GT Designer3 or the Utility, the latest setting is effective.

PLC Side Setting



TOSHIBA PLC

For details of the TOSHIBA PLC, refer to the following manual.

☞ TOSHIBA PLC user's Manual


Model name		Refer to
PLC CPU	T2 (PU224), T2E, T2N	☞ Page 508 Connecting to T2 (PU224), T2E or T2N
	T3, T3H	☞ Page 509 Connecting to T3 or T3H
	model 2000 (S2, S2T, S2E), model 3000 (S3)	☞ Page 509 Connecting to model 2000 (S2, S2T, S2E), model 3000 (S3)

Connecting to T2 (PU224), T2E or T2N

■Switch setting

Set the switches accordingly.

- Operation mode setting switch



Switch No.	Settings	Setting details
4	OFF (fixed)	Computer link
5	OFF (fixed)	

- DIP switch on module PCB (T2N only)

Switch No.	Set value	
	For RS-232C communication	For RS-422 communication
DIP switch: No. 1	ON (RS-232C)	OFF (RS-485 ^{*1})

^{*1} Can be used as RS-422.

■Transmission parameter setting

Enter the transmission parameters.

Item	Set value
Transmission speed ^{*1*2*3}	4800bps, 9600bps, 19200bps
Data bit	7bit
Stop bit	2bit
Parity bit	Even
Station No.	1

^{*1} Indicates only the transmission speeds that can be set on the GOT side.

^{*2} Fixed to 9600bps for T2E only.

^{*3} The transmission speed setting must be consistent with that of the GOT side.

For the transmission speed setting on the GOT side, refer to the following.

☞ Page 506 Setting communication interface (Communication settings)

Connecting to T3 or T3H


Enter the transmission parameters.

Item	Set value
Transmission speed ^{*1*2}	4800bps, 9600bps, 19200bps
Data bit	7bit
Stop bit	2bit
Parity bit	Even
Station No.	1

*1 Indicates only the transmission speeds that can be set on the GOT side.

*2 The transmission speed setting must be consistent with that of the GOT side.

For the transmission speed setting on the GOT side, refer to the following.

 Page 506 Setting communication interface (Communication settings)

Connecting to model 2000 (S2, S2T, S2E), model 3000 (S3)

Enter the transmission parameters.


Item	Set value
Transmission method	RS485 ^{*1}
RS485	COM1
Timeout time	5sec
Transmission speed ^{*2*3}	4800bps, 9600bps, 19200bps
Data bit	7bit
Stop bit	2bit
Parity bit	Even
Station No.	1

*1 Can be used as RS-422.

*2 Indicates only the transmission speeds that can be set on the GOT side.


*3 The transmission speed setting must be consistent with that of the GOT side.

For the transmission speed setting on the GOT side, refer to the following.

 Page 506 Setting communication interface (Communication settings)

12.3 Ethernet Connection

System configuration for connecting to Unified Controller nv Series




PLC		Connection cable		GOT		Number of connectable equipment
Model name	Ethernet module ^{*3}	Cable model ^{*1}	Maximum segment length ^{*2}	Option device ^{*5}	Model	
PU811	EN811	Twisted pair cable ^{*1} • 10BASE-T Shielded twisted pair cable (STP) or unshielded twisted pair cable (UTP): Category 3, 4, and 5 • 100BASE-TX Shielded twisted pair cable (STP): Category 5 and 5e	100m	- (Built in the GOT)	GT 27 GT 25 GT 23	When PLC:GOT is N: 1 The number of PLCs for 1 GOT 32 or less When PLC:GOT is 1: N The number of GOTs for 1 PLC No limit number ^{*4}
				GT25-J71E71-100	GT 27 GT 25	
PUM11 ^{*6} PUM12 ^{*6} PUM14 ^{*6}	-			- (Built in the GOT)	GT 27 GT 25 GT 23	
				GT25-J71E71-100	GT 27 GT 25	

- ^{*1} The destination connected with the twisted pair cable varies with the configuration of the applicable Ethernet network system. Connect to the Ethernet module, hub, transceiver or other system equipment corresponding to the applicable Ethernet network system. Use cables, connectors, and hubs that meet the IEEE802.3 10BASE-T/100BASE-TX standard.
- ^{*2} A length between a hub and a node.
The maximum distance differs depending on the Ethernet device to be used.
The following shows the number of the connectable nodes when a repeater hub is used.
• 10BASE-T: Max. 4 nodes for a cascade connection (500m)
• 100BASE-TX: Max. 2 nodes for a cascade connection (205m)
When switching hubs are used, the cascade connection between the switching hubs has no logical limit for the number of cascades. For the limit, contact the switching hub manufacturer.
- ^{*3} Product manufactured by TOSHIBA Corporation. For details of the product, contact TOSHIBA Corporation.
- ^{*4} There is no restriction for the number of GOTs. However, if the number of GOTs increases, the communication becomes high-loaded, and it may affect the communication performance.
- ^{*5} GT25-W, GT2505-V does not support the option device.
- ^{*6} Use a CPU with firmware version V01.90 or later.
Use an nV-Tool with version V4.14.5 or later.

GOT side settings

Setting communication interface (Communication settings)

Set the channel of the equipment to be connected to the GOT.



12

1. Select [Common] → [Controller Setting] from the menu.
2. In the [Controller Setting] window, select the channel No. to be used from the list menu.
3. Set the following items.
 - [Manufacturer]: [TOSHIBA]
 - [Controller Type]: [TOSHIBA Unified Controller nv]
 - [I/F]: Interface to be used
 - [Detail Setting]: Configure the settings according to the usage environment.
4. When you have completed the settings, click the [OK] button.

Point

The settings of connecting equipment can be confirmed in [I/F Communication Setting].
For details, refer to the following.

Page 47 I/F communication setting


Communication detail settings

Make the settings according to the usage environment.

Property	Value
GOT Net No.	1
GOT Station	1
GOT Communication Port No.	5022
Retry(Times)	3
Startup Time(Sec)	3
Timeout Time(Sec)	3
Delay Time(ms)	0

Item	Description	Range
GOT Net No.	Set the network No. of the GOT. (Default: 1)	1 to 239
GOT Station*1	Set the station No. of the GOT. (Default: 1)	1 to 254
GOT Communication Port No.	Set the GOT port No. for the connection with the Ethernet module. (Default: 5022*2)	1024 to 5010, 5014 to 65534 (Except for 5011 to 5013 and 49153 to 49170)
Retry	Set the number of retries to be performed when a communication timeout occurs. When receiving no response after retries, the communication times out. (Default: 3times)	0 to 5times
Startup Time	Specify the time period from the GOT startup until GOT starts the communication with the PLC CPU. (Default: 3sec)	3 to 255sec
Timeout Time	Set the time period for a communication to time out. (Default: 3sec)	1 to 90sec
Delay Time	Set the delay time for reducing the load of the network/destination PLC. (Default: 0ms)	0 to 10000 (ms)

*1 Set different values for [GOT Station] of [Detail Setting] and [Station] of [Connected Ethernet Controller Setting].

 Page 513 Connected Ethernet Controller Setting

*2 When assigning the same driver to the multiple channels, in the communication drivers set as the second and following, the default value of [GOT Communication Port No.] becomes the earliest number in the vacant numbers of No. 6000 and later.

GOT Ethernet Setting

The GOT can be connected to a different network by configuring the following setting.

■GOT IP address setting

Set the following communication port setting.

- Standard port (When using GT25-W, port 1)
- Extension port (When using GT25-W, port 2)

■GOT Ethernet common setting

Set the following setting which is common to the standard port and the extension port, or port 1 and port 2.

- [Default Gateway]
- [Peripheral S/W Communication Port No.]
- [Transparent Port No.]


■IP filter setting

By configuring the IP filter setting, the access from the specific IP address can be permitted or shut off.

For the detailed settings, refer to the following manual.

 Page 43 GOT Ethernet Setting

Connected Ethernet Controller Setting



12

Item	Description	Set value
Host	The host is displayed. (The host is indicated with an asterisk (*).)	-
Net No.	Set the network No. of the connected Ethernet module. (Default: 1)	1 to 239
Station ^{*1}	Set the station No. of the connected Ethernet module. (Default: 1)	1 to 254
Unit Type	TOSHIBA (fixed)	TOSHIBA (fixed)
IP Address	Set the IP address of the connected Ethernet module. (Default: 172.16.64.1)	PLC side IP address
Port No.	Set the port No. of the connected Ethernet module. (Default: 1024)	1024 to 65534
Communication format	UDP (fixed)	UDP (fixed)

^{*1} Set different values for [GOT Station] of [Detail Setting] and [Station] of [Connected Ethernet Controller Setting].

☞ Page 512 Communication detail settings

Point

- Communication interface setting by the Utility

The communication interface setting can be changed on the Utility's [Communication setting] after writing [Communication Settings] of project data.

For details on the Utility, refer to the following manual.

☞ GOT2000 Series User's Manual (Utility)

- Precedence in communication settings

When settings are made by GT Designer3 or the Utility, the latest setting is effective.

PLC side setting




TOSHIBA PLC

For details of TOSHIBA PLCs, refer to the following manual.

TOSHIBA PLC user's Manual

Setting of EN811



■Station No. setting switch

The station No. setting switches are hexadecimal rotary switches that determine the station No. on the Ethernet network. Set the station address (1 to 254) that has been assigned upon system configuration in a HEX code. Assign an address with a different value to each of the nodes in the system.

Switch name	Setting details	Setting range
STN-H	Upper address : 0 to F (Hex.)	01 to FE (Hex.)
STN-L	Lower address : 0 to F (Hex.)	

■Operation mode setting switch

- Operation mode

Switch No.	Settings		
1	OFF	ON	OFF
2	OFF	OFF	ON
3	OFF	OFF	OFF
Operation mode	Normal	For maintenance	

Switch No.	Settings
4	Not in use
5	

- IP address type

Switch No.	Settings			
6	OFF	OFF	OFF	ON
7	OFF	ON	OFF	ON
8	OFF	OFF	ON	ON
Operation mode	Class B 172.16.64.XX	Reserved	Class C 192.168.0.XX	Tool setting

- Class B 172.16.64.XX

XX indicates the value of the station No. setting switches.

Subnet mask : 255.255.192.0

- Class B 192.168.0.XX

XX indicates the value of the station No. setting switches.

Subnet mask : 255.255.255.0

- Tool setting

It can be set freely from the engineering tool, and the value has precedence over the value of the station No. setting switches.

Setting of PUM11, PUM12, and PUM14

Configure the communication setting of the PLC from the engineering tool nV-Tool V4.14.5 or later.

Set [Computer Link Write Mode] to [Asynchronization].

Precautions

Delay of device communication

Note that if a non-existent station, or a station which power is turned OFF is monitored, the communication of normal stations is also delayed.

Redundant system

When configuring a redundant system, the "Multicast address setting" for the configured PLC pair (System A: Primary, System B: Secondary) is required.

12.4 Device Range that Can Be Set

The device ranges of controller that can be used for GOT are as follows.

Note that the device ranges in the following tables are the maximum values that can be set in GT Designer3.

The device specifications of controllers may differ depending on the models, even though belonging to the same series.

Please make the setting according to the specifications of the controller actually used.

When a non-existent device or a device number outside the range is set, other objects with correct device settings may not be monitored.

Setting item

TOSHIBA PROSEC T/V Series


TOSHIBA Unified Controller nv Series

Item	Description	
Device	Set the device name, device number, and bit number. The bit number can be set only when specifying the bit of word device.	
Information	Displays the device type and setting range which are selected in [Device].	
Network	Set the station number of the controller to be monitored.	
	Host	Select this item for monitoring the host controller.
	Other	Select this for monitoring other controllers. After selecting the item, set the station number of the controller to be monitored. NW No.: Set the network No. Station No.: Set the station No.

- Device settings of TOSHIBA PLC

When setting a relay as a bit device


Set the device using the format of word address (DEC) + bit address (HEX).



When setting a relay as a word device

Set the device using the format of word address (DEC).

For the device name setting, enter "w" before the bit device name.



- Notation of device address (when using PROSEC V series)

The notation of device address setting is different between the TOSHIBA PLC peripheral software and GOT.

For the difference of notations between peripheral softwares and GOT, refer to the following.

☞ Page 518 TOSHIBA PLC (TOSHIBA PROSEC T/V Series)

TOSHIBA PLC (TOSHIBA PROSEC T/V Series)

Device name		Setting range	Device No. representation
Bit device	External input (X)	X0000 to X511F	Hexadecimal
	External output (Y)	Y0000 to Y511F	
	Internal relay (R) ^{*7}	R0000 to R4095F	
	Special relay (S) ^{*7}	S0000 to S511F	
	Link register relay (Z)	Z0000 to Z999F	
	Link relay (L)	L0000 to L255F	
	Timer (Contact) (T) ^{*1}	T0 to T999	Decimal
	Counter (Contact) (C) ^{*1}	C0 to C511	
	The bit specification of the word device ^{*2*5*7} (except external input, external output, internal relay, special relay link relay, timer and counter)	Setting range of each word device	-
Word device	External input (XW)	XW0 to XW511	Decimal
	External output (YW)	YW0 to YW511	
	Internal relay (RW) ^{*6*8}	RW0 to RW4095	
	Special relay (SW) ^{*8}	SW0 to SW511	
	Link relay (LW)	LW0 to LW255	
	Timer (Current value) (T) ^{*1}	T0 to T999	
	Counter (Current value) (C) ^{*1}	C0 to C511	
	Data register (D) ^{*3*6*8}	D0 to D8191	
	Link register (W)	W0 to W2047	
	File register (F) ^{*4}	F0 to F32767	

PROSEC T Series

- *1 The writing of the timer (contact)/(current value) and counter (contact)/(current value) are executed after being read by the GOT. Therefore, do not edit it in the sequence program during this period.
- *2 As bit specification of a word device is performed after the GOT reads the value, do not change the value in the sequence program during this period.
- *3 When the mode switch on the CPU module is set to "P-RUN", writing to D0000 through D4095 is disabled.
- *4 Extension file register is not supported.

PROSEC V Series

- *5 As bit specification of a word device is performed after the GOT reads the value, do not change the value in the sequence program during this period.
- *6 RW0000 and D0000 indicate the data register in the same region although they are shown in different notations.
- *7 For bit data, the conversion from the address notation for the TOSHIBA PLC to that for the GOT is shown as follows.
Address notation for TOSHIBA PLC ÷ 16=Word address (Quotient)...Bit address (Remainder)

Address notation for TOSHIBA PLC	Address notation for GOT	Conversion
S8191	S511F (Decimal) (Hexadecimal)	8191÷16= 511...15
R65535	R4095F (Decimal) (Hexadecimal)	65535÷16= 4095...15

- *8 For word data, the conversion from the address notation for the TOSHIBA PLC to that for the GOT is shown as follows.

Communication format		Address notation for TOSHIBA PLC	Address notation for GOT
16bit data		DW10	D10
32bit data	(Integer)	DD10 (Calculate the device No. in 32-bit unit)	D20
	(Real number)	DF10 (Calculate the device No. in 32-bit unit)	D20

TOSHIBA PLC (Unified Controller nv Series)

Device name		Setting range	Device No. representation
Bit device	External input (X)	X000000 to X16383F	Decimal+Hexadecimal
	External input (X)	Y000000 to Y16383F	
	Internal relay (R)	R00000 to R8191F	
	Input variable (I)	I000000 to I16383F	
	Output variable (Q)	Q000000 to Q16383F	
	Special relay (S)	S00000 to S1023F	
Word device	External input (XW)	XW0 to XW16383	Decimal
	External output (YW)	YW0 to YW16383	
	Internal relay (RW)	RW0 to RW8191	
	Special relay (SW)	SW0 to SW1023	
	Data register (D)	D0 to D8191	Decimal
	File register (F)	F0 to F32767	
	Input variable (IW)	IW0 to IW16383	
	Output variable (QW)	QW0 to QW16383	
	User global (UG)	UG0 to UG262143	



MEMO

13 CONNECTION TO TOSHIBA MACHINE PLC

- Page 521 Connectable Model List
- Page 522 System Configuration
- Page 524 Connection Diagram
- Page 530 GOT Side Settings
- Page 532 PLC Side Setting
- Page 533 Device Range that Can Be Set


13.1 Connectable Model List

The following table shows the connectable models.

Series	Model name	Clock	Communication Type	Connectable GOT	Refer to
TCmini Series	TC3-01	○	RS-232	<div>GT27GT25GT23GT21GS</div>	 Page 522 Connecting to TC3, TC5, TC6, TC8
	TC3-02	○			
	TC6-00	○			
	TC8-00	○			
	TC5-02	×	RS-485		
	TC5-03	×			
Robot controller	TS2000	×	RS-232	<div>GT27GT25GT23GT21GS</div>	 Page 523 Connecting to TS2000, TS2100
	TS2100	×			

13.2 System Configuration

Connecting to TC3, TC5, TC6, TC8



PLC		Connection cable		GOT		Number of connectable equipment
Model name	Communication Type	Cable model Connection diagram number	Max. distance	Option device ^{*3*4}	Model	
TC3,TC6,TC8	RS-232	(User preparing) Page 524 RS232 connection diagram 1)	15m	- (Built into GOT)	<div>GT 27</div> <div>GT 23</div> <div>GT 21</div> <div>GT 25</div> <div>GT 21</div> <div>GS</div>	1 GOT for 1 PLC
				GT15-RS2-9P	<div>GT 27</div> <div>GT 25</div>	
				GT10-C02H-6PT9P ^{*1}	<div>GT 27</div> <div>GT 23</div> <div>GT 21</div> <div>GT 25</div> <div>GT 21</div> <div>GS</div>	
		(User preparing) Page 524 RS232 connection diagram 3)	15m	- (Built into GOT)	<div>GT 27</div> <div>GT 23</div> <div>GT 21</div> <div>GT 25</div> <div>GT 21</div> <div>GS</div>	
TC5	RS-485	(User preparing) Page 526 RS485 connection diagram 1)	400m	- (Built into GOT)	<div>GT 27</div> <div>GT 23</div> <div>GT 21</div> <div>GT 25</div> <div>GT 21</div> <div>GS</div>	
		(User preparing) Page 527 RS485 connection diagram 2)		- (Built into GOT)	<div>GT 27</div> <div>GT 23</div> <div>GT 21</div> <div>GT 25</div> <div>GT 21</div> <div>GS</div>	
		(User preparing) Page 528 RS485 connection diagram 3)		FA-LTBGT2R4CBL05(0.5m) ^{*2} FA-LTBGT2R4CBL10(1m) ^{*2} FA-LTBGT2R4CBL20(2m) ^{*2}	<div>GT 27</div> <div>GT 23</div> <div>GT 21</div> <div>GT 25</div> <div>GT 21</div> <div>GS</div>	


*1 When a GT10-C02H-6PT9P unit of the sub version A or B is used, do not ground the case of the D-sub (9-pin) connector.

*2 Product manufactured by MITSUBISHI ELECTRIC ENGINEERING COMPANY LIMITED. For details of the product, contact MITSUBISHI ELECTRIC ENGINEERING COMPANY LIMITED.

*3 GT25-W is not compatible to the option devices other than FA-LTBGT2R4CBL□□.

*4 GT2505-V does not support the option device.

Connecting to TS2000, TS2100



Robot controller		Connection cable		GOT		Number of connectable equipment
Model name	Communication Type	Cable model Connection diagram number	Max. distance	Option device ^{*2}	Model	
TS2000 TS2100 (POD port)	RS-232	(User preparing) Page 524 RS232 connection diagram 2)	15m	- (Built into GOT)	<div>GT 27</div> <div>GT 25</div> <div>GT 23</div> <div>GT 21</div> <div>GT 21</div> <div>GS</div>	1 GOT for 1 robot controller
				GT15-RS2-9P	<div>GT 27</div> <div>GT 25</div>	
				GT10-C02H-6PT9P ^{*1}	<div>GT 21</div> <div>GT 21</div> <div>GT 21</div> <div>GT 21</div> <div>GT 21</div> <div>GT 21</div>	
		(User preparing) Page 525 RS232 connection diagram 4)	15m	- (Built into GOT)	<div>GT 21</div> <div>GT 21</div> <div>GT 21</div> <div>GT 21</div> <div>GT 21</div> <div>GT 21</div>	

*1 When a GT10-C02H-6PT9P unit of the sub version A or B is used, do not ground the case of the D-sub (9-pin) connector.

*2 GT25-W, GT2505-V does not support the option device.


13.3 Connection Diagram

The following diagram shows the connection between the GOT and the PLC.


RS-232 cable

Connection diagram


■RS232 connection diagram 1)




■RS232 connection diagram 2)



■RS232 connection diagram 3)



■RS232 connection diagram 4)



Precautions when preparing a cable

■Cable length

The length of the RS-232 cable must be 15m or less.

■GOT side connector

For the GOT side connector, refer to the following.

☞ Page 58 GOT connector specifications

■TOSHIBA MACHINE PLC side connector


Use the connector compatible with the TOSHIBA MACHINE PLC side module.

For details, refer to the TOSHIBA MACHINE PLC user's manual.

RS-485 cable

Connection diagram

■RS485 connection diagram 1)



*1 Pin No. of PLC side differs depending on the model. Refer to the following table.

Signal name	Model of PLC			
	TC5-02		TC5-03	
	CN24A	CN24B	CN14	CN18
	Pin No.	Pin No.	Pin No.	Pin No.
A	1	1	3	3
B	2	2	4	4
GND	3	3	5	5

*2 For the PLC side terminating resistor, refer to the following.


☞ PLC user's Manual to be used

*3 Set the terminating resistor of GOT side which will be a terminal.

For GT27, GT25(Except GT2505-V), GT23: Set the terminating resistor "Enable".For GT2505-V, GT21: Set the terminating resistor "110Ω".

☞ Page 62 Terminating resistors of GOT

■RS485 connection diagram 2)



*1 Pin No. of PLC side differs depending on the model. Refer to the following table.

Signal name	Model of PLC			
	TC5-02		TC5-03	
	CN24A	CN24B	CN14	CN18
	Pin No.	Pin No.	Pin No.	Pin No.
A	1	1	3	3
B	2	2	4	4
GND	3	3	5	5

*2 For the PLC side terminating resistor, refer to the following.


☞ PLC user's Manual to be used

*3 Set the terminating resistor of GOT side, which will be a terminal, to "110Ω".

☞ Page 62 Terminating resistors of GOT

*4 The signals RSA, RSB, CSA, and CSB are not provided for GT2104-PMBD, GT2103-PMBD.

■RS485 connection diagram 3)



*1 Pin No. of PLC side differs depending on the model. Refer to the following table.

Signal name	Model of PLC			
	TC5-02		TC5-03	
	CN24A	CN24B	CN14	CN18
	Pin No.	Pin No.	Pin No.	Pin No.
A	1	1	3	3
B	2	2	4	4
GND	3	3	5	5

*2 For the PLC side terminating resistor, refer to the following.

☞ PLC user's Manual to be used

*3 Set the terminating resistor of GOT side, which will be a terminal, to "110Ω".

☞ Page 62 Terminating resistors of GOT


Precautions when preparing a cable

■Cable length

The length of the RS-485 cable must be 400m or less.

■GOT side connector

For the GOT side connector, refer to the following.

 Page 58 GOT connector specifications

■PLC side connector

Use the connector compatible with the PLC side.

For details, refer to the PLC user's Manual to be used.

Connecting terminating resistors

■GOT side

When connecting a PLC to the GOT, a terminating resistor must be connected to the GOT.


- For GT27, GT25(Except GT2505-V), GT23

Set the terminating resistor using the terminating resistor setting switch.

- For GT2505-V, GT21

Set the terminating resistor using the terminating resistor selector.

For the procedure to set the terminating resistor, refer to the following.

 Page 62 Terminating resistors of GOT

■PLC side


When connecting a PLC to the GOT, a terminating resistor must be connected to the PLC.

For details, refer to the PLC user's Manual to be used.

13.4 GOT Side Settings

Setting communication interface (Communication settings)

Set the channel of the equipment to be connected to the GOT.



1. Select [Common] → [Controller Setting] from the menu.
 2. In the [Controller Setting] window, select the channel No. to be used from the list menu.
 3. Set the following items.
 - [Manufacturer]: [TOSHIBA MACHINE]
 - [Controller Type]: [TOSHIBA MACHINE TCmini]
 - [I/F]: Interface to be used
 - [Detail Setting]: Configure the settings according to the usage environment.
- ☞ Page 531 Communication detail settings
4. When you have completed the settings, click the [OK] button.

Point

The settings of connecting equipment can be confirmed in [I/F Communication Setting].
For details, refer to the following.

☞ Page 47 I/F communication setting

Communication detail settings

Make the settings according to the usage environment.

Property	Value
Transmission Speed(BPS)	9600
Data Bit	8 bit
Stop Bit	2 bit
Parity	None
Retry(Times)	3
Timeout Time(Sec)	3
Host Address	0
Delay Time(ms)	0

Item	Description	Range
Transmission Speed	Set this item when change the transmission speed used for communication with the connected equipment. (Default: 9600bps)	9600bps, 19200bps, 38400bps, 57600bps, 115200bps
Data Bit	Set this item when change the data length used for communication with the connected equipment. (Default: 8bit)	7bits/8bits
Stop Bit	Specify the stop bit length for communications. (Default: 2bits)	1bit/2bits
Parity	Specify whether or not to perform a parity check, and how it is performed during communication. (Default: None)	None Even Odd
Retry	Set the number of retries to be performed when a communication error occurs. (Default: 3times)	0 to 5times
Timeout Time	Set the time period for a communication to time out. (Default: 3sec)	1 to 30sec
Host Address	Specify the host address (station No. of the GOT to which the PLC is connected) in the connected network. (Default: 0)	0 to 63
Delay Time	Set this item to adjust the transmission timing of the communication request from the GOT. (Default: 0ms)	0 to 300 (ms)

13

Point

• Delay Time

When connecting to the PLC and RS-485, set the delay time to 1ms or more.

• Communication interface setting by the Utility

The communication interface setting can be changed on the Utility's [Communication Settings] after writing [Communication Settings] of project data.

For details on the Utility, refer to the following manual.

 GOT2000 Series User's Manual (Utility)

• Precedence in communication settings

When settings are made by GT Designer3 or the Utility, the latest setting is effective.

13.5 PLC Side Setting



TOSHIBA MACHINE PLC

For details of the TOSHIBA MACHINE PLC, refer to the following manual.

☞ TOSHIBA MACHINE PLC user's Manual

Model name		Refer to
PLC CPU	TC3, TC8	☞ Page 532 Connecting to TC3, TC8 series
	TC5	☞ Page 532 Connecting to TC5 series
	TC6	☞ Page 532 Connecting to TC6 series
Robot controller	TS2000, TS2100	☞ Page 532 Connecting to TS2000, TS2100

Connecting to TC3, TC8 series

No communication settings.

Communication is available using default value of the PLC.

Connecting to TC5 series

The setting of transmission speed is changeable.

Set the following Generic register 1(D) using engineering tool.

The communication may not work properly if the settings are made using the GOT.

Generic register	Description	Set value
D37F	Mode setting	3: Host communication connection mode
D37E	Transmission speed*1	0:9600bps1:19200bps2:38400bps
-	Data bit	8bits (fixed)
-	Parity bit	None (fixed)
-	Stop bit	2bits (fixed)

*1 Adjust the settings with GOT settings.

For the transmission speed setting on the GOT side, refer to the following.

☞ Page 530 Setting communication interface (Communication settings)

Connecting to TC6 series

The setting of transmission speed is changeable.

Set the following Special AUX Relay(A) using engineering tool.

The communication may not work properly if the settings are made using the GOT.

Transmission speed*1	Special AUX Relay		
	A158	A159	A15A
9600bps	OFF	OFF	OFF
19200bps	ON	OFF	OFF
38400bps	-	ON	OFF
57600bps	-	OFF	ON
115200bps	-	ON	ON

*1 The transmission speed setting must be consistent with that of the GOT side.

For the transmission speed setting on the GOT side, refer to the following.

☞ Page 530 Setting communication interface (Communication settings)

Connecting to TS2000, TS2100

No communication settings.

Communication is available using the default value of the robot controller.

13.6 Device Range that Can Be Set

The device ranges of controller that can be used for GOT are as follows.


Note that the device ranges in the following tables are the maximum values that can be set in GT Designer3.

The device specifications of controllers may differ depending on the models, even though belonging to the same series.

Please make the setting according to the specifications of the controller actually used.

When a non-existent device or a device number outside the range is set, other objects with correct device settings may not be monitored.


Setting item



Item	Description
Device	Set the device name, device number, and bit number. The bit number can be set only when specifying the bit of word device.
Information	Displays the device type and setting range which are selected in [Device].

Point


- Device settings for TOSHIBA MACHINE PLC
- When setting relay address or word register address as bit device
- Set the device No. with the rack No. (Hex), module position (Octal), and terminal No. (Hex), in that order.



When setting a relay address as a word device

Set the device No. with the rack No. (Hex) and module position (Octal), in that order.

For the device name setting, enter "w" before the bit device name.



TOSHIBA MACHINE PLC (TOSHIBA MACHINE TCmini)



Device name		Setting range	Device No. representation
Bit device	Input relay 1 (X)	X000 to XF7F	Hexadecimal + Octal + Hexadecimal
	Input relay 2 (I)	I000 to IF7F	
	Output relay 1 (Y)	Y000 to YF7F	
	Output relay 1 (O)	O000 to OF7F	
	Internal relay (R)	R000 to R77F	
	Extended internal relay 1 (GR)	GR000 to GRF7F	
	Extended internal relay 2 (H)	H000 to HF7F	
	Extended internal relay 3 (J)	J000 to JF7F	
	Extended internal relay 4 (K)	K000 to KF7F	
	Timer (Contact) (T)	T000 to T77F	
	Counter (Contact) (C)	C000 to C77F	
	Shift relay (S)	S000 to S07F	
	Latch relay (L)	L000 to L07F	
	Edge relay (E)	E000 to E77F	
	Special auxiliary relay (A)	A000 to A16F	
Word device	Input register 1 (XW)	XW00 to XWF7	Hexadecimal + Octal
	Input register 2 (IW)	IW00 to IWF7	
	Output register 1 (YW)	YW00 to YWF7	
	Output register 2 (OW)	OW00 to OWF7	
	Internal register (RW)	RW00 to RW77	
	Extended internal register 1 (GW)	GW00 to GWF7	
	Extended internal register 2 (HW)	HW00 to HWF7	
	Extended internal register 3 (JW)	JW00 to JWF7	
	Extended internal register 4 (KW)	KW00 to KWF7	
	Timer (Contact) register (TW)	TW00 to TW77	
	Counter (Contact) register (CW)	CW00 to CW77	
	Shift register (SW)	SW00 to SW07	
	Latch register (LW)	LW00 to LW07	
	Edge register (EW)	EW00 to EW77	
	Special auxiliary register (AW)	AW00 to AW16	Hexadecimal + Octal + Hexadecimal
	Generic register 1 (D)	D000 to DF7F	
	Generic register 2 (B)	B000 to BF7F	
	Generic register 3 (U)	U000 to UF7F	
	Generic register 4 (M)	M000 to MF7F	
	Generic register 5 (Q)	Q000 to QF7F	
	Timer/Counter current value (P)	P000 to P77F	
	Timer/Counter set value (V)	V000 to V77F+	

14 CONNECTION TO PANASONIC SERVO AMPLIFIER

- Page 535 Connectable Model List
- Page 536 System Configuration
- Page 538 Connection Diagram
- Page 544 GOT Side Settings
- Page 546 Servo Amplifier Side Setting
- Page 548 Device Range that Can Be Set
- Page 551 Precautions


14.1 Connectable Model List

The following table shows the connectable models.

Model name	Clock	Communication Type	Connectable GOT	Refer to
MINAS A4	×	RS-232	<div>GT</div> <div>27</div> <div>GT</div> <div>25</div> <div>GT</div> <div>23</div>	 Page 536 Connecting to MINAS A4, MINAS A4F, MINAS A4L series
MINAS A4F	×	RS-485		
MINAS A4L	×			
MINAS A5				 Page 537 Connecting to MINAS A5 series

14.2 System Configuration

Connecting to MINAS A4, MINAS A4F, MINAS A4L series




Servo amplifier		Connection cable 1)	Servo amplifier		Connection cable 2)		GOT		Max. total distance	Number of connectable equipment
Model name	Communication Type	Cable model*1	Model name	Communication Type	Cable model Connection diagram number	Max. distance	Option device*2*3	Model		
MINAS A4 MINAS A4F MINAS A4L	RS-485	DVOP1970(0.2m) DVOP1971(0.5m) DVOP1972(1m)	MINAS A4 MINAS A4F MINAS A4L	RS-232	DVOP1960*1 or (User preparing) Page 538 RS-232 connection diagram 1)	2m	- (Built into GOT)	GT 27 GT 25 GT 23	17m	16 servo amplifiers for 1 GOT
							GT15-RS2-9P	GT 27 GT 25		
	RS-485	DVOP1970(0.2m) DVOP1971(0.5m) DVOP1972(1m)	MINAS A4 MINAS A4F MINAS A4L	RS-485	(User preparing) Page 539 RS-485 connection diagram 2)	1m	GT15-RS4-TE	GT 27 GT 25	16m	15 servo amplifiers for 1 GOT
					(User preparing) Page 540 RS-422 connection diagram 3)	1m	FA-LTBGT2R4CBL05 (0.5m) FA-LTBGT2R4CBL10 (1m) FA-LTBGT2R4CBL20 (2m)	GT 27 GT 25 GT 23		
					(User preparing) Page 540 RS-422 connection diagram 4)	1m	- (Built into GOT)	GT 27 GT 25 GT 23		
							GT15-RS4-9S	GT 27 GT 25		

*1 The link unit is a product manufactured by PANASONIC Corporation. For details of this product, contact PANASONIC Corporation.

*2 GT25-W is not compatible to the option devices other than FA-LTBGT2R4CBL□□.

*3 GT2505-V does not support the option device.

Connecting to MINAS A5 series



Servo amplifier		Connection cable 1)		GOT		Max. total distance	Number of connectable equipment
Model name	Communication Type	Cable model Connection diagram number	Max. distance	Option device*4*5	Model		
MINAS A5	<ul style="list-style-type: none"> Between MINAS and GOT:RS-232 Between MINAS and MINAS:RS-485 	(User preparing) Page 543 RS-232/485 connection diagram 1)	*2	- (Built into GOT)	GT 27 GT 25 GT 23	33m	32 servo amplifiers for 1 GOT
				GT15-RS2-9P	GT 27 GT 25		
	RS-485	(User preparing) Page 541 RS-485 connection diagram 6)	*3	GT15-RS4-TE	GT 27 GT 25	32m	31 servo amplifiers for 1 GOT
		(User preparing) Page 542 RS-485 connection diagram 7) (For GT16)	*3	FA-LTBGT2R4CBL05 (0.5m) FA-LTBGT2R4CBL10 (1m) FA-LTBGT2R4CBL20 (2m)	GT 27 GT 25 GT 23		
		(User preparing) Page 542 RS-485 connection diagram 8)	*3	- (Built into GOT)	GT 27 GT 25 GT 23		
				GT15-RS4-9S	GT 27 GT 25		

*1 Product manufactured by Panasonic Corporation. For details of this product, contact Panasonic Corporation.

*2 The following shows the maximum distance.

- Between MINAS and GOT: 2m
- Between MINAS and MINAS: 1m

*3 The following shows the maximum distance.

- Between MINAS and GOT: 1m
- Between MINAS and MINAS: 1m

*4 GT25-W is not compatible to the option devices other than FA-LTBGT2R4CBL□□.

*5 GT2505-V does not support the option device.


14.3 Connection Diagram

The following diagram shows the connection between the GOT and the Servo amplifier.

RS-232 cable

Connection diagram

■RS-232 connection diagram 1)



Precautions when preparing a cable

■Cable length

The length of the RS-232 cable must be 2m or less.

■GOT side connector

For the GOT side connector, refer to the following.

☞ Page 58 GOT connector specifications

■PANASONIC servo amplifier side connector


Use the connector compatible with the PANASONIC servo amplifier.

For details, refer to the user's manual of the PANASONIC servo amplifier.


RS-485 cable

Connection diagram


■RS-485 connection diagram 1)




■RS-485 connection diagram 2)




■RS-422 connection diagram 3)




■RS-422 connection diagram 4)




■RS-485 connection diagram 5) (For GT16)




■RS-485 connection diagram 6)



■RS-485 connection diagram 7) (For GT16)



■RS-485 connection diagram 8)



Precautions when preparing a cable

■Cable length

The length of the RS-485 cable must be 1m or less.

■GOT side connector

For the GOT side connector, refer to the following.

📖 Page 58 GOT connector specifications

■PANASONIC servo amplifier side connector

Use the connector compatible with the PANASONIC servo amplifier.
For details, refer to the user's manual of the PANASONIC servo amplifier.

Connecting terminating resistors


■GOT side

- For GT27, GT25(Except GT2505-V), GT23
Set the terminating resistor setting switch of the GOT main unit to "Disable".
 - For GT2505-V
Set the terminating resistor selector to "110Ω".
- For details of terminating resistor settings, refer to the following.
- 📖 Page 62 Terminating resistors of GOT

RS-232/RS-485 cable

Connection diagram

■RS-232/485 connection diagram 1)



Precautions when preparing a cable

■Cable length

- The length of the cable between GOT and MINAS must be 2m or less.
- The length of the cable between MINAS and MINAS must be 1m or less.

■GOT side connector

For the GOT side connector, refer to the following.

📖 Page 58 GOT connector specifications


■PANASONIC servo amplifier side connector

Use the connector compatible with the PANASONIC servo amplifier.
For details, refer to the user's manual of the PANASONIC servo amplifier.

14.4 GOT Side Settings

Setting communication interface (Communication settings)

Set the channel of the equipment to be connected to the GOT.



1. Select [Common] → [Controller Setting] from the menu.
2. In the [Controller Setting] window, select the channel No. to be used from the list menu.
3. Set the following items.
 - [Manufacturer]: [Panasonic]
 - [Controller Type]: Select one of the following items according to the controller to be connected.
[Panasonic MINAS A4]
[Panasonic MINAS A5]
 - [I/F]: Interface to be used
 - [Detail Setting]: Configure the settings according to the usage environment.
4. When you have completed the settings, click the [OK] button.

Point

The settings of connecting equipment can be confirmed in [I/F Communication Setting].

For details, refer to the following.

☞ Page 47 I/F communication setting

Communication detail settings

Make the settings according to the usage environment.

Property	Value
Transmission Speed(BPS)	9600
Data Bit	8 bit
Stop Bit	1 bit
Parity	None
Retry(Times)	3
Timeout Time(Sec)	3
Host Address	0
Delay Time(ms)	0

Item	Description	Range
Transmission Speed	Set this item when change the transmission speed used for communication with the connected equipment. (Default: 9600bps)	9600bps, 19200bps, 38400bps, 57600bps, 115200bps
Data Bit	Set this item when change the data length used for communication with the connected equipment. (Default: 8bits)	7bit/8bit
Stop Bit	Specify the stop bit length for communications. (Default: 1bit)	1bit/2bit
Parity	Specify whether or not to perform a parity check, and how it is performed during communication. (Default: None)	None Even Odd
Retry	Set the number of retries to be performed when a communication error occurs. (Default: 3times)	0 to 5times
Timeout Time ^{*1}	Set the time period for a communication to time out. (Default: 3sec)	1 to 30sec
Host Address	Specify the station No. of the servo amplifier to connect the GOT. (Default: 0)	0 to 31
Delay Time	Set this item to adjust the transmission timing of the communication request from the GOT. (Default: 0ms)	0 to 300ms

14

Point

- Communication interface setting by the Utility

The communication interface setting can be changed on the Utility's [Communication Settings] after writing [Communication Settings] of project data.

For details on the Utility, refer to the following manual.

📖 GOT2000 Series User's Manual (Utility)

- Precedence in communication settings

When settings are made by GT Designer3 or the Utility, the latest setting is effective.

14.5 Servo Amplifier Side Setting



PANASONIC Servo Amplifier

For details of the PANASONIC Servo Amplifier, refer to the following manual.

PANASONIC Servo Amplifier user's Manual

Connecting to MINAS A4/A4F/A4L

MINAS A4/A4F/A4L communication settings

Set them from the main unit front panel of MINAS A4/A4F/A4L or using the setup support software.

Pr No.	Set value
Address of axis (Parameter No.00)	0 to 15
Baud rate setup of RS232 ^{*1} (Parameter No.0C)	2:9600bps 3:19200bps 4:38400bps 5:57600bps
Baud rate setup of RS485 ^{*1} (Parameter No.0D)	2:9600bps 3:19200bps 4:38400bps 5:57600bps

*1 Only transmission speeds available on the GOT side are shown. Adjust the settings with GOT settings.



Axis name setting

- The axis name is determined according to the rotary switch ID set value when the power supply to the servo amplifier is turned on. This value will be the station number (axis number) during communication.
- The axis name setting can be changed only with the rotary switch ID.

Connecting to MINAS A5

MINAS A5 communication settings

Set them from the main unit front panel of MINAS A5 or using the setup support software.

Pr No.	Set value
Address of axis (Parameter No.00)	0 to 31
Baud rate setup of RS232 ^{*1} (Parameter No.5.29)	2:9600bps 3:19200bps 4:38400bps 5:57600bps
Baud rate setup of RS485 ^{*1} (Parameter No.5.30)	2:9600bps 3:19200bps 4:38400bps 5:57600bps

*1 Only transmission speeds available on the GOT side are shown.
Adjust the settings with GOT settings.

Station number setting

Set each station number so that no station number overlaps.

The station number can be set without regard to the cable connection order. There is no problem even if station numbers are not consecutive.


- When connecting the GOT and servo amplifier with RS-232

Set the station number (axis number) of the servo amplifier connected to the GOT to 0. Set the station numbers (axis numbers) of other servo amplifiers connected to the GOT to other than 0.

- When connecting the GOT and servo amplifier with RS-485

The GOT will be the station number (axis number) 0. Set the station numbers (axis numbers) of other connected servo amplifiers to other than 0.

Example of RS-232 connection between GOT-servo amplifier



Examples of station number setting

Direct specification

When setting the device, specify the station number of the servo amplifier of which data is to be changed.

Model name	Specification range
MINAS A4, MINAS A4F, MINAS A4L	0 to 15
MINAS A5	0 to 31

Indirect specification

When setting the device, indirectly specify the station number of the inverter of which data is to be changed using the 16-bit GOT internal data register (GD10 to GD25).

When specifying the station No. from 100 to 115 on drawing software, the value of GD10 to GD25 compatible to the station No. specification will be the station No. of the servo amplifier.

Specification Station No.	Compatible device	Setting range
100	GD10	<ul style="list-style-type: none"> • MINAS A4, MINAS A4F, MINAS A4L 0 to 15 <ul style="list-style-type: none"> • MINAS A5 0 to 31 For the setting other than the above, a communication timeout error will occur.
101	GD11	
102	GD12	
103	GD13	
104	GD14	
105	GD15	
106	GD16	
107	GD17	
108	GD18	
109	GD19	
110	GD20	
111	GD21	
112	GD22	
113	GD23	
114	GD24	
115	GD25	

14.6 Device Range that Can Be Set

The device ranges of controller that can be used for GOT are as follows.


Note that the device ranges in the following tables are the maximum values that can be set in GT Designer3.

The device specifications of controllers may differ depending on the models, even though belonging to the same series.

Please make the setting according to the specifications of the controller actually used.

When a non-existent device or a device number outside the range is set, other objects with correct device settings may not be monitored.

Setting item



Item		Description
Device		Set the device name, device number, and bit number. The bit number can be set only when specifying the bit of word device.
Information		Displays the device type and setting range which are selected in [Device].
Network		Set the monitor target of the set device.
	Station No.	Set this item when monitoring the Servo amplifier of the specified station No.

PANASONIC servo amplifier (PANASONIC MINAS-A4 Series)

Device name ^{*1}		Setting range	Device No. representation
Bit device	Status (STS) ^{*2}	STS0 to STS7	Decimal
	Input signal (INP) ^{*2}	INP0 to INP31	
	Output signal (OTP) ^{*2}	OTP0 to OTP47	
	Absolute encoder (Status)(AEST) ^{*2}	AEST0 to AEST15	
	Writing of parameter to EEPROM (EPRW) ^{*3}	EPRW0	
	Clear of user alarm history (in EEPROM as well) (ALHC) ^{*3}	ALHC0	
	Alarm clear (ALMC) ^{*3}	ALMC0	
	Absolute clear (ABSC) ^{*3}	ABSC0	
Word device	Status (Control modes) (STCM) ^{*2}	STCM0	Decimal
	Present speed (SPD) ^{*2}	SPD0	
	Present torque output (TRQ) ^{*2}	TRQ0	
	Absolute encoder (Encoder ID)(AEID) ^{*2}	AEID0	
	Absolute encoder (Multi-turn data)(AEMD) ^{*2}	AEMD0	
	Parameter (PRM)	PRM0000 to PRM007F	Hexadecimal
	Present alarm data (ALM) ^{*2}	ALM0	Decimal
	user alarm history (ALHI) ^{*2}	ALHI1 to ALHI14	
	User parameter (MIN. value) (PRMN) ^{*2}	PRMN0000 to PRMN007F	Hexadecimal
	User parameter (MAX. value) (PRMX) ^{*2}	PRMX0000 to PRMX007F	
	User parameter (Property)(PRPR) ^{*2}	PRPR0000 to PRPR007F	
Double word device	Feedback pulse counter (FBPC) ^{*2}	FBPC0	Decimal
	Present deviation counter (DVC) ^{*2}	DVC0	
	Absolute encoder (Single turn data)(AESD) ^{*2}	AESD0	
	External scale deviation and sum of pulses (ESA) ^{*2}	ESA0 to ESA1	

*1 The GOT cannot read or write data from/to consecutive devices.

*2 Only reading is possible.

*3 Only writing is possible.

PANASONIC servo amplifier (PANASONIC MINAS-A5 Series)

Device name* ¹		Setting range	Device No. representation
Bit device	Status (STS)* ²	STS0 to STS7	Decimal
	Input signal (INP)* ²	INP0 to INP31	
	Output signal (OTP)* ²	OTP0 to OTP47	
	Absolute encoder (Status)(AEST)* ²	AEST0 to AEST15	
	Writing of parameter to EEPROM (EPRW)* ³	EPRW0	
	Clear of user alarm history (in EEPROM as well) (ALHC)* ³	ALHC0	
	Alarm clear (ALMC)* ³	ALMC0	
	Absolute clear (ABSC)* ³	ABSC0	
Word device	Status (Control modes) (STCM)* ²	STCM0	Decimal
	Present speed (SPD)* ²	SPD0	
	Present torque output (TRQ)* ²	TRQ0	
	Absolute encoder (Encoder ID)(AEID)* ²	AEID0	
	Absolute encoder (Multi-turn data)(AEMD)* ²	AEMD0	
	Parameter (Class 0)(PRM0)	PRM00 to PRM017	
	Parameter (Class 1)(PRM1)	PRM10 to PRM127	
	Parameter (Class 2)(PRM2)	PRM20 to PRM223	
	Parameter (Class 3)(PRM3)	PRM30 to PRM329	
	Parameter (Class 4)(PRM4)	PRM40 to PRM442	
	Parameter (Class 5)(PRM5)	PRM50 to PRM535	
	Parameter (Class 6)(PRM6)	PRM60 to PRM639	
	Present alarm data (ALM)* ²	ALM0	
	Present alarm data (Sub) (ALMS)* ²	ALMS0	
	user alarm history (ALHI)* ²	ALHI1 to ALHI14	
	user alarm history (Sub)(ALHI)* ²	ALHS1 to ALHS14	
	User parameter (Class 0, MIN. value)(PRMN0)* ²	PRMN00 to PRMN017	
	User parameter (Class 1, MIN. value)(PRMN1)* ²	PRMN10 to PRMN127	
	User parameter (Class 2, MIN. value)(PRMN2)* ²	PRMN20 to PRMN223	
	User parameter (Class 3, MIN. value)(PRMN3)* ²	PRMN30 to PRMN329	
	User parameter (Class 4, MIN. value)(PRMN4)* ²	PRMN40 to PRMN442	
	User parameter (Class 5, MIN. value)(PRMN5)* ²	PRMN50 to PRMN535	
	User parameter (Class 6, MIN. value)(PRMN6)* ²	PRMN60 to PRMN639	
Word device	User parameter (Class 0, MAX. value)(PRMX0)* ²	PRMX00 to PRMX017	Decimal
	User parameter (Class 1, MAX. value)(PRMX1)* ²	PRMX10 to PRMX127	
	User parameter (Class 2, MAX. value)(PRMX2)* ²	PRMX20 to PRMX223	
	User parameter (Class 3, MAX. value)(PRMX3)* ²	PRMX30 to PRMX329	
	User parameter (Class 4, MAX. value)(PRMX4)* ²	PRMX40 to PRMX442	
	User parameter (Class 5, MAX. value)(PRMX5)* ²	PRMX50 to PRMX535	
	User parameter (Class 6, MAX. value)(PRMX6)* ²	PRMX60 to PRMX639	
	User parameter (Class 0, Property)(PRPR0)* ³	PRPR00 to PRPR017	
	User parameter (Class 1, Property)(PRPR1)* ³	PRPR10 to PRPR127	
	User parameter (Class 2, Property)(PRPR2)* ³	PRPR20 to PRPR223	
	User parameter (Class 3, Property)(PRPR3)* ³	PRPR30 to PRPR329	
	User parameter (Class 4, Property)(PRPR4)* ³	PRPR40 to PRPR442	
	User parameter (Class 5, Property)(PRPR5)* ³	PRPR50 to PRPR535	
	User parameter (Class 6, Property)(PRPR6)* ³	PRPR60 to PRPR639	
	Feedback pulse counter (FBPC)* ²	FBPC0	
	Present deviation counter (DVC)* ²	DVC0	
	Absolute encoder (Single turn data)(AESD)* ²	AESD0	
	External scale deviation and sum of pulses (ESA)* ²	ESA0 to ESA1	


- *1 The GOT cannot read or write data from/to consecutive devices.
- *2 Only reading is possible.
- *3 Only writing is possible.

14.7 Precautions

Station number setting in the servo system

Configure the servo system so that there is a servo amplifier with a station number set with a host address.

For details of host address setting, refer to the following manual.

 Page 545 Communication detail settings

Monitor speed

When monitoring multiple station devices placed on the same GOT screen, the monitor speed is slow. Even when monitoring a single station, the monitor speed is slow if the device points is large.

Mixing of MINAS A4 series and MINAS A5 series











MINAS A4 series and MINAS A5 series cannot be mixed. The multiple MINAS A4 series can be used together.

15 CONNECTION TO PANASONIC INDUSTRIAL DEVICES SUNX PLC

- Page 553 Connectable Model List
- Page 554 System Configuration
- Page 578 Connection Diagram
- Page 590 GOT Side Settings
- Page 593 PLC Side Setting
- Page 596 Device Range that Can Be Set

15.1 Connectable Model List

The following table shows the connectable models.

Model name	Clock	Communication Type	Connectable GOT	Refer to
FP0-C16CT	×	RS-232	<div>GT 27</div> <div>GT 25</div> <div>GT 23</div> <div>GT 21</div> <div>GS</div>	 Page 554 Connecting to FP0-C16CT, FP0-C32CT, or FP0R
FP0-C32CT				
FP0R	○			
FP1-C24C	○	RS-232	<div>GT 27</div> <div>GT 25</div> <div>GT 23</div> <div>GT 21</div> <div>GS</div>	 Page 555 Connecting to FP1-C24C or FP1-C40C
FP1-C40C	○			
FP2	○ ^{*1}	RS-232	<div>GT 27</div> <div>GT 25</div> <div>GT 23</div> <div>GT 21</div> <div>GS</div>	 Page 556 Connecting to FP2 or FP2SH
FP2SH	○			
FP3	○ ^{*2}	RS-232	<div>GT 27</div> <div>GT 25</div> <div>GT 23</div> <div>GT 21</div> <div>GS</div>	 Page 559 Connecting to FP3 or FP5
FP5	○			
FP10(S)	○	RS-232	<div>GT 27</div> <div>GT 25</div> <div>GT 23</div> <div>GT 21</div> <div>GS</div>	 Page 561 Connecting to FP10(S)
FP10SH	○	RS-232	<div>GT 27</div> <div>GT 25</div> <div>GT 23</div> <div>GT 21</div> <div>GS</div>	 Page 564 Connecting to FP10SH
FP-M(C20TC)	○	RS-232	<div>GT 27</div> <div>GT 25</div> <div>GT 23</div> <div>GT 21</div> <div>GS</div>	 Page 566 Connecting to FP-M(C20TC) or FP-M(C32TC)
FP-M(C32TC)	○			
FPΣ	○	RS-232	<div>GT 27</div> <div>GT 25</div> <div>GT 23</div> <div>GT 21</div> <div>GS</div>	 Page 568 Connecting to FPΣ
FP-X	○	RS-232 RS-422	<div>GT 27</div> <div>GT 25</div> <div>GT 23</div> <div>GT 21</div> <div>GS</div>	 Page 570 Connecting to FP-X
FP7	○ ^{*3}	RS-232 RS-422 RS-485	<div>GT 27</div> <div>GT 25</div> <div>GT 23</div> <div>GT 21</div> <div>GS</div>	 Page 573 Connecting to FP7


*1 Any of the extension memory unit FP2-EM1, FP2-EM2 or FP2-EM3 is required.

*2 The clock function is available for the AFP3210C-F, AFP3211C-F, AFP3212C-F and AFP3220C-F.

*3 The GOT can only read the clock data. In the clock setting, though the adjust is available, the broadcast is not available.

15.2 System Configuration

Connecting to FP0-C16CT, FP0-C32CT, or FP0R




PLC		Connection cable	Max. distance	GOT		Number of connectable equipment
Model name	Communication Type	Cable model Connection diagram number		Option device ^{*3}	Model	
FP0-C16CT FP0-C32CT FP0R (Tool port)	RS-232	AFC8503(3m) ^{*1}	3m	- (Built into GOT)		1 GOT for 1 PLC
				GT15-RS2-9P		
				GT10-C02H-6PT9P ^{*2}		
		AFC8503(3m) ^{*1} + (User preparing) Page 580 RS-232 connection diagram 9)	3.5m	- (Built into GOT)		
FP0-C16CT FP0-C32CT FP0R (RS232C port)	RS-232	GT09-C30R20904-3C(3m) or (User preparing) Page 579 RS-232 connection diagram 4)	15m	- (Built into GOT)		
				GT15-RS2-9P		
				GT10-C02H-6PT9P ^{*2}		
		(User preparing) Page 581 RS-232 connection diagram 12)	15m	- (Built into GOT)		

^{*1} Product manufactured by Panasonic Industrial Devices SUNX Co., Ltd. For details of this product, contact Panasonic Industrial Devices SUNX Co., Ltd.

^{*2} When a GT10-C02H-6PT9P unit of the sub version A or B is used, do not ground the case of the D-sub (9-pin) connector.

^{*3} GT25-W, GT2505-V does not support the option device.

Connecting to FP1-C24C or FP1-C40C



PLC				Connection cable	Max. distance	GOT		Number of connectable equipment
Model name	Communication Type	FP peripheral device connection cable*1 Cable model Connection diagram number	RS422/232C conversion adapter*1	Cable model Connection diagram number		Option device*3	Model	
FP1-C24C FP1-C40C (Tool port)	RS-232	AFP15205(0.5m)	AFP8550	GT09-C30R20901-25P(3m) or (User preparing) Page 578 RS-232 connection diagram 1)	15.5m	- (Built into GOT)	<div>GT 27</div> <div>GT 23</div> <div>GT 21</div> <div>GT 25</div> <div>GT 21</div> <div>GS</div>	1 GOT for 1 PLC
						GT15-RS2-9P	<div>GT 27</div> <div>GT 25</div>	
						GT10-C02H-6PT9P*2	<div>GT 27</div> <div>GT 23</div> <div>GT 21</div> <div>GT 25</div> <div>GT 21</div> <div>GS</div>	
FP1-C24C FP1-C40C (RS232C port)	RS-232	-	-	GT09-C30R20903-9P(3m) or (User preparing) Page 578 RS-232 connection diagram 3)	15m	- (Built into GOT)	<div>GT 27</div> <div>GT 23</div> <div>GT 21</div> <div>GT 25</div> <div>GT 21</div> <div>GS</div>	
						GT15-RS2-9P	<div>GT 27</div> <div>GT 25</div>	
						GT10-C02H-6PT9P*2	<div>GT 27</div> <div>GT 23</div> <div>GT 21</div> <div>GT 25</div> <div>GT 21</div> <div>GS</div>	
				(User preparing) Page 582 RS-232 connection diagram 13)	15m	- (Built into GOT)	<div>GT 27</div> <div>GT 23</div> <div>GT 21</div> <div>GT 25</div> <div>GT 21</div> <div>GS</div>	


*1 Product manufactured by Panasonic Industrial Devices SUNX Co., Ltd. For details of this product, contact Panasonic Industrial Devices SUNX Co., Ltd.





































*2 When a GT10-C02H-6PT9P unit of the sub version A or B is used, do not ground the case of the D-sub (9-pin) connector.

*3 GT25-W, GT2505-V does not support the option device.

Connecting to FP2 or FP2SH

When connecting to tool port or RS232C port




PLC		Connection cable	Max. distance	GOT		Number of connectable equipment
Model name	Communication Type	Cable model Connection diagram number		Option device ^{*3}	Model	
FP2 FP2SH (Tool port)	RS-232	AFC8503(3m) ^{*1}	3m	- (Built into GOT)	     	1 GOT for 1 PLC
				GT15-RS2-9P	 	
				GT10-C02H-6PT9P ^{*2}	   	
		AFC8503(3m) ^{*1} + (User preparing) Page 580 RS-232 connection diagram 9)	3.5m	- (Built into GOT)	   	
FP2 FP2SH (RS232C port)	RS-232	AFB85853(3m) ^{*1} GT09-C30R20902-9P(3m) or (User preparing) Page 578 RS-232 connection diagram 2)	15m	- (Built into GOT)	     	
				GT15-RS2-9P	 	
				GT10-C02H-6PT9P ^{*2}	   	
		AFB85853(3m) ^{*1} GT09-C30R20902-9P(3m) or (User preparing) Page 578 RS-232 connection diagram 2) + (User preparing) Page 581 RS-232 connection diagram 11)	15m	- (Built into GOT)	   	
		(User preparing) Page 581 RS-232 connection diagram 10)	15m	- (Built into GOT)	   	







*1 Product manufactured by Panasonic Industrial Devices SUNX Co., Ltd. For details of this product, contact Panasonic Industrial Devices SUNX Co., Ltd.

*2 When a GT10-C02H-6PT9P unit of the sub version A or B is used, do not ground the case of the D-sub (9-pin) connector.

*3 GT25-W, GT2505-V does not support the option device.

When connecting to computer communication unit




PLC			Connection cable	Max. distance	GOT		Number of connectable equipment
Model name	Computer communication unit*1	Communication Type	Cable model Connection diagram number		Option device*3	Model	
FP2 FP2SH	AFP2462	RS-232	AFB85853(3m)*1 GT09-C30R20902-9P(3m) or  Page 578 RS-232 connection diagram 2)	15m	- (Built into GOT)		1 GOT for 1 computer communication unit
					GT15-RS2-9P		
					GT10-C02H-6PT9P*2		
			 Page 581 RS-232 connection diagram 10)	15m	- (Built into GOT)		

*1 Product manufactured by Panasonic Industrial Devices SUNX Co., Ltd. For details of this product, contact Panasonic Industrial Devices SUNX Co., Ltd.

*2 When a GT10-C02H-6PT9P unit of the sub version A or B is used, do not ground the case of the D-sub (9-pin) connector.



*3 GT25-W, GT2505-V does not support the option device.

When connecting to tool port

15

*3 GT25-W, GT2505-V does not support the option device.

When connecting to computer communication unit



PLC			Connection cable	Max. distance	GOT		Number of connectable equipment
Model name	Computer communication unit ^{*1}	Communication Type	Cable model Connection diagram number		Option device ^{*3}	Model	
FP3	AFP3462	RS-232	AFB85853(3m) ^{*1} GT09-C30R20902-9P(3m) or Page 578 RS-232 connection diagram 2)	15m	- (Built into GOT)		1 GOT for 1 computer communication unit
					GT15-RS2-9P		
					GT10-C02H-6PT9P ^{*2}		
			Page 581 RS-232 connection diagram 10)	15m	- (Built into GOT)		
FP5	AFP5462	RS-232	AFB85853(3m) ^{*1} GT09-C30R20902-9P(3m) or Page 578 RS-232 connection diagram 2)	15m	- (Built into GOT)		
					GT15-RS2-9P		
					GT10-C02H-6PT9P ^{*2}		
			Page 581 RS-232 connection diagram 10)	15m	- (Built into GOT)		


*1 Product manufactured by Panasonic Industrial Devices SUNX Co., Ltd. For details of this product, contact Panasonic Industrial Devices SUNX Co., Ltd.

*2 When a GT10-C02H-6PT9P unit of the sub version A or B is used, do not ground the case of the D-sub (9-pin) connector.

*3 GT25-W, GT2505-V does not support the option device.

Connecting to FP10(S)

When connecting to tool port





PLC				Connection cable	Max. distance	GOT		Number of connectable equipment
Model name	FP peripheral device connection cable*1	RS422/232 conversion adapter*1	Communication Type	Cable model Connection diagram number		Option device*3	Model	
	Cable model Connection diagram number							
FP10(S)	AFP5520(0.5m)	AFP8550	RS-232	GT09-C30R20901-25P or <small>(User manual)</small> Page 578 RS-232 connection diagram 1)	15.5m	- (Built into GOT)	<div> <div>GT 27</div> <div>GT 25</div> <div>GT 23</div> <div>GT 21</div> </div> <div> <div>GT 21</div> <div>GS</div> </div>	1 GOT for 1 RS422/232 conversion adapter
						GT15-RS2-9P	<div> <div>GT 27</div> <div>GT 25</div> </div>	
						GT10-C02H-6PT9P*2	<div> <div>GT 21</div> <div>GT 23</div> <div>GT 25</div> </div> <div> <div>GT 21</div> <div>GT 23</div> <div>GT 25</div> </div>	
				<small>(User manual)</small> Page 580 RS-232 connection diagram 8)	15.5m	- (Built into GOT)	<div> <div>GT 21</div> <div>GT 23</div> <div>GT 25</div> </div> <div> <div>GT 21</div> <div>GT 23</div> <div>GT 25</div> </div>	

*1 Product manufactured by Panasonic Industrial Devices SUNX Co., Ltd. For details of this product, contact Panasonic Industrial Devices SUNX Co., Ltd.

*2 When a GT10-C02H-6PT9P unit of the sub version A or B is used, do not ground the case of the D-sub (9-pin) connector.

*3 GT25-W, GT2505-V does not support the option device.

When connecting to RS232C port




PLC		Connection cable	Max. distance	GOT		Number of connectable equipment
Model name	Communication Type	Cable model Connection diagram number		Option device*3	Model	
FP10(S)	RS-232	AFB85853(3m)*1 GT09-C30R20902-9P(3m) or (User preparing) Page 578 RS-232 connection diagram 2)	15m	- (Built into GOT)		1 GOT for 1 PLC
				GT15-RS2-9P		
				GT10-C02H-6PT9P*2		
		AFB85853(3m)*1 GT09-C30R20902-9P(3m) or (User preparing) Page 578 RS-232 connection diagram 2) + (User preparing) Page 581 RS-232 connection diagram 11)	15m	- (Built into GOT)		
				- (Built into GOT)		
		(User preparing) Page 581 RS-232 connection diagram 10)	15m	- (Built into GOT)		

*1 Product manufactured by Panasonic Industrial Devices SUNX Co., Ltd. For details of this product, contact Panasonic Industrial Devices SUNX Co., Ltd.

*2 When a GT10-C02H-6PT9P unit of the sub version A or B is used, do not ground the case of the D-sub (9-pin) connector.

*3 GT25-W, GT2505-V does not support the option device.



When connecting to computer communication unit

15

*2 When a GT10-C02H-6PT9P unit of the sub version A or B is used, do not ground the case of the D-sub (9-pin) connector.

Connecting to FP10SH

When connecting to tool port or RS232C port




PLC		Connection cable	Max. distance	GOT		Number of connectable equipment
Model name	Communication Type	Cable model Connection diagram number		Option device ^{*3}	Model	
FP10SH	RS-232	AFB85853(3m) ^{*1} GT09-C30R20902-9P(3m) or (User preparing) Page 578 RS-232 connection diagram 2)	15m	- (Built into GOT)		1 GOT for 1 PLC
				GT15-RS2-9P		
				GT10-C02H-6PT9P ^{*2}		
		AFB85853(3m) ^{*1} GT09-C30R20902-9P(3m) or (User preparing) Page 578 RS-232 connection diagram 2) + (User preparing) Page 581 RS-232 connection diagram 11)	15m	- (Built into GOT)		
		(User preparing) Page 581 RS-232 connection diagram 10)	15m	- (Built into GOT)		















^{*1} Product manufactured by Panasonic Industrial Devices SUNX Co., Ltd. For details of this product, contact Panasonic Industrial Devices SUNX Co., Ltd.

^{*2} When a GT10-C02H-6PT9P unit of the sub version A or B is used, do not ground the case of the D-sub (9-pin) connector.

^{*3} GT25-W, GT2505-V does not support the option device.

When connecting to computer communication unit



PLC			Connection cable	Max. distance	GOT		Number of connectable equipment
Model name	Computer communication unit*1	Communication Type	Cable model Connection diagram number		Option device*3	Model	
FP10SH	AFP3462	RS-232	AFB85853(3m)*1 GT09-C30R20902-9P(3m) or  Page 578 RS-232 connection diagram 2)	15m	- (Built into GOT)	   	1 GOT for 1 computer communication unit
					GT15-RS2-9P	 	
					GT10-C02H-6PT9P*2	   	
			 Page 581 RS-232 connection diagram 10)	15m	- (Built into GOT)	 	


*1 Product manufactured by Panasonic Industrial Devices SUNX Co., Ltd. For details of this product, contact Panasonic Industrial Devices SUNX Co., Ltd.

*2 When a GT10-C02H-6PT9P unit of the sub version A or B is used, do not ground the case of the D-sub (9-pin) connector.





















*3 GT25-W, GT2505-V does not support the option device.

Connecting to FP-M(C20TC) or FP-M(C32TC)

When connecting to tool port or RS232C port



PLC		Connection cable	Max. distance	GOT		Number of connectable equipment
Model name	Communication Type	Cable model Connection diagram number		Option device ^{*3}	Model	
FP-M(C20TC), FP-M(C32TC) (Tool port)	RS-232	AFC8503(3m) ^{*1}	3m	- (Built into GOT)		1 GOT for 1 PLC
				GT15-RS2-9P		
				GT10-C02H-6PT9P ^{*2}		
		AFC8503(3m) ^{*1} + (User preparing) Page 580 RS-232 connection diagram 9)	3.5m	- (Built into GOT)		
		(User preparing) Page 581 RS-232 connection diagram 10)	15m	- (Built into GOT)		

PLC		Connection cable	Max. distance	GOT		Number of connectable equipment
Model name	Communication Type	Cable model Connection diagram number		Option device* ³	Model	
FP-M(C20TC), FP-M(C32TC) (RS232C port)	RS-232	AFB85853(3m)* ¹ GT09-C30R20902-9P(3m) or  Page 578 RS-232 connection diagram 2)	15m	- (Built into GOT)	     	1 GOT for 1 PLC
				GT15-RS2-9P	 	
				GT10-C02H-6PT9P* ²	   	
		AFB85853(3m)* ¹ GT09-C30R20902-9P(3m) or  Page 578 RS-232 connection diagram 2) +  Page 581 RS-232 connection diagram 11)	15m	- (Built into GOT)	 	
		 Page 581 RS-232 connection diagram 10)	15m	- (Built into GOT)	 	


*1 Product manufactured by Panasonic Industrial Devices SUNX Co., Ltd. For details of this product, contact Panasonic Industrial Devices SUNX Co., Ltd.


*2 When a GT10-C02H-6PT9P unit of the sub version A or B is used, do not ground the case of the D-sub (9-pin) connector.

*3 GT25-W, GT2505-V does not support the option device.

Connecting to FPΣ

When connecting to tool port




PLC		Connection cable	Max. distance	GOT		Number of connectable equipment
Model name	Communication Type	Cable model Connection diagram number		Option device ^{*3}	Model	
FPΣ	RS-232	AFC8503(3m) ^{*1}	3m	- (Built into GOT)		1 GOT for 1 PLC
		GT15-RS2-9P				
		GT10-C02H-6PT9P ^{*2}				
		AFC8503(3m) ^{*1} +  Page 580 RS-232 connection diagram 9)	3.5m	- (Built into GOT)		

^{*1} Product manufactured by Panasonic Industrial Devices SUNX Co., Ltd. For details of this product, contact Panasonic Industrial Devices SUNX Co., Ltd.

^{*2} When a GT10-C02H-6PT9P unit of the sub version A or B is used, do not ground the case of the D-sub (9-pin) connector.

^{*3} GT25-W, GT2505-V does not support the option device.

When connecting to COM port


15





*2 When a GT10-C02H-6PT9P unit of the sub version A or B is used, do not ground the case of the D-sub (9-pin) connector.

*3 GT25-W, GT2505-V does not support the option device.

Connecting to FP-X

When connecting to tool port





PLC		Connection cable	Max. distance	GOT		Number of connectable equipment
Model name	Communication Type	Cable model Connection diagram number		Option device ^{*3}	Model	
FP-X	RS-232	AFC8503(3m) ^{*1}	3m	- (Built into GOT)		1 GOT for 1 PLC
				GT15-RS2-9P		
				GT10-C02H-6PT9P ^{*2}		
		AFC8503(3m) ^{*1} + (User preparing) Page 580 RS-232 connection diagram 9)	3.5m	- (Built into GOT)		













^{*1} Product manufactured by Panasonic Industrial Devices SUNX Co., Ltd. For details of this product, contact Panasonic Industrial Devices SUNX Co., Ltd.



























^{*2} When a GT10-C02H-6PT9P unit of the sub version A or B is used, do not ground the case of the D-sub (9-pin) connector.

^{*3} GT25-W, GT2505-V does not support the option device.

When connecting to communication cassette



PLC			Connection cable	Max. distance	GOT		Number of connectable equipment		
Model name	Communication cassette ^{*1}	Communication Type	Cable model Connection diagram number		Option device ^{*4}	Model			
FP-X	AFPX-COM1 (RS232C one channel type)	RS-232	 Page 579 RS-232 connection diagram 5)	15m	- (Built into GOT)		1 GOT for 1 PLC		
					GT15-RS2-9P				
					GT10-C02H-6PT9P ^{*3}				
			 Page 582 RS-232 connection diagram 14)	15m	- (Built into GOT)				
	AFPX-COM2 ^{*2} (RS232C two channel type)				 Page 579 RS-232 connection diagram 6)	15m		- (Built into GOT)	
								GT15-RS2-9P	
								GT10-C02H-6PT9P ^{*3}	
			 Page 582 RS-232 connection diagram 15)	15m	- (Built into GOT)				

PLC			Connection cable	Max. distance	GOT		Number of connectable equipment
Model name	Communication cassette ^{*1}	Communication Type	Cable model Connection diagram number		Option device ^{*4}	Model	
FP-X	AFPX-COM3 (RS485/RS422 one channel type)	RS-422	 Page 585 RS-422 connection diagram 1)	1200m	- (Built into GOT)	   	1 GOT for 1 PLC
					GT15-RS4-9S		
					GT10-C02H-9SC	 	
			 Page 585 RS-422 connection diagram 2)	1200m	- (Built into GOT)	   	
	AFPX-COM4 ^{*2} (RS485 one channel and RS232C one channel mixed type)	RS-232	 Page 580 RS-232 connection diagram 7)	15m	- (Built into GOT)	   	
					GT15-RS2-9P		
					GT10-C02H-6PT9P ^{*3}	  	
			 Page 583 RS-232 connection diagram 16)	15m	- (Built into GOT)	  	

*1 Product manufactured by Panasonic Industrial Devices SUNX Co., Ltd. For details of this product, contact Panasonic Industrial Devices SUNX Co., Ltd.


*2 To connect C30 and C60, USB port may set at the COM2 port on AFPX-COM2 and AFPX-COM4. In this case, set the COM2 port to RS232C.

*3 When a GT10-C02H-6PT9P unit of the sub version A or B is used, do not ground the case of the D-sub (9-pin) connector.

*4 GT25-W, GT2505-V does not support the option device.

Connecting to FP7

When connecting to Serial port built into CPU module



PLC		Connection cable	Max. distance	GOT		Number of connectable equipment
Model name	Communication Type	Cable model Connection diagram number		Option device ^{*3}	Model	
FP7	RS-232	<div>(User preparing)</div> Page 583 RS-232 connection diagram 17)	15m	- (Built into GOT)	<div> <div>GT 27</div> <div>GT 23</div> <div>GT 21</div> <div>GT 25</div> <div>GS</div> </div>	1 GOT for 1 PLC
				GT15-RS2-9P	<div> <div>GT 27</div> <div>GT 25</div> </div>	
				GT10-C02H-6PT9P ^{*2}	<div> <div>GT 21</div> <div>GT 25</div> </div>	
		<div>(User preparing)</div> Page 583 RS-232 connection diagram 18)	15m	- (Built into GOT)	<div> <div>GT 21</div> <div>GT 25</div> </div>	

*1

Product manufactured by Panasonic Industrial Devices SUNX Co., Ltd. For details of this product, contact Panasonic Industrial Devices SUNX Co., Ltd.


*2

When a GT10-C02H-6PT9P unit of the sub version A or B is used, do not ground the case of the D-sub (9-pin) connector.

*3































GT25-W, GT2505-V does not support the option device.



















When connecting to communication cassette



PLC			Connection cable	Max. distance	GOT		Number of connectable equipment
Model name	Communication cassette ^{*1}	Communication Type	Cable model Connection diagram number		Option device ^{*3}	Model	
FP7	AFP7CCS1	RS-232	(User preparation) Page 583 RS-232 connection diagram 17)	15m	- (Built into GOT)	<div>GT 27</div> <div>GT 23</div> <div>GT 21</div> <div>GS</div>	1 GOT for 1 PLC
					GT15-RS2-9P	<div>GT 27</div> <div>GT 25</div>	
					GT10-C02H-6PT9P ^{*2}	<div>GT 03P 21</div> <div>GT 03P 21</div> <div>GT 04P R4</div> <div>GT 04P R2</div>	
	AFP7CCS2 ([3 Wire] is selected)	RS-232	(User preparation) Page 583 RS-232 connection diagram 18)	15m	- (Built into GOT)	<div>GT 04P 21</div> <div>GT 03P 21</div> <div>GT 04P R4</div> <div>GT 04P R2</div>	
					GT15-RS2-9P	<div>GT 27</div> <div>GT 25</div>	
					GT10-C02H-6PT9P ^{*2}	<div>GT 03P 21</div> <div>GT 03P 21</div> <div>GT 04P R4</div> <div>GT 04P R2</div>	
			(User preparation) Page 583 RS-232 connection diagram 18) (3 Wire)	15m	- (Built into GOT)	<div>GT 04P 21</div> <div>GT 03P 21</div> <div>GT 04P R4</div> <div>GT 04P R2</div>	

PLC			Connection cable	Max. distance	GOT		Number of connectable equipment
Model name	Communication cassette ^{*1}	Communication Type	Cable model Connection diagram number		Option device ^{*3}	Model	
FP7	AFP7CCS2 ([5 Wire] is selected)	RS-232	(User preparing) Page 584 RS-232 connection diagram 19) (5 Wire)	15m	- (Built into GOT)		1 GOT for 1 PLC
					GT15-RS2-9P		
					GT10-C02H-6PT9P ^{*2}		
			(User preparing) Page 584 RS-232 connection diagram 20) (5 Wire)	15m	- (Built into GOT)		
	AFP7CCS1M1 ([RS-422] is selected)	RS-422	(User preparing) Page 586 RS-422 connection diagram 3)	400m	- (Built into GOT)		
					GT15-RS4-9S		
					GT10-C02H-9SC		
			(User preparing) Page 586 RS-422 connection diagram 4)	400m	- (Built into GOT)		
	AFP7CCS1M1 ([RS-485] is selected)	RS-485	(User preparing) Page 588 RS-485 connection diagram 1)	1200m	- (Built into GOT)		
					GT15-RS4-9S		
					GT10-C02H-9SC		
			(User preparing) Page 588 RS-485 connection diagram 2)	1200m	- (Built into GOT)		

PLC			Connection cable	Max. distance	GOT		Number of connectable equipment
Model name	Communication cassette ^{*1}	Communication Type	Cable model Connection diagram number		Option device ^{*3}	Model	
FP7	AFP7CCS1M2 ([RS-422] is selected)	RS-422	 Page 586 RS-422 connection diagram 3)	400m	- (Built into GOT)	  	1 GOT for 1 PLC
					GT15-RS4-9S		
					GT10-C02H-9SC		
	AFP7CCS1M2 ([RS-485] is selected)	RS-485	 Page 586 RS-422 connection diagram 4)	400m	- (Built into GOT)	  	
					GT15-RS4-9S		
					GT10-C02H-9SC		
	AFP7CCS1M2 ([RS-485] is selected)	RS-485	 Page 588 RS-485 connection diagram 1)	1200m	- (Built into GOT)	  	1 GOT for 1 PLC
					GT15-RS4-9S		
					GT10-C02H-9SC		
	AFP7CCS1M1	RS-232	 Page 588 RS-485 connection diagram 2)	1200m	- (Built into GOT)	  	
					GT15-RS2-9P		
					GT10-C02H-6PT9P ^{*2}		
	AFP7CCS1M1	RS-232	 Page 583 RS-232 connection diagram 17)	15m	- (Built into GOT)	  	1 GOT for 1 PLC
			 Page 583 RS-232 connection diagram 18)	15m	- (Built into GOT)		

PLC			Connection cable	Max. distance	GOT		Number of connectable equipment
Model name	Communication cassette ^{*1}	Communication Type	Cable model Connection diagram number		Option device ^{*3}	Model	
FP7	AFP7CCS1M1	RS-485	 Page 588 RS-485 connection diagram 1)	1200m	- (Built into GOT)	     	1 GOT for 1 PLC
					GT15-RS4-9S	 	
					GT10-C02H-9SC	   	
			 Page 588 RS-485 connection diagram 2)	1200m	- (Built into GOT)	   	

*1 Product manufactured by Panasonic Industrial Devices SUNX Co., Ltd. For details of this product, contact Panasonic Industrial Devices SUNX Co., Ltd.

*2 When a GT10-C02H-6PT9P unit of the sub version A or B is used, do not ground the case of the D-sub (9-pin) connector.

*3 GT25-W, GT2505-V does not support the option device.


15.3 Connection Diagram

The following diagram shows the connection between the GOT and the PLC.


RS-232 cable

Connection diagram


■RS-232 connection diagram 1)




■RS-232 connection diagram 2)




■RS-232 connection diagram 3)




■RS-232 connection diagram 4)




■RS-232 connection diagram 5)



■RS-232 connection diagram 6)




■RS-232 connection diagram 7)




*1 GT27: CD, GT23:NC


■RS-232 connection diagram 8)




■RS-232 connection diagram 9)




■RS-232 connection diagram 10)




■RS-232 connection diagram 11)




■RS-232 connection diagram 12)




■RS-232 connection diagram 13)




■RS-232 connection diagram 14)




■RS-232 connection diagram 15)



■RS-232 connection diagram 16)



■RS-232 connection diagram 17)




*1 The details of the connection on the PLC are shown below.

Built-in port: COM.0

Communication cassette: AFP7CCS1, AFP7CCS2 of CH1([3 Wire] is selected), AFP7CCS2 of CH2([3 Wire] is selected), AFP7CCS1M1

■RS-232 connection diagram 18)




*1 The details of the connection on the PLC are shown below.

Built-in port: COM.0

Communication cassette: AFP7CCS1, AFP7CCS2 of CH1([3 Wire] is selected), AFP7CCS2 of CH2([3 Wire] is selected), AFP7CCS1M1

■RS-232 connection diagram 19)




*1 The details of the connection on the PLC are shown below.

Communication cassette: AFP7CCS2([5 Wire] is selected)

*2 Connect to the terminal for which the front panel LED of the communication cassette shown in parentheses is ON.

■RS-232 connection diagram 20)



*1 The details of the connection on the PLC are shown below.

Communication cassette : AFP7CCS2([5 Wire] is selected)

*2 Connect to the terminal for which the front panel LED of the communication cassette shown in parentheses is ON.

Precautions when preparing a cable

■Cable length

The length of the RS-232 cable must be 15m or less. The length of the cable must be 3m or less with a transmission speed of 38400bps.

■GOT side connector

For the GOT side connector, refer to the following.

☞ Page 58 GOT connector specifications

■Connector for Panasonic Industrial Devices SUNX PLC


Use the connector applicable to the Panasonic Industrial Devices SUNX PLC.

For details, refer to the Panasonic Industrial Devices SUNX PLC user's manual.


RS-422 cable

Connection diagram

■RS-422 connection diagram 1)




■RS-422 connection diagram 2)



*1 The signals RSA, RSB, CSA, and CSB are not provided for GT2104-PMBD, GT2103-PMBD. Return connection is not required.

■RS-422 connection diagram 3)



*1 The details of the connection on the PLC are shown below.

Communication cassette: AFP7CCM1, AFP7CCM2 of CH1([RS-422] is selected), AFP7CCM2 of CH2([RS-422] is selected)

*2 Set the terminating resistor settings of the PLC side to [ON].


*3 For the GOT side terminating resistor settings, refer to the following.

GT27, GT25(Except GT2505-V), GT23: Connecting terminating resistors "Disable"

For GT2505-V and GT21: Set the terminating resistor to "330 Ω".

For GS21: Since the terminating resistor is fixed to 330 Ω, no setting is required for the terminating resistor.

■RS-422 connection diagram 4)



*1 The details of the connection on the PLC are shown below.

Communication cassette: AFP7CCM1, AFP7CCM2 of CH1([RS-422] is selected), AFP7CCM2 of CH2([RS-422] is selected)

*2 Set the terminating resistor settings of the PLC side to [ON].

*3 Set the terminating resistor settings of the GOT side to "330Ω".

*4 The signals RSA, RSB, CSA, and CSB are not provided for GT2104-PMBD, GT2103-PMBD. Return connection is not required.

Precautions when preparing a cable

■Cable length

The length of the RS-422 cable must be 1200m or less.

■GOT side connector

For the GOT side connector, refer to the following.

☞ Page 58 GOT connector specifications

■Connector for Panasonic Industrial Devices SUNX PLC

Use the connector applicable to the Panasonic Industrial Devices SUNX PLC.

For details, refer to the Panasonic Industrial Devices SUNX PLC user's manual.

Connecting terminating resistors

■GOT side

- For GT27, GT25(Except GT2505-V), GT23

Set the terminating resistor setting switch of the GOT main unit to "Disable".

- For GT2505-V, GT21

Set the terminating resistor selector to "330Ω".

- For GS21

Since the terminating resistor is fixed to 330 Ω, no setting is required for the terminating resistor.


For details of terminating resistor settings, refer to the following.

☞ Page 62 Terminating resistors of GOT

RS-485 cable

Connection diagram

■RS-485 connection diagram 1)



*1 The details of the connection on the PLC are shown below.

Communication cassette: AFP7CCM1([RS-485] is selected), AFP7CCM2 of CH1([RS-485] is selected), AFP7CCM2 of CH2([RS-485] is selected)


*2 Set the terminating resistor settings of the PLC side to [ON].

*3 For the GOT side terminating resistor settings, refer to the following.

GT27, GT25(Except GT2505-V), GT23: Connecting terminating resistors "Disable"

GT2505-V, GT21: Connecting terminating resistors "110Ω"

■RS-485 connection diagram 2)



*1 The details of the connection on the PLC are shown below.

Communication cassette: AFP7CCM1([RS-485] is selected), AFP7CCM2 of CH1([RS-485] is selected), AFP7CCM2 of CH2([RS-485] is selected)

*2 Set the terminating resistor settings of the PLC side to [ON].

*3 Set the terminating resistor settings of the GOT side to "110Ω".

*4 The signals RSA, RSB, CSA, and CSB are not provided for GT2104-PMBD, GT2103-PMBD. Return connection is not required.

Precautions when preparing a cable

■Cable length

The length of the RS-485 cable must be 1200m or less.

■GOT side connector

For the GOT side connector, refer to the following.

☞ Page 58 GOT connector specifications

■Connector for Panasonic Industrial Devices SUNX PLC

Use the connector applicable to the Panasonic Industrial Devices SUNX PLC.

For details, refer to the Panasonic Industrial Devices SUNX PLC user's manual.

Connecting terminating resistors

■GOT side


- For GT27, GT25(Except GT2505-V), GT23

Set the terminating resistor setting switch of the GOT main unit to "Disable".

- For GT2505-V, GT21

Set the terminating resistor selector to "110Ω".


For details of terminating resistor settings, refer to the following.

 Page 62 Terminating resistors of GOT

15.4 GOT Side Settings

Setting communication interface (Communication settings)

Set the channel of the equipment to be connected to the GOT.



1. Select [Common] → [Controller Setting] from the menu.
2. In the [Controller Setting] window, select the channel No. to be used from the list menu.
3. Set the following items.
 - [Manufacturer]: [Panasonic]
 - [Controller Type]: Select one of the following items according to the controller to be connected.

When connecting to FP0/1/2/3/5, FP-M, FPΣ, FP-X: [Panasonic MEVNET-FP]

When connecting to FP7: [Panasonic FP7]

- [I/F]: Interface to be used
- [Detail Setting]: Configure the settings according to the usage environment.

☞ Page 591 Communication detail settings

4. When you have completed the settings, click the [OK] button.

Point

The settings of connecting equipment can be confirmed in [I/F Communication Setting].

For details, refer to the following.

☞ Page 47 I/F communication setting

Communication detail settings

Make the settings according to the usage environment.

Panasonic MEWNET-FP

Property	Value
Transmission Speed(BPS)	9600
Data Bit	8 bit
Stop Bit	1 bit
Parity	Odd
Retry(Times)	0
Timeout Time(Sec)	3
Host Address	1
Delay Time(ms)	0

Item	Description	Range
Transmission Speed	Set this item when change the transmission speed used for communication with the connected equipment. (Default: 9600bps)	4800bps, 9600bps, 19200bps, 38400bps, 57600bps, 115200bps
Data Bit	Set this item when change the data length used for communication with the connected equipment. (Default: 8bits)	7bits/8bits
Retry	Set the number of retries to be performed when a communication timeout occurs. When receiving no response after retries, the communication times out. (Default: 0time)	0 to 5times
Timeout Time	Set the time period for a communication to time out. (Default: 3sec)	1 to 30sec
Host Address	Specify the host address (station No. of the PLC to which the GOT is connected) in the network of the GOT. (Default: 1)	1 to 31
Delay Time	Set this item to adjust the transmission timing of the communication request from the GOT. (Default: 0ms)	0 to 300 (ms)

Panasonic MEWTOCOL-7

Property	Value
Transmission Speed(BPS)	9600
Data Bit	8bit
Stop Bit	1bit
Parity	Odd
Retry(Times)	0
Timeout Time(Sec)	3
Delay Time(ms)	0

Item	Description	Range
Transmission Speed	Set this item when change the transmission speed used for communication with the connected equipment. (Default: 9600bps)	4800bps, 9600bps, 19200bps, 38400bps, 57600bps, 115200bps
Data Bit	Set this item when change the data length used for communication with the connected equipment. (Default: 8bits)	7bits/8bits
Retry	Set the number of retries to be performed when a communication timeout occurs. When receiving no response after retries, the communication times out. (Default: 0time)	0 to 5times
Timeout Time	Set the time period for a communication to time out. (Default: 3sec)	1 to 30sec
Delay Time	Set this item to adjust the transmission timing of the communication request from the GOT. (Default: 0ms)	0 to 300 (ms)

- Communication interface setting by the Utility

The communication interface setting can be changed on the Utility's [Communication Settings] after writing [Communication Settings] of project data.

For details on the Utility, refer to the following manual.

☞ GOT2000 Series User's Manual (Utility)

- Precedence in communication settings

When settings are made by GT Designer3 or the Utility, the latest setting is effective.

15.5 PLC Side Setting



Panasonic Industrial Devices SUNX PLC

For details of the Panasonic Industrial Devices SUNX PLC, refer to the following manual.

Panasonic Industrial Devices SUNX PLC user's Manual

Connecting to FP0/1/2/3/5, FP-M, FPΣ, FP-X

Connecting to the tool port of the PLC CPU

Item	Set value
Transmission speed*1	4800bps, 9600bps, 19200bps, 38400bps, 57600bps, 115200bps
Data bit	7bit, 8bit
Stop bit	1bit
Parity bit	Odd
Modem connection	No
Module No.	1

- *1 Indicates only the transmission speeds that can be set on the GOT side.
Set the same transmission speed of the GOT.
For the transmission speed setting on the GOT side, refer to the following.
 Page 590 Setting communication interface (Communication settings)
The setting range varies with the connected PLC.

Connecting to the RS232C and COM port of the PLC CPU

Item	Set value
Transmission speed*1	4800bps, 9600bps, 19200bps, 38400bps, 57600bps, 115200bps
Data bit	7bit, 8bit
Stop bit	1bit
Parity bit	Odd
Modem connection	No
Serial port action selection*2	1 (Computer link)
Module No.	1

- *1 Indicates only the transmission speeds that can be set on the GOT side.
Set the same transmission speed of the GOT.
For the transmission speed setting on the GOT side, refer to the following.
 Page 590 Setting communication interface (Communication settings)
The setting range varies with the connected PLC.
- *2 Set when connecting to FP0, FP1, FP2 or FP-M.

Connecting to the computer communication unit

Item	Set value
Transmission speed*1	4800bps, 9600bps, 19200bps
Data bit	7bit, 8bit
Stop bit	1bit
Parity bit	Odd
Parity check	Yes
Control signal	Invalidate CS, CD

- *1 Indicates only the transmission speeds that can be set on the GOT side.
Set the same transmission speed of the GOT.
For the transmission speed setting on the GOT side, refer to the following.
 Page 590 Setting communication interface (Communication settings)
The setting range varies with the connected PLC.

Connecting to the communication cassette

■Communication settings

Set the communication settings for the COM 1 port and COM2 port to connect GOT.

Item	Set value
Communication mode	Computer link
Transmission speed*1	4800bps, 9600bps, 19200bps, 38400bps, 57600bps, 115200bps
Modem connection	No
Data bit	7bit, 8bit
Parity check	Odd
Stop bit	1bit
Unit No.	1
Port selection*2	Communication cassette

*1 Indicates only the transmission speeds that can be set on the GOT side.

Set the same transmission speed of the GOT.


For the transmission speed setting on the GOT side, refer to the following.

☞ Page 590 Setting communication interface (Communication settings)

*2 Set the COM2 port only.

■Switch setting on the Communication cassette (AFPX-COM3)

Set the switch on the back.




Switch No.	Setting	Setting details
1	OFF	RS422
2	OFF	
3	OFF	
4	OFF	Terminating resistor OFF

Connecting to FP7

Set the communication using the ladder software "FPWIN GR7".
Assign COM numbers to the CPU module's built-in SCU and communication cassette, and then set the communication settings.

Item	Set value
Communication mode	MEWTOCOL7-COM
Station No.	1
Transmission speed*1	4800bps, 9600bps, 19200bps, 38400bps, 57600bps, 115200bps
Data bit*1	7bit, 8bit
Parity bit*1	Odd
Stop bit*1	1bit
RS/CS	Invalid
Send wait time (Set value × 0.01ms)	0
Terminator code STX	Invalid
Termination setting	CR
Modem initialization	Do not initialize

*1 Adjust the settings with GOT settings.
For the setting on the GOT side, refer to the following.
 Page 590 Setting communication interface (Communication settings)

15.6 Device Range that Can Be Set

The device ranges of controller that can be used for GOT are as follows.


Note that the device ranges in the following tables are the maximum values that can be set in GT Designer3.

The device specifications of controllers may differ depending on the models, even though belonging to the same series.


Please make the setting according to the specifications of the controller actually used.

When a non-existent device or a device number outside the range is set, other objects with correct device settings may not be monitored.

Setting item



For [Panasonic MEWNET-FP]




For [Panasonic FP7]

Item	Description
Device	Set the device name, device number, and bit number. The bit number can be set only when specifying the bit of word device.
Information	Displays the device type and setting range which are selected in [Device].

Device settings of PANASONIC PLC

- When setting a relay as a bit device


Set the device using the format of word address (DEC) + bit address (HEX).



- When setting a relay as a word device

Set the device number.

Select the device name whose head character is "W" and set the device number in decimal.



Panasonic Industrial Devices SUNX PLC (Panasonic MEWNET-FP)

Device name		Setting range ^{*1}	Device No. representation
Bit device	Input relay (X) ^{*2*3}	X0000 to X511F	Decimal + Hexadecimal
	Output relay (Y) ^{*3}	Y0000 to Y511F	
	Internal relay (R)	R0000 to R886F	
	Special relay (R) ^{*2}	R9000 to R911F	
	Link relay (L) ^{*5}	L0000 to L639F	
	Timer contact (T) ^{*2*4}	T0 to T3071	Decimal
	Counter contact (C) ^{*2*4}	C0 to C3071	
	Word device bit	Specified bit of the following word devices (except input relay, output relay, internal relay, special relay and link relay)	-
Word device	Input relay (WX) ^{*2}	WX000 to WX511	Decimal
	Output relay (WY)	WY000 to WY511	
	Internal relay (WR)	WR000 to WR886	
	Special relay (WR) ^{*2}	WR900 to WR911	
	Link relay (WL)	WL000 to WL639	
	Timer/Counter (Elapsed value) (EV) ^{*4}	EV0 to EV3071	
	Timer/Counter (Set value) (SV) ^{*4}	SV0 to SV3071	
	Data register (DT)	DT0 to DT10239	
	Special data register (DT)	DT0 to DT32764 DT90000 to DT90511	
	Link register (LD) ^{*5}	LD0 to LD8447	
	File register (FL) ^{*5*6}	FL0 to FL32764	
	Bit device word	Converting bit devices into word (Except Timer contact and Counter contact)	-

*1 The device range for the case where FP10SH is used.

For FP0, FP1, FP2, FP3, FP5, FP-10(S), or FP-M, device ranges are different in individual CPUs.

*2 Writing to device is not allowed.

*3 Only those devices that have been assigned to I/O contacts by peripheral software can be used.

*4 The device points of the timer and counter differs depending on the head numbers of the counter set by the value of the system register (No. 5).

*5 This device does not exist in FP0, FP1, and FP-M.

*6 When FP2SH is used, one bank of "32765 × 3 banks" can be monitored.

Panasonic Industrial Devices SUNX PLC (Panasonic FP-7)

Device name		Setting range	Device No. representation
Bit device	Input relay (X)	X0000 to X511F	Decimal + Hexadecimal
	Output relay (Y)	Y0000 to Y511F	
	Internal relay (R)	R0000 to R2047F	
	Link relay (L)	L0000 to L1023F	
	System relay (SR) ^{*1}	SR0000 to SR223F	
	Pulses relay (P) ^{*1}	P0000 to P255F	
	Direct Input (IN) ^{*1}	IN000 to IN62F	
	Direct Output (OT) ^{*1}	OT000 to OT62F	
	Input relay (Local)(_X)	_X0000 to _X511F	
	Output relay (Local)(_Y)	_Y0000 to _Y511F	
	Internal relay (Local)(_R)	_R00000 to _R2047F	
	Link relay (Local)(_L)	_L00000 to _L1023F	
	Pass through relay (local)(_P) ^{*1}	_P0000 to _P255F	
	Timer contact (T) ^{*1}	T0 to T4095	Decimal
	Counter contact (C) ^{*1}	C0 to C1023	
	Error notification relay (E) ^{*1}	E0 to E4095	
	Timer contact (Local)(_T) ^{*1}	_T0 to _T4095	
	Counter contact (Local)(_C) ^{*1}	_C0 to _C1023	-
	The bit specification of the word device ^{*2} (except Input relay, Output relay, Internal relay, Special relay, Link relay)	Setting range of each word device	
Word device	Data register (DT)	DT0 to DT999423	Decimal
	Link register (LD)	LD0 to LD16383	
	Input relay (WX)	WX000 to WX511	
	Output relay (WY)	WY000 to WY511	
	Internal relay (WR)	WR0000 to WR2047	
	Link relay (WL)	WL0000 to WL1023	
	Direct Input (WI)	WI00 to WL62	
	Direct Output (WO)	WO00 to WO62	
	System relay (WS)	WS000 to WS223	
	Unit memory (UM)	UM0 to UM524287	
	System data register (SD)	SD0 to SD255	
	Data register (Local)(_DT)	_DT0 to _DT999423	
	Link register (Local)(_LD)	_LD0 to _LD16383	
	Input relay (Local)(_WX)	_WX000 to _WX511	
	Output relay (Local)(_WY)	_WY000 to _WY511	
	Internal relay (Local)(_WR)	_WR0000 to _WR2047	
	Link relay (Local)(_WL)	_WL0000 to _WL1023	
	The word specification of the bit device(except Timer contact, Counter contact)	Setting range of each bit device	-
Double word device	Timer setting value area (TS)	TS0 to TS4095	Decimal
	Timer elapsed value area (TE)	TE0 to TE4095	
	Counter setting value area (CS)	CS0 to CS1023	
	Counter elapsed value area (CE)	CE0 to CE1023	
	Timer setting value area (local)(_TS)	_TS0 to _TS4095	
	Timer elapsed value area (local)(_TE)	_TE0 to _TE4095	
	Counter setting value area (local)(_CS)	_CS0 to CS1023	
	Counter elapsed value area (local)(_CE)	_CE0 to _CE1023	
	Index register (I)	I0 to IE	Hexadecimal

*1 Writing to device is not allowed.

*2 As bit specification of a word device is performed after the GOT reads the value, do not change the value in the sequence program during this period.

MEMO

REVISIONS

* The manual number is given on the bottom left of the back cover.

Print Date	* Manual Number	Revision
Sep., 2013	SH(NA)-081198ENG-A	Compatible with GT Works3 Version1.100E
Nov., 2013	SH(NA)-081198ENG-B	Compatible with GT Works3 Version1.104J • Changing the icons of the supported models
Jan., 2014	SH(NA)-081198ENG-C	Compatible with GT Works3 Version1.108N • The AZBIL (formerly Yamatake Corporation) temperature controller (AHC2001) is supported.
Apr., 2014	SH(NA)-081198ENG-D	Compatible with GT Works3 Version1.111R • GT25 and GS21 have been added. • The enlargement of the communication setting range of the TOSHIBA PLC is supported.
Oct., 2014	SH(NA)-081198ENG-E	Compatible with GT Works3 Version1.122C • GT21 is added. • IP Filter setting is supported.
Jan., 2015	SH(NA)-081198ENG-F	Compatible with GT Works3 Version1.126G • GT21 corresponding to IAI robot controller connection.
Apr., 2015	SH(NA)-081198ENG-G	Compatible with GT Works3 Version1.130L • GT27 is added (GT2705-VTBD). • GT21 is added (GT2104-RTBD, GT2103-PMBDS2, GT2103-PMBLS).
Jun., 2015	SH(NA)-081198ENG-H	Compatible with GT Works3 Version1.134Q • TOSHIBA Unified Controller nv
Oct., 2015	SH(NA)-081198ENG-I	Compatible with GT Works3 Version1.144A • GT21 is added (GT2104-PMBD, GT2104-PMBDS). • GT21 corresponding to KEYENCE PLC (Ethernet connection).
Dec., 2015	SH(NA)-081198ENG-J	Compatible with GT Works3 Version1.150G • Station blocking function compatible Ethernet connection • Station monitoring function of the following connection CC-Link IE controller network connection CC-Link IE Field Network connection • GT21 corresponding to connection to OMRON temperature controller
May, 2016	SH(NA)-081198ENG-K	Compatible with GT Works3 Version1.155M • GT21 is added (GT2105-QTBDS, GT2105-QMBDS, GT2104-PMBDS2, GT2104-PMBLS). • Some corrections
Aug., 2016	SH(NA)-081198ENG-L	Compatible with GT Works3 Version1.160S • IAI robot controller connection supported device is added (RO,JIM,PNM,OSC). • GT21 is added AZBIL control equipment. • Panasonic Industrial Devices SUNX FP7 series connection is supported. • GOT2000 series Ethernet communication unit is supported.
Jan., 2017	SH(NA)-081198ENG-M	Compatible with GT Works3 Version1.170C • GT2107-W is added (GT2107-WTBD, GT2107-WTSD). • OMRON temperature controller models are added. <THERMAC NEO series> E5AN-H, E5CN-H, E5EN-H, E5AN-HT, E5CN-HT, E5EN-HT <E5□C series> E5CC(-T,-B), E5DC, E5GC, E5EC(-T,-B), E5AC(-T) <THERMACR series> E5AR(-T), E5ER(-T) • Compatible KEYENCE PLCs are added. (KV7000 series)
Apr., 2017	SH(NA)-081198ENG-N	Compatible with GT Works3 Version1.175H • GT25 is added (GT25-W). • OMRON PLC NJ series is supported.
Jun., 2017	SH(NA)-081198ENG-O	Compatible with GT Works3 Version1.180N • GT25 is added (GT2505-V). • For Ethernet connection, the default value of the GOT station No. is changed to [18]. • When connecting to OMRON PLC NJ Series, the communication module CJ1W-EIP21 is supported.
Oct., 2017	SH(NA)-081198ENG-P	Some corrections

Print Date	* Manual Number	Revision
Dec., 2017	SH(NA)-081198ENG-Q	Compatible with GT Works3 Version 1.190Y • Compatible with avoiding overlapping of [GOT Communication Port No.]
Apr., 2018	SH(NA)-081198ENG-R	Compatible with GT Works3 Version 1.195D • Compatible OMRON PLC are added (NX series).
Jul., 2018	SH(NA)-081198ENG-S	Compatible with GT Works3 Version 1.200J • Compatible OMRON temperature controllers are added (E5□D series).
Oct., 2018	SH(NA)-081198ENG-T	Compatible with GT Works3 Version 1.205P • GT2505-V supports the following connection using the RS-232/485 signal conversion adapter (GT14-RS2T4-9P). Connection to azbil control equipment Connection to omron temperature controller Connection to shinko technos indicating controller • Compatible OMRON PLCs are added (NX701). • Compatible KEYENCE PLCs are added (KV-N14□□, KV-N24□□, KV-N40□□, KV-N60□□, KV-NC32T). • Compatible TOSHIBA Unified Controller nv are added. <Controller type1 light> PUM11, PUM12, PUM14
Jan., 2019	SH(NA)-081198ENG-U	Compatible with GT Works3 Version 1.210U • GT2505-V supports the following connection using the RS-232/485 signal conversion adapter (GT14-RS2T4-9P). Connection to CHINO controller
Apr., 2019	SH(NA)-081198ENG-V	Compatible with GT Works3 Version 1.215Z • Compatible OMRON PLCs are added (NX102).
Jul., 2019	SH(NA)-081198ENG-W	Some corrections
Oct., 2019	SH(NA)-081198ENG-X	Some corrections
Jan., 2020	SH(NA)-081198ENG-Y	Compatible with GT Works3 Version 1.230Q • IAI robot controller models (PCON-CB, PCON-CFB, ACON-CB, SCON-CB, EC) have been added. • Devices used for connecting IAI robot controller have been added.

This manual confers no industrial property rights or any rights of any other kind, nor does it confer any patent licenses.

Mitsubishi Electric Corporation cannot be held responsible for any problems involving industrial property rights which may occur as a result of using the contents noted in this manual.

©2013 MITSUBISHI ELECTRIC CORPORATION

WARRANTY

Please check the following product warranty details before using this product.

■ 1. Gratis Warranty Term and Gratis Warranty Range

If any faults or defects (hereinafter "Failure") found to be the responsibility of Mitsubishi occurs during use of the product within the gratis warranty term, the product shall be repaired at no cost via the sales representative or Mitsubishi Service Company. However, if repairs are required onsite at domestic or overseas location, expenses to send an engineer will be solely at the customer's discretion.

Mitsubishi shall not be held responsible for any re-commissioning, maintenance, or testing on-site that involves replacement of the failed module.

(1) Gratis Warranty Term

The gratis warranty term of the product shall be for thirty-six (36) months after the date of purchase or delivery to a designated place.

Note that after manufacture and shipment from Mitsubishi, the maximum distribution period shall be six (6) months, and the longest gratis warranty term after manufacturing shall be forty-two (42) months.

The gratis warranty term of repair parts shall not exceed the gratis warranty term before repairs.

(2) Gratis Warranty Range

- (a) The customer shall be responsible for the primary failure diagnosis unless otherwise specified.
If requested by the customer, Mitsubishi Electric Corporation or its representative firm may carry out the primary failure diagnosis at the customer's expense.
The primary failure diagnosis will, however, be free of charge should the cause of failure be attributable to Mitsubishi Electric Corporation.
- (b) The range shall be limited to normal use within the usage state, usage methods, and usage environment, etc., which follow the conditions and precautions, etc., given in the instruction manual, user's manual and caution labels on the product.
- (c) Even within the gratis warranty term, repairs shall be charged in the following cases.
 - Failure occurring from inappropriate storage or handling, carelessness or negligence by the user. Failure caused by the user's hardware or software design.
 - Failure caused by unapproved modifications, etc., to the product by the user.
 - When the Mitsubishi product is assembled into a user's device, Failure that could have been avoided if functions or structures, judged as necessary in the legal safety measures the user's device is subject to or as necessary by industry standards, had been provided.
 - Failure that could have been avoided if consumable parts designated in the instruction manual had been correctly serviced or replaced.
 - Replacing consumable parts such as a battery, backlight, and fuse.
 - Failure caused by external irresistible forces such as fires or abnormal voltages, and Failure caused by force majeure such as earthquakes, lightning, wind and water damage.
 - Failure caused by reasons that could not be predicted by scientific technology standards at the time of shipment from Mitsubishi.
 - Any other failure found not to be the responsibility of Mitsubishi or that admitted not to be so by the user.

■ 2. Onerous repair term after discontinuation of production

- (1) Mitsubishi shall accept onerous product repairs for seven (7) years after production of the product is discontinued. Discontinuation of production shall be notified with Mitsubishi Technical Bulletins, etc.
- (2) Mitsubishi shall not accept a request for product supply (including spare parts) after production is discontinued.

■ 3. Overseas service

Overseas, repairs shall be accepted by Mitsubishi's local overseas FA Center.

Note that the repair conditions at each FA Center may differ.

■ 4. Exclusion of loss in opportunity and secondary loss from warranty liability

Regardless of the gratis warranty term, Mitsubishi shall not be liable for compensation to:

- (1) Damages caused by any cause found not to be the responsibility of Mitsubishi.
- (2) Loss in opportunity, lost profits incurred to the user by Failures of Mitsubishi products.
- (3) Special damages and secondary damages whether foreseeable or not, compensation for accidents, and compensation for damages to products other than Mitsubishi products.
- (4) Replacement by the user, maintenance of on-site equipment, start-up test run and other tasks.

■ 5. Changes in product specifications

The specifications given in the catalogs, manuals, or technical documents are subject to change without prior notice.

■ 6. Product application

- (1) In using the Mitsubishi graphic operation terminal, the usage conditions shall be that the application will not lead to a major accident even if any problem or fault should occur in the graphic operation terminal device, and that backup and fail-safe functions are systematically provided outside of the device for any problem or fault.
- (2) The Mitsubishi graphic operation terminal has been designed and manufactured for applications in general industries, etc. Thus, applications in which the public could be affected such as in nuclear power plants and other power plants operated by respective power companies, and applications in which a special quality assurance system is required, such as for Railway companies or Public service shall be excluded from the graphic operation terminal applications.
In addition, applications in which human life or property could be greatly affected, such as in aircraft, medical, railway applications, incineration and fuel devices, manned transportation equipment, recreation and amusement devices, safety devices, shall also be excluded from the graphic operation terminal.
Even for the above applications, however, Mitsubishi Electric Corporation may consider the possibility of an application, provided that the customer notifies Mitsubishi Electric Corporation of the intention, the application is clearly defined and any special quality is not required, after the user consults the local Mitsubishi representative.

Copyright Notice

MELDAS, MELSEC, iQ Platform, MELSOFT, GOT, CC-Link, CC-Link/LT, and CC-Link IE are trademarks or registered trademarks of Mitsubishi Electric Corporation in Japan and other countries.

Microsoft, Windows, Windows Vista, Windows NT, Windows Server, SQL Server, Visual C++, Visual C#, Visual Basic, Excel, and Access are trademarks or registered trademarks of Microsoft Corporation in the United States and other countries.

Ethernet is a registered trademark of Xerox Corporation in the United States.

MODBUS is a trademark of Schneider Electric SA.

DeviceNet is a trademark of ODVA (Open DeviceNet Vendor Association, Inc.).

VNC is a registered trademark of RealVNC Ltd. in the United States and other countries.

Unicode is a trademark or registered trademark of Unicode, Inc. in the United States and other countries.

PictBridge is a registered trademark of Canon Inc.

Adobe and Adobe Reader are registered trademarks of Adobe Systems Incorporated.

Oracle and JavaScript are registered trademarks of Oracle Corporation and/or its affiliates in the United States and other countries.

QR Code is a trademark or registered trademark of DENSO WAVE INCORPORATED in Japan, the United States, and/or other countries.

Anybus is a registered trademark of HMS Industrial Networks AB.

Android and Google Chrome are trademarks or registered trademarks of Google Inc.

iOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license.

Safari and iPhone are trademarks of Apple Inc. registered in the United States and other countries. The iPhone trademark is used under license from AIPHONE CO., LTD.

Intel and Intel Core are trademarks or registered trademarks of Intel Corporation in the United States and other countries.

Other company and product names herein are trademarks or registered trademarks of their respective owners.

SH(NA)-081198ENG-Y

GOT2000 Series Connection Manual

(Non-Mitsubishi Electric Products 1)

For GT Works3 Version1

MODEL	GOT2000-CON2-SW1-E
MODEL CODE	_____
SH(NA)-081198ENG-Y(2001)MEE	

When exported from Japan, this manual does not require application to the Ministry of Economy, Trade and Industry for service transaction permission.

MITSUBISHI ELECTRIC CORPORATION

HEAD OFFICE : TOKYO BUILDING, 2-7-3 MARUNOUCHI, CHIYODA-KU, TOKYO 100-8310, JAPAN
NAGOYA WORKS : 1-14 , YADA-MINAMI 5-CHOME , HIGASHI-KU, NAGOYA , JAPAN

Specifications subject to change without notice. Printed in Japan, January 2020.